
COMPOSITE STRAIGHT SQUARE FLANGE JACK **SOLDER TYPE**


CABLE .250


R187.130.000


Series: 7/16 COMPOSITE












24.8

24.7



All dimensions are in mm.

COMPONENTS	MATERIALS

BODY CENTER CONTACT **OUTER CONTACT INSULATOR GASKET** OTHERS PARTS

COMPOSITE MATERIAL - BLACK BRONZE BRASS PTFE SILICONE RUBBER

C



SILVER 5 OVER COPPER 0.5 ARGENT 3 SUR BBR 0.5

Issue: 0908 A

In the effort to improve our products, we reserve the right to make changes judged to

be necessary.



TECHNICAL DATA SHEET

COMPOSITE STRAIGHT SQUARE FLANGE JACK **SOLDER TYPE**

CABLE .250

R187.130.000

Series: 7/16 COMPOSITE

PACKAGING

Standard	Unit	Other	
10	'W' option	Contact us	

ELECTRICAL CHARACTERISTICS

Impedance 50 Ω Frequency 0-7.5 GHz

1.20* + **0.0000** x F(GHz) Maxi **VSWR** Insertion loss **0.05** $\sqrt{F(GHz)}$ dB Maxi

RF leakage NA - F(GHz)) dB Maxi

Voltage rating **1400** Veff Maxi 2700 Veff mini Dielectric withstanding voltage Insulation resistance 10000 M Ω mini

MECHANICAL CHARACTERISTICS

Center contact retention

200 N mini Axial force – Mating end Axial force – Opposite end **100** N mini Torque NA N.cm mini

Recommended torque

NA N.cm Mating Panel nut NA N.cm NA N.cm Clamp nut A/F clamp nut **0.0000** mm

Mating life 500 Cycles mini

Weight **75.1700** g

ENVIRONMENTAL

Operating temperature -40/+85 ° C

Hermetic seal NA Atm.cm3/s

Panel leakage **IP67**

SPECIFICATION

807752-0E - -

CABLE ASSEMBLY

Stripping	a	b	c	d	e	f
mm	5.10	0.00	0.00	0.00	0.00	0.00

Assembly instruction:

Recommended cable(s)

KS 3 RG 401

Characteristics indicated on this data sheet are those that can be achieved with the highest performance cable. Intrinsic limitations of the cable may diminish the performance of the assembly

Cable retention

- pull off **200** N mini - torque NA N.cm

TOOLING

Part Number	Description	Hexagon
		•

OTHER CHARACTERISTICS

VSWR: 1.2 max0~7.5GHz

PIM3:-125dBm under 2 carriers of +43dBm



In the effort to improve our products, we reserve the right to make changes judged to be necessary.






COMPOSITE STRAIGHT SQUARE FLANGE JACK **SOLDER TYPE CABLE .250**

R187.130.000


Series: 7/16 COMPOSITE

ASSEMBLY INSTRUCTION




Step 1

- -Remove jacket and dielectric of the cable with stripping tool.
- -Trim cable inner conductor with trimmer.
- -Check dimension 5.1 mm.




Step 2

-Push the prepared cable through body.



Step 3

- -Input the PTFE washer into cable inner contact,
- -Solder the center contact to the cable inner contact
- (-Solder in wire or paste form can be used.
- -Solder with induction soldering, solder tongs or solder iron).



Step 4

- -Push center contact with hand press until stop,
- -check interface dimension 1.92.

CAUTION:

To make sure the solder joint on the center contact will not be damaged, it is important to push the center contact and not to pull at the cable

Issue: 0908 A

In the effort to improve our products, we reserve the right to make changes judged to be necessary.




COMPOSITE STRAIGHT SQUARE FLANGE JACK SOLDER TYPE CABLE .250


R187.130.000

Series: 7/16 COMPOSITE

Assembly instruction

Before the installation, the outer contact is slightly protruded from the rear flange (0.1~0.3mm). During the installation, the outer contact is pushed inside the composite housing. In its final position, the outer contact is aligned with the rear flange, and in contact with the panel. During mating, the outer contact is pressed against the panel, reducing significantly the IM3 generation.





Issue: 0908 A

In the effort to improve our products, we reserve the right to make changes judged to be necessary.

