



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Anti-vandal	PV1C2405S	52-PV1C2405S	2018	OBSOLETE	SS BODY AND SS ACTUATOR
Anti-vandal	PV1DS2405S	52-PV1DS2405S	2018	OBSOLETE	ANTI ROTATION SS BODY AC
Anti-vandal	PV3SZ01Z11305S	03-PV3SZ01Z11305S	2019	OBSOLETE	
Anti-vandal	PV3SZ01Z12305S	03-PV3SZ01Z12305S		OBSOLETE	
Anti-vandal	PV3SZ01Z13305S	03-PV3SZ01Z13305S	2019	OBSOLETE	
Anti-vandal	PV3C2B050-223	52-PV3C2B050223	2019	OBSOLETE	Lack of sales
Anti-vandal	PV3F23011-341	52-PV3F23011341	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3F23011-344	52-PV3F23011344	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3F230BB-344	52-PV3F230BB344	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3F230NN	52-PV3F230NN	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3F230NN-211	52-PV3F230NN211	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3F230SS	52-PV3F230SS	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3F230SS-243	52-PV3F230SS243	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3F230SS-331	52-PV3F230SS331	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3F230SS-341	52-PV3F230SS341	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3F230SS-343	52-PV3F230SS343	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3F230SS-344	52-PV3F230SS344	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3F230SS-3H4	52-PV3F230SS3H4	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3F2G011	52-PV3F2G011	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3F2G011-243	52-PV3F2G011243	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3F2G0NN	52-PV3F2G0NN	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3F2G0NN-214	52-PV3F2G0NN214	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3F2G0NN-234	52-PV3F2G0NN234	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3F2G0NN-244	52-PV3F2G0NN244	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3F2G0NN-311	52-PV3F2G0NN311	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3F2G0NN-314	52-PV3F2G0NN314	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3F2G0NN-321	52-PV3F2G0NN321	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3F2G0NN-331	52-PV3F2G0NN331	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3F2G0NN-334	52-PV3F2G0NN334	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3F2G0NN-341	52-PV3F2G0NN341	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3F2G0NN-344	52-PV3F2G0NN344	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3F2G0NN-346	52-PV3F2G0NN346	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3F2G0NN-351	52-PV3F2G0NN351	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3F2G0SS	52-PV3F2G0SS	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3F2G0SS-311	52-PV3F2G0SS311	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3G230NN	52-PV3G230NN	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3G2B0S8G335	52-PV3G2B0S8G335	2019	OBSOLETE	Lack of sales
Anti-vandal	PV3G2B0S9G315	52-PV3G2B0S9G315	2019	OBSOLETE	Lack of sales
Anti-vandal	PV3G2B0SGG325	52-PV3G2B0SGG325	2019	OBSOLETE	Lack of sales
Anti-vandal	PV3H23011-345	52-PV3H23011345	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3H230NN	52-PV3H230NN	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3H230NN-345	52-PV3H230NN345	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3H230SS	52-PV3H230SS	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3H230SS-344	52-PV3H230SS344	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3H230SS-345	52-PV3H230SS345	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3H230SS-346	52-PV3H230SS346	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3H2B0GG-343	52-PV3H2B0GG343	2019	OBSOLETE	GOLD BODY AND ACTUATOR
Anti-vandal	PV3H2G011-304	52-PV3H2G011304	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3H2G0BBG-345	52-PV3H2G0BBG345	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3H2G0NN	52-PV3H2G0NN	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3H2G0NN-214	52-PV3H2G0NN214	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3H2G0NN-234	52-PV3H2G0NN234	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3H2G0NN-244	52-PV3H2G0NN244	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3H2G0NN-2G4	52-PV3H2G0NN2G4	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3H2G0NN-314	52-PV3H2G0NN314	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3H2G0NN-321	52-PV3H2G0NN321	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3H2G0NN-334	52-PV3H2G0NN334	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3H2G0NN-344	52-PV3H2G0NN344	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3H2G0SS	52-PV3H2G0SS	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3H2G0SS-311	52-PV3H2G0SS311	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3H2G0SS-341	52-PV3H2G0SS341	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3SG230B	52-PV3SG230BB	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3SH230BB	52-PV3SH230BB	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3SH230SBG-M01	52-PV3SH230SBGM01	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3SWF2G011G	52-PV3SWF2G011G	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3SWF2H011G	52-PV3SWF2H011G	2019	OBSOLETE	
Anti-vandal	PV3SWG230BB	52-PV3SWG230BB	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3SWG2B012G	52-PV3SWG2B012G	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3SWG2G0BB	52-PV3SWG2G0BB	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3SWH230NN	52-PV3SWH230NN	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3SWH2B017	52-PV3SWH2B017	2019	OBSOLETE	
Anti-vandal	PV3SWH2B018	52-PV3SWH2B018	2019	OBSOLETE	
Anti-vandal	PV3SWH2B019	52-PV3SWH2B019	2019	OBSOLETE	
Anti-vandal	PV3SWH2B0NNG	52-PV3SWH2B0NNG	2019	OBSOLETE	
Anti-vandal	PV3SWH2B0SSG	52-PV3SWH2B0SSG	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3SWZ012B0SS	52-PV3SWZ012B0SS	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3SZ01230SS	52-PV3SZ01230SS	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3WF23011-311	52-PV3WF23011311	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3WF23011-333	52-PV3WF23011333	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3WF23011G-344	52-PV3WF23011G344	2015	OBSOLETE	Only momentary functions are active



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Anti-vandal	PV3WF230BB-334	52-PV3WF230BB334	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3WF230BBG-204	52-PV3WF230BBG204	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3WF230SS-311	52-PV3WF230SS311	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3WF230SS-324	52-PV3WF230SS324	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3WF230SS-331	52-PV3WF230SS331	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3WF230SS-334	52-PV3WF230SS334	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3WF230SS-341	52-PV3WF230SS341	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3WF230SS-344	52-PV3WF230SS344	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3WF230SS-3N4	52-PV3WF230SS3N4	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3WF2B0S0-346	52-PV3WF2B0S0346	2019	OBSOLETE	POLISHED STAINLESS STEEL
Anti-vandal	PV3WF2G0BB-344	52-PV3WF2G0BB344	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3WF2G0SS-335	52-PV3WF2G0SS335	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3WG2B010G	52-PV3WG2B010G	2019	OBSOLETE	IP67
Anti-vandal	PV3WG2B017G-341	52-PV3WG2B017G341	2019	OBSOLETE	IP67
Anti-vandal	PV3WG2G0NN-331	52-PV3WG2G0NN331	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3WG2G0SS-3G1	52-PV3WG2G0SS3G1	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3WG2H0NN-311	52-PV3WG2H0NN311	2019	OBSOLETE	IP67
Anti-vandal	PV3WH23011343	52-PV3WH23011343	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3WH230BB-344	52-PV3WH230BB344	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3WH230SS-241	52-PV3WH230SS241	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3WH230SS-344	52-PV3WH230SS344	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3WH230SSG-231	52-PV3WH230SSG231	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3WH2B0S1	52-PV3WH2B0S1	2019	OBSOLETE	
Anti-vandal	PV3WH2B0S1G	52-PV3WH2B0S1G	2019	OBSOLETE	
Anti-vandal	PV3WH2B0SS-314	52-PV3WH2B0SS314	2019	OBSOLETE	
Anti-vandal	PV3WH2B0SS-345	52-PV3WH2B0SS345	2019	OBSOLETE	
Anti-vandal	PV3WH2B0SS-353	52-PV3WH2B0SS353	2019	OBSOLETE	
Anti-vandal	PV3WH2G0BB-304	52-PV3WH2G0BB304	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3WH2G0BB-326	52-PV3WH2G0BB326	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3WH2G0BB-346	52-PV3WH2G0BB346	2015	OBSOLETE	Only momentary functions are active
Anti-vandal	PV3WH2H0BB-345	52-PV3WH2H0BB345	2019	OBSOLETE	
Anti-vandal	PV4230SS3K1M01	52-PV4230SS3K1M01		OBSOLETE	
Anti-vandal	PV4D52B0SSG	52-PV4D52B0SSG	2018	OBSOLETE	MACH SS BODY ACTUATOR
Anti-vandal	PV4F230SS-3N4	52-PV4F230SS3N4		OBSOLETE	
Anti-vandal	PV4F2H0SS-345-M01	52-PV4F2H0SS345M01		OBSOLETE	
Anti-vandal	PV4F2Y0SS-201	52-PV4F2Y0SS201		OBSOLETE	
Anti-vandal	PV4F2Y0SS-215	52-PV4F2Y0SS215		OBSOLETE	
Anti-vandal	PV4F2Y0SS-216	52-PV4F2Y0SS216		OBSOLETE	
Anti-vandal	PV4F2Y0SS-234	52-PV4F2Y0SS234		OBSOLETE	
Anti-vandal	PV4F201Z1330SS	52-PV4F201Z1330SS	2018	OBSOLETE	WITH WIRE HARNESS
Anti-vandal	PV4H2B0SS-311-PILOT	52-PV4H2B0SS311PIL	2019	OBSOLETE	PILOT SYMBOL ETCHED
Anti-vandal	PV6DF240SS-341-PWR	52-PV6DF240SS341PW		OBSOLETE	SEE 52-PV6F240SS341M01
Anti-vandal	PV6F240MM-3H1	52-PV6F240MM3H1	2017	OBSOLETE	BLACK DELRIN PLASTIC
Anti-vandal	PV6F240SS-344	52-PV6F240SS344		OBSOLETE	
Anti-vandal	PV7F2Y0SS-3Q1	52-PV7F2Y0SS3Q1		OBSOLETE	SEE 52-PV7F2Y0SS3Q1
Anti-vandal	PV7F2T0MM-344-M03	52-PV7F2T0MM344M03	2016	OBSOLETE	
Anti-vandal	PV7F2T0SS-301-M03	52-PV7F2T0SS301M03	2016	OBSOLETE	See 52-PV7F2T0SS301M16
Anti-vandal	PV7F2Y0MM-M04	52-PV7F2Y0MMM04		OBSOLETE	
Anti-vandal	PV7F2T0NN-314	52-PV7F2T0NN314		OBSOLETE	SEE 52-PV7F2T0NN314
Anti-vandal	PV8F2T0SSG-333-M07	52-PV8F2T0SSG333M07	2016	OBSOLETE	Gold not available for PV8
Anti-vandal	PV8F2U0NNG-334	52-PV8F2U0NNG334	2016	OBSOLETE	Gold not available for PV8
Anti-vandal	PV8F2V0SSG-304	52-PV8F2V0SSG304	2016	OBSOLETE	Gold not available for PV8
Anti-vandal	PV8F2V0SSG-331	52-PV8F2V0SSG331	2016	OBSOLETE	Gold not available for PV8
Anti-vandal	PV8F2V1SSG-3G1	52-PV8F2V1SSG3G1	2016	OBSOLETE	Gold not available for PV8
Anti-vandal	PV8F2V1SSG-3K1	52-PV8F2V1SSG-3K1	2016	OBSOLETE	Gold not available for PV8
Anti-vandal	PV8F2Y0SSG-344	52-PV8F2Y0SSG344	2016	OBSOLETE	Gold not available for PV8
Anti-vandal	PV8H2Y0SSG	52-PV8H2Y0SSG	2016	OBSOLETE	Gold not available for PV8
Anti-vandal	PV8F2T0SSG-333-M07	52-PV8S00217	2016	OBSOLETE	
Anti-vandal	PVA6FP24B01	T960023	2018	OBSOLETE	
Anti-vandal	ULV4F2BSSGM06	T940055		OBSOLETE	ARROW GRAPHIC
CAPS	MINITASTFLATCLEAR	D110001		OBSOLETE	
CAPS	FLATGRYLENS	D110013		OBSOLETE	
CAPS	FLATGRNLENS	D110015		OBSOLETE	
CAPS	FLATREDLENS	D110017		OBSOLETE	
CAPS	PAPERINSERTWHT	D120000		OBSOLETE	
CAPS	PAPERINSERTYEL	D120001		OBSOLETE	
CAPS	STDBODYX	C010001		OBSOLETE	
CAPS	STDBODY1	C010003		OBSOLETE	
CAPS	WTBODY1	C010004		OBSOLETE	
CAPS	STDBODY2	C010005		OBSOLETE	
CAPS	STDBODY3	C010007		OBSOLETE	
CAPS	STDBODY1/3	C010011		OBSOLETE	(RED/YEL LEDS)
CAPS	STDBODY2/3	C010012		OBSOLETE	(GRN/YEL LEDS)
CAPS	WTBODY1/2	C010013		OBSOLETE	(RED/GRN LEDS)
CAPS	STDBODY2/2	C010015		OBSOLETE	(GRN/GRN LEDS)
CAPS	WTBODY2,3	C010017		OBSOLETE	
CAPS	4501BLACK0	C040021		OBSOLETE	
CAPS	4501.8GRYXX	C041003		OBSOLETE	
CAPS	4501.8GRYXWHTENTER	C041100		OBSOLETE	
CAPS	4501BLKOWHTR1	C049960		OBSOLETE	801844A



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
CAPS	4501BLKOWHTR3B	C049962		OBSOLETE	80184AC4
CAPS	4501BLKOWHTR6	C049965		OBSOLETE	50216K3
CAPS	4501M21REDLED	XC0029P		OBSOLETE	
CAPS	4502A11	XC0036P		OBSOLETE	
CAPS	4541M11	XC0130A		OBSOLETE	
CAPS	ACC-C23-2	03-ACCC232	2015	OBSOLETE	
CAPS	SHAFT EXTRUSION VALOX	A035100		OBSOLETE	
CAPS	PLUNGER HOUSING VALOX	A035200		OBSOLETE	
CAPS	TAABLKWHHELP	A041450		OBSOLETE	
CAPS	TAABLKWHTARROWLEFT	A041451		OBSOLETE	
CAPS	TAABLKWHTARROWUP	A041452		OBSOLETE	
CAPS	TAABLKWHTMENU	A041455		OBSOLETE	
CAPS	TAABLKWHTRUN	A041456		OBSOLETE	
CAPS	TAABLKWHTENTER	A041457		OBSOLETE	
CAPS	TAABLKWHT	A041458		OBSOLETE	
CAPS	TAGBLK	A041601		OBSOLETE	(T041601)
CAPS	TAGWHT	A041602		OBSOLETE	
CAPS	TAGGRY	A041603		OBSOLETE	(T041603)
CAPS	TAGRED	A041604		OBSOLETE	(T041604)
CAPS	TAGCHR	A041605		OBSOLETE	(T041605)
CAPS	TAGGRN	A041606		OBSOLETE	
CAPS	TAGBLK94V0	A041607		OBSOLETE	3C2X
CAPS	TAHBLK	A041608		OBSOLETE	
CAPS	TAJBLK	A041610		OBSOLETE	
CAPS	TABBLK	A041611		OBSOLETE	
CAPS	TABWHT	A041612		OBSOLETE	NON SPEC
CAPS	TABGRY	A041613		OBSOLETE	
CAPS	TABRED	A041614		OBSOLETE	
CAPS	TABCHROME	A041615		OBSOLETE	
CAPS	TACBLK	A041621		OBSOLETE	(T041621)
CAPS	TACWHT	A041622		OBSOLETE	NON SPEC (T041622)
CAPS	TACGRY	A041623		OBSOLETE	
CAPS	TACRED	A041624		OBSOLETE	(T041624)
CAPS	TACBLU	A041625		OBSOLETE	
CAPS	GDCTACBLK94V0BUTTON	A041627		OBSOLETE	
CAPS	TADBLK	A041631		OBSOLETE	(T041631)
CAPS	TADWHT	A041632		OBSOLETE	NON SPEC (T041632)
CAPS	TADGRY	A041633		OBSOLETE	(T041633)
CAPS	TADRED	A041634		OBSOLETE	
CAPS	TAGBLKARROWDOWN	A041635		OBSOLETE	
CAPS	TAGBLKARROWUP	A041636		OBSOLETE	
CAPS	TAGBLKSEL	A041637		OBSOLETE	
CAPS	TAGBLK	A041638		OBSOLETE	
CAPS	TAGBLK#	A041639		OBSOLETE	
CAPS	TAMCHR	A041640		OBSOLETE	
CAPS	TAMBLK	A041641		OBSOLETE	(T041641)
CAPS	TAMWHT	A041642		OBSOLETE	NON SPEC (T041642)
CAPS	TAMGRY	A041643		OBSOLETE	(T041643)
CAPS	TAMBLK94V0	A041644		OBSOLETE	(T041644)
CAPS	TAUDGR94V0	A041645	2002	OBSOLETE	
CAPS	TAULGR94V0	A041646		OBSOLETE	(P041646)
CAPS	TAUOFFWHT94V0	A041647		OBSOLETE	(P041647)
CAPS	TAUBLK94V0	A041648		OBSOLETE	(P041648)
CAPS	TAGBLK0	A041649		OBSOLETE	
CAPS	TAABLK	A041651		OBSOLETE	
CAPS	TAAWHT	A041652		OBSOLETE	NON SPEC
CAPS	TAAGRY	A041653		OBSOLETE	
CAPS	TAARED	A041654		OBSOLETE	
CAPS	TAAGRYFRSPEC	A041655		OBSOLETE	
CAPS	TAGBLK9	A041656		OBSOLETE	
CAPS	TAAC269BLKWHTALT	A041657		OBSOLETE	
CAPS	TAGBLK8	A041658		OBSOLETE	
CAPS	TAGBLK7	A041659		OBSOLETE	
CAPS	TAGBLK6	A041660		OBSOLETE	
CAPS	TAEBLK	A041661		OBSOLETE	
CAPS	TAEWHT	A041662		OBSOLETE	NON SPEC
CAPS	TAEGRY	A041663		OBSOLETE	
CAPS	TAERED	A041664		OBSOLETE	
CAPS	TAGBLK5	A041665		OBSOLETE	
CAPS	TAGBLK4	A041666		OBSOLETE	
CAPS	TAGBLK3	A041667		OBSOLETE	
CAPS	TAGBLK2	A041668		OBSOLETE	
CAPS	TAGBLK1	A041669		OBSOLETE	
CAPS	TA12BLK	A041671		OBSOLETE	(T041671)
CAPS	TA12WHT	A041672		OBSOLETE	NON SPEC (T041672)
CAPS	TA12GRY	A041673		OBSOLETE	(T041673)
CAPS	TA12RED	A041674		OBSOLETE	(T041674)
CAPS	TA12CHR	A041675		OBSOLETE	
CAPS	TA12BLU	A041679		OBSOLETE	(T041679)
CAPS	TAUDGR94V0	A041683		OBSOLETE	(P041683)



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
CAPS	TAFBLK	A041690		OBSOLETE	
CAPS	TACACHRCAP	A047008		OBSOLETE	
CAPS	TH201BLKORG	A800181		OBSOLETE	
CAPS	TH201BLKGRN	A800182		OBSOLETE	
CAPS	TH201BLKYEL	A800183		OBSOLETE	
CAPS	TH201BLKBLU	A800184		OBSOLETE	
CAPS	TH201BLKWHT	A800185		OBSOLETE	NON SPEC
CAPS	TH120BLKBLU	A800200		OBSOLETE	
CAPS	TH120BLKWHT	A800201		OBSOLETE	NON SPEC
CAPS	TH120BLKORG	A800202		OBSOLETE	
CAPS	TH120BLKYEL	A800203		OBSOLETE	
CAPS	TH120BLKGRN	A800204		OBSOLETE	
CAPS	TH100BLKORG	A800210		OBSOLETE	
CAPS	TH100BLKGRN	A800211		OBSOLETE	
CAPS	TH100BLKYEL	A800212		OBSOLETE	
CAPS	TH100BLKBLU	A800213		OBSOLETE	
CAPS	TH100BLKWHT	A800214		OBSOLETE	NON SPEC
CAPS	1RBLK	A800300		OBSOLETE	
CAPS	1RWHT	A800301		OBSOLETE	
CAPS	1RRED	A800302		OBSOLETE	(Q800302)
CAPS	1RLGR	A800303		OBSOLETE	
CAPS	1RDGR	A800304		OBSOLETE	(Q800304)
CAPS	1RBLU	A800305		OBSOLETE	
CAPS	1RBLK-94V0	A800306		OBSOLETE	
CAPS	1RCREAM-CUSTOM	A800307		OBSOLETE	
CAPS	1RGRAY-CUSTOM	A800308		OBSOLETE	(Q800308)
CAPS	1SBLK	A800310		OBSOLETE	(Q800310)
CAPS	1SWHT	A800311		OBSOLETE	
CAPS	1SRED	A800312		OBSOLETE	(Q800312)
CAPS	1SDGR	A800313		OBSOLETE	
CAPS	1SLGR	A800314		OBSOLETE	(Q800314)
CAPS	1SBLU	A800315		OBSOLETE	(Q800315)
CAPS	2SBLK-94V0	A800316		OBSOLETE	
CAPS	1SDGR-94V0	A800317		OBSOLETE	
CAPS	1DFBLK	A800320		OBSOLETE	
CAPS	1DFRED	A800321		OBSOLETE	
CAPS	1DFLGR	A800323		OBSOLETE	
CAPS	1DFDGR	A800325		OBSOLETE	
CAPS	1CFBLK	A800350		OBSOLETE	
CAPS	1CFRED	A800351		OBSOLETE	
CAPS	1CFBLU	A800352		OBSOLETE	
CAPS	1CFGRY	A800353		OBSOLETE	
CAPS	1CBLK	A800400		OBSOLETE	(Q800400)
CAPS	1CWHT	A800401		OBSOLETE	(Q800401)
CAPS	1CRED	A800402		OBSOLETE	(Q800402)
CAPS	1CDGR	A800403		OBSOLETE	SEE Q800405
CAPS	1CBLU	A800404		OBSOLETE	
CAPS	1CIVR	A800406		OBSOLETE	IVORY COLOR
CAPS	1DBLK	A800420		OBSOLETE	(Q800420)
CAPS	1DWHT	A800421		OBSOLETE	
CAPS	1DRED	A800422		OBSOLETE	(Q800422)
CAPS	1DDGR	A800423		OBSOLETE	(Q800423)
CAPS	1DBLU	A800424		OBSOLETE	(Q800424)
CAPS	1DBLK-94V0	A800425		OBSOLETE	
CAPS	1DLGR	A800426		OBSOLETE	(Q800426)
CAPS	TA2800BK	B030000	2015	OBSOLETE	this cap fit on TL1100, P227, P297 and P197 series; use TAD or TAM series caps
CAPS	TA2800RED	B030003		OBSOLETE	this cap fit on TL1100, P227, P297 and P197 series; use TAD or TAM series caps
CAPS	RAFBLK	B030100		OBSOLETE	
CAPS	320.26BLK	B040153		OBSOLETE	CAP
CAPS	320.02CAP (CLEAR)	B040203		OBSOLETE	(MAKROLON)
CAPS	320.03CLR	B040305		OBSOLETE	CAP DO NOT ORDER
CAPS	320.05CHR	B040508		OBSOLETE	(COMPLETE CAP)
CAPS	320.05BLKTOP	B040509		OBSOLETE	CAP
CAPS	320.05WHT	B040510		OBSOLETE	COMPLETE
CAPS	320.05GRY	B040511		OBSOLETE	COMPLETE
CAPS	320.05CHR	B040512		OBSOLETE	COMPLETE
CAPS	320.02BLKCAPBASE	B040550		OBSOLETE	
CAPS	320.06BLK	B040560		OBSOLETE	CAP
CAPS	320.21RED/BLKPGDNEXEC	B042108		OBSOLETE	
CAPS	320.21BLU/BLKFUNC/ACK	B042109		OBSOLETE	
CAPS	320.21GRYBLKRIGHTARROW>	B042110		OBSOLETE	
CAPS	320.21RED/BLKTOGGLE	B042111		OBSOLETE	
CAPS	320.21GRN/BLKTIME/DATE	B042112		OBSOLETE	
CAPS	320WHTGRY2	B080466		OBSOLETE	
CAPS	320.01BLKWHTF	B081370		OBSOLETE	
CAPS	320.01GRY-/	B081427		OBSOLETE	
CAPS	320.21BLKWHTPAUSE	B086080		OBSOLETE	
CAPS	320.21BLKWHTMENU	B086081		OBSOLETE	
CAPS	320.21BLKWHTSELECT	B086082		OBSOLETE	
CAPS	320.21BLKWHT+	B086083		OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
CAPS	320.21BLKWHT-	B086084		OBSOLETE	
CAPS	320.21BLKGRYDOWNNARROW	B086089		OBSOLETE	
CAPS	320.21BLKGRYLEFTARROW	B086090		OBSOLETE	
CAPS	320.22BLKWHTENTER	B093068		OBSOLETE	
CAPS	320.22BLKWHTCLEAR	B093069		OBSOLETE	
CAPS	320.22BLKWHT0	B093070		OBSOLETE	
CAPS	320.22BLKWHT1	B093071		OBSOLETE	
CAPS	320.22BLKWHT2	B093072		OBSOLETE	
CAPS	320.22BLKWHT3	B093073		OBSOLETE	
CAPS	320.22BLKWHT4	B093074		OBSOLETE	
CAPS	320.22BLKWHT5	B093075		OBSOLETE	
CAPS	320.22BLKWHT6	B093076		OBSOLETE	
CAPS	320.22BLKWHT7	B093077		OBSOLETE	
CAPS	320.22BLKWHT8	B093078		OBSOLETE	
CAPS	320.22BLKWHT9	B093079		OBSOLETE	
CAPS	320.22BLKWHT125	B093113		OBSOLETE	
CAPS	320.22BLKWHT250	B093114		OBSOLETE	
CAPS	320.22BLKWHT500	B093115		OBSOLETE	
CAPS	320.22BLKWHT750	B093116		OBSOLETE	
CAPS	320.22BLKWHT1000	B093117		OBSOLETE	
CAPS	320.22BLKWHT1500	B093118		OBSOLETE	
CAPS	320.22BLKWHT2000	B093119		OBSOLETE	
CAPS	320.22BLKWHT3000	B093120		OBSOLETE	
CAPS	320.22BLKWHT4000	B093121		OBSOLETE	
CAPS	320.22BLKWHT6000	B093122		OBSOLETE	
CAPS	320.22BLKWHT8000	B093123		OBSOLETE	
CAPS	320.22WHTBLK2	B099002		OBSOLETE	
CAPS	TALGRY	B099421	2008	OBSOLETE	PANTONE 10C No replacement for this Cap
CAPS	TAKWHT	B099429	2008	OBSOLETE	No replacement for this Cap
CAPS	5100BLKWHTCLEAR	B099517		OBSOLETE	
CAPS	320.094BLKWHT1	B099522		OBSOLETE	
CAPS	320.094BLKWHT2	B099523		OBSOLETE	
CAPS	320.094BLKWHT3	B099524		OBSOLETE	
CAPS	320.094BLKWHT4	B099525		OBSOLETE	
CAPS	320.094BLKWHT5	B099526		OBSOLETE	
CAPS	320.094BLKWHT6	B099527		OBSOLETE	
CAPS	320.094BLKWHT7	B099528		OBSOLETE	
CAPS	320.094BLKWHT8	B099529		OBSOLETE	
CAPS	320.094BLKWHT9	B099530		OBSOLETE	
CAPS	320.094BLKWHTCLEAR	B099532		OBSOLETE	
CAPS	TAGBLKF1	B099701		OBSOLETE	(PANTONE 538C)
CAPS	TAGBLKF2	B099702		OBSOLETE	(PANTONE 538C)
CAPS	TAGBLKNAV	B099703		OBSOLETE	(PANTONE 538C)
CAPS	TAO-BLK	D042000	2012	OBSOLETE	No replacement for this Cap
CAPS	JNTAM BUTTON	D800000	2006	OBSOLETE	No replacement for this Cap
CAPS	JNTAMWHTBUTTON	D800001	2006	OBSOLETE	No replacement for this Cap
CAPS	JNTAMREDBUTTON	D800002	2006	OBSOLETE	No replacement for this Cap
CAPS	TL6100.01CAPBLACK	D800100	2013	OBSOLETE	No replacement for this Cap
CAPS	TL6100.01CAPRED	D800101	2013	OBSOLETE	No replacement for this Cap
CAPS	TL6100.01CAPWHT	D800102	2013	OBSOLETE	No replacement for this Cap
CAPS	TL6100.02CAPBLACK	D800103	2013	OBSOLETE	No replacement for this Cap
CAPS	TL6100.02CAPRED	D800104	2013	OBSOLETE	No replacement for this Cap
CAPS	TL6100.02CAPWHITE	D800105	2013	OBSOLETE	No replacement for this Cap
CAPS	TL6100.03CAPBLACK	D800106	2013	OBSOLETE	No replacement for this Cap
CAPS	TL6100.03CAPRED	D800107	2013	OBSOLETE	No replacement for this Cap
CAPS	TL6100.03CAPWHITE	D800108	2013	OBSOLETE	No replacement for this Cap
CAPS	2FPP1WHT	H070311		OBSOLETE	
CAPS	3F401BLU	H070319		OBSOLETE	
CAPS	TAUDGRCAP	I028101		OBSOLETE	
CAPS	420B1BLKBUTTON	L040001		OBSOLETE	
CAPS	420B8WHTBUTTON	L040002		OBSOLETE	
CAPS	420B2GRYBUTTON	L040003		OBSOLETE	
CAPS	420AWHTBLKARROWUP	L070300		OBSOLETE	
CAPS	420AWHTSQBUTTON	L113002		OBSOLETE	
CAPS	TL6190CAP	P600010		OBSOLETE	SEE P600014
CAPS	TL6190BUTTONGRAY	P600012		OBSOLETE	SEE P600014
CAPS	700C3BLK	T700300		OBSOLETE	CAP
CAPS	1CLGR	A000000		OBSOLETE	(SEE Q800403)
CAPS	1DFWHT	A800324		OBSOLETE	
CAPS	1CFWHT	A800354		OBSOLETE	
Detector	PP2-7UX-2B2	34-PP27UX2B2		OBSOLETE	
Detector	TD1105B	D200016	2012	OBSOLETE	Left (B) orientation discontinued, Use TD1105A Right (A) orientation
Detector	TD1105B	P200016	2012	OBSOLETE	Left (B) orientation discontinued, Use TD1105A Right (A) orientation
Detector	TD1104	P200014	2019	OBSOLETE	
Detector	TD1104	P200014	2019	OBSOLETE	
Detector	TD4700AQ-GOLD	N470002	2020	OBSOLETE	
DIP	KAD02SJTR	W829002		OBSOLETE	
DIP	KAD04SJTR	W829003		OBSOLETE	
DIP	KAD06SJTR	W829004		OBSOLETE	
DIP	KAD08SJTR	W829005		OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
DIP	KAD10SJTR	W829006		OBSOLETE	
DIP	KAD02SJGR	W829022		OBSOLETE	
DIP	KAD04SJGR	W829023		OBSOLETE	
DIP	KAD06SJGR	W829024		OBSOLETE	
DIP	KAD08SJGR	W829025		OBSOLETE	
DIP	KAD10SJGR	W829026		OBSOLETE	
DIP	KAD02SJTT	W829032		OBSOLETE	
DIP	KAD04SJTT	W829033		OBSOLETE	
DIP	KAD06SJTT	W829034		OBSOLETE	
DIP	KAD08SJTT	W829035		OBSOLETE	
DIP	KAD10SJTT	W829036		OBSOLETE	
DIP	KAD02SJGT	W829042		OBSOLETE	
DIP	KAD04SJGT	W829043		OBSOLETE	
DIP	KAD06SJGT	W829044		OBSOLETE	
DIP	KAD08SJGT	W829045		OBSOLETE	
DIP	KAD10SJGT	W829046		OBSOLETE	
DIP	KAD02TJTR	W829052		OBSOLETE	
DIP	KAD04TJTR	W829053		OBSOLETE	
DIP	KAD06TJTR	W829054		OBSOLETE	
DIP	KAD08TJTR	W829055		OBSOLETE	
DIP	KAD10TJTR	W829056		OBSOLETE	
DIP	KAD02TJGR	W829062		OBSOLETE	
DIP	KAD04TJGR	W829063		OBSOLETE	
DIP	KAD06TJGR	W829064		OBSOLETE	
DIP	KAD08TJGR	W829065		OBSOLETE	
DIP	KAD10TJGR	W829066		OBSOLETE	
DIP	KAD02TJTT	W829072		OBSOLETE	
DIP	KAD04TJTT	W829073		OBSOLETE	
DIP	KAD06TJTT	W829074		OBSOLETE	
DIP	KAD08TJTT	W829075		OBSOLETE	
DIP	KAD10TJTT	W829076		OBSOLETE	
DIP	KAD02TJGT	W829082		OBSOLETE	
DIP	KAD04TJGT	W829083		OBSOLETE	
DIP	KAD06TJGT	W829084		OBSOLETE	
DIP	KAD08TJGT	W829085		OBSOLETE	
DIP	KAD10TJGT	W829086		OBSOLETE	
DIP	KAD02TGTR	W829102		OBSOLETE	
DIP	KAD04TGTR	W829103		OBSOLETE	
DIP	KAD06TGTR	W829104		OBSOLETE	
DIP	KAD08TGTR	W829105		OBSOLETE	
DIP	KAD10TGTR	W829106		OBSOLETE	
DIP	KAD02TGGR	W829122		OBSOLETE	
DIP	KAD04TGGR	W829123		OBSOLETE	
DIP	KAD06TGGR	W829124		OBSOLETE	
DIP	KAD08TGGR	W829125	2006	OBSOLETE	Use KAN series PCB footprint compatible
DIP	KAD10TGGR	W829126		OBSOLETE	
DIP	KAD02TGTT	W829132		OBSOLETE	
DIP	KAD04TGTT	W829133		OBSOLETE	
DIP	KAD06TGTT	W829134		OBSOLETE	
DIP	KAD08TGTT	W829135		OBSOLETE	
DIP	KAD10TGTT	W829136		OBSOLETE	
DIP	KAD02TGGT	W829142		OBSOLETE	
DIP	KAD04TGGT	W829143		OBSOLETE	
DIP	KAD06TGGT	W829144		OBSOLETE	
DIP	KAD08TGGT	W829145		OBSOLETE	
DIP	KAD10TGGT	W829146		OBSOLETE	
DIP	KAD02SGTR	W829152		OBSOLETE	
DIP	KAD04SGTR	W829153		OBSOLETE	
DIP	KAD06SGTR	W829154		OBSOLETE	
DIP	KAD08SGTR	W829155		OBSOLETE	
DIP	KAD10SGTR	W829156		OBSOLETE	
DIP	KAD02SGGR	W829162		OBSOLETE	
DIP	KAD04SGGR	W829163		OBSOLETE	
DIP	KAD06SGGR	W829164		OBSOLETE	
DIP	KAD08SGGR	W829165		OBSOLETE	
DIP	KAD10SGGR	W829166		OBSOLETE	
DIP	KAD02SGTT	W829172		OBSOLETE	(SEE W829182 - GOLD ROHS
DIP	KAD04SGTT	W829173		OBSOLETE	
DIP	KAD06SGTT	W829174		OBSOLETE	
DIP	KAD08SGTT	W829175		OBSOLETE	
DIP	KAD10SGTT	W829176		OBSOLETE	(SEE W829186 - GOLD ROHS
DIP	KAD02SGGT	W829182		OBSOLETE	
DIP	KAD04SGGT	W829183		OBSOLETE	
DIP	KAD06SGGT	W829184		OBSOLETE	
DIP	KAD08SGGT	W829185		OBSOLETE	
DIP	KAD10SGGT	W829186		OBSOLETE	
DIP	KAH1108RR	N811000		OBSOLETE	
DIP	KAH1108RT	N811001		OBSOLETE	
DIP	KAH04SSGET	W810000		OBSOLETE	**MASTER DRAWING**
DIP	KAH110RTHALFPITCH10UAU	W810001		OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
DIP	KAH110RRHALFPITCH3uAU	W810002		OBSOLETE	3 MICRO-INC
DIP	KAH08TSGERHALFPITCH	W810003		OBSOLETE	**MASTER DRAWING**
DIP	KAH08TSGET	W810004		OBSOLETE	
DIP	KAH04TSGER	W810108		OBSOLETE	SEE W810003
DIP	KAH06SSGET	W810116		OBSOLETE	
DIP	KAH04SSGET	W810120		OBSOLETE	
DIP	KAH08SSGET	W810125		OBSOLETE	
DIP	KAJ025HST	W822002	2012	OBSOLETE	(REPLACEMENT W822022)
DIP	KAJ035HST	W822003	2012	OBSOLETE	(REPLACEMENT W822023)
DIP	KAJ045HST	W822004	2012	OBSOLETE	(REPLACEMENT W822024)
DIP	KAJ055HST	W822005	2012	OBSOLETE	(REPLACEMENT W822025)
DIP	KAJ065HST	W822006	2012	OBSOLETE	(REPLACEMENT W822026)
DIP	KAJ075HST	W822007	2012	OBSOLETE	(REPLACEMENT W822027)
DIP	KAJ085HST	W822008	2012	OBSOLETE	(REPLACEMENT W822028)
DIP	KAJ095HST	W822009	2012	OBSOLETE	(REPLACEMENT W822029)
DIP	KAJ105HST	W822010	2012	OBSOLETE	(REPLACEMENT W822030)
DIP	KAJ125HST	W822012	2012	OBSOLETE	(REPLACEMENT W822031)
DIP	KAJ025HGT	W822022	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ035HGT	W822023	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ045HGT	W822024	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ055HGT	W822025	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ065HGT	W822026	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ075HGT	W822027	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ085HGT	W822028	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ095HGT	W822029	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ105HGT	W822030	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ125HGT	W822031	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ08THGT	W822032	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ02LHST	W822102	2012	OBSOLETE	(REPLACEMENT W822122)
DIP	KAJ03LHST	W822103	2012	OBSOLETE	(REPLACEMENT W822123)
DIP	KAJ04LHST	W822104	2012	OBSOLETE	(REPLACEMENT W822124)
DIP	KAJ05LHST	W822105	2012	OBSOLETE	(REPLACEMENT W822125)
DIP	KAJ06LHST	W822106	2012	OBSOLETE	(REPLACEMENT W822126)
DIP	KAJ07LHST	W822107	2012	OBSOLETE	(REPLACEMENT W822127)
DIP	KAJ08LHST	W822108	2012	OBSOLETE	(REPLACEMENT W822128)
DIP	KAJ09LHST	W822109	2012	OBSOLETE	(REPLACEMENT W822129)
DIP	KAJ10LHST	W822110	2012	OBSOLETE	(REPLACEMENT W822130)
DIP	KAJ12LHST	W822112	2012	OBSOLETE	(REPLACEMENT W822131)
DIP	KAJ02LHGT	W822122	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ03LHGT	W822123	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ04LHGT	W822124	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ05LHGT	W822125	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ06LHGT	W822126	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ07LHGT	W822127	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ08LHGT	W822128	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ09LHGT	W822129	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ10LHGT	W822130	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ12LHGT	W822131	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ04THGR	W822524	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ04THST	W822525	2012	OBSOLETE	(NO REPLACEMENT)
DIP	KAJ04THGT	W822526	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ01LAST	W823101	2012	OBSOLETE	(NO REPLACEMENT)
DIP	KAJ02LAST	W823102	2012	OBSOLETE	(REPLACEMENT W823122)
DIP	KAJ03LAST	W823103	2012	OBSOLETE	(REPLACEMENT W823123)
DIP	KAJ04LAST	W823104	2012	OBSOLETE	(REPLACEMENT W823124)
DIP	KAJ05LAST	W823105	2012	OBSOLETE	(REPLACEMENT W823125)
DIP	KAJ06LAST	W823106	2012	OBSOLETE	(REPLACEMENT W823126)
DIP	KAJ07LAST	W823107	2012	OBSOLETE	(REPLACEMENT W823127)
DIP	KAJ08LAST	W823108	2012	OBSOLETE	(REPLACEMENT W823128)
DIP	KAJ09LAST	W823109	2012	OBSOLETE	(REPLACEMENT W823129)
DIP	KAJ10LAST	W823110	2012	OBSOLETE	(REPLACEMENT W823130)
DIP	KAJ12LAST	W823112	2012	OBSOLETE	(REPLACEMENT W823131)
DIP	KAJ02SAST	W823113	2012	OBSOLETE	(NO REPLACEMENT)
DIP	KAJ03SAST	W823114	2012	OBSOLETE	(NO REPLACEMENT)
DIP	KAJ04SAST	W823115	2012	OBSOLETE	(NO REPLACEMENT)
DIP	KAJ05SAST	W823116	2012	OBSOLETE	(NO REPLACEMENT)
DIP	KAJ06SAST	W823117	2012	OBSOLETE	(NO REPLACEMENT)
DIP	KAJ07SAST	W823118	2012	OBSOLETE	(NO REPLACEMENT)
DIP	KAJ08SAST	W823119	2012	OBSOLETE	(NO REPLACEMENT)
DIP	KAJ01LAGT	W823121	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ02LAGT	W823122	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ03LAGT	W823123	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ04LAGT	W823124	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ05LAGT	W823125	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ06LAGT	W823126	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ07LAGT	W823127	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ08LAGT	W823128	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ09LAGT	W823129	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ10LAGT	W823130	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ12LAGT	W823131	2012	OBSOLETE	Use KAE series PCB footprint compatible



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
DIP	KAJ01LGGT	W823132	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ04LJGR	W823234	2012	OBSOLETE	
DIP	KAJ02TAST	W823302	2012	OBSOLETE	(REPLACEMENT W823322)
DIP	KAJ03TAST	W823303	2012	OBSOLETE	(REPLACEMENT W823323)
DIP	KAJ04TAST	W823304	2012	OBSOLETE	(REPLACEMENT W823324)
DIP	KAJ05TAST	W823305	2012	OBSOLETE	(REPLACEMENT W823325)
DIP	KAJ06TAST	W823306	2012	OBSOLETE	(REPLACEMENT W823326)
DIP	KAJ07TAST	W823307	2012	OBSOLETE	(REPLACEMENT W823327)
DIP	KAJ08TAST	W823308	2012	OBSOLETE	(REPLACEMENT W823328)
DIP	KAJ09TAST	W823309	2012	OBSOLETE	(REPLACEMENT W823329)
DIP	KAJ10TAST	W823310	2012	OBSOLETE	(REPLACEMENT W823330)
DIP	KAJ12TAST	W823312	2012	OBSOLETE	(REPLACEMENT W823331)
DIP	KAJ02TAGT	W823322	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ03TAGT	W823323	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ04TAGT	W823324	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ05TAGT	W823325	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ06TAGT	W823326	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ07TAGT	W823327	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ08TAGT	W823328	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ09TAGT	W823329	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ10TAGT	W823330	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ12TAGT	W823331	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ08TJGT	W823332	2012	OBSOLETE	
DIP	KAJ08SAST	W823408	2012	OBSOLETE	(NO REPLACEMENT)
DIP	KAJ04LGGR	W825004	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ04SJGT	W825005	2012	OBSOLETE	
DIP	KAJ03LGGR	W825006	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ07LGGR	W825007	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ02LGST	W825102	2012	OBSOLETE	(REPLACEMENT W825122)
DIP	KAJ03LGST	W825103	2012	OBSOLETE	(REPLACEMENT W825123)
DIP	KAJ04LGST	W825104	2012	OBSOLETE	(REPLACEMENT W825124)
DIP	KAJ05LGST	W825105	2012	OBSOLETE	(REPLACEMENT W825125)
DIP	KAJ06LGST	W825106	2012	OBSOLETE	(REPLACEMENT W825126)
DIP	KAJ07LGST	W825107	2012	OBSOLETE	(REPLACEMENT W825127)
DIP	KAJ08LGST	W825108	2012	OBSOLETE	(REPLACEMENT W825128)
DIP	KAJ09LGST	W825109	2012	OBSOLETE	(REPLACEMENT W825129)
DIP	KAJ10LGST	W825110	2012	OBSOLETE	(REPLACEMENT W825130)
DIP	KAJ12LGST	W825111	2012	OBSOLETE	(REPLACEMENT W825131)
DIP	KAJ02LGGT	W825122	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ03LGGT	W825123	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ04LGGT	W825124	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ05LGGT	W825125	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ06LGGT	W825126	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ07LGGT	W825127	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ08LGGT	W825128	2012	OBSOLETE	SEE N800208
DIP	KAJ09LGGT	W825129	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ10LGGT	W825130	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ12LGGT	W825131	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ10LGGR	W825132	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ06LGGR	W825133	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ02SGST	W825202	2012	OBSOLETE	
DIP	KAJ03SGST	W825203	2012	OBSOLETE	(REPLACEMENT W825223)
DIP	KAJ04SGST	W825204	2012	OBSOLETE	(REPLACEMENT W825414)
DIP	KAJ05SGST	W825205	2012	OBSOLETE	(REPLACEMENT W825225)
DIP	KAJ06SGST	W825206	2012	OBSOLETE	(REPLACEMENT W825226)
DIP	KAJ07SGST	W825207	2012	OBSOLETE	(REPLACEMENT W825227)
DIP	KAJ08SGST	W825208	2012	OBSOLETE	(REPLACEMENT W825228)
DIP	KAJ09SGST	W825209	2012	OBSOLETE	(REPLACEMENT W825229)
DIP	KAJ10SGST	W825210	2012	OBSOLETE	(REPLACEMENT W825230)
DIP	KAJ12SGST	W825211	2012	OBSOLETE	(REPLACEMENT W825231)
DIP	KAJ02SGGT	W825222	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ03SGGT	W825223	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ04SGGT	W825224	2012	OBSOLETE	SEE W825414
DIP	KAJ05SGGT	W825225	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ06SGGT	W825226	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ07SGGT	W825227	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ08SGGT	W825228	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ09SGGT	W825229	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ10SGGT	W825230	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ12SGGT	W825231	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ10SGGR	W825232	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ04SGSR	W825254	2012	OBSOLETE	(NO REPLACEMENT)
DIP	KAJ06SGSR	W825256	2012	OBSOLETE	(REPLACEMENT W825385)
DIP	KAJ02TGST	W825302	2012	OBSOLETE	(REPLACEMENT W825322)
DIP	KAJ03TGST	W825303	2012	OBSOLETE	(REPLACEMENT W825323)
DIP	KAJ04TGST	W825304	2012	OBSOLETE	(REPLACEMENT W825324)
DIP	KAJ05TGST	W825305	2012	OBSOLETE	(REPLACEMENT W825325)
DIP	KAJ06TGST	W825306	2012	OBSOLETE	(REPLACEMENT W825326)
DIP	KAJ07TGST	W825307	2012	OBSOLETE	(REPLACEMENT W825327)
DIP	KAJ08TGST	W825308	2012	OBSOLETE	(REPLACEMENT W825328)



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
DIP	KAJ09TGST	W825309	2012	OBSOLETE	(REPLACEMENT W825329)
DIP	KAJ10TGST	W825310	2012	OBSOLETE	(REPLACEMENT W825330)
DIP	KAJ12TGST	W825311	2012	OBSOLETE	(REPLACEMENT W825331)
DIP	KAJ02TGGT	W825322	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ03TGGT	W825323	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ04TGGT	W825324	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ05TGGT	W825325	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ06TGGT	W825326	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ07TGGT	W825327	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ08TGGT	W825328	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ09TGGT	W825329	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ10TGGT	W825330	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ12TGGT	W825331	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ01LHST	W825337	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ01SJSR	W825338	2012	OBSOLETE	(NO REPLACEMENT)
DIP	KAJ01SHST	W825339	2012	OBSOLETE	(NO REPLACEMENT)
DIP	KAJ01SAST	W825340	2012	OBSOLETE	(NO REPLACEMENT)
DIP	KAJ01TGSR	W825341	2012	OBSOLETE	(REPLACEMENT W825361)
DIP	KAJ02TGSR	W825342	2012	OBSOLETE	(REPLACEMENT W825362)
DIP	KAJ03TGSR	W825343	2012	OBSOLETE	(REPLACEMENT W825363)
DIP	KAJ04TGSR	W825344	2012	OBSOLETE	(REPLACEMENT W825364)
DIP	KAJ05TGSR	W825345	2012	OBSOLETE	(REPLACEMENT W825365)
DIP	KAJ06TGSR	W825346	2012	OBSOLETE	(REPLACEMENT W825366)
DIP	KAJ07TGSR	W825347	2012	OBSOLETE	(REPLACEMENT W825367)
DIP	KAJ08TGSR	W825348	2012	OBSOLETE	(REPLACEMENT W825368)
DIP	KAJ09TGSR	W825349	2012	OBSOLETE	(REPLACEMENT W825369)
DIP	KAJ10TGSR	W825350	2012	OBSOLETE	(REPLACEMENT W825370)
DIP	KAJ12TGSR	W825351	2012	OBSOLETE	(REPLACEMENT W825371)
DIP	KAJ12TJSR	W825360	2012	OBSOLETE	(NO REPLACEMENT)
DIP	KAJ01TGGR	W825361	2012	OBSOLETE	
DIP	KAJ02TGGR	W825362	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ03TGGR	W825363	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ04TGGR	W825364	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ05TGGR	W825365	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ06TGGR	W825366	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ07TGGR	W825367	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ08TGGR	W825368	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ09TGGR	W825369	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ10TGGR	W825370	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ12TGGR	W825371	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ01TGGT	W825372	2012	OBSOLETE	CANNOT PRODUCE
DIP	KAJ01SGGT	W825373	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ04SGGR	W825384	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ06SGGR	W825385	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ05SGGR	W825386	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ08SGGR	W825387	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ02LGGR	W825400	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ04SGST	W825404	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ04SGGT	W825414	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAJ08SGGT	W825418	2012	OBSOLETE	
DIP	KAL1104RT	N110400		OBSOLETE	
DIP	KAL1106RT	N110600		OBSOLETE	
DIP	KAL1108RT	N110800		OBSOLETE	
DIP	KAL1108ET	N110850		OBSOLETE	
DIP	KAL1110RT	N111000		OBSOLETE	
DIP	KAL2102RT	N111020		OBSOLETE	
DIP	KAL2104RT	N111040		OBSOLETE	
DIP	KAL2106RT	N111060		OBSOLETE	
DIP	KAL2108RR	N111079		OBSOLETE	
DIP	KAL2108RT	N111080		OBSOLETE	
DIP	KAL2110RT	N111100		OBSOLETE	
DIP	KAL2104ER	N112105		OBSOLETE	
DIP	KAL2104RR	N122104		OBSOLETE	
DIP	KAL2108ER	N122108		OBSOLETE	
DIP	KAL2110ER	N122110		OBSOLETE	
DIP	KAL02SASET	W810005		OBSOLETE	
DIP	KAL04SASET	W810006		OBSOLETE	
DIP	KAL06SASET	W810007		OBSOLETE	
DIP	KAL08SASET	W810008		OBSOLETE	
DIP	KAL10SASET	W810009		OBSOLETE	
DIP	KAL02SSGET	W810010		OBSOLETE	
DIP	KAL04SSGET	W810011		OBSOLETE	
DIP	KAL06SSGET	W810012		OBSOLETE	
DIP	KAL06SSGER	W810013		OBSOLETE	
DIP	KAL08SSGER	W810014		OBSOLETE	
DIP	KAL08SSGET	W810015		OBSOLETE	
DIP	KAL10SSGET	W810016		OBSOLETE	
DIP	KAL02LSGET	W810017		OBSOLETE	
DIP	KAL04LSGET	W810018		OBSOLETE	
DIP	KAL06LSGET	W810020		OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
DIP	KAL08LSGET	W810021		OBSOLETE	
DIP	KAL10LSGET	W810022		OBSOLETE	
DIP	KAL02LSGER	W810023		OBSOLETE	
DIP	KAL04SSGER	W810024		OBSOLETE	
DIP	KAL06LSGER	W810025		OBSOLETE	
DIP	KAL08LSGER	W810026		OBSOLETE	
DIP	KAL10LSGER	W810027		OBSOLETE	
DIP	KAP1112VT	N411116		OBSOLETE	
DIP	KAR02LAST	W827002	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR03LAST	W827003	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR04LAST	W827004	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR05LAST	W827005	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR06LAST	W827006	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR08LAST	W827007	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR10LAST	W827008	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR08LASTREVERSED	W827017	2012	OBSOLETE	ON POSITION (NO REPLACE)
DIP	KAR02LAGT	W827022	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR03LAGT	W827023	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR04LAGT	W827024	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR05LAGT	W827025	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR06LAGT	W827026	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR08LAGT	W827027	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR10LAGT	W827028	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR02LHST	W827102	2012	OBSOLETE	(REPLACEMENT W827122)
DIP	KAR03LHST	W827103	2012	OBSOLETE	(REPLACEMENT W827123)
DIP	KAR04LHST	W827104	2012	OBSOLETE	(REPLACEMENT W827124)
DIP	KAR05LHST	W827105	2012	OBSOLETE	(REPLACEMENT W827125)
DIP	KAR06LHST	W827106	2012	OBSOLETE	(REPLACEMENT W827126)
DIP	KAR08LHST	W827107	2012	OBSOLETE	(REPLACEMENT W827127)
DIP	KAR10LHST	W827108	2012	OBSOLETE	(REPLACEMENT W827128)
DIP	KAR02LHGT	W827122	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR03LHGT	W827123	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR04LHGT	W827124	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR05LHGT	W827125	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR06LHGT	W827126	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR08LHGT	W827127	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR10LHGT	W827128	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR02LGST	W827402	2012	OBSOLETE	(REPLACEMENT W827422)
DIP	KAR03LGST	W827403	2012	OBSOLETE	(REPLACEMENT W827423)
DIP	KAR04LGST	W827404	2012	OBSOLETE	(REPLACEMENT W827424)
DIP	KAR05LGST	W827405	2012	OBSOLETE	(REPLACEMENT W827425)
DIP	KAR06LGST	W827406	2012	OBSOLETE	(REPLACEMENT W827426)
DIP	KAR08LGST	W827407	2012	OBSOLETE	(REPLACEMENT W827427)
DIP	KAR10LGST	W827408	2012	OBSOLETE	(REPLACEMENT W827428)
DIP	KAR02LGGT	W827422	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR03LGGT	W827423	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR04LGGT	W827424	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR05LGGT	W827425	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR06LGGT	W827426	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR08LGGT	W827427	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR10LGGT	W827428	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR02LGSR	W827442	2012	OBSOLETE	(REPLACEMENT W827462)
DIP	KAR03LGSR	W827443	2012	OBSOLETE	(REPLACEMENT W827463)
DIP	KAR04LGSR	W827444	2012	OBSOLETE	(REPLACEMENT W827464)
DIP	KAR05LGSR	W827445	2012	OBSOLETE	(REPLACEMENT W827465)
DIP	KAR06LGSR	W827446	2012	OBSOLETE	(REPLACEMENT W827466)
DIP	KAR08LGSR	W827447	2012	OBSOLETE	(REPLACEMENT W827467)
DIP	KAR10LGSR	W827448	2012	OBSOLETE	(REPLACEMENT W827468)
DIP	KAR02LGGR	W827462	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR03LGGR	W827463	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR04LGGR	W827464	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR05LGGR	W827465	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR06LGGR	W827466	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR08LGGR	W827467	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR10LGGR	W827468	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR02SAST	W828002	2012	OBSOLETE	
DIP	KAR03SAST	W828003	2012	OBSOLETE	
DIP	KAR04SAST	W828004	2012	OBSOLETE	
DIP	KAR05SAST	W828005	2012	OBSOLETE	
DIP	KAR06SAST	W828006	2012	OBSOLETE	
DIP	KAR08SAST	W828007	2012	OBSOLETE	
DIP	KAR10SAST	W828008	2012	OBSOLETE	
DIP	KAR02SAGT	W828022	2012	OBSOLETE	
DIP	KAR03SAGT	W828023	2012	OBSOLETE	
DIP	KAR04SAGT	W828024	2012	OBSOLETE	
DIP	KAR05SAGT	W828025	2012	OBSOLETE	
DIP	KAR06SAGT	W828026	2012	OBSOLETE	
DIP	KAR08SAGT	W828027	2012	OBSOLETE	
DIP	KAR10SAGT	W828028	2012	OBSOLETE	
DIP	KAR02SGST	W828402	2012	OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
DIP	KAR03SGST	W828403	2012	OBSOLETE	
DIP	KAR04SGST	W828404	2012	OBSOLETE	(REPLACEMENT W828424)
DIP	KAR05SGST	W828405	2012	OBSOLETE	
DIP	KAR06SGST	W828406	2012	OBSOLETE	
DIP	KAR08SGST	W828407	2012	OBSOLETE	
DIP	KAR10SGST	W828408	2012	OBSOLETE	
DIP	KAR05SHST	W828415	2012	OBSOLETE	
DIP	KAR06SHST	W828416	2012	OBSOLETE	
DIP	KAR06LJGR	W828417	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR08SHST	W828418	2012	OBSOLETE	
DIP	KAR125JGT	W828419	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR02SGGT	W828422	2012	OBSOLETE	
DIP	KAR03SGGT	W828423	2012	OBSOLETE	
DIP	KAR04SGGT	W828424	2012	OBSOLETE	
DIP	KAR05SGGT	W828425	2012	OBSOLETE	
DIP	KAR06SGGT	W828426	2012	OBSOLETE	
DIP	KAR08SGGT	W828427	2012	OBSOLETE	
DIP	KAR10SGGT	W828428	2012	OBSOLETE	
DIP	KAR10LJGR	W828429	2012	OBSOLETE	Use KAE series PCB footprint compatible
DIP	KAR02SGSR	W828442	2012	OBSOLETE	
DIP	KAR03SGSR	W828443	2012	OBSOLETE	
DIP	KAR04SGSR	W828444	2012	OBSOLETE	
DIP	KAR05SGSR	W828445	2012	OBSOLETE	
DIP	KAR06SGSR	W828446	2012	OBSOLETE	
DIP	KAR08SGSR	W828447	2012	OBSOLETE	
DIP	KAR10SGSR	W828448	2012	OBSOLETE	
DIP	KAR02SGGR	W828462	2012	OBSOLETE	
DIP	KAR03SGGR	W828463	2012	OBSOLETE	
DIP	KAR04SGGR	W828464	2012	OBSOLETE	
DIP	KAR05SGGR	W828465	2012	OBSOLETE	
DIP	KAR06SGGR	W828466	2012	OBSOLETE	
DIP	KAR08SGGR	W828467	2012	OBSOLETE	
DIP	KAR10SGGR	W828468	2012	OBSOLETE	
DIP	KAS2102R	N321022		OBSOLETE	
DIP	KAS2110R	N321113		OBSOLETE	
DIP	KAS2112R	N321114		OBSOLETE	
DIP	KAT1104E	N711040		OBSOLETE	
DIP	KAW1S101E	N511010		OBSOLETE	PHASE OUT
DIP	KAW1S101R	N511014		OBSOLETE	PHASE OUT
DIP	KAW1H102E	N511022		OBSOLETE	
DIP	KAW1H104E	N511042		OBSOLETE	
DIP	KAW1H104R	N511046		OBSOLETE	DIR-04H (W/ TAPE)
DIP	KAW1H105E	N511052		OBSOLETE	PHASE OUT
DIP	KAW1H106E	N511062		OBSOLETE	
DIP	KAW1H108E	N511082		OBSOLETE	
DIP	KAW1H108RT	N511087		OBSOLETE	
DIP	KAW1H110E	N511102		OBSOLETE	
DIP	KAW2104ER	N610042		OBSOLETE	
DIP	KAW2101E	N611010		OBSOLETE	PHASE OUT
DIP	KAW2101RT	N611014		OBSOLETE	PHASE OUT
DIP	KAW2102E	N611020		OBSOLETE	PHASE OUT
DIP	KAW2102R	N611023		OBSOLETE	PHASE OUT
DIP	KAW2102RT	N611024		OBSOLETE	PHASE OUT
DIP	KAW2102RR	N611025		OBSOLETE	PHASE OUT
DIP	KAW2102TRTOPTAPESEAL	N611026		OBSOLETE	SEE N611025
DIP	KAW2103E	N611030		OBSOLETE	PHASE OUT
DIP	KAW2103RR	N611031		OBSOLETE	SEE N611035
DIP	KAW2103RT	N611034		OBSOLETE	PHASE OUT
DIP	KAW2103RR	N611035		OBSOLETE	PHASE OUT
DIP	KAW2104E	N611040		OBSOLETE	PHASE OUT
DIP	KAW2104TRTOPTAPESEAL	N611041		OBSOLETE	SEE N611045
DIP	KAW2104R	N611043		OBSOLETE	PHASE OUT
DIP	KAW2104RT	N611044		OBSOLETE	PHASE OUT
DIP	KAW2104RR	N611045		OBSOLETE	OBSOLETE
DIP	KAW2105TRTOPTAPESEAL	N611051		OBSOLETE	SEE N611055
DIP	KAW2105RR	N611055		OBSOLETE	PHASE OUT
DIP	KAW2105RT	N611056		OBSOLETE	PHASE OUT
DIP	KAW2106E	N611060		OBSOLETE	PHASE OUT
DIP	KAW2106RTTOPTAPESEAL	N611061		OBSOLETE	SEE N611065
DIP	KAW2106RR	N611065		OBSOLETE	PHASE OUT
DIP	KAW2107RTTOPTAPESEAL	N611071		OBSOLETE	SEE N611075
DIP	KAW2107RT	N611074		OBSOLETE	PHASE OUT
DIP	KAW2107RR	N611076		OBSOLETE	PHASE OUT
DIP	KAW2108RRTOPTAPESEAL	N611081		OBSOLETE	SEE N611085
DIP	KAW2108R	N611083		OBSOLETE	PHASE OUT
DIP	KAW2108RT	N611084		OBSOLETE	PHASE OUT
DIP	KAW2108RR	N611085		OBSOLETE	PHASE OUT
DIP	KAW2109E	N611090		OBSOLETE	PHASE OUT
DIP	KAW2109RR	N611091		OBSOLETE	PHASE OUT
DIP	KAW2110RT	N611104		OBSOLETE	PHASE OUT



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
DIP	KAW2110RTTOPTAPESEAL	N611106		OBSOLETE	SEE N611105
DIP	KAW2112E	N611120		OBSOLETE	
DIP	KAW2112RT	N611121		OBSOLETE	ORDER N611124
DIP	KAW2112R	N611123		OBSOLETE	PHASE OUT
DIP	KAW2112RT	N611124		OBSOLETE	
DIP	KAW2112RR	N611214		OBSOLETE	PHASE OUT
DIP	KAW01LASET	W810028		OBSOLETE	
DIP	KAW01LHSET	W810029		OBSOLETE	
DIP	KAW04SSGET	W810030		OBSOLETE	
DIP	KAW04TSGET	W810031		OBSOLETE	
DIP	KAW04TSGER	W810032		OBSOLETE	
DIP	KAW05LSGET	W810033		OBSOLETE	SEE W810045
DIP	KAW05SSGET	W810034		OBSOLETE	
DIP	KAW05TSGET	W810035		OBSOLETE	
DIP	KAW05TSGER	W810036		OBSOLETE	
DIP	KAW06LSGET	W810037		OBSOLETE	SEE W810045
DIP	KAW06SSGET	W810038		OBSOLETE	
DIP	KAW06TSGET	W810039		OBSOLETE	
DIP	KAW06TSGER	W810040		OBSOLETE	
DIP	KAW07LSGET	W810041		OBSOLETE	SEE W810045
DIP	KAW07SSGET	W810042		OBSOLETE	
DIP	KAW07TSGET	W810043		OBSOLETE	
DIP	KAW07TSGER	W810044		OBSOLETE	
DIP	KAW08LSGET	W810045		OBSOLETE	(MASTER DRAWING)
DIP	KAW08SSGET	W810046		OBSOLETE	
DIP	KAW08TSGET	W810047		OBSOLETE	
DIP	KAW08TSGER	W810048		OBSOLETE	
DIP	KAW09LSGET	W810049		OBSOLETE	SEE W810045
DIP	KAW09SSGET	W810050		OBSOLETE	
DIP	KAW09TSGET	W810051		OBSOLETE	
DIP	KAW09TSGER	W810052		OBSOLETE	
DIP	KAW10SSGET	W810053		OBSOLETE	
DIP	KAW10TSGET	W810054		OBSOLETE	
DIP	KAW10TSGER	W810055		OBSOLETE	
DIP	KAW12LSGET	W810056		OBSOLETE	SEE W810045
DIP	KAW12SSGET	W810057		OBSOLETE	
DIP	KAW12TSGET	W810058		OBSOLETE	
DIP	KAW10LSGET	W810059		OBSOLETE	SEE W810045
DIP	KAW12TSGER	W810060		OBSOLETE	
DIP	KAW01ASET	W810061		OBSOLETE	
DIP	KAW01TASET	W810062		OBSOLETE	
DIP	KAW01SHSET	W810063		OBSOLETE	
DIP	KAW01THSET	W810064		OBSOLETE	
DIP	KAW02LASET	W810065		OBSOLETE	
DIP	KAW02LHSET	W810066		OBSOLETE	
DIP	KAW02ASET	W810067		OBSOLETE	
DIP	KAW02TASET	W810068		OBSOLETE	
DIP	KAW02SHSET	W810069		OBSOLETE	
DIP	KAW02THSET	W810070		OBSOLETE	
DIP	KAW04LASET	W810071		OBSOLETE	
DIP	KAW04LHSET	W810072		OBSOLETE	
DIP	KAW04ASET	W810073		OBSOLETE	
DIP	KAW04TASET	W810074		OBSOLETE	
DIP	KAW04SHSET	W810075		OBSOLETE	
DIP	KAW04THSET	W810076		OBSOLETE	
DIP	KAW06LASET	W810077		OBSOLETE	
DIP	KAW06LHSET	W810078		OBSOLETE	
DIP	KAW06ASET	W810079		OBSOLETE	
DIP	KAW06TASET	W810080		OBSOLETE	
DIP	KAW06SHSET	W810081		OBSOLETE	
DIP	KAW06THSET	W810082		OBSOLETE	
DIP	KAW08LASET	W810083		OBSOLETE	
DIP	KAW08LHSET	W810084		OBSOLETE	
DIP	KAW08ASET	W810085		OBSOLETE	
DIP	KAW08TASET	W810086		OBSOLETE	
DIP	KAW08SHSET	W810087		OBSOLETE	
DIP	KAW08THSET	W810088		OBSOLETE	
DIP	KAW10LASET	W810089		OBSOLETE	
DIP	KAW10LHSET	W810090		OBSOLETE	
DIP	KAW10ASET	W810091		OBSOLETE	
DIP	KAW10TASET	W810092		OBSOLETE	
DIP	KAW10SHSET	W810093		OBSOLETE	
DIP	KAW10THSET	W810094		OBSOLETE	
DIP	KAW01LSGET	W810095		OBSOLETE	SEE W810045
DIP	KAW01SSGET	W810096		OBSOLETE	
DIP	KAW02LSGET	W810097		OBSOLETE	SEE W810045
DIP	KAW02SSGET	W810098		OBSOLETE	
DIP	KAW02TSGET	W810099		OBSOLETE	
DIP	KAW02TSGER	W810100		OBSOLETE	
DIP	KAW03LSGET	W810101		OBSOLETE	SEE W810045



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
DIP	KAW03SSGET	W810102		OBSOLETE	
DIP	KAW03TSGET	W810103		OBSOLETE	
DIP	KAW03TSGER	W810104		OBSOLETE	
DIP	KAW04LSGET	W810105		OBSOLETE	SEE W810045
DIP	KAW02SSSER	W810106		OBSOLETE	
DIP	KAW03SSSER	W810107		OBSOLETE	
DIP	KAW04TSSER	W810109		OBSOLETE	
DIP	KAW10TSSER	W810118		OBSOLETE	
DIP	KAW08TSSER	W810121		OBSOLETE	
DIP	KAW02TSSER	W810130		OBSOLETE	
DIP	LDA-04-R-B-nr	06-LDA04RBNR		OBSOLETE	
DIP	LDI-02H-B	06-LDI02HB		OBSOLETE	
DIP	LDJR-04-T-B	06-LDJR04TB		OBSOLETE	
DIP	LDJR-08-T-B	06-LDJR08TB		OBSOLETE	
DIP	LDM-01-B	06-LDM01B		OBSOLETE	
DIP	LDM-02-B	06-LDM02B		OBSOLETE	
DIP	LDM-03-B-nr	06-LDM03BNR		OBSOLETE	
DIP	LDM-04-B	06-LDM04B		OBSOLETE	
DIP	LDMR-01-B	06-LDMR01B		OBSOLETE	
DIP	LDMR-02-T-B	06-LDMR02TB		OBSOLETE	
DIP	LDMR-04-T-B	06-LDMR04TB		OBSOLETE	
DIP	LDMR-06-T-B	06-LDMR06TB		OBSOLETE	
DIP	LDMR-07-T-B-nr	06-LDMR07TBNR		OBSOLETE	
DIP	LDMR-10-T-B	06-LDMR10TB		OBSOLETE	
DIP	LDP-04-R-B-nr	06-LDP04RBNR		OBSOLETE	
DIP	LDP-08-R-B-nr	06-LDP08RBNR		OBSOLETE	
DIP	LDPL-04-R-B-nr	06-LDPL04RBNR		OBSOLETE	
DIP	LDS-03-R-B-nr	06-LDS03RBNR		OBSOLETE	
DIP	LDS-06-R-B-nr	06-LDS06RBNR		OBSOLETE	
DIP	LDS-07-R-B-nr	06-LDS07RBNR		OBSOLETE	
DIP	LDSR-03-R-T-B-nr	06-LDSR03RTBNR		OBSOLETE	
DIP	LDSR-04-R-B-nr	06-LDSR04RBNR		OBSOLETE	
DIP	LDSR-06-R-T-B-nr	06-LDSR06RTBNR		OBSOLETE	
DIP	LDSR-10-R-T-B-nr	06-LDSR10RTBNR		OBSOLETE	
DIP-Rotary	SRK10	04-SRK10	2016	OBSOLETE	No sales, use RDT series for new designs with P1 for 3X3 thru hole PCB footprint
DIP-Rotary	SRK10C	04-SRK10C	2016	OBSOLETE	No sales, use RDT series for new designs with P1 for 3X3 thru hole PCB footprint
DIP-Rotary	SRK16HC	04-SRK16HC	2016	OBSOLETE	No sales, use RDT series for new designs with P1 for 3X3 thru hole PCB footprint
DIP-Rotary	SRK16C	no drawing	2016	OBSOLETE	No sales, use RDT series for new designs with P1 for 3X3 thru hole PCB footprint
HARDWARE		0		OBSOLETE	DO NOT USE
HARDWARE	Lamb Catalog 2004	00-CATALOG		OBSOLETE	
HARDWARE	Lamb Industries Catalog	00-LAMBCATALOG2007		OBSOLETE	
HARDWARE	ACC-P01	03-ACCP01		OBSOLETE	
HARDWARE	ACC-P01	14-ACCP01		OBSOLETE	
HARDWARE	ACC-B01-2	17-ACCB012		OBSOLETE	
HARDWARE	ACC-C02-3	17-ACCC023		OBSOLETE	
HARDWARE	ACC-C03-2	17-ACCC032		OBSOLETE	
HARDWARE	ACC-C07-2	17-ACCC072		OBSOLETE	
HARDWARE	ACC-N01-1	17-ACCN011		OBSOLETE	
HARDWARE	ACC-N01-3	17-ACCN013		OBSOLETE	
HARDWARE	ACC-W01-3	17-ACCW013		OBSOLETE	
HARDWARE	ACC-W03-1	17-ACCW031		OBSOLETE	
HARDWARE	ACC-W03-3	17-ACCW033		OBSOLETE	
HARDWARE	ACC-W04-1	17-ACCW041		OBSOLETE	
HARDWARE	L101-J1V3GE2	17-L101J1V3GE2		OBSOLETE	
HARDWARE	L101-MD1CGE	17-L101MD1CGE		OBSOLETE	
HARDWARE	L101-SYZGE	17-L101SYZGE		OBSOLETE	
HARDWARE	NU-021	17-NU021		OBSOLETE	
HARDWARE	P-70A-nr	22-P70ANR		OBSOLETE	
HARDWARE	ACC-C16-2	29-ACCC162	2019	OBSOLETE	
HARDWARE	ACC-C16-3	29-ACCC163	2017	OBSOLETE	Decreasing demand, stream line series
HARDWARE	ACC-C16-6	29-ACCC166	2017	OBSOLETE	Decreasing demand, stream line series
HARDWARE	ACC-C16-9	29-ACCC169	2017	OBSOLETE	Decreasing demand, stream line series
HARDWARE	ACC-C17-2	29-ACCC172	2019	OBSOLETE	
HARDWARE	ACC-C17-3	29-ACCC173	2017	OBSOLETE	Decreasing demand, stream line series
HARDWARE	ACC-C17-6	29-ACCC176	2017	OBSOLETE	Decreasing demand, stream line series
HARDWARE	ACC-C17-9	29-ACCC179	2017	OBSOLETE	Decreasing demand, stream line series
HARDWARE	ACC-KF05	34-ACCKF05	2018	OBSOLETE	Decreasing demand, stream line series
HARDWARE	ACC-F01-2	38-ACCF012	2018	OBSOLETE	Decreasing demand, stream line series
HARDWARE	ACC-M01-3	38-ACCM013		OBSOLETE	CANNOT PRODUCE
HARDWARE	ACC-M04-3	38-ACCM043	2019	OBSOLETE	
HARDWARE	PV4ORING15MM	52-PV4ORING15MM		OBSOLETE	SEE 52-PV1PV4ORING
HARDWARE	PV4ORING19MM	52-PV4ORING19MM		OBSOLETE	
HARDWARE	10MMREVRELEBARSPRING	A020998		OBSOLETE	REVERSE TYPE
HARDWARE	10MMREVRELEASESHEET	A020999		OBSOLETE	REVERSE TYPE
HARDWARE	2XTA10MMCHASSIS	A021000		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	3XTA10MMCHASSIS	A021001		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	4XTA10MMCHASSIS	A021002		OBSOLETE	
HARDWARE	5XTA10MMCHASSIS	A021003		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	6XTA10MMCHASSIS	A021004		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	7XTA10MMCHASSIS	A021005		OBSOLETE	STANDARD 2.38mm HOLES



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
HARDWARE	8XTA10MMCHASSIS	A021006		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	11XTA10MMCHASSIS	A021009		OBSOLETE	
HARDWARE	12XTA10MMCHASSIS	A021010		OBSOLETE	
HARDWARE	15XTA10MMCHASSIS	A021013		OBSOLETE	
HARDWARE	17XTA10MMCHASSIS	A021015		OBSOLETE	
HARDWARE	18XTA10MMCHASSIS	A021016		OBSOLETE	
HARDWARE	1XTA05SCHASSIS	A021030		OBSOLETE	
HARDWARE	2XTA12.5MMCHASSIS	A021051		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	3XTA12.5MMCHASSIS	A021052		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	4XTA12.5MMCHASSIS	A021053		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	5XTA12.5MMCHASSIS	A021054		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	6XTA12.5MMCHASSIS	A021055		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	7XTA12.5MMCHASSIS	A021056		OBSOLETE	WITH STANDARD HOLE
HARDWARE	8XTA12.5MMCHASSIS	A021057		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	9XTA12.5MMCHASSIS	A021058		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	10XTA12.5MMCHASSIS	A021059		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	11XTA12.5MMCHASSIS	A021060		OBSOLETE	WITH STANDARD HOLE
HARDWARE	12XTA12.5MMCHASSIS	A021061		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	13XTA12.5MMCHASSIS	A021062		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	15XTA12.5MMCHASSIS	A021064		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	20XTA12.5MMCHASSIS	A021069		OBSOLETE	WITH STANDARD HOLE
HARDWARE	23XTA12.5MMCHASSIS	A021072		OBSOLETE	WITH STANDARD HOLE
HARDWARE	2XTA15MMCHASSIS	A021101		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	3XTA15MMCHASSIS	A021102		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	4XTA15MMCHASSIS	A021103		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	5XTA15MMCHASSIS	A021104		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	6XTA15MMCHASSIS	A021105		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	7XTA15MMCHASSIS	A021106		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	8XTA15MMCHASSIS	A021107		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	9XTA15MMCHASSIS	A021108		OBSOLETE	
HARDWARE	10XTA15MMCHASSIS	A021109		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	12XTA15MMCHASSIS	A021111		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	13XTA15MMCHASSIS	A021112		OBSOLETE	
HARDWARE	16XTA15MMCHASSIS	A021115		OBSOLETE	
HARDWARE	8XTA15MMCHASSIS	A021120		OBSOLETE	WITH CUT MOUNTING EARS
HARDWARE	2XTA17.5MMCHASSIS	A021151		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	3XTA17.5MMCHASSIS	A021152		OBSOLETE	
HARDWARE	4XTA17.5MMCHASSIS	A021153		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	5XTA17.5MMCHASSIS	A021154		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	7XTA17.5MMCHASSIS	A021156		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	8XTA17.5MMCHASSIS	A021157		OBSOLETE	
HARDWARE	9XTA17.5MMCHASSIS	A021158		OBSOLETE	
HARDWARE	10XTA17.5MMCHASSIS	A021159		OBSOLETE	
HARDWARE	12XTA17.5MMCHASSIS	A021161		OBSOLETE	
HARDWARE	14XTA17.5MMCHASSIS	A021163		OBSOLETE	
HARDWARE	20XTA17.5MMCHASSIS	A021169		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	12XTA12.5MM4/40THDCHAS	A021170		OBSOLETE	FRT THD 4/40-BACK NO THD
HARDWARE	3XTA17.5CHAS.125FB	A021171		OBSOLETE	3.18mm HOLES (.125)
HARDWARE	2XTA20MMCHASSIS	A021201		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	3XTA20MMCHASSIS	A021202		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	4XTA20MMCHASSIS	A021203		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	6XTA20MMCHASSIS	A021205		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	8XTA20MMCHASSIS	A021207		OBSOLETE	
HARDWARE	9XTA20MMCHASSIS	A021208		OBSOLETE	
HARDWARE	10XTA20MMCHASSIS	A021209		OBSOLETE	
HARDWARE	12XTA20MMCHASSIS	A021211		OBSOLETE	
HARDWARE	6XTA20MMCHASSIS.125FB	A021212		OBSOLETE	3.18mm HOLES (.125)
HARDWARE	TA000300SINGLECHASSIS	A021251		OBSOLETE	STANDARD 2.38mm HOLES
HARDWARE	TA000303SINGLECHASSIS	A021252		OBSOLETE	3.18mm HOLES (.125)
HARDWARE	TEKSINGLESTATIONCHASSIS	A021256		OBSOLETE	
HARDWARE	TA000302SINGLECHASSIS	A021276		OBSOLETE	TAPPED FOR 4-40 SCREWS
HARDWARE	2XTA10MMRELEASEBAR	A031301		OBSOLETE	
HARDWARE	3XTA10MMRELEASEBAR	A031302		OBSOLETE	
HARDWARE	4XTA10MMRELEASEBAR	A031303		OBSOLETE	
HARDWARE	5XTA10MMRELEASEBAR	A031304		OBSOLETE	
HARDWARE	6XTA10MMRELEASEBAR	A031305		OBSOLETE	
HARDWARE	7XTA10MMRELEASEBAR	A031306		OBSOLETE	
HARDWARE	8XTA10MMRELEASEBAR	A031307		OBSOLETE	
HARDWARE	PXTA10MMRELBAR	A031308		OBSOLETE	
HARDWARE	11XTA10MMRELEASEBAR	A031310		OBSOLETE	
HARDWARE	12XTA10MMRELEASEBAR	A031311		OBSOLETE	
HARDWARE	13XTA10MMRELEASEBAR	A031312		OBSOLETE	
HARDWARE	2XTA12.5MMRELEASEBAR	A031351		OBSOLETE	
HARDWARE	3XTA12.5MMRELEASEBAR	A031352		OBSOLETE	
HARDWARE	4XTA12.5MMRELEASEBAR	A031353		OBSOLETE	
HARDWARE	5XTA12.5MMRELEASEBAR	A031354		OBSOLETE	
HARDWARE	6XTA12.5MMRELEASEBAR	A031355		OBSOLETE	
HARDWARE	7XTA12.5MMRELEASEBAR	A031356		OBSOLETE	
HARDWARE	8XTA12.5MMRELEASEBAR	A031357		OBSOLETE	
HARDWARE	9XTA12.5MMRELEASEBAR	A031358		OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
HARDWARE	10XTA12.5MMRELEASEBAR	A031359		OBSOLETE	
HARDWARE	12XTA12.5MMRELEASEBAR	A031361		OBSOLETE	
HARDWARE	20XTA12.5MMRELEASEBAR	A031369		OBSOLETE	
HARDWARE	23XTA12.5MMRELEASEBAR	A031372		OBSOLETE	
HARDWARE	2XTA15MMRELEASEBAR	A031401		OBSOLETE	
HARDWARE	3XTA15MMRELEASEBAR	A031402		OBSOLETE	
HARDWARE	4XTA15MMRELEASEBAR	A031403		OBSOLETE	
HARDWARE	5XTA15MMRELEASEBAR	A031404		OBSOLETE	
HARDWARE	6XTA15MMRELEASEBAR	A031405		OBSOLETE	
HARDWARE	7XTA15MMRELEASEBAR	A031406		OBSOLETE	
HARDWARE	8XTA15MMRELEASEBAR	A031407		OBSOLETE	
HARDWARE	10XTA15MMRELEASEBAR	A031409		OBSOLETE	
HARDWARE	12XTA15MMRELEASEBAR	A031411		OBSOLETE	
HARDWARE	16XTA15MMRELEASEBAR	A031414		OBSOLETE	
HARDWARE	2XTA17.5MMRELEASEBAR	A031451		OBSOLETE	
HARDWARE	3XTA17.5MMRELEASEBAR	A031452		OBSOLETE	
HARDWARE	4XTA17.5MMRELEASEBAR	A031453		OBSOLETE	
HARDWARE	5XTA17.5MMRELEASEBAR	A031454		OBSOLETE	
HARDWARE	7XTA17.5MMRELEASEBAR	A031456		OBSOLETE	
HARDWARE	8XTA17.5MMRELEASEBAR	A031457		OBSOLETE	
HARDWARE	10XTA17.5MMRELEASEBAR	A031459		OBSOLETE	
HARDWARE	12XTA17.5RELEASEBAR	A031461		OBSOLETE	
HARDWARE	14XTA17.5MMRELEASEBAR	A031463		OBSOLETE	
HARDWARE	13XTA20MMRELEASEBAR	A031466		OBSOLETE	
HARDWARE	13XTA20MMCHASSIS	A031467		OBSOLETE	
HARDWARE	2XTA20MMRELEASEBAR	A031501		OBSOLETE	
HARDWARE	3XTA20MMRELEASEBAR	A031502		OBSOLETE	
HARDWARE	4XTA20MMRELEASEBAR	A031503		OBSOLETE	
HARDWARE	5XTA20MMRELEASEBAR	A031504		OBSOLETE	
HARDWARE	6XTA20MMRELEASEBAR	A031505		OBSOLETE	
HARDWARE	8XTA20MMRELEASEBAR	A031507		OBSOLETE	
HARDWARE	9XTA20MMRELEASEBAR	A031508		OBSOLETE	
HARDWARE	10XTA20MMRELEASEBAR	A031509		OBSOLETE	
HARDWARE	10MMLEAFSPRING	A031553		OBSOLETE	FOR TA SERIES REL BAR
HARDWARE	12.5MMCOILSPRING	A031601		OBSOLETE	FOR TA SERIES REL BAR
HARDWARE	15MMCOILSPRING	A031602		OBSOLETE	FOR TA SERIES REL BAR
HARDWARE	17.5MMCOILSPRING	A031603		OBSOLETE	FOR TA SERIES REL BAR
HARDWARE	20MMCOILRELEASESPRING	A031604		OBSOLETE	
HARDWARE	AMPFEMALECONNECTOR	A173977-2		OBSOLETE	FOR XA1981P
HARDWARE	2XTA10MMCHASSIS	A501000		OBSOLETE	WITH CUT MOUNTING EARS
HARDWARE	3XTA10MMCHASSIS	A501001		OBSOLETE	WITH CUT MOUNTING EARS
HARDWARE	4XTA10MMCHASSIS	A501002		OBSOLETE	WITH CUT MOUNTING EARS
HARDWARE	5XTA10MMCHASSIS	A501003		OBSOLETE	WITH CUT MOUNTING EARS
HARDWARE	6XTA10MMCHASSIS	A501004		OBSOLETE	WITH CUT MOUNTING EARS
HARDWARE	8XTA10MMCHASSIS	A501006		OBSOLETE	WITH CUT MOUNTING EARS
HARDWARE	9XTA10MMCHASSIS	A501007		OBSOLETE	WITH CUT MOUNTING EARS
HARDWARE	10XTA10MMCHASSIS	A501008		OBSOLETE	WITH CUT MOUNTING EARS
HARDWARE	2XTA12.5MMCHASSIS	A501051		OBSOLETE	WITH CUT MOUNTING EARS
HARDWARE	3XTA12.5MMCHASSIS	A501052		OBSOLETE	WITH CUT MOUNTING EARS
HARDWARE	8XTA12.5MMCHASSIS	A501056		OBSOLETE	WITH CUT MOUNTING EARS
HARDWARE	9XTA12.5MMCHASSIS	A501057		OBSOLETE	WITH CUT MOUNTING EARS
HARDWARE	2XTA15MMCHASSIS	A501101		OBSOLETE	WITH CUT MOUNTING EARS
HARDWARE	3X15MMCHASSIS	A501102		OBSOLETE	WITH CUT MOUNTING EARS
HARDWARE	5XTA15MMCHASSIS	A501104		OBSOLETE	WITH CUT MOUNTING EARS
HARDWARE	6XTA15MMCHASSIS	A501105		OBSOLETE	WITH CUT MOUNTING EARS
HARDWARE	7XTA15MMCHASSIS	A501106		OBSOLETE	WITH CUT MOUNTING EARS
HARDWARE	8XTA12.5MMCHASSIS	A501111		OBSOLETE	WITH CUT MOUNTING EARS
HARDWARE	5XTA17.5MMCHASSIS	A501154		OBSOLETE	WITH CUT MOUNTING EARS
HARDWARE	8XTA17.5MMCHASSIS	A501157		OBSOLETE	WITH CUT MOUNTING EARS
HARDWARE	2XTA20MMCHASSIS	A501201		OBSOLETE	WITH CUT MOUNTING EARS
HARDWARE	4X12.5MMCHASSISWITHTE	A522102		OBSOLETE	4-40 F 4-40 FRONT/.126 B
HARDWARE	5XTA17.5MMCHASSISWITHTE	A522153		OBSOLETE	4-40 TAPPED & EXT 4-40 F
HARDWARE	5X20MMCHASSIS440TE	A522204		OBSOLETE	FRT TAPPED & EXT 4-40 FR
HARDWARE	2XTA10MMCHASSIS.125FB	A531000		OBSOLETE	
HARDWARE	3XTA10MMCHASSIS.125FB	A531001		OBSOLETE	
HARDWARE	4XTA12.5MMCHASSIS.125FB	A531053		OBSOLETE	
HARDWARE	10XTA12.5MMCHASSIS.125	A531059		OBSOLETE	FB
HARDWARE	5XTA15MMCHASSIS.125FB	A539064		OBSOLETE	
HARDWARE	3XTA20MMCHASSIS.125FB	A540003		OBSOLETE	
HARDWARE	14XTA20MMCHASSI.125F094	A542514		OBSOLETE	B WITH INDICATOR HOLES
HARDWARE	9XTA15MMCHASSIS3.2HOLES	A550109		OBSOLETE	
HARDWARE	6X17.5MMCHASSIS440TEF	A550155		OBSOLETE	TAPPED & EXT 4-40 FRONT
HARDWARE	7X17.5MMCHASSIS440TEF	A550156		OBSOLETE	TAPPED & EXT 4-40 FRONT
HARDWARE	7XTA15MMCHASSIS.125FB	A550158		OBSOLETE	
HARDWARE	4XTA15MMCHASSIS440TEF	A552122		OBSOLETE	4-40 FRONT/.125 BOTTOM
HARDWARE	MTH10MMCOILSPRING	A960091		OBSOLETE	
HARDWARE	MTH12.5MMCOILSPRING	A960092		OBSOLETE	
HARDWARE	MTH15MMSPRING	A960093		OBSOLETE	
HARDWARE	MTH17.5MMCOILSPRING	A960094		OBSOLETE	
HARDWARE	MTH20MMCOILSPRING	A960095		OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
HARDWARE	MTHSINGLESTATIONCHASSIS	A960100		OBSOLETE	
HARDWARE	MTHKZXBACKETONLY	A960200		OBSOLETE	
HARDWARE	MTHCCLIPATI	A960201		OBSOLETE	
HARDWARE	2XMTH7.5MMCHASSISCU	A960222		OBSOLETE	TEARS**
HARDWARE	4XMTH7.5MMCHASSISCU	A960224		OBSOLETE	TEARS**
HARDWARE	5XMTH7.5MMCHASSISCU	A960225		OBSOLETE	TEARS**
HARDWARE	6XMTH7.5MMCHASSISCU	A960226		OBSOLETE	TEARS**
HARDWARE	7XMTH7.5MMCHASSISCU	A960227		OBSOLETE	TEARS**
HARDWARE	8XMTH7.5MMCHASSIS	A960228		OBSOLETE	CUTEARS
HARDWARE	9XMTH7.5MMCHASSIS	A960229		OBSOLETE	CUTEARS
HARDWARE	10XMTH7.5MMCHASSIS	A960230		OBSOLETE	CUTEAR
HARDWARE	11XMTH7.5MMCHASSIS	A960231		OBSOLETE	CUTEAR
HARDWARE	12XMTH7.5MMCHASSIS	A960232		OBSOLETE	CUTEAR
HARDWARE	3XMTH10MMCHASSISCUTEARS	A960243		OBSOLETE	
HARDWARE	4XMTH10MMCHASSISCUTEAR	A960244		OBSOLETE	
HARDWARE	5XMTH10MMCHASSISCUTEARS	A960245		OBSOLETE	
HARDWARE	4XMTH12.5MMCHASSISCUTEAR	A960264		OBSOLETE	
HARDWARE	2XMTH7.5MMCHASSISM3TE	A960342		OBSOLETE	
HARDWARE	2XMTH10MMCHASSISM3TE	A960362		OBSOLETE	
HARDWARE	5XMTH10CHASSISM3TE	A960365		OBSOLETE	
HARDWARE	6XMTH10MMCHASSISM3TE	A960366		OBSOLETE	
HARDWARE	3XMTH12.5MMCHASSISM3TE	A960383		OBSOLETE	
HARDWARE	4XMTH12.5MMCHASSISM3TE	A960384		OBSOLETE	
HARDWARE	5XMTH12.5MMCHASSISM3TE	A960385		OBSOLETE	
HARDWARE	6XMTH12.5MMCHASSISM3TE	A960386		OBSOLETE	
HARDWARE	8XMTH12.5MMCHASSISM3T&	A960388		OBSOLETE	E
HARDWARE	2XMTH15CHASM3T	A960402		OBSOLETE	
HARDWARE	3XMTH15MMCHASSISM3TE	A960403		OBSOLETE	
HARDWARE	4XMTH15CHASSISM3TE	A960404		OBSOLETE	
HARDWARE	5XMTH15CHASM3T	A960405		OBSOLETE	
HARDWARE	6XMTH15MMCHASSISM3TE	A960406		OBSOLETE	
HARDWARE	7XMTH15CHASM3T	A960407		OBSOLETE	
HARDWARE	7XMTH12.5MMRELEASEBAR	A960408		OBSOLETE	
HARDWARE	7XMTH12.5MMCHASSIS	A960412		OBSOLETE	
HARDWARE	2XMTH17.5MMCHASSISM3TE	A960422		OBSOLETE	
HARDWARE	3XMTH17.5MMCHASSISM3TE	A960423		OBSOLETE	
HARDWARE	4XMTH17.5MMCHASSISM3TE	A960424		OBSOLETE	
HARDWARE	6XMTH17.5MMCHASSISM3TE	A960426		OBSOLETE	
HARDWARE	4XMTH20MMCHASSIS	A960450		OBSOLETE	
HARDWARE	4XMTH20MMRELEASEBAR	A960460		OBSOLETE	
HARDWARE	3XMTH7.5MMRELEASEBAR	A960503		OBSOLETE	
HARDWARE	4XMTH7.5MMRELEASEBAR	A960504		OBSOLETE	
HARDWARE	10XMTH10MMRELEASEBAR	A960514		OBSOLETE	
HARDWARE	10XMTH10MMCHASSIS	A960515		OBSOLETE	
HARDWARE	3XMTH10MMRELEASEBAR	A960523		OBSOLETE	
HARDWARE	4XMTH10MMRELEASEBAR	A960524		OBSOLETE	
HARDWARE	5XMTH10MMRELEASEBAR	A960525		OBSOLETE	
HARDWARE	6XMTH10MMRELEASEBAR	A960526		OBSOLETE	
HARDWARE	3XMTH12.5MMRELEASEBAR	A960543		OBSOLETE	
HARDWARE	4XMTH12.5MMRELEASEBAR	A960544		OBSOLETE	
HARDWARE	5XMTH12.5MMRELEASEBAR	A960545		OBSOLETE	
HARDWARE	6XMTH12.5MMRELEASEBAR	A960546		OBSOLETE	
HARDWARE	2XMTH15RELEASEBAR	A960562		OBSOLETE	
HARDWARE	3XMTH15MMRELEASEBAR	A960563		OBSOLETE	
HARDWARE	4XMTH15RELEASEBAR	A960564		OBSOLETE	
HARDWARE	52XMTH15RELEASEBAR	A960565		OBSOLETE	
HARDWARE	6XMTH15RELEASEBAR	A960566		OBSOLETE	
HARDWARE	7XMTH15RELEASEBAR	A960567		OBSOLETE	
HARDWARE	8XMTH15RELEASEBAR	A960568		OBSOLETE	
HARDWARE	9XMTH15RELEASEBAR	A960569		OBSOLETE	
HARDWARE	10XMTH15RELEASEBAR	A960570		OBSOLETE	
HARDWARE	11XMTH15RELEASEBAR	A960571		OBSOLETE	
HARDWARE	12XMTH15RELEASEBAR	A960572		OBSOLETE	
HARDWARE	2XMTH17.5MMRELEASEBAR	A960582		OBSOLETE	
HARDWARE	3XMTH17.5MMRELEASEBAR	A960583		OBSOLETE	
HARDWARE	4XMTH17.5MMRELEASEBAR	A960584		OBSOLETE	
HARDWARE	5XMTH17.5MMRELEASEBAR	A960585		OBSOLETE	
HARDWARE	6XMTH17.5MMRELEASEBAR	A960586		OBSOLETE	
HARDWARE	8XMTH15MMCHASSISM3TE	A960608		OBSOLETE	
HARDWARE	9XMTH15MMCHASSISM3TE	A960609		OBSOLETE	
HARDWARE	10XMTH15MMCHASSISM3TE	A960610		OBSOLETE	
HARDWARE	11XMTH15MMCHASSISM3TE	A960611		OBSOLETE	
HARDWARE	12XMTH15MMCHASSISM3TE	A960612		OBSOLETE	
HARDWARE	KB5B6GRNLED	AM275GC15		OBSOLETE	LED FOR P001084(Z000003)
HARDWARE	GASKET1x0.687INCHID	C100000		OBSOLETE	1/16** IN RUBBERLITE EN
HARDWARE	GRNLED	D062006		OBSOLETE	(160-1142-ND)
HARDWARE	DOUBLELAMPExtractor	D080000		OBSOLETE	11021K
HARDWARE	TL9000RUBBERACTUATOR	D390010		OBSOLETE	
HARDWARE	5MMF250GOLDDOME	D990004		OBSOLETE	
HARDWARE	ACC-P02	EB-ACCP02		OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
HARDWARE	RSSEAL	M050900	2018	OBSOLETE	
HARDWARE	RSSEALFRAME	M050901	2018	OBSOLETE	
HARDWARE	HDW3DRESSNUT	T100001		OBSOLETE	SEE T100006
HARDWARE	HDW12BLK15/32NUTSTEEL	T100013		OBSOLETE	BLACK OXIDE FINISH
HARDWARE	RBW2 GASKET	Y001000		OBSOLETE	SEE Y000100
HARDWARE	M3QUICKCONNECT	Y100100		OBSOLETE	
HARDWARE	KBSBGRNLED	Z000002		OBSOLETE	LED FOR P001084
HARDWARE	LEDSUBMINATUREEPLUSPCPLTG	Z000007		OBSOLETE	AM27-ESH63
HARDWARE	MISC. PARTS	ZZZZZ25		OBSOLETE	
Keylock	KLS-S314-1-10002	17-KLSS314110002		OBSOLETE	
Keylock	KLS-S314-1-10003	17-KLSS314110003		OBSOLETE	
Keylock	KLS-S314-1-10004	17-KLSS314110004		OBSOLETE	
Keylock	KLS-S314-1-10005	17-KLSS314110005		OBSOLETE	
Keylock	KLS-S314-1-10006	17-KLSS314110006		OBSOLETE	
Keylock	KLS-S314-1-10007	17-KLSS314110007		OBSOLETE	
Keylock	KLS-S314-1-10008	17-KLSS314110008		OBSOLETE	
Keylock	KLS-S314-1-10009	17-KLSS314110009		OBSOLETE	
Keylock	KLS-S314-1-10010	17-KLSS314110010		OBSOLETE	
Keylock	KLS-S314-1-10011	17-KLSS314110011		OBSOLETE	
Keylock	KLS-S314-1-10012	17-KLSS314110012		OBSOLETE	
Keylock	KLS-S314-1-10013	17-KLSS314110013		OBSOLETE	
Keylock	KLS-S314-1-10014	17-KLSS314110014		OBSOLETE	
Keylock	KLS-S314-1-10015	17-KLSS314110015		OBSOLETE	
Keylock	KLS-S314-1-10016	17-KLSS314110016		OBSOLETE	
Keylock	KLS-S314-1-10017	17-KLSS314110017		OBSOLETE	
Keylock	KLS-S314-1-10018	17-KLSS314110018		OBSOLETE	
Keylock	KLS-S314-1-10019	17-KLSS314110019		OBSOLETE	
Keylock	KLS-S314-1-10020	17-KLSS314110020		OBSOLETE	
Keylock	KLS-S314-1-10021	17-KLSS314110021		OBSOLETE	
Keylock	KLS-S314-1-10022	17-KLSS314110022		OBSOLETE	
Keylock	KLS-S314-1-10023	17-KLSS314110023		OBSOLETE	
Keylock	KLS-S314-1-10024	17-KLSS314110024		OBSOLETE	
Keylock	KLS-S314-1-10025	17-KLSS314110025		OBSOLETE	
Keylock	KO107ACOMMONKEY	K100308		OBSOLETE	
Keylock	KO129CKEYCODEA126	K100515		OBSOLETE	ORDER K200249
Keylock	KO114B10001	K200105	2006	OBSOLETE	see KO series for other active options
Keylock	KO120A7325	K200120	2003	OBSOLETE	see KO series for other active options
Keylock	KO119A7308	K200138	2007	OBSOLETE	see KO series for other active options
Keylock	KO119A7327	K200157	2007	OBSOLETE	see KO series for other active options
Keylock	KO119A7328	K200158	2007	OBSOLETE	see KO series for other active options
Keylock	KO119A7329	K200159	2007	OBSOLETE	see KO series for other active options
Keylock	KO119A7330	K200160	2007	OBSOLETE	see KO series for other active options
Keylock	KO119A7331	K200161	2007	OBSOLETE	see KO series for other active options
Keylock	KO119A7332	K200162	2007	OBSOLETE	see KO series for other active options
Keylock	KO130QA126	K200226		OBSOLETE	DO NOT ORDER SEE K200243
Keylock	KO130JA126	K200240		OBSOLETE	DO NOT ORDER SEE K200219
Keylock	KO130HA126	K200250		OBSOLETE	SEE K200217
Keylock	KO130HA126	K200251		OBSOLETE	SEE K200217
Keylock	KO1030A126	K200252		OBSOLETE	ORDER K200224
Keylock	KO1300A126	K200253		OBSOLETE	ORDER K200224
Keylock	KO130ABLKA126	K200290		OBSOLETE	BLACK BEZEL
Keylock	KO1300A126 BLACK BEZEL	K200291		OBSOLETE	
Keylock	KO1300C01	K200294	2005	OBSOLETE	see KO series for other active options
Keylock	KO129GA126	K200312	2006	OBSOLETE	see KO series for other active options
Keylock	KO129HA126	K200313	2006	OBSOLETE	see KO series for other active options
Keylock	KO104A10001	K300101	2016	OBSOLETE	No drop in panel size to replace, consider 12mm or 19mm panel diam. offerings
Keylock	KO104B10001	K300102	2016	OBSOLETE	No drop in panel size to replace, consider 12mm or 19mm panel diam. offerings
Keylock	KO104B10002	K300103	2016	OBSOLETE	No drop in panel size to replace, consider 12mm or 19mm panel diam. offerings
Keylock	KO104B10003	K300104	2016	OBSOLETE	No drop in panel size to replace, consider 12mm or 19mm panel diam. offerings
Keylock	KO104B10004	K300105	2016	OBSOLETE	No drop in panel size to replace, consider 12mm or 19mm panel diam. offerings
Keylock	KO104B10005	K300106	2016	OBSOLETE	No drop in panel size to replace, consider 12mm or 19mm panel diam. offerings
Keylock	KO104B10006	K300107	2016	OBSOLETE	No drop in panel size to replace, consider 12mm or 19mm panel diam. offerings
Keylock	KO104B10007	K300108	2016	OBSOLETE	No drop in panel size to replace, consider 12mm or 19mm panel diam. offerings
Keylock	KO104B10008	K300109	2016	OBSOLETE	No drop in panel size to replace, consider 12mm or 19mm panel diam. offerings
Keylock	KO104B10009	K300110	2016	OBSOLETE	No drop in panel size to replace, consider 12mm or 19mm panel diam. offerings
Keylock	KO104A10002	K300111	2016	OBSOLETE	No drop in panel size to replace, consider 12mm or 19mm panel diam. offerings
Keylock	KO104A10003	K300112	2016	OBSOLETE	No drop in panel size to replace, consider 12mm or 19mm panel diam. offerings
Keylock	KO104A10004	K300113	2016	OBSOLETE	No drop in panel size to replace, consider 12mm or 19mm panel diam. offerings
Keylock	KO104A10005	K300114	2016	OBSOLETE	No drop in panel size to replace, consider 12mm or 19mm panel diam. offerings
Keylock	KO5321102	K600100		OBSOLETE	
Keylock	KO4212COMMONKEY	K900001		OBSOLETE	DO NOT ORDER SEE K200223
Keylock	KOSERIESCLIP	K900004		OBSOLETE	
Keylock	KO104AWireAssy	XK0094P	2016	OBSOLETE	No drop in panel size to replace, consider 12mm or 19mm panel diam. offerings
LT	4XLTPB102UOA	XA0889A		OBSOLETE	(SEE XA0889P)
LT	4XLTPB102UOA	XA0889P		OBSOLETE	
Pressure	ME2-420-2	54-ME24202		OBSOLETE	
Pressure	ME2-89-Z03-90	54-ME289Z0390		OBSOLETE	
Pressure	ME7-600V-111	54-ME7600V111	2017	OBSOLETE	SEE ENGR
Push Button	PB-12L01	03-PB12L01	2015	OBSOLETE	
Push Button	PB-12L01	03-PB12L01	2015	OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Push Button	PB-12L03	03-PB12L03	2015	OBSOLETE	
Pushbutton	TS01-CGE2	17-TS01CGE2		OBSOLETE	
Pushbutton	PR141C1900-nr	38-PR141C1900NR		OBSOLETE	
Pushbutton	LDT110011100	XD0056P		OBSOLETE	
Pushbutton	11031X4XX	XD0174C		OBSOLETE	
Pushbutton	11031X5XX	XD0175C		OBSOLETE	
Pushbutton	110311100	XD0214C		OBSOLETE	
Pushbutton	111011100BULK	XD0343A		OBSOLETE	
Pushbutton	13001XXX	XD0004A		OBSOLETE	
Pushbutton	13032XXX	XD0079A		OBSOLETE	
Pushbutton	13001XXX4	XD0347P		OBSOLETE	
Pushbutton	13001XX1	XD0364A		OBSOLETE	
Pushbutton	220A150QWHT	L400103		OBSOLETE	
Pushbutton	220C150QBLK	L400301		OBSOLETE	
Pushbutton	220C150QRED	L400302		OBSOLETE	
Pushbutton	220C150QWHT	L400303		OBSOLETE	
Pushbutton	220C1BLK	L990301		OBSOLETE	
Pushbutton	320E11BODY	A300012		OBSOLETE	2 LOWPOST IN #3 POSITION
Pushbutton	320.E11UL94VO	A300014		OBSOLETE	2 HIGHPOST #3 POSITION
Pushbutton	FIXEDCONTACTAG	A700000		OBSOLETE	STRAIGHT
Pushbutton	FIXEDCONTACTAGBENT	A700001		OBSOLETE	
Pushbutton	HOUSINGE11	A700002		OBSOLETE	
Pushbutton	HOUSINGU11	A700003		OBSOLETE	
Pushbutton	DOMEE11U11	A700004		OBSOLETE	
Pushbutton	DOMEE12	A700005		OBSOLETE	
Pushbutton	320E12BODYNOTERMINALS	B010003		OBSOLETE	
Pushbutton	320U11BODYNOTERMINALS	B010004		OBSOLETE	
Pushbutton	320E12BODY	B01E1-1		OBSOLETE	
Pushbutton	320E12WITHFIXEDCONTACT	B01E12		OBSOLETE	
Pushbutton	330U11BODYGOLD	B01MU12		OBSOLETE	
Pushbutton	320E12CONTACTDOME	B050000		OBSOLETE	
Pushbutton	320U11CONTACTDOME	B050002		OBSOLETE	PAIRw/B01MU11-3030840027
Pushbutton	FIXEDCONTACTAGST	B050003		OBSOLETE	
Pushbutton	FIXEDCONTACTAGAST	B050004		OBSOLETE	
Pushbutton	FIXEDCONTACTAGBT	B050005		OBSOLETE	
Pushbutton	FIXEDCONTACTAGABT	B050006		OBSOLETE	
Pushbutton	320DOME9N	B050007		OBSOLETE	
Pushbutton	320TERMINALFIXED	B700000		OBSOLETE	STRAIGHT
Pushbutton	320TERMINALFIXEDBENT	B700001		OBSOLETE	
Pushbutton	320.02E118JBLK94V0	XA1979P		OBSOLETE	ORDER-XA1979A
Pushbutton	320.22E11RED	XB0012P		OBSOLETE	Actuator .22 EOL 2009
Pushbutton	320.22E11ORG	XB0013A		OBSOLETE	Actuator .22 EOL 2009
Pushbutton	320.22E11ORG	XB0013P		OBSOLETE	Actuator .22 EOL 2009
Pushbutton	320.02U11BLK	XB0027A		OBSOLETE	
Pushbutton	320.02U11BLK	XB0027P		OBSOLETE	
Pushbutton	320.01U11WHT	XB0040B		OBSOLETE	
Pushbutton	320.01U11WHT	XB0040P		OBSOLETE	
Pushbutton	320U11WHT	XB0050C		OBSOLETE	
Pushbutton	320.2E11BLKWITLEDHLDR	XB0053A		OBSOLETE	DO NOT ORDER
Pushbutton	320U11BLK	XB0095A		OBSOLETE	
Pushbutton	320U11BLK	XB0095P		OBSOLETE	
Pushbutton	320.02E11TACBLK	XB0118A		OBSOLETE	
Pushbutton	320.02E12BLK	XB0139A		OBSOLETE	
Pushbutton	320.02U11BLK	XB0146A		OBSOLETE	
Pushbutton	320.02U11BLK	XB0146P		OBSOLETE	
Pushbutton	320U11GRY	XB0154P		OBSOLETE	
Pushbutton	320U11RED	XB0155B		OBSOLETE	
Pushbutton	320U11RED	XB0155P		OBSOLETE	
Pushbutton	320U11BLU	XB0156P		OBSOLETE	
Pushbutton	320.22E11BLKWHT125	XB0413A		OBSOLETE	Actuator .22 EOL 2009
Pushbutton	320.22E11BLKWHT250	XB0414A		OBSOLETE	Actuator .22 EOL 2009
Pushbutton	320.22E11BLKWHT500	XB0415A		OBSOLETE	Actuator .22 EOL 2009
Pushbutton	320.22E11BLKWHT750	XB0416A		OBSOLETE	Actuator .22 EOL 2009
Pushbutton	320.22E11BLKWHT1000	XB0417A		OBSOLETE	Actuator .22 EOL 2009
Pushbutton	320.22E11BLKWHT1500	XB0418A		OBSOLETE	Actuator .22 EOL 2009
Pushbutton	320.22E11BLKWHT2000	XB0419A		OBSOLETE	Actuator .22 EOL 2009
Pushbutton	320.22E11BLKWHT3000	XB0420A		OBSOLETE	Actuator .22 EOL 2009
Pushbutton	320.22E11BLKWHT4000	XB0421A		OBSOLETE	Actuator .22 EOL 2009
Pushbutton	320.22E11BLKWHT6000	XB0422A		OBSOLETE	Actuator .22 EOL 2009
Pushbutton	320.22E11BLKWHT8000	XB0423A		OBSOLETE	Actuator .22 EOL 2009
Pushbutton	320.03E11TA2800RED	XB0556A		OBSOLETE	
Pushbutton	320.22LEIGHTRONIX	XB0570A		OBSOLETE	Actuator .22 EOL 2009
Pushbutton	320.094E11BLK	XB0586A		OBSOLETE	SEE XB0870A
Pushbutton	320.094E11BLK	XB0586P		OBSOLETE	SEE XB0870A
Pushbutton	320.01U11RED	XB0620A		OBSOLETE	
Pushbutton	320.01U11RED	XB0620P		OBSOLETE	
Pushbutton	320.21E11BLKPAUSE	XB0623A		OBSOLETE	WHITE PRINTING
Pushbutton	320.21E11BLKMENU	XB0624A		OBSOLETE	WHITE PRINTING
Pushbutton	320.21E11BLKSELECT	XB0625A		OBSOLETE	WHITE PRINTING
Pushbutton	320.21E11BLK+	XB0626A		OBSOLETE	WHITE PRINTING



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Pushbutton	320.21E11BLK-	XB0627A		OBSOLETE	WHITE PRINTING
Pushbutton	320.08U11BLK	XB0633A		OBSOLETE	
Pushbutton	320.08U11BLK	XB0633P		OBSOLETE	
Pushbutton	320.04E11WHTBULK	XB0657A		OBSOLETE	
Pushbutton	320.05E11BLKBULK	XB0659A		OBSOLETE	
Pushbutton	320E11BLK100%POWER	XB0679A		OBSOLETE	WHITE PRINTING
Pushbutton	320.21U11BLK	XB0691A		OBSOLETE	
Pushbutton	320.21U11BLK	XB0691P		OBSOLETE	
Pushbutton	320.2E11GRYYELLED	XB0692A		OBSOLETE	SEE XB0798A
Pushbutton	320.03U11BLK	XB0693A		OBSOLETE	
Pushbutton	320.22E11BLKENTER	XB0695A		OBSOLETE	Actuator .22 EOL 2009
Pushbutton	320.01U11BLK	XB0696A		OBSOLETE	
Pushbutton	320.01U11BLK	XB0696P		OBSOLETE	
Pushbutton	320.04U11BLK	XB0697A		OBSOLETE	
Pushbutton	320.21E11BLKARROW	XB0699A		OBSOLETE	LEFT**
Pushbutton	320.21E11BLKARROW	XB0700A		OBSOLETE	DOWN**
Pushbutton	320.21U11GRY	XB0703A		OBSOLETE	
Pushbutton	330.21U11GRY	XB0703P		OBSOLETE	
Pushbutton	320.03E11TADGRY	XB0711P		OBSOLETE	
Pushbutton	320U11GRY	XB0725A		OBSOLETE	
Pushbutton	320.03E11TAKBLK	XB0726A		OBSOLETE	
Pushbutton	320.03E11TADGRY	XB0727A		OBSOLETE	
Pushbutton	320.01U11ORG	XB0728A		OBSOLETE	
Pushbutton	320.01U11BLU	XB0729A		OBSOLETE	
Pushbutton	330.03U11.08BLK	XB0747A		OBSOLETE	
Pushbutton	320.01U11GRY	XB0753A		OBSOLETE	
Pushbutton	320.22E11BLU	XB0766A		OBSOLETE	Actuator .22 EOL 2009
Pushbutton	320.22E11BLU	XB0766P		OBSOLETE	Actuator .22 EOL 2009
Pushbutton	320.1E11WHT	XB0774P		OBSOLETE	
Pushbutton	320.22E11GRN	XB0776A		OBSOLETE	Actuator .22 EOL 2009
Pushbutton	320.22E11GRN	XB0776P		OBSOLETE	Actuator .22 EOL 2009
Pushbutton	320.21E11GRN	XB0778P		OBSOLETE	(SEE XB0823A)
Pushbutton	320.03E11TADRED	XB0788A		OBSOLETE	
Pushbutton	320.03E11TADRED	XB0788P		OBSOLETE	
Pushbutton	320.2U11WHT	XB0791P		OBSOLETE	
Pushbutton	320.04E12BLU	XB0810A		OBSOLETE	
Pushbutton	320.04U11YEL	XB0815A		OBSOLETE	
Pushbutton	320.03E11TA12GRY	XB0816A		OBSOLETE	
Pushbutton	320.02E11TALBLK	XB0818A		OBSOLETE	
Pushbutton	320.02E11MAKRAC01V	XB0819A		OBSOLETE	
Pushbutton	320.08U11GRN	XB0820A		OBSOLETE	
Pushbutton	320.08E11BLK	XB0822A		OBSOLETE	SEE XB0510A
Pushbutton	320E12YEL	XB0840A		OBSOLETE	
Pushbutton	320U11YEL	XB0841A		OBSOLETE	
Pushbutton	320.22U11RED	XB0843A		OBSOLETE	Actuator .22 EOL 2009
Pushbutton	320.02E11TAGWHT	XB0845A		OBSOLETE	
Pushbutton	320.02E11.08ORG	XB0864A		OBSOLETE	SEE XB0563B
Pushbutton	320.05E11BLK	XB0868A		OBSOLETE	MOUNT CAP HORIZONTAL
Pushbutton	320.02E11.09WHT	XB0871A		OBSOLETE	SEE XB0919A
Pushbutton	320.02U11GRY	XB0882A		OBSOLETE	
Pushbutton	320.2U11GRY	XB0882P		OBSOLETE	
Pushbutton	320.03E11TACWHT	XB0885A		OBSOLETE	
Pushbutton	320.03E11TAAGRY	XB0886A		OBSOLETE	
Pushbutton	320.03E11TABGRY	XB0887A		OBSOLETE	
Pushbutton	320.03E11YEL	XB0902A		OBSOLETE	
Pushbutton	320.03E11YEL	XB0902P		OBSOLETE	
Pushbutton	320.03E11BLU	XB0903A		OBSOLETE	
Pushbutton	320.03E11BLU	XB0903P		OBSOLETE	
Pushbutton	320.07E11320.11LEDHOLD	XB0904A		OBSOLETE	
Pushbutton	320.2E11WHTGRNLED	XB0908P		OBSOLETE	SEE XB0908A
Pushbutton	320.2E11WHTREDLED	XB0909P		OBSOLETE	SEE XB0909A
Pushbutton	320.03E11TABCHROME	XB0910A		OBSOLETE	SEE XB0910P
Pushbutton	320.03E11TABCHROME	XB0910P		OBSOLETE	
Pushbutton	320.02E11BLKTAGBLK	XB0916A		OBSOLETE	
Pushbutton	320.06E11BLK	XB0553A		OBSOLETE	
Pushbutton	320.06E11BLK	XB0553P		OBSOLETE	
Pushbutton	4XTA102UEEAAGPN	XA1972P		OBSOLETE	
Pushbutton	330.03U11.08RED	XA1983A		OBSOLETE	
Pushbutton	330.03U11.08RED	XA1983P		OBSOLETE	
Pushbutton	330.22E11BLK	XB0618A		OBSOLETE	
Pushbutton	330.03U11.08BLK	XB0747P		OBSOLETE	
Pushbutton	330.03U11.175RED	XB0806A		OBSOLETE	
Pushbutton	330.22E11WHT	XB0883A		OBSOLETE	
Pushbutton	4200A0MOMENTARY	L010500		OBSOLETE	SILVER**
Pushbutton	4200A0MOMOMENTSILENT	L010501		OBSOLETE	
Pushbutton	420FE0LATCHINGSILVER	L010550		OBSOLETE	
Pushbutton	4200A3MOMENTARYGOLD	L010600		OBSOLETE	
Pushbutton	4200A3MOMGOLDSILENT	L010601		OBSOLETE	
Pushbutton	420EE3LATCHINGGOLD	L010650		OBSOLETE	
Pushbutton	420B5REDBUTTON	L040004		OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Pushbutton	420B3YELBUTTON	L040005		OBSOLETE	
Pushbutton	420B7GRNBUTTON	L040006		OBSOLETE	
Pushbutton	420B6ORGBUTTON	L040008		OBSOLETE	
Pushbutton	420B4BLUBUTTON	L040009		OBSOLETE	
Pushbutton	420B9AMBBUTTON	L040010		OBSOLETE	
Pushbutton	420BBLKWHTARROW	L040130		OBSOLETE	RIGHT**
Pushbutton	420BBLKWHTARROWUP	L040131		OBSOLETE	
Pushbutton	420BBLKWHTENTER	L040150		OBSOLETE	
Pushbutton	420BBLKWHTPRINT	L040152		OBSOLETE	
Pushbutton	420BBLKWHTENTER	L040162		OBSOLETE	
Pushbutton	420BBLKWHTARROWUP	L040576		OBSOLETE	
Pushbutton	420BBLKWHT0	L041030		OBSOLETE	
Pushbutton	420BBLKWHT1	L041031		OBSOLETE	
Pushbutton	420BBLKWHT2	L041032		OBSOLETE	
Pushbutton	420BBLKWHT3	L041033		OBSOLETE	
Pushbutton	420BBLKWHT4	L041034		OBSOLETE	
Pushbutton	420BBLKWHT5	L041035		OBSOLETE	
Pushbutton	420BBLKWHT6	L041036		OBSOLETE	
Pushbutton	420BBLKWHT7	L041037		OBSOLETE	
Pushbutton	420BBLKWHT8	L041038		OBSOLETE	
Pushbutton	420BBLKWHT9	L041039		OBSOLETE	
Pushbutton	420BBLKWHTONOFF	L041050		OBSOLETE	
Pushbutton	420BBLKWHTCLEAR	L041054		OBSOLETE	
Pushbutton	420BBLKWHTMUTE	L041056		OBSOLETE	
Pushbutton	420BBLKWHTTEST	L041062		OBSOLETE	
Pushbutton	420BGRYBLKUNIT	L041226		OBSOLETE	
Pushbutton	420BGRYBLKMODE	L041227		OBSOLETE	
Pushbutton	420BREDWHTDHOLD	L041411		OBSOLETE	
Pushbutton	420BREDWHTCHOLD	L041412		OBSOLETE	
Pushbutton	420BBLUWHTDATE	L041577		OBSOLETE	
Pushbutton	420BBLUWHTCALB	L041600		OBSOLETE	
Pushbutton	420BORGWHTPDI	L042277		OBSOLETE	
Pushbutton	420B2GRYBLKONOFF	L042400		OBSOLETE	
Pushbutton	420B2GRYBLKCLOSE	L042401		OBSOLETE	
Pushbutton	420B2GRYBLKOPEN	L042402		OBSOLETE	
Pushbutton	420B2GRYBLKUPARROW	L042403		OBSOLETE	
Pushbutton	420B2GRYBLKUPDOWN	L042404		OBSOLETE	ARROW**
Pushbutton	420B2GRYBLKRIGHT	L042405		OBSOLETE	ARROW**
Pushbutton	420ETEXTENDER	L047001		OBSOLETE	
Pushbutton	420AREDWHTSELECT	L070559		OBSOLETE	
Pushbutton	420AREDWHTENTER	L070560		OBSOLETE	
Pushbutton	420AREDWHTARROWUP	L070561		OBSOLETE	
Pushbutton	420V5REDLED	L092204		OBSOLETE	
Pushbutton	420V5REDLEDSPECIAL	L092205		OBSOLETE	BEND**
Pushbutton	420V7GRNLED	L092206		OBSOLETE	
Pushbutton	420V7GRNLEDSPECIAL	L092207		OBSOLETE	BEND**
Pushbutton	420V3YELLED	L092210		OBSOLETE	
Pushbutton	420SS1	L101001		OBSOLETE	
Pushbutton	420SS8	L101002		OBSOLETE	
Pushbutton	420SS2GRYCOVER	L101003		OBSOLETE	
Pushbutton	420SSRED	L101004		OBSOLETE	
Pushbutton	420SS4	L101009		OBSOLETE	
Pushbutton	420ES1	L102401		OBSOLETE	
Pushbutton	420ES2	L102403		OBSOLETE	
Pushbutton	420E11	L102501		OBSOLETE	BLACK COVER
Pushbutton	420E18	L102502		OBSOLETE	WHITE COVER
Pushbutton	420E12	L102503		OBSOLETE	GREY COVER
Pushbutton	420E14	L102504		OBSOLETE	BLU COVER
Pushbutton	420E15	L102505		OBSOLETE	RED COVER
Pushbutton	420E16	L102506		OBSOLETE	ORG COVER
Pushbutton	420E17	L102507		OBSOLETE	GRN COVER
Pushbutton	420E21	L102601		OBSOLETE	BLACK COVER
Pushbutton	420E28	L102602		OBSOLETE	WHT COVER
Pushbutton	420E23	L102603		OBSOLETE	YEL COVER
Pushbutton	420E24	L102604		OBSOLETE	BLUE COVER
Pushbutton	420E25	L102605		OBSOLETE	RED COVER
Pushbutton	420E26	L102606		OBSOLETE	ORANGE COVER
Pushbutton	420E27	L102607		OBSOLETE	GREEN COVER
Pushbutton	420E22	L102608		OBSOLETE	GREY COVER
Pushbutton	420E29	L102609		OBSOLETE	AMBER
Pushbutton	420L5REDLENS	L112704		OBSOLETE	
Pushbutton	420L7GRNLENS	L112706		OBSOLETE	
Pushbutton	420L3YELLENS	L112710		OBSOLETE	
Pushbutton	420ABLKSQBUTTON	L113001		OBSOLETE	
Pushbutton	420AGRYSQBUTTON	L113003		OBSOLETE	
Pushbutton	420AREDSQBUTTON	L113004		OBSOLETE	
Pushbutton	420AORGSQLBUTTON	L113005		OBSOLETE	
Pushbutton	420AGRNSQBUTTON	L113006		OBSOLETE	
Pushbutton	420AAMBSQBUTTON	L113007		OBSOLETE	
Pushbutton	420AYELSQLBUTTON	L113008		OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Pushbutton	420ABLUSQBUTTON	L113009		OBSOLETE	
Pushbutton	420OAOBBLKSSBLK	XL0022A		OBSOLETE	DO NOT ORDER SEE XL0022P
Pushbutton	420OAOBBLKSSBLK	XL0022P		OBSOLETE	
Pushbutton	420OAOBBLKSSGRY	XL0024A		OBSOLETE	MOMENTARY**(SEE XL0024P)
Pushbutton	420OAOBBLKSSGRY	XL0024P		OBSOLETE	MOMENTARY**
Pushbutton	420OAOBREDSSGRY	XL0025A		OBSOLETE	DO NOT ORDER SEE XL0025P
Pushbutton	420OAOBREDSSGRY	XL0025P		OBSOLETE	
Pushbutton	420OAOAWHT	XL0043P		OBSOLETE	
Pushbutton	420EEOB1SS1	XL0089A		OBSOLETE	DO NOT ORDER SEE XL0089P
Pushbutton	420EEOB1SS1	XL0089P		OBSOLETE	
Pushbutton	420OA3B1ES1	XL0091A		OBSOLETE	DO NOT ORDER SEE XL0091P
Pushbutton	420OA3B1ES1	XL0091P		OBSOLETE	
Pushbutton	420OAOB1SS1SILENT	XL0095A		OBSOLETE	DO NOT ORDER SEE XL0095P
Pushbutton	420OAOB1SS1SILENT	XL0095P		OBSOLETE	
Pushbutton	420OAOBBLKE1BLKVTRED	XL0096A		OBSOLETE	DO NOT ORDER SEE XL0096P
Pushbutton	420OAOBBLKE1BLKVTRED	XL0096P		OBSOLETE	
Pushbutton	420OAOBBLKE1BLKVTGRN	XL0097A		OBSOLETE	DO NOT ORDER SEE XL0097P
Pushbutton	420OAOBBLKE1BLKVT	XL0097P		OBSOLETE	GRN**
Pushbutton	420OAOB18TESTSS4	XL0103A		OBSOLETE	DO NOT ORDER SEE XL0103P
Pushbutton	420OAOB18TESTSS4	XL0103P		OBSOLETE	
Pushbutton	420EEOB18MUTESS4	XL0104A		OBSOLETE	DO NOT ORDER SEE XL0104P
Pushbutton	420EEOB18MUTESS4	XL0104P		OBSOLETE	
Pushbutton	420OAOBBLUSSWHT	XL0109A		OBSOLETE	DO NOT ORDER SEE XL0109P
Pushbutton	420OAOBBLUSSWHT	XL0109P		OBSOLETE	
Pushbutton	420OAOBWHITE2BLKVT	XL0119A		OBSOLETE	GRNVBRE**D
Pushbutton	420OAOBWHITE2BLKVT	XL0119P		OBSOLETE	GRNVBRE**D
Pushbutton	420OA3B5E11VT5	XL0123P		OBSOLETE	
Pushbutton	420OA3B4E11VT3	XL0124A		OBSOLETE	DO NOT ORDER SEE XLO124P
Pushbutton	420OA3B4E11VT3	XL0124P		OBSOLETE	
Pushbutton	420OA3B4E51	XL0125P		OBSOLETE	
Pushbutton	420EEOB1E11VT5	XL0129A		OBSOLETE	DO NOT ORDER SEE XL0129P
Pushbutton	420EEOB1E11VT5	XL0129P		OBSOLETE	
Pushbutton	420OAOB8E11VT7	XL0141A		OBSOLETE	DO NOT ORDER SEE XL0141P
Pushbutton	420OAOB8E11VT7	XL0141P		OBSOLETE	
Pushbutton	420OAOA5	XL0144A		OBSOLETE	(SEE XL0144P)
Pushbutton	420OAOA5	XL0144P		OBSOLETE	
Pushbutton	420OAOBREDSSBLK	XL0146A		OBSOLETE	DO NOT ORDER SEE XL0146P
Pushbutton	420OAOBREDSSBLK	XL0146P		OBSOLETE	
Pushbutton	420OA3B1SS1	XL0148A		OBSOLETE	DO NOT ORDER SEE XL0148P
Pushbutton	420OA3B1SS1	XL0148P		OBSOLETE	
Pushbutton	420OAOBBLUSSWHT	XL0149P		OBSOLETE	
Pushbutton	420OA3BWHITSSBLK	XL0150A		OBSOLETE	DO NOT ORDER SEE XL0150P
Pushbutton	420OA3BWHITSSBLK	XL0150P		OBSOLETE	
Pushbutton	420EEOAGRY	XL0151A		OBSOLETE	DO NOT ORDER SEE XL0151P
Pushbutton	420EEOAGRY	XL0151P		OBSOLETE	
Pushbutton	420OAA2	XL0152A		OBSOLETE	DO NOT ORDER SEE XL0152P
Pushbutton	420OAA2	XL0152P		OBSOLETE	
Pushbutton	420OA3BWHITSSBLK	XL0153A		OBSOLETE	DO NOT ORDER SEE XL0153P
Pushbutton	420OA3BWHITSSBLK	XL0153P		OBSOLETE	
Pushbutton	420OA3BYELE2BLKVT	XL0154A		OBSOLETE	GRNVBRE** D
Pushbutton	420OA3BYELE2BLKVT	XL0154P		OBSOLETE	GRNVBRE** D
Pushbutton	420OA3B5E18VT5	XL0155A		OBSOLETE	DO NOT ORDER SEE XL0155P
Pushbutton	420OA3B5E18VT5	XL0155P		OBSOLETE	
Pushbutton	420OA3B7E18VT7	XL0156A		OBSOLETE	DO NOT ORDER SEE XL0156P
Pushbutton	420OA3B7E18VT7	XL0156P		OBSOLETE	
Pushbutton	420OAOA5WHTARROWUP	XL0158A		OBSOLETE	DO NOT ORDER SEE XL0158P
Pushbutton	420OAOA5WHTARROWUP	XL0158P		OBSOLETE	
Pushbutton	420OAOBREDESBLK	XL0160A		OBSOLETE	DO NOT ORDER SEE XL0160P
Pushbutton	420OAOBREDESBLK	XL0160P		OBSOLETE	
Pushbutton	420EEOB1ES1	XL0163A		OBSOLETE	DO NOT ORDER SEE XL0163P
Pushbutton	420EEOB1ES1	XL0163P		OBSOLETE	
Pushbutton	420EEOBBLKE1BLKVT	XL0164P		OBSOLETE	
Pushbutton	420OAOBGRNSSBLK	XL0165A		OBSOLETE	DO NOT ORDER SEE XL0165P
Pushbutton	420OAOBGRNSSBLK	XL0165P		OBSOLETE	
Pushbutton	420OA3ABLK	XL0166A		OBSOLETE	DO NOT ORDER SEE XL0166P
Pushbutton	420OA3ABLK	XL0166P		OBSOLETE	
Pushbutton	420OAOABLK	XL0167A		OBSOLETE	DO NOT ORDER SEE XL0167P
Pushbutton	420OAOABLK	XL0167P		OBSOLETE	
Pushbutton	420EEOABLK	XL0168A		OBSOLETE	DO NOT ORDER SEE XL0168P
Pushbutton	420EEOABLK	XL0168P		OBSOLETE	
Pushbutton	420OAOBBLKE2BLKVTGRN-	XL0169A		OBSOLETE	DO NOT ORDER SEE XL0169P
Pushbutton	420OAOBBLKE2BLKVT	XL0169P		OBSOLETE	GRNVBRE** D
Pushbutton	420OA3BGRY	XL0174A		OBSOLETE	DO NOT ORDER SEE XL0174P
Pushbutton	420OA3BGRY	XL0174P		OBSOLETE	
Pushbutton	420OA3B5E21VT5VB7	XL0175A		OBSOLETE	DO NOT ORDER SEE XL0175P
Pushbutton	420OA3B5E21VT5VB7	XL0175P		OBSOLETE	
Pushbutton	420OA3AWHT	XL0176A		OBSOLETE	DO NOT ORDER SEE XL0176P
Pushbutton	420OA3AWHT	XL0176P		OBSOLETE	
Pushbutton	420OAOB1E12VT7	XL0177A		OBSOLETE	DO NOT ORDER SEE XL0177P
Pushbutton	420OAOB1E12VT7	XL0177P		OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Pushbutton	420EEOABLK	XL0178A		OBSOLETE	DO NOT ORDER SEE XL0178P
Pushbutton	420EEOABLK	XL0178P		OBSOLETE	
Pushbutton	420OAOABLKSILENT	XL0179A		OBSOLETE	DO NOT ORDER SEE XL0179P
Pushbutton	420OAOABLKSILENT	XL0179P		OBSOLETE	
Pushbutton	420OA3BREDSSBLK	XL0180A		OBSOLETE	DO NOT ORDER SEE XL0180P
Pushbutton	420OA3BREDSSBLK	XL0180P		OBSOLETE	
Pushbutton	420OAOBBLUSSWHT	XL0181A		OBSOLETE	DO NOT ORDER SEE XL0181P
Pushbutton	420OAOBBLUSSWHT	XL0181P		OBSOLETE	
Pushbutton	420OA3B1E12VT7	XL0182A		OBSOLETE	DO NOT ORDER SEE XL0182P
Pushbutton	420OA3B1E12VT7	XL0182P		OBSOLETE	
Pushbutton	420EEOBBLKE1ORGVTYEL	XL0183A		OBSOLETE	SEE XL0183P
Pushbutton	420EEOBBLKE1ORGVTYEL	XL0183P		OBSOLETE	
Pushbutton	420OA3BREDSSBLK	XL0184A		OBSOLETE	DO NOT ORDER SEE XL0184P
Pushbutton	420OA3BREDSSBLK	XL0184P		OBSOLETE	VERTICLE
Pushbutton	420OAOBBLUSSGRY	XL0185A		OBSOLETE	DO NOT ORDER SEE XL0185P
Pushbutton	420OAOBBLUSSGRY	XL0185P		OBSOLETE	(420B4SS2)
Pushbutton	420EEOBBLUSSGRY	XL0186A		OBSOLETE	DO NOT ORDER SEE XL0186P
Pushbutton	420EEOBBLUSSGRY	XL0186P		OBSOLETE	
Pushbutton	420OA3ARED	XL0187P		OBSOLETE	HORIZONTAL
Pushbutton	420OA3AGRND	XL0188P		OBSOLETE	HORIZONTAL
Pushbutton	420OA3ARED	XL0189P		OBSOLETE	VERTICAL
Pushbutton	420OA3AGRND	XL0190P		OBSOLETE	VERTICAL
Pushbutton	420OAOBGRYE2BLKVT	XL0191A		OBSOLETE	YELVBRED (XL0191P)
Pushbutton	420OAOBGRYE2BLKVT	XL0191P		OBSOLETE	YELVBRE** D
Pushbutton	420OAOBYELE2BLKVTGRN	XL0192A		OBSOLETE	VBRED
Pushbutton	420OAOBYELE2BLKVT	XL0192P		OBSOLETE	GRNVBRE** D
Pushbutton	420OAOBBLKE1BLKVTYEL	XL0193A		OBSOLETE	DO NOT ORDER SEE XL0193P
Pushbutton	420OAOBBLKE1BLKVTYEL	XL0193P		OBSOLETE	
Pushbutton	420EEOBWHITE1GRVYTRED	XL0194P		OBSOLETE	
Pushbutton	420EEOBBLUE2BLKVTGRNV	XL0195P		OBSOLETE	BYE
Pushbutton	420OAOWHITE1BLKVTY	XL0196A		OBSOLETE	DO NOT ORDER SEE XL0196P
Pushbutton	420OAOWHITE1BLKVTY	XL0196P		OBSOLETE	
Pushbutton	420OA3BBLKE2BLKVTYEL	XL0197A		OBSOLETE	VBGRN (SEE XL0197P)
Pushbutton	420OA3BBLKE2BLKVTYEL	XL0197P		OBSOLETE	VBGRN
Pushbutton	420OA3BBLKE1BLKVTRED	XL0198A		OBSOLETE	SEE (XL0198P)
Pushbutton	420OA3BBLKE1BLKVTRED	XL0198P		OBSOLETE	
Pushbutton	420EEOBWHITE2BLKVTYELVB	XL0199A		OBSOLETE	RE (SEE XL0199P)
Pushbutton	420EEOBWHITE2BLKVTYELV	XL0199P		OBSOLETE	BRE
Pushbutton	420OAOBWHITE2BLKVTYELVB	XL0200A		OBSOLETE	RE (SEE XL0200P)
Pushbutton	420OAOBWHITE2BLKVT	XL0200P		OBSOLETE	YELVBRE**
Pushbutton	420OAOBGRYSSBLK	XL0201A		OBSOLETE	
Pushbutton	420OAOBGRYSSBLK	XL0201P		OBSOLETE	
Pushbutton	420EEOBGRYE1BLKVTGRN	XL0202A		OBSOLETE	
Pushbutton	420EEOBGRYE1BLKVTGRN	XL0202P		OBSOLETE	
Pushbutton	420EEOBREDE2BLKVTREDV	XL0203A		OBSOLETE	BGRN
Pushbutton	420EEOBREDE2BLKVTREDV	XL0203P		OBSOLETE	BGRN
Pushbutton	420OA3BWHITE1BLKVTGRN	XL0204A		OBSOLETE	(SEE XL0204P)
Pushbutton	420OA3BWHITE1BLKVT	XL0204P		OBSOLETE	GRN**
Pushbutton	420EE3BWHITE2BLKVTGRNVB	XL0205A		OBSOLETE	YEL
Pushbutton	420EE3BWHITE2BLKVTGRNVE	XL0205P		OBSOLETE	BYEL
Pushbutton	420OA3BWHITESBLK	XL0206A		OBSOLETE	
Pushbutton	420OA3BWHITESBLK	XL0206P		OBSOLETE	
Pushbutton	420OAOBBLKE1BLKVTYEL	XL0207A		OBSOLETE	(SEE XL0207P)
Pushbutton	420OAOBBLKE1GRNVTYEL	XL0208A		OBSOLETE	(SEE XL0208P)
Pushbutton	420OAOBBLKE1GRNVTYEL	XL0208P		OBSOLETE	
Pushbutton	420OAOBBLKE1GRVVTYEL	XL0209A		OBSOLETE	(SEE XL0209P)
Pushbutton	420OAOBBLKE1GRVVTYEL	XL0209P		OBSOLETE	
Pushbutton	420OAOBBLUSSRED	XL0210A		OBSOLETE	(SEE XL0210P)
Pushbutton	420OAOBBLUSSRED	XL0210P		OBSOLETE	
Pushbutton	420OA3BYELE1BLKVTYEL	XL0211A		OBSOLETE	(SEE XL0211P)
Pushbutton	420OA3BYELE1BLKVTYEL	XL0211P		OBSOLETE	
Pushbutton	420OA3BREDESBLK	XL0212A		OBSOLETE	(SEE XL0212P)
Pushbutton	420OA3BREDESBLK	XL0212P		OBSOLETE	
Pushbutton	420OA3BBLUE2BLKVTYEL	XL0213A		OBSOLETE	VBGRN (SEE XL0213P)
Pushbutton	420OA3BBLUE2BLKVTYEL	XL0213P		OBSOLETE	VBGRN
Pushbutton	420OAOAGRND	XL0214A		OBSOLETE	(SEE XL0214P)
Pushbutton	420OAOAGRND	XL0214P		OBSOLETE	
Pushbutton	420OA3BBLUSSGRY	XL0215A		OBSOLETE	(SEE XL0215P)
Pushbutton	420OA3BBLUSSGRY	XL0215P		OBSOLETE	
Pushbutton	420OA3BREDSSGRY	XL0216A		OBSOLETE	(SEE XL0216P)
Pushbutton	420OA3BREDSSGRY	XL0216P		OBSOLETE	
Pushbutton	520.03.08GRYBLK0	A799000		OBSOLETE	
Pushbutton	520.03.08GRYBLK1	A799001		OBSOLETE	
Pushbutton	520.03.08GRYBLK2	A799002		OBSOLETE	
Pushbutton	520.03.08GRYBLK3	A799003		OBSOLETE	
Pushbutton	520.03.08GRYBLK4	A799004		OBSOLETE	
Pushbutton	520.03.08GRYBLK5	A799005		OBSOLETE	
Pushbutton	520.03.08GRYBLK6	A799006		OBSOLETE	
Pushbutton	520.03.08GRYBLK7	A799007		OBSOLETE	
Pushbutton	520.03.08GRYBLK8	A799008		OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Pushbutton	520.03.08GRYBLK9	A799009		OBSOLETE	
Pushbutton	520.03.08GRYBLKFCFN	A799010		OBSOLETE	
Pushbutton	520.03.08GRYBLKPAGE	A799011		OBSOLETE	
Pushbutton	520.03.08GRYBLKNEXT	A799012		OBSOLETE	
Pushbutton	520.03.08GRYBLKPREV	A799013		OBSOLETE	
Pushbutton	520.03.08GRYBLKRMT	A799014		OBSOLETE	
Pushbutton	520.03.08GRYBLKENTR	A799015		OBSOLETE	
Pushbutton	520.03.08GRYBLKARROW	A799016		OBSOLETE	
Pushbutton	520.03.08GRYBLKMENU	A799018		OBSOLETE	
Pushbutton	520.03BLK	A800050		OBSOLETE	CAP ONLY
Pushbutton	520.03YEL	A800051		OBSOLETE	CAP ONLY
Pushbutton	520.03WHT	A800052		OBSOLETE	CAP ONLY
Pushbutton	520.03BLU	A800053		OBSOLETE	CAP ONLY
Pushbutton	520.03RED	A800054		OBSOLETE	CAP ONLY
Pushbutton	520.03GRN	A800055		OBSOLETE	CAP ONLY
Pushbutton	520.03LGR	A800056		OBSOLETE	CAP ONLY
Pushbutton	520.03DGR	A800057		OBSOLETE	CAP ONLY
Pushbutton	520.03BLKESC	A800058		OBSOLETE	
Pushbutton	520.03BLKENTER	A800059		OBSOLETE	
Pushbutton	520.03BLKARROWDOWN	A800060		OBSOLETE	
Pushbutton	520.01BLK	A800100		OBSOLETE	
Pushbutton	520.01YEL	A800101		OBSOLETE	
Pushbutton	520.01WHT	A800102		OBSOLETE	
Pushbutton	520.01BLU	A800103		OBSOLETE	
Pushbutton	520.01RED	A800104		OBSOLETE	
Pushbutton	520.01GRN	A800105		OBSOLETE	
Pushbutton	520.01LGR	A800106		OBSOLETE	
Pushbutton	520.01DGR	A800107		OBSOLETE	
Pushbutton	520.01.01SPCGF	A800109		OBSOLETE	
Pushbutton	520.02BLK	A800120		OBSOLETE	
Pushbutton	520.02YEL	A800121		OBSOLETE	
Pushbutton	520.02WHT	A800122		OBSOLETE	
Pushbutton	520.02BLU	A800123		OBSOLETE	
Pushbutton	520.02RED	A800124		OBSOLETE	
Pushbutton	520.02GRN	A800125		OBSOLETE	
Pushbutton	520.02LGR	A800126		OBSOLETE	
Pushbutton	520.02DGR	A800127		OBSOLETE	
Pushbutton	520.04LGR	A800130		OBSOLETE	
Pushbutton	520.04BLK	A800131		OBSOLETE	
Pushbutton	520.04DGR	A800132		OBSOLETE	
Pushbutton	520.05LGR	A800140		OBSOLETE	
Pushbutton	520.05BLK	A800141		OBSOLETE	
Pushbutton	520.03BLKWHTSCAN	A800162		OBSOLETE	
Pushbutton	520.03BLKWHTCLEAR	A800163		OBSOLETE	
Pushbutton	520.03BLKWHTINFO	A800164		OBSOLETE	
Pushbutton	520.03BLKWHTPREF	A800165		OBSOLETE	
Pushbutton	520.03BLKWHTSPEC	A800166		OBSOLETE	
Pushbutton	520.03BLKWHTTRIP	A800167		OBSOLETE	
Pushbutton	520.03BLKWHTBRIGHT	A800168		OBSOLETE	
Pushbutton	520.03BLKWHTPROG	A800169		OBSOLETE	
Pushbutton	520.03BLKWHTDRIVE	A800170		OBSOLETE	
Pushbutton	520.03BLKWHTDIAG	A800171		OBSOLETE	
Pushbutton	520.03BLKARROWDOWN	A800173		OBSOLETE	
Pushbutton	520.03BLKESC	A800174		OBSOLETE	
Pushbutton	520.03BLKENTER	A800175		OBSOLETE	
Pushbutton	520.03BLKVIDEO	A800176		OBSOLETE	
Pushbutton	520.03BLKWHTCOACH	A800177		OBSOLETE	
Pushbutton	520.03BLK	XA0814A		OBSOLETE	(SEE XA0814P)
Pushbutton	520.03BLK	XA0814P		OBSOLETE	
Pushbutton	520.03WHT	XA1153A		OBSOLETE	(SEE XA1153P)
Pushbutton	520.03WHT	XA1153P		OBSOLETE	
Pushbutton	520.03LGR	XA1154A		OBSOLETE	(SEE XA1154P)
Pushbutton	520.03LGR	XA1154P		OBSOLETE	
Pushbutton	520.03DGR	XA1186A		OBSOLETE	(SEE XA1186P)
Pushbutton	520.03DGR	XA1186P		OBSOLETE	
Pushbutton	520.03BLU	XA1191A		OBSOLETE	(SEE XA1191P)
Pushbutton	520.03BLU	XA1191P		OBSOLETE	
Pushbutton	520.03YEL	XA1360A		OBSOLETE	(SEE XA1360P)
Pushbutton	520.03YEL	XA1360P		OBSOLETE	
Pushbutton	520.03RED	XA1361A		OBSOLETE	(SEE XA1361P)
Pushbutton	520.03RED	XA1361P		OBSOLETE	
Pushbutton	520.03GRN	XA1362A		OBSOLETE	(SEE XA1362P)
Pushbutton	520.03GRN	XA1362P		OBSOLETE	
Pushbutton	520.04.01TABBLK	XA1388A		OBSOLETE	(SEE XA1388P)
Pushbutton	520.04.01TABBLK	XA1388P		OBSOLETE	
Pushbutton	520.01.0803LGRBLK0	XA1394A		OBSOLETE	
Pushbutton	520.01.0803LGRBLK1	XA1395A		OBSOLETE	
Pushbutton	520.01.0803LGRBLK2	XA1396A		OBSOLETE	
Pushbutton	520.01.0803LGRBLK3	XA1397A		OBSOLETE	
Pushbutton	520.01.0803LGRBLK4	XA1398A		OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Pushbutton	520.01.0803LGRBLK5	XA1399A		OBSOLETE	
Pushbutton	520.01.0803LGRBLK6	XA1400A		OBSOLETE	
Pushbutton	520.01.0803LGRBLK7	XA1401A		OBSOLETE	
Pushbutton	520.01.0803LGRBLK8	XA1402A		OBSOLETE	
Pushbutton	520.01.0803LGRBLK9	XA1403A		OBSOLETE	
Pushbutton	520.01.0803LGRFCTN	XA1404A		OBSOLETE	BLACK PRINTING
Pushbutton	520.01.0803LGRPAGE	XA1405A		OBSOLETE	BLACK PRINTING
Pushbutton	520.01.0803LGRNEXT	XA1406A		OBSOLETE	BLACK PRINTING
Pushbutton	520.01.0803LGRPREV	XA1407A		OBSOLETE	BLACK PRINTING
Pushbutton	520.01.0803LGRMT	XA1408A		OBSOLETE	BLACK PRINTING
Pushbutton	520.01.0803LGRENT	XA1409A		OBSOLETE	BLACK PRINTING
Pushbutton	520.01.0803LGRARROW	XA1410A		OBSOLETE	DWN/LEFT - BLACK PRINT
Pushbutton	520.04.01TAMBLK	XA1532A		OBSOLETE	(SEE XA1532P)
Pushbutton	520.04.01TAMBLK	XA1532P		OBSOLETE	
Pushbutton	520.04.01TADBLK	XA1631A		OBSOLETE	(SEE XA1631P)
Pushbutton	520.04.01TADBLK	XA1631P		OBSOLETE	
Pushbutton	520.04.01.09BLK	XA1738A		OBSOLETE	
Pushbutton	520.04.01.09BLK	XA1738P		OBSOLETE	
Pushbutton	520.04BLK.094BLK	XA1853A		OBSOLETE	
Pushbutton	520.04BLK.094BLK	XA1853P		OBSOLETE	
Pushbutton	520.01.05.08RED	XA1854P		OBSOLETE	
Pushbutton	520.04.01.08RED	XA1865P		OBSOLETE	
Pushbutton	520.04BLKTABBLK	XA1877A		OBSOLETE	SEE XA1877P
Pushbutton	520.04BLKTABBLK	XA1877P		OBSOLETE	
Pushbutton	520.01.0803LGRMENU	XA1883A		OBSOLETE	BLACK PRINTING
Pushbutton	520.03BLKARROWDOWN	XA1938A		OBSOLETE	
Pushbutton	520.03BLKESC	XA1939A		OBSOLETE	
Pushbutton	520.03BLKENTER	XA1940A		OBSOLETE	
Pushbutton	520.01BLK03RED	XA1963A		OBSOLETE	(SEE XA1963P)
Pushbutton	520.01BLK03RED	XA1963P		OBSOLETE	
Pushbutton	520.01BLK03BLU	XA1964A		OBSOLETE	(SEE XA1964P)
Pushbutton	520.01BLK03BLU	XA1964P		OBSOLETE	
Pushbutton	520.01BLK03YEL	XA1965A		OBSOLETE	(SEE XA1965P)
Pushbutton	520.01BLK03YEL	XA1965P		OBSOLETE	
Pushbutton	520.04BLKTAGBLK	XA2023A		OBSOLETE	(SEE XA2023P)
Pushbutton	520.04BLKTAGBLK	XA2023P		OBSOLETE	
Pushbutton	520.04BLKTAGCHR	XA2024A		OBSOLETE	(SEE XA2024P)
Pushbutton	520.04BLKTAGCHR	XA2024P		OBSOLETE	
Pushbutton	520.04.01TADGRAY	XA2029A		OBSOLETE	(SEE XA2029P)
Pushbutton	520.04.01TADGRAY	XA2029P		OBSOLETE	
Pushbutton	520.04BLKTA12GRY	XA2046A		OBSOLETE	
Pushbutton	520.04BLKTA12GRY	XA2046P		OBSOLETE	
Pushbutton	5500REDLEDWITHBEND	R010200		OBSOLETE	
Pushbutton	5500GREENLEDWITHBEND	R010201		OBSOLETE	
Pushbutton	5500YELLOWLEDWITHBEND	R010202		OBSOLETE	
Pushbutton	5500CBSIGRNLEDNOBEND	R010212		OBSOLETE	
Pushbutton	5500CBSIREDLEDNOBEND	R010213		OBSOLETE	
Pushbutton	5511M2X0	XR0109P		OBSOLETE	SEE XR0109B
Pushbutton	5511M8X	XR0169P		OBSOLETE	SEE XR0250P
Pushbutton	6201C1X	C103000		OBSOLETE	
Pushbutton	700SP7M1QEAP2	T711011		OBSOLETE	SEE T711030
Pushbutton	700SP7M1QEAP2BLK	T711030		OBSOLETE	
Pushbutton	700DP7B20VS2QEC3BLK	XT0082A		OBSOLETE	MADE OBSOLETE PCR 15858
Pushbutton	700DP7B20VS2QEC3BLK	XT0082P		OBSOLETE	MADE OBSOLETE PCR 15858
Pushbutton	700SP7B20M6QEC3BLK	XT0083A		OBSOLETE	MADE OBSOLETE PCR 15858
Pushbutton	700SP7B20M6QEC3BLK	XT0083P		OBSOLETE	MADE OBSOLETE PCR 15858
Pushbutton	700SP7B10M6QEC3BL	XT0103A		OBSOLETE	MADE OBSOLETE PCR 15858
Pushbutton	700SP7B10M6QEC3BL	XT0103P		OBSOLETE	MADE OBSOLETE PCR 15858
Pushbutton	720AF200REDQ	R012000		OBSOLETE	
Pushbutton	720AF200YELQ	R012001		OBSOLETE	
Pushbutton	720AF200GRNQ	R012002		OBSOLETE	
Pushbutton	721AF200GRNQ	R012003		OBSOLETE	
Pushbutton	800SP9B5M6REH	ST804000		OBSOLETE	(SEE ST811011)
Pushbutton	800SP9B5M6RE	T804000		OBSOLETE	(SEE T811011)
Pushbutton	800SP9B7M7RE	T811057		OBSOLETE	SEE T811002
Pushbutton	800SP8B6M2RE	T822029		OBSOLETE	
Pushbutton	800AWSP8M61KRESPEC	T834003		OBSOLETE	TERM** **PART CANNOT BE
Pushbutton	800BWSPP9SM6REFLUSH	T833018		OBSOLETE	FLUSH ACTUATOR
Pushbutton	800BWSPP9SM6RE0.110INCH	T833019		OBSOLETE	0.110 INCH ACTUATOR
Pushbutton	800SP8M1QEOP1BLKBLK	T822005	2015	OBSOLETE	
Pushbutton	800SP8M1REOP1BLKBLK	T822040	2015	OBSOLETE	
Pushbutton	800SP9M1QEOP1BLK	T811028	2015	OBSOLETE	
Pushbutton	800SP9M1REOP1BLK	T811039	2015	OBSOLETE	
Pushbutton	800SP9M1REOP1RED	T811043	2015	OBSOLETE	
Pushbutton	901AGQF180	D310960		OBSOLETE	SEE P010961 NEW DESIGN
Pushbutton	52810070194V0	P020308		OBSOLETE	
Pushbutton	D16OAT12CYEL	XF0300P		OBSOLETE	(SEE XF0266P)
Pushbutton	D16OAR10GRN	XF0334P		OBSOLETE	
Pushbutton	D16OAR20GRN	XF0390P		OBSOLETE	SEE - XF0301P
Pushbutton	D16OAS110ORG	XF0722A		OBSOLETE	SEE - XF0722P



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Pushbutton	D16OAS110WHT	XF0723A		OBSOLETE	SEE - XF0723P
Pushbutton	D16OAT12CWHT	XF0733A		OBSOLETE	SEE - XF0733P
Pushbutton	D16OAS12CWHT	XF0734A		OBSOLETE	SEE - XF0734P
Pushbutton	D16EET11KGRNWHT	XF0735A		OBSOLETE	SEE - XF0735P
Pushbutton	D16EER110RED	XF0857A		OBSOLETE	CONCAVELENS-SEE XF0857P
Pushbutton	D16EES12KREDRED-WA6WIRES	XF0916P	2020	OBSOLETE	Not on Website
Pushbutton	FC001A62BCNAG	P040278		OBSOLETE	
Pushbutton	FC12B	P050000		OBSOLETE	
Pushbutton	FC001A22BANAGNOKNOB	P050004		OBSOLETE	
Pushbutton	FC001A23BANAGNOKNOB	P052303		OBSOLETE	
Pushbutton	FC001A43OBNAG	P054300		OBSOLETE	
Pushbutton	FC001A22BANAG	P152205		OBSOLETE	
Pushbutton	GS6.90F130QP	L300001		OBSOLETE	
Pushbutton	GSR6.84F130QP	L300002	2017	OBSOLETE	
Pushbutton	GSR6.34F300QP	L300003		OBSOLETE	
Pushbutton	GSR6.34F160QP	L300004		OBSOLETE	
Pushbutton	GS5.20F300QG	L300005		OBSOLETE	
Pushbutton	GS4.70F130QG	L300008		OBSOLETE	
Pushbutton	GS4.70F160QG	L300009		OBSOLETE	
Pushbutton	GS5.20F200QG	L300010		OBSOLETE	
Pushbutton	GS6.90F500QP	L300014		OBSOLETE	
Pushbutton	GS6.90F160QG	L300015		OBSOLETE	
Pushbutton	GS6.90F300QG	L300016		OBSOLETE	
Pushbutton	GSR6.34F300RP	L300023		OBSOLETE	(GOLD CONTACTS)
Pushbutton	GS4.70F130RG	L300028		OBSOLETE	(GULL WING)
Pushbutton	GS4.70F160RG	L300029		OBSOLETE	(GULL WING)
Pushbutton	GS4.70F300RG	L300030		OBSOLETE	(GULL WING)
Pushbutton	GS5.20F130RG	L300031		OBSOLETE	(GULL WING)
Pushbutton	GS5.20F160RG	L300032		OBSOLETE	(GULL WING)
Pushbutton	GS5.20F300RG	L300033		OBSOLETE	(GULL WING)
Pushbutton	GSR6.84F300QP	L300043		OBSOLETE	
Pushbutton	GSR6.84F300RP	L300044		OBSOLETE	
Pushbutton	GSE10.00F130QP	L400001		OBSOLETE	
Pushbutton	GS4.70F160QP	L400002		OBSOLETE	
Pushbutton	GSE4.70F300QP	L400004		OBSOLETE	
Pushbutton	GS4.70F300QG	L400010		OBSOLETE	
Pushbutton	GS4.70F130RP	L400022		OBSOLETE	(GOLD CONTACTS)
Pushbutton	GS4.70F160RP	L400023		OBSOLETE	
Pushbutton	GSE4.70F130RG	L400028		OBSOLETE	
Pushbutton	GS4.70F300RP	L400029		OBSOLETE	
Pushbutton	GSE6.90F300RP	L400046		OBSOLETE	
Pushbutton	GSE4.70F160QP	L400099		OBSOLETE	
Pushbutton	GSE4.70F130QP	L400100		OBSOLETE	
Pushbutton	GS4.70F500QP	L400102		OBSOLETE	
Pushbutton	GSR8.54F130QP	L600000		OBSOLETE	
Pushbutton	GS10.00F130RG	L600008		OBSOLETE	
Pushbutton	GSR11.54F130QP	L600010		OBSOLETE	
Pushbutton	GSR11.54F160QP	L600011		OBSOLETE	
Pushbutton	GSR11.54F300QP	L600012		OBSOLETE	
Pushbutton	GSE10.00F130RG	L600028		OBSOLETE	
Pushbutton	GSR8.54F300QP	L600100		OBSOLETE	
Pushbutton	JB2256EEF200NC	D300076		OBSOLETE	LATCHING
Pushbutton	JB2256OAF200NC	D300077		OBSOLETE	MOMENTARY
Pushbutton	JB4256EEF400NCLATCHING	D300078		OBSOLETE	
Pushbutton	JN2UOANAGX	D300000	2013	OBSOLETE	reference active drawing P200000 for slight cosmetic differences on JN2UOANAGX
Pushbutton	JN2UEENAGX	D300001	2013	OBSOLETE	reference active drawing P200001 for slight cosmetic differences on JN2UEENAGX
Pushbutton	1XJN002UOA	D300002	2013	OBSOLETE	No replacement
Pushbutton	1XJN002UEE	D300003		OBSOLETE	
Pushbutton	1XJN002UOA	P200002		OBSOLETE	
Pushbutton	1XJN002UEE	P200003		OBSOLETE	
Pushbutton	1XJN00TAEBLK2UOAAAGPN	XA1774A		OBSOLETE	
Pushbutton	JN2UEENAGJNTAMRED	XD0369P		OBSOLETE	
Pushbutton	JN2UEENAGTAGRED	XD0375A	2007	OBSOLETE	Discontinued caps for poor fit, use base switch JN2UEENAGX with no cap
Pushbutton	JN2UEENAGX/TADGRY	XD0376A	2007	OBSOLETE	Discontinued caps for poor fit, use base switch JN2UEENAGX with no cap
Pushbutton	JN2UEENAGTAGGRY	XD0377A	2007	OBSOLETE	Discontinued caps for poor fit, use base switch JN2UEENAGX with no cap
Pushbutton	JN2UEENAGTABBLK	XD0378A	2007	OBSOLETE	Discontinued caps for poor fit, use base switch JN2UEENAGX with no cap
Pushbutton	JN2UOANAGTAGWHT	XD0379A	2007	OBSOLETE	Discontinued caps for poor fit, use base switch JN2UOANAGX with no cap
Pushbutton	JN2UOANAG.094BLK	XD0380A	2007	OBSOLETE	Discontinued caps for poor fit, use base switch JN2UOANAGX with no cap
Pushbutton	JN2UOANAGXJNTAMWHT	XD0381P	2007	OBSOLETE	Discontinued caps for poor fit, use base switch JN2UOANAGX with no cap
Pushbutton	JN2UOANAGTABBLK	XD0383A	2007	OBSOLETE	Discontinued caps for poor fit, use base switch JN2UOANAGX with no cap
Pushbutton	JN2UOANAGXTACWHT	XD0384A	2007	OBSOLETE	Discontinued caps for poor fit, use base switch JN2UOANAGX with no cap
Pushbutton	JN2UOANAGTAGRED	XD0385A	2007	OBSOLETE	Discontinued caps for poor fit, use base switch JN2UOANAGX with no cap
Pushbutton	JN2UOANAGTAGBLK	XD0386A	2007	OBSOLETE	Discontinued caps for poor fit, use base switch JN2UOANAGX with no cap
Pushbutton	JN2UOANAGJNTAMBLK	XD0387A	2007	OBSOLETE	Discontinued caps for poor fit, use base switch JN2UOANAGX with no cap
Pushbutton	JN2UOANAGJNTAMBLK	XD0387P	2007	OBSOLETE	Discontinued caps for poor fit, use base switch JN2UOANAGX with no cap
Pushbutton	JN2UOANAGTAGKRY	XD0388A	2007	OBSOLETE	Discontinued caps for poor fit, use base switch JN2UOANAGX with no cap
Pushbutton	JN2UEENAGTAGBLK	XD0390A	2007	OBSOLETE	Discontinued caps for poor fit, use base switch JN2UEENAGX with no cap
Pushbutton	JN2UOANAGTAGGRY	XD0393A	2007	OBSOLETE	Discontinued caps for poor fit, use base switch JN2UOANAGX with no cap
Pushbutton	JN2UOANAGTAGCHR	XD0396A	2007	OBSOLETE	Discontinued caps for poor fit, use base switch JN2UOANAGX with no cap
Pushbutton	JN2UOANAGXTAGBLK	XD0400A	2007	OBSOLETE	Discontinued caps for poor fit, use base switch JN2UOANAGX with no cap



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Pushbutton	JN2UOANAGXJNTAMRED	XD0405A	2007	OBSOLETE	Discontinued caps for poor fit, use base switch JN2UOANAGX with no cap
Pushbutton	JN2UOANAGXJNTAMRED	XD0405P	2007	OBSOLETE	Discontinued caps for poor fit, use base switch JN2UOANAGX with no cap
Pushbutton	JN2UOANAGXJNTAMWHT	XD0406P		OBSOLETE	SEE XD0381P
Pushbutton	JN2UOANAGTACWHT	XP0047A		OBSOLETE	
Pushbutton	JN2UOANAGTAGRED	XP0049A		OBSOLETE	
Pushbutton	JN2UOANAGXTAGBLK	XP0050A		OBSOLETE	SEE XD00
Pushbutton	JN2UEENAGTADGRY	XP0124A		OBSOLETE	
Pushbutton	1XJN00TAEBLK2UOAGPN	XP0204A		OBSOLETE	
Pushbutton	JN2UOANAGTAGGRY	XP0218A		OBSOLETE	
Pushbutton	JS1100AQ	W360000		OBSOLETE	
Pushbutton	JS1200AAQ	P000500		OBSOLETE	
Pushbutton	JS1200ABQ	P000501		OBSOLETE	
Pushbutton	KLBCCKCOMMONKEY	C900011		OBSOLETE	
Pushbutton	KLD	C900030		OBSOLETE	
Pushbutton	KLE	C900040		OBSOLETE	
Pushbutton	KLF	C900050		OBSOLETE	
Pushbutton	KLCKCOMMONKEY	C900081		OBSOLETE	
Pushbutton	KS-00Q-01	29-KS00Q01	2019	OBSOLETE	
Pushbutton	KS-00Q-02	29-KS00Q02	2019	OBSOLETE	
Pushbutton	KS-00Q-03	29-KS00Q03	2019	OBSOLETE	
Pushbutton	KS-01Q-01	29-KS01Q01	2019	OBSOLETE	
Pushbutton	KS-01Q-02	29-KS01Q02	2019	OBSOLETE	
Pushbutton	KS-01Q-03	29-KS01Q03	2019	OBSOLETE	
Pushbutton	KS-01Q-05	29-KS01Q05	2017	OBSOLETE	
Pushbutton	KS-03G-01	29-KS03G01	2017	OBSOLETE	
Pushbutton	KS-03Q-01	29-KS03Q01		OBSOLETE	
Pushbutton	KS-03Q-02	29-KS03Q02	2019	OBSOLETE	
Pushbutton	KS-03Q-03	29-KS03Q03		OBSOLETE	
Pushbutton	KS-04Q-01	29-KS04Q01	2019	OBSOLETE	
Pushbutton	KS-04Q-02	29-KS04Q02	2017	OBSOLETE	
Pushbutton	KS-04Q-03	29-KS04Q03	2017	OBSOLETE	
Pushbutton	L16PLT10KREDRED	XF0198P		OBSOLETE	SEE - XF0062P
Pushbutton	L16PLR10CORG	XF0360P		OBSOLETE	SEE XF0856P
Pushbutton	LAKOAV31BBLU	XF0776A	2019	OBSOLETE	
Pushbutton	LAKOAV31BBLU	XF0776A	2019	OBSOLETE	
Pushbutton	LAKOAV11JREDRED	XF0637A		OBSOLETE	SEE - XF0637P
Pushbutton	LAKOAV110GRN	XF0638A		OBSOLETE	SEE - XF0638P
Pushbutton	LAKOAV110BLU	XF0639A		OBSOLETE	SEE - XF0639P
Pushbutton	LAKOAV31BBLU	XF0776A	2019	OBSOLETE	
Pushbutton	LASEEU11JGRN	XF0484A		OBSOLETE	(SEE XF0484P)
Pushbutton	LASEEU11JGRN	XF0484P		OBSOLETE	
Pushbutton	LASOAV11KREDRED	XF0513A		OBSOLETE	(SEE XF0513P)
Pushbutton	LASOAV11KREDRED	XF0513P		OBSOLETE	
Pushbutton	LASOAV11KGRNGRN	XF0514A		OBSOLETE	(SEE XF0514P)
Pushbutton	LASOAV11KGRNGRN	XF0514P		OBSOLETE	
Pushbutton	LASOAV11KYELVEL	XF0515A		OBSOLETE	(SEE XF0515P)
Pushbutton	LASOAV11KYELVEL	XF0515P		OBSOLETE	
Pushbutton	LASEEV11KGRNBLU	XF0516A		OBSOLETE	(XF0516P)
Pushbutton	LASEEV11KGRNBLU	XF0516P		OBSOLETE	
Pushbutton	LASOAV11KYELORG	XF0517A		OBSOLETE	(SEE XF0517P)
Pushbutton	LASOAV11KYELORG	XF0517P		OBSOLETE	
Pushbutton	LASEEU11JREDRED	XF0644P		OBSOLETE	SEE - F060625
Pushbutton	LASEEV12KGRNGRN	XF0655A		OBSOLETE	SEE - XF0655P
Pushbutton	LBOABRX	B600000		OBSOLETE	(#5TERMRREMOVED)
Pushbutton	LBOAGYRX	B600001		OBSOLETE	(#6TERMINALREMOVED)
Pushbutton	LBOABRWITHCAP	B600002		OBSOLETE	
Pushbutton	LBOABB	B600003		OBSOLETE	
Pushbutton	LBOABG	B600004		OBSOLETE	
Pushbutton	LBOABY	B600005		OBSOLETE	
Pushbutton	LBOABRWITHCAP	B600006		OBSOLETE	
Pushbutton	LBEEBY	B600007		OBSOLETE	
Pushbutton	LB1EEBY	B610000		OBSOLETE	
Pushbutton	LC2259EENPWWITHSTRING	A010301		OBSOLETE	
Pushbutton	LC2255EENPWWITHCRIMP94V0	A010302		OBSOLETE	
Pushbutton	LC2259OANPWWITHSTRING	A010303		OBSOLETE	
Pushbutton	LC2255EENP	A538001		OBSOLETE	W/ Crimp
Pushbutton	LC2251OASP	P070002	2009	OBSOLETE	Decreasing demand, stream line series
Pushbutton	LC1257EESP	P070111	2015	OBSOLETE	Low sales
Pushbutton	LC1257EENP	P070112		OBSOLETE	
Pushbutton	LC1257OANP	P070121	2009	OBSOLETE	Decreasing demand, stream line series
Pushbutton	LC1257EENS	P070126	2015	OBSOLETE	Low sales
Pushbutton	LC1257OANS	P070127	2009	OBSOLETE	Decreasing demand, stream line series
Pushbutton	LC2251EENP	P070140		OBSOLETE	OBSOLETE
Pushbutton	LC2251OANP	P070146		OBSOLETE	NYLON 6/6
Pushbutton	LC2256EENS	P070190		OBSOLETE	
Pushbutton	LC2258OANS	P070211	2018	OBSOLETE	
Pushbutton	LC2258EESP	P070215	2017	OBSOLETE	
Pushbutton	LC1258EENS	P070225	2018	OBSOLETE	Drawing needs stamp
Pushbutton	LC2259EESP	P070235		OBSOLETE	
Pushbutton	LC2259OASP	P070236		OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Pushbutton	LC2262EENP	P070240		OBSOLETE	
Pushbutton	LC2255EENPTAULGR	XA1796P		OBSOLETE	
Pushbutton	LC2255EENPTAUDGR	XA1797P		OBSOLETE	
Pushbutton	LC2255EENPTAUBLK	XA1864P		OBSOLETE	
Pushbutton	LC1258EENPEN1BLKCAP	XP0234P		OBSOLETE	
Pushbutton	LC2255EENPLC1BLK	XP0286P		OBSOLETE	NYLON 6/6
Pushbutton	LC1258EENP700C2BLK	XP0199A		OBSOLETE	SEE - XP0199P
Pushbutton	LC2255OASP	P020102	2018	OBSOLETE	
Pushbutton	LF62	A010300		OBSOLETE	
Pushbutton	LL1105SPF065Q	P010236	2018	OBSOLETE	
Pushbutton	LL1105TF065Q	P010237	2018	OBSOLETE	
Pushbutton	LL1105LF065Q	P010238		OBSOLETE	
Pushbutton	LL1105BF065Q	P010239	2018	OBSOLETE	
Pushbutton	LL1105FF065Q	P010240		OBSOLETE	
Pushbutton	LL1105SF065Q	P010242		OBSOLETE	
Pushbutton	LL1105MF065Q	P010244		OBSOLETE	
Pushbutton	LL1105DF065Q	P010246		OBSOLETE	
Pushbutton	LL1105PF065Q	P010249	2018	OBSOLETE	
Pushbutton	LL1105QF065Q	P010252	2018	OBSOLETE	
Pushbutton	LL1105F065Q	P090000		OBSOLETE	
Pushbutton	LL1105WF065Q	P090006	2018	OBSOLETE	
Pushbutton	LP11-SD1CGE	17-LP11SD1CGE		OBSOLETE	
Pushbutton	LP110A1TCSGVL	B233002	2016	OBSOLETE	SEE B233003
Pushbutton	LP40A1PBCTR	B240022		OBSOLETE	SEE B240001
Pushbutton	LT8UEEAAGPN	A010400		OBSOLETE	
Pushbutton	6XMT102UEE94V0	A902004		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	4XMT12.52UOA	A902008		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	7XMT102UGR	A902010		OBSOLETE	
Pushbutton	6XMT12.54UGR	A902011		OBSOLETE	
Pushbutton	7XMT104UGR	A902012		OBSOLETE	
Pushbutton	6XMT104UGR	A902013		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	6XMT102UGR	A902014		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	5XMT1204UGR252UGR	A902019		OBSOLETE	
Pushbutton	6XMT1152UGRM3TE	A912005		OBSOLETE	ALL POSITIONS ARE 2U
Pushbutton	MTH2UEENAGVX	A960001		OBSOLETE	
Pushbutton	MTH2UEENAGX	A960002		OBSOLETE	
Pushbutton	MTH2UOANAGVX	A960003		OBSOLETE	
Pushbutton	MTH2UOANAGX	A960004		OBSOLETE	
Pushbutton	MTH4UEENAGVX	A960005		OBSOLETE	
Pushbutton	MTH4UEENAGX	A960006		OBSOLETE	
Pushbutton	MTH4UOANAGX	A960008		OBSOLETE	
Pushbutton	MTH6UEENAGVX	A960009		OBSOLETE	
Pushbutton	MTH6UEENAGX	A960010		OBSOLETE	PACKAGING = BLISTER TRAY
Pushbutton	MTH6UOANAGX	A960012		OBSOLETE	PACKAGING = BLISTER TRAY
Pushbutton	MTH2UEESAGX	A960013		OBSOLETE	
Pushbutton	MTH2UOASAGX	A960014		OBSOLETE	
Pushbutton	MTH4UEESAGX	A960015		OBSOLETE	
Pushbutton	MTH2UEENAGR300GFSTRING	A960019		OBSOLETE	
Pushbutton	MTH2UEEKZSNAGX	A960020		OBSOLETE	
Pushbutton	MTH4UEEKZSNAGX	A960021		OBSOLETE	
Pushbutton	MTH6UEEKZSNAGX	A960022		OBSOLETE	
Pushbutton	MTH2UEESNPAGX	A960023		OBSOLETE	
Pushbutton	MTH2UEENAGR300GF	A960026		OBSOLETE	EVERBRITE CRIMPED TERMS.
Pushbutton	MTH6UEENAGVR	A960027		OBSOLETE	RETENTIVE PINS (Q960014)
Pushbutton	MTH2UOANAGVR	A960028		OBSOLETE	RETENTIVE PINS
Pushbutton	MTH2UEENAU	A960029		OBSOLETE	(MTH-2P W/GOLD CONTACTS)
Pushbutton	MTH4UEEKZXSAGX	A960031		OBSOLETE	
Pushbutton	MTH2UEENAGR	A960035		OBSOLETE	RETENTIVE PINS
Pushbutton	MTH2UOANAGR	A960036		OBSOLETE	RETENTIVE PINS
Pushbutton	MTH2UOAKZSNAGVX	A960037		OBSOLETE	VALOX / NON-SHORTING
Pushbutton	MTH6UEENAGR	A960043		OBSOLETE	(6-PINS RETENTIVE)
Pushbutton	MTH4UEENAGR	A960044		OBSOLETE	(4-PINS RETENTIVE)
Pushbutton	MTH4UEECCLIP	A960045		OBSOLETE	
Pushbutton	MTH4UEENAGXHMG	A960046		OBSOLETE	
Pushbutton	MTH2UEENAGXHMG	A960047		OBSOLETE	
Pushbutton	MTH2UEEKZXSAGX	A960051		OBSOLETE	
Pushbutton	MTHRELEASESHEET	A960090		OBSOLETE	
Pushbutton	6XMT101DBLK2UEE94V0	XA0677B		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	6XMT101DBLK2UEE94V0	XA0677P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	MTH2UO94V01DBLK94V0	XA0705B		OBSOLETE	(SEE XA0605P)
Pushbutton	MTH2UO94V01DBLK94V0	XA0705P		OBSOLETE	
Pushbutton	MTH4UEE1DDGR	XA1045B		OBSOLETE	(SEE XA1045P)
Pushbutton	MTH4UEE1DDGR	XA1045P		OBSOLETE	
Pushbutton	MTH2UOA1DBLK	XA1046B		OBSOLETE	(SEE XA1046P)
Pushbutton	MTH2UOA1DBLK	XA1046P		OBSOLETE	
Pushbutton	MTH2UEENAG1DDGR	XA1047B		OBSOLETE	(SEE XA1047P)
Pushbutton	MTH2UEENAG1DDGR	XA1047P		OBSOLETE	
Pushbutton	MTH2UOA1DBLK	XA1057B		OBSOLETE	(SEE XA1057P)
Pushbutton	MTH2UOA1DBLK	XA1057P		OBSOLETE	
Pushbutton	MTH2UEENAG1DBLK	XA1058A		OBSOLETE	(SEE XA1058P)



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Pushbutton	MTH2UEENAG1DBLK	XA1058P		OBSOLETE	
Pushbutton	3XMT10STA124UGR	XA1085P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	7XMT101CBLK2UGRN	XA1093A		OBSOLETE	(SEE XA1093P)
Pushbutton	7XMT101CBLK2UGRN	XA1093P		OBSOLETE	
Pushbutton	6XMT12.51DDGR4UGR	XA1095A		OBSOLETE	(SEE XA1095P)
Pushbutton	6XMT12.51DDGR4UGR	XA1095P		OBSOLETE	
Pushbutton	MTH2UEENAG1RBLK	XA1124A		OBSOLETE	(SEE XA1124P)
Pushbutton	MTH2UEENAG1RBLK	XA1124P		OBSOLETE	
Pushbutton	MTH2UOANAG1CBLK	XA1147A		OBSOLETE	(SEE XA1147P)
Pushbutton	MTH2UOANAG1CBLK	XA1147P		OBSOLETE	
Pushbutton	MTH2UEE1CBLK	XA1157A		OBSOLETE	(SEE XA1157P)
Pushbutton	MTH2UEE1CBLK	XA1157P		OBSOLETE	
Pushbutton	4XMT102UGR	XA1158A		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	4XMT102UGR	XA1158P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	3XMT102UEE	XA1159A		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	3XMT102UEE	XA1159P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	1XMT102UEE	XA1197A		OBSOLETE	(SEE XA1197P)
Pushbutton	1XMT102UEE	XA1197P		OBSOLETE	
Pushbutton	MTH4UEE1CBLK	XA1217A		OBSOLETE	(SEE XA1217P)
Pushbutton	MTH4UEE1CBLK	XA1217P		OBSOLETE	
Pushbutton	5XMT102UOA	XA1243A		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	5XMT102UOA	XA1243P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	MTH6UEENAG1SBLK	XA1255A		OBSOLETE	
Pushbutton	MTH6UEENAG1SBLK	XA1255P		OBSOLETE	
Pushbutton	MTH2UOANAGPN1RBLK	XA1280A		OBSOLETE	(SEE XA1280P)
Pushbutton	MTH2UOANAGPN1RBLK	XA1280P		OBSOLETE	
Pushbutton	MTH2UOA1RRED	XA1291A		OBSOLETE	(SEE XA1291P)
Pushbutton	MTH2UOA1RRED	XA1291P		OBSOLETE	
Pushbutton	4XMT12.52UEE	XA1293A		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	4XMT12.52UEE	XA1293P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	MTH2UEE1RWHT	XA1294A		OBSOLETE	(SEE XA1294P)
Pushbutton	MTH2UEE1RWHT	XA1294P		OBSOLETE	
Pushbutton	3XMT102UGR	XA1366A		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	3XMT102UGR	XA1366P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	MTH4UEE1RBLK	XA1391A		OBSOLETE	(SEE XA1391P)
Pushbutton	MTH4UEE1RBLK	XA1391P		OBSOLETE	
Pushbutton	MTH2UEEN1RBLK	XA1420A		OBSOLETE	(SEE XA1420P)
Pushbutton	MTH2UEEN1RBLK	XA1420P		OBSOLETE	
Pushbutton	MTH6UEENAG1RGRY	XA1443A		OBSOLETE	(SEE XA1443P)
Pushbutton	MTH6UEENAG1RGRY	XA1443P		OBSOLETE	
Pushbutton	MTH4UOA1RRED	XA1452A		OBSOLETE	(SEE XA1452P)
Pushbutton	MTH4UOA1RRED	XA1452P		OBSOLETE	
Pushbutton	4XMT12.52UGRCUTEARS	XA1465A		OBSOLETE	(SEE XA1465P)
Pushbutton	4XMT12.52UGRCUTEARS	XA1465P		OBSOLETE	
Pushbutton	MTH2UEENAG1DWHT	XA1522A		OBSOLETE	(SEE XA1522P)
Pushbutton	MTH2UEENAG1DWHT	XA1522P		OBSOLETE	
Pushbutton	MTH2UEENAG1SBLK	XA1578A		OBSOLETE	(SEE XA1578P)
Pushbutton	MTH2UEENAG1SBLK	XA1578P		OBSOLETE	
Pushbutton	MTH2UEENAG1SRED	XA1579A		OBSOLETE	(SEE XA1579P)
Pushbutton	MTH2UEENAG1SRED	XA1579P		OBSOLETE	
Pushbutton	3XMT104UGR	XA1587A		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	3XMT104UGR	XA1587P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	MTH4UEESAG1RBLK	XA1591A		OBSOLETE	
Pushbutton	MTH4UEESAG1RBLK	XA1591P		OBSOLETE	
Pushbutton	MTH2UEEKZXPAAVEY	XA1597A		OBSOLETE	
Pushbutton	MTH2UEEKZXPAAVEY	XA1597P		OBSOLETE	
Pushbutton	MTH4UEENAG1SBLK	XA1601A		OBSOLETE	
Pushbutton	MTH4UEENAG1SBLK	XA1601P		OBSOLETE	
Pushbutton	3XMT101DDGR2UOAN	XA1604A		OBSOLETE	(SEE XA1604P)
Pushbutton	3XMT101DDGR2UOAN	XA1604P		OBSOLETE	
Pushbutton	MTH4UEENAGKZX1SDGR	XA1627A		OBSOLETE	(SEE XA1627P)
Pushbutton	MTH4UEENAGKZX1SDGR	XA1627P		OBSOLETE	
Pushbutton	MTH4UEENAGV1SBLK	XA1628A		OBSOLETE	(SEE XA1628P)
Pushbutton	MTH4UEENAGV1SBLK	XA1628P		OBSOLETE	
Pushbutton	3XMT12.5MM2UGRN	XA1630A		OBSOLETE	(SEE XA1630P)
Pushbutton	3XMT12.5MM2UGRN	XA1630P		OBSOLETE	
Pushbutton	4XMT104UGRN	XA1643A		OBSOLETE	(SEE XA1643P)
Pushbutton	4XMT104UGRN	XA1643P		OBSOLETE	
Pushbutton	MTH4UCISCO38UL94V0	XA1644P		OBSOLETE	
Pushbutton	MTH4UEEKZ1RLGR	XA1650A		OBSOLETE	(SEE XA1650P)
Pushbutton	MTH4UEEKZ1RLGR	XA1650P		OBSOLETE	
Pushbutton	1XMT12UEENAGVX1CBLK	XA1661A		OBSOLETE	(SEE XA1661P)
Pushbutton	1XMT12UEENAGVX1CBLK	XA1661P		OBSOLETE	
Pushbutton	1XMT12UEENV	XA1671A		OBSOLETE	(SEE XA1671P)
Pushbutton	1XMT12UEENV	XA1671P		OBSOLETE	
Pushbutton	1XMT12UOANAG	XA1693A		OBSOLETE	(SEE XA1693P)
Pushbutton	1XMT12UOANAG	XA1693P		OBSOLETE	
Pushbutton	MTH4UEENAG1RBLK	XA1720A		OBSOLETE	
Pushbutton	MTH4UEENAG1RBLK	XA1720P		OBSOLETE	(XQ0017P)
Pushbutton	MTH6UEENAG1RBLK	XA1722A		OBSOLETE	SEE XA1722P



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Pushbutton	MTH6UEENAG1RBLK	XA1722P		OBSOLETE	
Pushbutton	3XMTH104UGR	XA1731A		OBSOLETE	SEE XA1731P
Pushbutton	3XMTH104UGR	XA1731P		OBSOLETE	
Pushbutton	5XMTH101RDGR2UGRNAG	XA1744P		OBSOLETE	STA 5 = OA
Pushbutton	MTH2UEENAG1CWHT	XA1745A		OBSOLETE	SEE XA1745P
Pushbutton	MTH2UEENAG1CWHT	XA1745P		OBSOLETE	
Pushbutton	MTH4UEENAG1CWHT	XA1746A		OBSOLETE	SEE XA1746P
Pushbutton	MTH4UEENAG1CWHT	XA1746P		OBSOLETE	
Pushbutton	MTH2UOAKZXSAG1SBLK	XA1756A		OBSOLETE	SEE XA1756P
Pushbutton	MTH2UOAKZXSAG1SBLK	XA1756P		OBSOLETE	
Pushbutton	MTH4UEESAG1DBLK	XA1761A		OBSOLETE	SEE XA1761P
Pushbutton	MTH4UEESAG1DBLK	XA1761P		OBSOLETE	
Pushbutton	4XMTH12.52UOA	XA1778A		OBSOLETE	SEE XA1778P
Pushbutton	4XMTH12.52UOA	XA1778P		OBSOLETE	
Pushbutton	MTH2UOAKZXSAGX	XA1780A		OBSOLETE	SEE XA1780P
Pushbutton	MTH2UOAKZXSAGX	XA1780P		OBSOLETE	
Pushbutton	MTH2UOAKZSNAG1CBLU	XA1781A		OBSOLETE	SEE XA1781P
Pushbutton	MTH2UOAKZSNAG1CBLU	XA1781P		OBSOLETE	
Pushbutton	MTH2UOAKZSNAG1CRED	XA1782A		OBSOLETE	MOUNT HORIZONTAL
Pushbutton	MTH2UOAKZSNAG1CRED	XA1782P		OBSOLETE	MOUNT HORIZONTAL
Pushbutton	MTH2UOANAG1DDGR	XA1787A		OBSOLETE	SEE XA1787P
Pushbutton	MTH2UOANAG1DDGR	XA1787P		OBSOLETE	
Pushbutton	MTH2UOANAG1CRED	XA1793A		OBSOLETE	SEE XA1793P
Pushbutton	MTH2UOANAG1CRED	XA1793P		OBSOLETE	
Pushbutton	MTH2UOANAGV1CDGR	XA1799A		OBSOLETE	SEE XA1799P
Pushbutton	MTH2UOANAGV1CDGR	XA1799P		OBSOLETE	
Pushbutton	MTH4UEEKZSNAGV1RLGR	XA1802A		OBSOLETE	SEE XA1802P
Pushbutton	MTH4UEEKZSNAGV1RLGR	XA1802P		OBSOLETE	
Pushbutton	MTH2UOANAG1CBLU	XA1807A		OBSOLETE	SEE XA1807P
Pushbutton	MTH2UOANAG1CBLU	XA1807P		OBSOLETE	
Pushbutton	MTH6UEENAG1DBLK	XA1809A		OBSOLETE	SEE XA1809P
Pushbutton	MTH6UEENAG1DBLK	XA1809P		OBSOLETE	
Pushbutton	MTH4UEENAG1RLGR	XA1810A		OBSOLETE	SEE XA1810P
Pushbutton	MTH4UEENAG1RLGR	XA1810P		OBSOLETE	
Pushbutton	MTH2UOANAGV1SDGR	XA1815A		OBSOLETE	SEE XA1815P
Pushbutton	MTH2UOANAGV1SDGR	XA1815P		OBSOLETE	
Pushbutton	MTH2UOANAGVX1SDGR	XA1816A		OBSOLETE	SEE XA1816P
Pushbutton	MTH2UOANAGVX1SDGR	XA1816P		OBSOLETE	
Pushbutton	4XMTH104UGRNAG	XA1817A		OBSOLETE	SEE XA1817P
Pushbutton	4XMTH104UGRNAG	XA1817P		OBSOLETE	(SEE XA1643P)
Pushbutton	MTH2UEEKZXSAG1DLGR	XA1818A		OBSOLETE	SEE XA1818P
Pushbutton	MTH2UEEKZXSAG1DLGR	XA1818P		OBSOLETE	SHORTING NOT AVAILABLE
Pushbutton	1XMTH1CBLU2UOANAG	XA1837A		OBSOLETE	SEE XA1837P
Pushbutton	1XMTH1CBLU2UOANAG	XA1837P		OBSOLETE	
Pushbutton	1XMTH1CRED4UOA	XA1838A		OBSOLETE	SEE XA1838P
Pushbutton	1XMTH1CRED4UOA	XA1838P		OBSOLETE	
Pushbutton	MTH2UOANAGVX1RBLK	XA1846A		OBSOLETE	SEE XA1846P
Pushbutton	MTH2UOANAGVX1RBLK	XA1846P		OBSOLETE	
Pushbutton	MTH2UOAKZSNAGV1RRED	XA1858A		OBSOLETE	SEE XA1858P
Pushbutton	MTH2UOAKZSNAGV1RRED	XA1858P		OBSOLETE	
Pushbutton	MTH2UEEKZSNAG1RBLK	XA1859A		OBSOLETE	SEE XA1859P
Pushbutton	MTH2UEEKZSNAG1RBLK	XA1859P		OBSOLETE	
Pushbutton	1XMTH1RRED6UOANAG	XA1866A		OBSOLETE	SEE XA1866P
Pushbutton	1XMTH1RRED6UOANAG	XA1866P		OBSOLETE	
Pushbutton	1XMTH1RRED4UOANAG	XA1867A		OBSOLETE	SEE XA1867P
Pushbutton	1XMTH1RRED4UOANAG	XA1867P		OBSOLETE	
Pushbutton	6XMTH12.51RBLK2UGRN	XA1868A		OBSOLETE	XEE XA1868P
Pushbutton	6XMTH12.51RBLK2UGRN	XA1868P		OBSOLETE	
Pushbutton	3XMTH12.51RBLK4UEEN	XA1869A		OBSOLETE	SEE XA1869P
Pushbutton	3XMTH12.51RBLK4UEEN	XA1869P		OBSOLETE	
Pushbutton	7XMTH12.51RBLK2UGRN	XA1870A		OBSOLETE	
Pushbutton	7XMTH12.51RBLK2UGRN	XA1870P		OBSOLETE	
Pushbutton	7XMTH12.51RBLK2UEEN	XA1871A		OBSOLETE	SEE XA1871P
Pushbutton	7XMTH12.51RBLK2UEEN	XA1871P		OBSOLETE	
Pushbutton	7XMTH12.51RBLK2UGRN	XA1873A		OBSOLETE	SEE XA1873P
Pushbutton	7XMTH12.51RBLK2UGRN	XA1873P		OBSOLETE	
Pushbutton	MTH2UOANAGV1RRED	XA1874A		OBSOLETE	SEE XA1874P
Pushbutton	MTH2UOANAGV1RRED	XA1874P		OBSOLETE	
Pushbutton	7XMTH12.51RBLK4UGRN	XA1875A		OBSOLETE	SEE XA1875P
Pushbutton	7XMTH12.51RBLK4UGRN	XA1875P		OBSOLETE	
Pushbutton	5XMTH12.51RBLK4UGRN	XA1876A		OBSOLETE	SEE XA1876P
Pushbutton	5XMTH12.51RBLK4UGRN	XA1876P		OBSOLETE	
Pushbutton	MTH4UEEKZSNAG1RBLK	XA1882A		OBSOLETE	SEE XA1882P
Pushbutton	MTH4UEEKZSNAG1RBLK	XA1882P		OBSOLETE	
Pushbutton	MTH4UEEKZSNAG1SBLK	XA1884A		OBSOLETE	SEE XA1884P
Pushbutton	MTH4UEEKZSNAG1SBLK	XA1884P		OBSOLETE	(XQ0011P)
Pushbutton	5XMTH101CBLK2UGRNAG	XA1902A		OBSOLETE	SEE XA1902P
Pushbutton	5XMTH101CBLK2UGRNAG	XA1902P		OBSOLETE	
Pushbutton	MTH2UEENAGV1RBLK94V0	XA1909A		OBSOLETE	(SEE XA1909P)
Pushbutton	MTH2UEENAGV1RBLK94V0	XA1909P		OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Pushbutton	MTH4UEENAG1RWHT	XA1916A		OBSOLETE	SEE XA1916P
Pushbutton	MTH4UEENAG1RWHT	XA1916P		OBSOLETE	
Pushbutton	MTH2UEEKZLNAGV	XA1924A		OBSOLETE	SEE XA1924P
Pushbutton	MTH2UEEKZLNAGV	XA1924P		OBSOLETE	
Pushbutton	MTH2UOAKZLNAGV	XA1925A		OBSOLETE	
Pushbutton	MTH2UEENAG1RRED	XA1928A		OBSOLETE	SEE XA1928P
Pushbutton	MTH2UEENAG1RRED	XA1928P		OBSOLETE	(XQ0016P)
Pushbutton	MTH4UEENAG1DLGR	XA1934A		OBSOLETE	SEE XA1934P
Pushbutton	MTH4UEENAG1DLGR	XA1934P		OBSOLETE	
Pushbutton	10XMT1104UGRN	XA1937P		OBSOLETE	
Pushbutton	7XMT1101CDGR4UGR	XA1942A		OBSOLETE	SEE XA1942P
Pushbutton	7XMT1101CDGR4UGR	XA1942P		OBSOLETE	
Pushbutton	8XMT1101DBLK2UGRN	XA1946P		OBSOLETE	
Pushbutton	5XMT1101SBLK2UGRN	XA1955A		OBSOLETE	(SEE XA1955P)
Pushbutton	5XMT1101SBLK2UGRN	XA1955P		OBSOLETE	
Pushbutton	7XMT1101CDGR4UGR2UEE	XA1959P		OBSOLETE	
Pushbutton	6XMT1151CWHT2UEEN	XA1973A		OBSOLETE	(SEE XA1973P)
Pushbutton	6XMT1151CWHT2UEEN	XA1973P		OBSOLETE	
Pushbutton	6XMT1151RWHT2UEEN	XA1975A		OBSOLETE	(SEE XA1975P)
Pushbutton	6XMT1151RWHT2UGRNAGEEN	XA1975P		OBSOLETE	
Pushbutton	3XMT1104UGR	XA1976A		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	3XMT1104UGR	XA1976P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	MTH2UEESAG1SBLK	XA1978A		OBSOLETE	(SEE XA1978P)
Pushbutton	MTH2UEESAG1SBLK	XA1978P		OBSOLETE	
Pushbutton	MTH4UEENAGV1RDGR	XA1982A		OBSOLETE	(SEE XA1982P)
Pushbutton	MTH4UEENAGV1RDGR	XA1982P		OBSOLETE	
Pushbutton	8XMT112.51RBLK2UEEN	XA1988A		OBSOLETE	AGX (SEE XA1988P)
Pushbutton	8XMT112.51RBLK2UEENAGX	XA1988P		OBSOLETE	
Pushbutton	12XMT1151DBLK6UGR	XA1992A		OBSOLETE	(SEE XA1992P)
Pushbutton	12XMT1151DBLK6UGR	XA1992P		OBSOLETE	
Pushbutton	4XMT112.51RWHT4UG	XA1994A		OBSOLETE	(SEE XA1994P)
Pushbutton	4XMT112.51RWHT4UG	XA1994P		OBSOLETE	
Pushbutton	6XMT1102UGRNAG	XA1999A		OBSOLETE	(SEE XA 1999P)
Pushbutton	6XMT1102UGRNAG	XA1999P		OBSOLETE	
Pushbutton	5XMT112.51CBLK2UGRNAG	XA2010A		OBSOLETE	(SEE XA2010P)
Pushbutton	5XMT112.51CBLK2UGRNAG	XA2010P		OBSOLETE	
Pushbutton	6XMT11CRED2UGRNAG	XA2019A		OBSOLETE	(SEE XA2019P)
Pushbutton	6XMT11CRED2UGRNAG	XA2019P		OBSOLETE	
Pushbutton	MTH2UOANAG1RWHT	XA2033A		OBSOLETE	(SEE XA2033P)
Pushbutton	MTH2UOANAG1RWHT	XA2033P		OBSOLETE	
Pushbutton	11XMT117.5MM1RRED2U	XA2043P		OBSOLETE	
Pushbutton	11XMT117.51RRED4UGRNAG	XA2050P		OBSOLETE	
Pushbutton	MTH6UEEKZLNAG1RLGR	XA2053A		OBSOLETE	
Pushbutton	MTH6UEEKZLNAG1RLGR	XA2053P		OBSOLETE	
Pushbutton	MTH4UEENAG1RRED	XA2060A		OBSOLETE	
Pushbutton	MTH4UEENAG1RRED	XA2060P		OBSOLETE	
Pushbutton	MTH2UEESNPAG1DLGR	XA2061A		OBSOLETE	
Pushbutton	MTH2UEESNPAG1DLGR	XA2061P		OBSOLETE	
Pushbutton	MTH2UEESAG1RBLK	XA2081A		OBSOLETE	(SEE XA2081P)
Pushbutton	MTH2UEESAG1RBLK	XA2081P		OBSOLETE	
Pushbutton	MTH2UOAKZLNAGX	XA2082A		OBSOLETE	
Pushbutton	MTH2UOAKZLNAGX	XA2082P		OBSOLETE	
Pushbutton	MTH6UEEKZLNAG1RBLK	XA2083A		OBSOLETE	SEE XA2083P
Pushbutton	MTH6UEEKZLNAG1RBLK	XA2083P		OBSOLETE	
Pushbutton	MTH2UOAKZLNAG1RBLK	XA2084A		OBSOLETE	(SEE XA2084P)
Pushbutton	MTH2UOAKZLNAG1RBLK	XA2084P		OBSOLETE	
Pushbutton	MTH2UEENAGXP	XA2088A		OBSOLETE	
Pushbutton	5XMT1151CBLK2UOANAGX	XA2090A		OBSOLETE	(SEE XA2090P)
Pushbutton	5XMT1151CBLK2UOANAGX	XA2090P		OBSOLETE	
Pushbutton	MTH2UOANAG1SDGR	XA2099A		OBSOLETE	
Pushbutton	MTL4UEENAGRED	B571001		OBSOLETE	
Pushbutton	MTL4UOANAGRED	B571002		OBSOLETE	
Pushbutton	MTL4UEENAGGRN	B571003		OBSOLETE	
Pushbutton	MTL4UOANAGGRN	B571004		OBSOLETE	
Pushbutton	MTL4UEENAGYEL	B571005		OBSOLETE	
Pushbutton	MTL4UOANAGYEL	B571006		OBSOLETE	
Pushbutton	P16PMR11ABOR	XF0120P		OBSOLETE	
Pushbutton	P16PMR11ABOY	XF0128P		OBSOLETE	
Pushbutton	P16OAR110R	XF0210P		OBSOLETE	(SEE XF0129P)
Pushbutton	P16EES11EWHT	XF0347P		OBSOLETE	
Pushbutton	P16EES11EWHT	XF0354P		OBSOLETE	
Pushbutton	P16EES11HREDRED	XP0931P	2021	OBSOLETE	
Pushbutton	P197OASB	P010054	2020	OBSOLETE	
Pushbutton	P197EEPB	P030051	2020	OBSOLETE	
Pushbutton	P197EEPB	P030051	2020	OBSOLETE	
Pushbutton	P197 SB POWER SWITCH	P030052	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P197EESB	P030052	2020	OBSOLETE	
Pushbutton	P197EESB	P030052	2020	OBSOLETE	
Pushbutton	P197OASA	P030053	2018	OBSOLETE	
Pushbutton	P197EEPC	P030054	2020	OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Pushbutton	P197EEPC	P030054	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P197EEPC	P030054	2020	OBSOLETE	
Pushbutton	P197EEPD	P030055	2020	OBSOLETE	
Pushbutton	P197 SA (LATCHING)	P030056	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P197EESA	P030056	2020	OBSOLETE	
Pushbutton	P197EESA	P030056	2020	OBSOLETE	
Pushbutton	P197OAPB	P030058	2020	OBSOLETE	
Pushbutton	P197OAPC	P030059	2020	OBSOLETE	
Pushbutton	P197OAPC	P030059	2020	OBSOLETE	
Pushbutton	P197OAPC	P030059	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P197OAPD	P030060	2020	OBSOLETE	
Pushbutton	P197OA PD	P030060	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P197OASATACBLK	XA1790A		OBSOLETE	SEE XP0205A
Pushbutton	P197EEPDTAGBLK	XP0171A	2010	OBSOLETE	Decreasing demand, stream line series
Pushbutton	P197 OA SA (TAD-BLK)	XP0181A	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P197OASATADBLK	XP0181A	2020	OBSOLETE	
Pushbutton	P197EESBTH201WHT	XP0184A		OBSOLETE	
Pushbutton	P197OASATAGGRN	XP0197A		OBSOLETE	
Pushbutton	P197 OA SA (TAG/BLK)	XP0202A	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P197OASATAGBLK	XP0202A	2020	OBSOLETE	
Pushbutton	P197 OA SA (TAC-BLK)	XP0205A	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P197OASATACBLK	XP0205A	2020	OBSOLETE	
Pushbutton	P197OASBTAGBLK	XP0211A	2010	OBSOLETE	Decreasing demand, stream line series
Pushbutton	P197EEPDP320.094BLK	XP0212A	2010	OBSOLETE	Decreasing demand, stream line series
Pushbutton	P197EEPBTAEGRY	XP0229A	2010	OBSOLETE	Decreasing demand, stream line series
Pushbutton	P197OASATABGRY	XP0231A	2007	OBSOLETE	Decreasing demand, stream line series
Pushbutton	P197OASATAGGRN	XP0298A	2010	OBSOLETE	Decreasing demand, stream line series
Pushbutton	P197OASBTADGRY	XP0306A	2010	OBSOLETE	Decreasing demand, stream line series
Pushbutton	P227EE2A18A	P030098	2020	OBSOLETE	
Pushbutton	P227EE2A18B	P030099	2020	OBSOLETE	TOP LUGS ONLY
Pushbutton	P227EE2B20A	P030100	2020	OBSOLETE	
Pushbutton	P227EE2B20A	P030100	2020	OBSOLETE	
Pushbutton	P227EE2DXA	P030102	2020	OBSOLETE	
Pushbutton	P227 EE 2B 18A (LATCHING)	P030104	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P227EE2B18A	P030104	2020	OBSOLETE	
Pushbutton	P227OA2B18A	P030105		OBSOLETE	
Pushbutton	P227EE1B18B	P030107		OBSOLETE	
Pushbutton	P227EE2A20B	P030110	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P227EE2A20B	P030110	2020	OBSOLETE	
Pushbutton	P 227 EEB 18 -Cut Solder Tabs/Epoxy	P030111	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P227EE1B18C	P030111	2020	OBSOLETE	
Pushbutton	P227 EE 1CXK	P030113	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P227EE1CXK	P030113	2020	OBSOLETE	
Pushbutton	P227 EE 2A 20A (LATCHING)	P030116	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P227EE2A20A	P030116	2020	OBSOLETE	
Pushbutton	P227EE2B20BWITHCUTBRCKT	P030117		OBSOLETE	
Pushbutton	P227EE1A20B	P030119		OBSOLETE	
Pushbutton	P227EE2DXC	P030120	2018	OBSOLETE	
Pushbutton	P227EE1A18B	P030121		OBSOLETE	
Pushbutton	P227EE2B18A	P030122		OBSOLETE	DUPLICATE SEE P030104
Pushbutton	P227 EE 2B 18B	P030123	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P227EE2B18B	P030123	2020	OBSOLETE	
Pushbutton	P227 OA 2B 20C (Momentary)	P030124	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P227OA2B20C	P030124	2020	OBSOLETE	
Pushbutton	P227EE2B18C	P030125		OBSOLETE	
Pushbutton	P227EE2CXC	P030126	2020	OBSOLETE	Decreasing demand, stream line series
Pushbutton	P227EE2CXC	P030126	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P227EE2CXC	P030126	2020	OBSOLETE	
Pushbutton	P227EE1A20A	P030127		OBSOLETE	
Pushbutton	P227EE1B20C	P030128	2020	OBSOLETE	Decreasing demand, stream line series
Pushbutton	P227EE1B20C	P030128	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P227EE1B20C	P030128	2020	OBSOLETE	
Pushbutton	P227EE1B20B	P030129	2020	OBSOLETE	Decreasing demand, stream line series
Pushbutton	P227EE1B20B	P030129	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P227EE1B20B	P030129	2020	OBSOLETE	
Pushbutton	P227EE2B20B	P030130	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P227EE2B20B	P030130	2020	OBSOLETE	
Pushbutton	P227EE1A18A	P030131	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P227EE1A18A	P030131	2020	OBSOLETE	
Pushbutton	P227OA1CXK	P030132	2020	OBSOLETE	Decreasing demand, stream line series
Pushbutton	P227OA1CXK	P030132	2020	OBSOLETE	
Pushbutton	P227OA1DXC	P030133	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P227OA1DXC	P030133	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P227OA1DXC	P030133	2020	OBSOLETE	
Pushbutton	P227EE1B20A	P030134	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P227EE1B20A	P030134	2020	OBSOLETE	
Pushbutton	P227EE1DXC	P030135		OBSOLETE	
Pushbutton	P227EE1A20C	P030136		OBSOLETE	
Pushbutton	P227EE1DXA	P030137	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P227EE1DXA	P030137	2020	OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Pushbutton	P2270A1A18A	P030138		OBSOLETE	
Pushbutton	P227EE1B18A	P030139	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P227EE1B18A	P030139	2020	OBSOLETE	
Pushbutton	P227EE2A20B094BLK	X0258A	2020	OBSOLETE	EOL - Not on Website
Pushbutton	1X000300P228EE	XA2006A		OBSOLETE	(SEE XA2006P)
Pushbutton	P227EEB20TA12BLK	XP0032A	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P227EEB20TA12BLK	XP0032A	2020	OBSOLETE	
Pushbutton	P227EEB20TAGBLK	XP0033A	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P227EEB20TAGBLK	XP0033A	2020	OBSOLETE	
Pushbutton	P227EE2DXATAGBLK	XP0046A	2010	OBSOLETE	Decreasing demand, stream line series
Pushbutton	P227EEB20TACBLK	XP0048A	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P227EEB20TACBLK	XP0048A	2020	OBSOLETE	
Pushbutton	P227EEB20TA12GRY	XP0060A	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P227EEB20TA12GRY	XP0060A	2020	OBSOLETE	
Pushbutton	P227EE1CTAGBLK	XP0108A		OBSOLETE	(SEE XP0117A)
Pushbutton	P227EE1CTAGBLK	XP0117A		OBSOLETE	SEE XP0254A
Pushbutton	P227EE2B18TAEBLK4	XP0148A		OBSOLETE	
Pushbutton	P227EE2A18ATADGRY	XP0179A		OBSOLETE	
Pushbutton	P227EE2A18ATADGRY	XP0179A	2013	OBSOLETE	Decreasing demand, stream line series
Pushbutton	P227EE2B20ATH201WHT	XP0186A		OBSOLETE	
Pushbutton	P227 EE 1C C/ 320.09 BLK	XP0195A	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P227EE1CC320.09BLK	XP0195A	2020	OBSOLETE	
Pushbutton	P227EE1A20B320.09GRY	XP0200A	2013	OBSOLETE	Decreasing demand, stream line series
Pushbutton	P227 EE 1C C/ TAM BLK	XP0220A	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P227EE1CCTAMBLK	XP0220A	2020	OBSOLETE	
Pushbutton	P227EE2B20ATH201BLU	XP0226A		OBSOLETE	
Pushbutton	P227EE2A20ATAAGRY	XP0235A		OBSOLETE	
Pushbutton	P227EE2A20ATABWHT	XP0236A		OBSOLETE	
Pushbutton	P227 EE 1C X C /TA12 BLK (CAP MOU	XP0244A	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P227EE1CXCTA12BL	XP0244A	2020	OBSOLETE	
Pushbutton	P227EE1CXCTA12CHR	XP0245A		OBSOLETE	
Pushbutton	P227EE2B18CTAGBLK	XP0252A		OBSOLETE	
Pushbutton	P227EE1CXCTAGBLK	XP0254A	2020	OBSOLETE	
Pushbutton	P227EE1CXCTAGBLK (HORIZONTAL M	XP0254A	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P227EE1CXCTAGBLK	XP0254P	2020	OBSOLETE	
Pushbutton	P227EE1CXCTAGBLK (HORIZONTAL M	XP0254P	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P2270A2B20CTAGBLK	XP0256A	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P2270A2B20CTAGBLK	XP0256A	2020	OBSOLETE	
Pushbutton	P227EE1A20B.094BLK	XP0257A	2013	OBSOLETE	Decreasing demand, stream line series
Pushbutton	P227EE2A20B094BLK	XP0258A	2020	OBSOLETE	
Pushbutton	P227EE1B18TAGBLK	XP0259A	2010	OBSOLETE	Decreasing demand, stream line series
Pushbutton	P227EE1CCTAGBLKUL94VO	XP0260A		OBSOLETE	
Pushbutton	P227EE1CXCTAMGRY	XP0261A	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P227EE1CXCTAMGRY	XP0261A	2020	OBSOLETE	
Pushbutton	P227EE1CXCTAABLK	XP0267A		OBSOLETE	
Pushbutton	P227EE1A20BTACGRY	XP0275A	2010	OBSOLETE	Decreasing demand, stream line series
Pushbutton	P227EE1A20BTAMBLK	XP0276A	2010	OBSOLETE	Decreasing demand, stream line series
Pushbutton	P227EE1A18ATADGRY	XP0283A	2013	OBSOLETE	Decreasing demand, stream line series
Pushbutton	P227EE2A18ATAGBLK	XP0287A	2013	OBSOLETE	Decreasing demand, stream line series
Pushbutton	P227EE1A18BTAGBLK	XP0291A	2013	OBSOLETE	Decreasing demand, stream line series
Pushbutton	P227EE1CXCTAGRED	XP0293A	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P227EE1CXCTAGRED	XP0293A	2020	OBSOLETE	
Pushbutton	P227EE1B20BTAGBLK	XP0295A		OBSOLETE	
Pushbutton	P2270A1CXCTAGRED	XP0299A	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P2270A1CXCTAGRED	XP0299A	2020	OBSOLETE	
Pushbutton	P2270A1DXCTAGRED	XP0300A	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P2270A1DXCTAGRED	XP0300A	2020	OBSOLETE	
Pushbutton	P227EE1B20BTADWHT	XP0301A		OBSOLETE	
Pushbutton	P227EE1A20CTACGRY	XP0308A	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P227EE1A20CTACGRY	XP0308A	2020	OBSOLETE	
Pushbutton	P227EE2CXC320.09BLK	XP0310A	2013	OBSOLETE	Decreasing demand, stream line series
Pushbutton	P227EE1CXCTACGRY	XP0312A	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P227EE1CXCTACGRY	XP0312A	2020	OBSOLETE	
Pushbutton	P227EE1CXCTADWHT	XP0313A	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P227EE1CXCTADWHT	XP0313A	2020	OBSOLETE	
Pushbutton	P228EE	A000010		OBSOLETE	
Pushbutton	P2280A	A000011		OBSOLETE	
Pushbutton	1X000300P228EE	XA2006P		OBSOLETE	
Pushbutton	4XP228GR	XA2035A		OBSOLETE	(SEE XA2035P)
Pushbutton	4XP228GR	XA2035P		OBSOLETE	
Pushbutton	P297 EE P B	P030115	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P297EEPA	P030118		OBSOLETE	
Pushbutton	P297 EE PB (TAG/BLK)	XP0238A	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P297 EE PB (TAG/BLK)	XP0238P	2020	OBSOLETE	EOL - Not on Website
Pushbutton	P297EEPATABGRY	XP0253A	2007	OBSOLETE	Decreasing demand, stream line series
Pushbutton	PA4R41C1000-124	14-P4R41C1000124		OBSOLETE	
Pushbutton	PA562J	14-PA562J		OBSOLETE	
Pushbutton	P197 PB POWER SWITCH	P030051	2020	OBSOLETE	EOL - Not on Website
Pushbutton	PB4UEENPCPIN	P400000		OBSOLETE	
Pushbutton	PR141C1000-114	38-PR141C1000114	2021	OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Pushbutton	PR141C1000-115	38-PR141C1000115	2021	OBSOLETE	
Pushbutton	PR141C1000-134	38-PR141C1000134	2021	OBSOLETE	
Pushbutton	PR141C1000-135	38-PR141C1000135	2021	OBSOLETE	
Pushbutton	PR141C1000-136	38-PR141C1000136	2021	OBSOLETE	
Pushbutton	PR141C1011-134	38-PR141C1011134	2021	OBSOLETE	
Pushbutton	PR141C1021-116	38-PR141C1021116	2021	OBSOLETE	
Pushbutton	PR141C1900	38-PR141C1900	2021	OBSOLETE	
Pushbutton	PR141C2200	38-PR141C2200	2021	OBSOLETE	
Pushbutton	PR141C4900-115	38-PR141C4900115	2021	OBSOLETE	
Pushbutton	PR142C1000-117	38-PR142C1000117	2021	OBSOLETE	
Pushbutton	PR142C1000-124	38-PR142C1000124	2021	OBSOLETE	
Pushbutton	PR142C1011-107	38-PR142C1011107	2021	OBSOLETE	
Pushbutton	PR142C1015-106	38-PR142C1015106	2021	OBSOLETE	
Pushbutton	PR142C1100	38-PR142C1100	2021	OBSOLETE	
Pushbutton	PR142C1200	38-PR142C1200	2021	OBSOLETE	
Pushbutton	PR142C1911	38-PR142C1911	2021	OBSOLETE	
Pushbutton	PR142C2000-137	38-PR142C2000137	2021	OBSOLETE	
Pushbutton	PR142C2821	38-PR142C2821	2021	OBSOLETE	
Pushbutton	PR142C2825	38-PR142C2825	2021	OBSOLETE	
Pushbutton	PR142C3000-136	38-PR142C3000136	2021	OBSOLETE	
Pushbutton	PR144C1000-104	38-PR144C1000104	2021	OBSOLETE	
Pushbutton	PR144C1000-136	38-PR144C1000136	2021	OBSOLETE	
Pushbutton	PR144C1100	38-PR144C1100	2021	OBSOLETE	
Pushbutton	PR144C1200	38-PR144C1200	2021	OBSOLETE	
Pushbutton	PR144C1927	38-PR144C1927	2021	OBSOLETE	
Pushbutton	PR144C19296	38-PR144C19296	2021	OBSOLETE	
Pushbutton	PR144C2821	38-PR144C2821	2021	OBSOLETE	
Pushbutton	PR14EC1000-114	38-PR14EC1000114	2021	OBSOLETE	
Pushbutton	PR14EC1000-134	38-PR14EC1000134	2021	OBSOLETE	
Pushbutton	PR14EC1000-137	38-PR14EC1000137	2021	OBSOLETE	
Pushbutton	PR14EC1000-144	38-PR14EC1000144	2021	OBSOLETE	
Pushbutton	PR14EC1900	38-PR14EC1900	2021	OBSOLETE	
Pushbutton	PR14EC19296	38-PR14EC19296	2021	OBSOLETE	
Pushbutton	PR141C1000-136-ACC-F03-1	38-PR1500267	2021	OBSOLETE	
Pushbutton	PR141C4000-134-ACC-F03-1	38-PR1500270	2021	OBSOLETE	
Pushbutton	PR141C1100/ACC-F03-1	38-PR1500094	2018	OBSOLETE	
Pushbutton	PR144C1200/ACC-F03-1	38-PR1500116	2018	OBSOLETE	
Pushbutton	PR144C1000-116/ACC-F03-1	38-PR1500211	2018	OBSOLETE	**
Pushbutton	PR144C1800-ACC-F03-1	38-PR1500220	2018	OBSOLETE	
Pushbutton	PR144C19296-ACCRPM	38-PR1500232	2018	OBSOLETE	BS# 593101
Pushbutton	PR14EC1000-116/ACC-F03-1	38-PR1500209	2018	OBSOLETE	**
Pushbutton	PS636SINGLECHASSIS	C070000		OBSOLETE	
Pushbutton	PS636321	C070007		OBSOLETE	(REV PC & SO)
Pushbutton	PS636231	C070008		OBSOLETE	
Pushbutton	PS63621X	C070009		OBSOLETE	
Pushbutton	PS636321	C070010		OBSOLETE	
Pushbutton	PS63631X	C070012		OBSOLETE	
Pushbutton	PS636121	C070013		OBSOLETE	
Pushbutton	PS636131	C070014		OBSOLETE	
Pushbutton	PS636211	XC0232A		OBSOLETE	
Pushbutton	PS636211TAGBLK	XC0270A		OBSOLETE	
Pushbutton	PS636311	XC0271A		OBSOLETE	(SEE XC0271P)
Pushbutton	PS636311	XC0271P		OBSOLETE	
Pushbutton	RP8100B2M1CEBLKYELN1L-WA	ST081034	2020	OBSOLETE	
Pushbutton	RP81XXB1M1CEBLKBLKN1L	T081010		OBSOLETE	SEE ST081010
Pushbutton	RP81XXB1M1CEBLKREDN1L	T081025		OBSOLETE	SEE ST081025
Pushbutton	RP81xxB2M1CEBLKYELN1L-WA	T081034	2020	OBSOLETE	
Pushbutton	SK-12G01-G3	03-SK12G01G3		OBSOLETE	
Pushbutton	SK-22F05-G7	03-SK22F05G7		OBSOLETE	
Pushbutton	TA2UEEFAGPN	A010011		OBSOLETE	
Pushbutton	TA2UEECAUVN	A010018		OBSOLETE	
Pushbutton	TA2UOAFUAPN	A010061		OBSOLETE	
Pushbutton	TA2UDUMMYQA	A010077		OBSOLETE	NO PC PINS
Pushbutton	TA2UOARBAGPN	A010081		OBSOLETE	
Pushbutton	TADUMMYQA	A010082		OBSOLETE	.43 BODY NO PINS
Pushbutton	LT4UEECAUPS	A010093		OBSOLETE	
Pushbutton	TA4UEEFAGPN	A010104		OBSOLETE	
Pushbutton	TA4UOACUAPN	A010165		OBSOLETE	
Pushbutton	TA4UOAFAGPN	A010183		OBSOLETE	
Pushbutton	TA6UEEEAGPN	A010205		OBSOLETE	
Pushbutton	LT6UEEAAGPN	A010226		OBSOLETE	
Pushbutton	TA6UOACAGPNW1/2STAPLE	A010253		OBSOLETE	
Pushbutton	TA6UOACAGPN	A010261		OBSOLETE	
Pushbutton	TA6UOACUAPNW1/2STAPLE	A010262		OBSOLETE	
Pushbutton	TA8UEECAUPN	A010404		OBSOLETE	
Pushbutton	TA8UOACAGPN	A010543		OBSOLETE	
Pushbutton	TA16UEEBAUPN	A011213		OBSOLETE	
Pushbutton	LTPB4UEELTPB6UEEAGPN	A020903		OBSOLETE	
Pushbutton	5XTA20MMCHASSIS	A021204		OBSOLETE	
Pushbutton	TA101BLKGRN	A900105		OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Pushbutton	TA101BLKWHTGRN	A900106		OBSOLETE	
Pushbutton	TA101BLKBLKBLU	A900109		OBSOLETE	
Pushbutton	1XTA0003TH201BG2UEE	XA0485B		OBSOLETE	(SEE XA0485P)
Pushbutton	1XTA0003TH201BG2UEE	XA0485P		OBSOLETE	
Pushbutton	9XTA152UEEAGPN	XA1193A		OBSOLETE	(SEE XA1193P)
Pushbutton	9XTA152UEE	XA1193P		OBSOLETE	
Pushbutton	4XTA12.5TAGBLK2UGRCA	XA1225A		OBSOLETE	GPN** (SEE XA1225P)
Pushbutton	4XTA12.5TAGBLK2UGRCAGPN	XA1225P		OBSOLETE	
Pushbutton	8XTA12.5TAGBLK2UGRCAG	XA1328A		OBSOLETE	(SEE XA1328P)
Pushbutton	8XTA12.5TAGBLK2UGRCAG	XA1328P		OBSOLETE	
Pushbutton	2XTA17.5T2H201BLKORG2U	XA1329A		OBSOLETE	EAAAGPN (SEE XA1329P)
Pushbutton	2XTA17.5T2H201BLKORG2U	XA1329P		OBSOLETE	EAAAGPN
Pushbutton	7XTA10TACBLK2UGRAAGPN	XA1480A		OBSOLETE	(SEE XA1480P)
Pushbutton	7XTA10TACBLK2UGRAAGPN	XA1480P		OBSOLETE	
Pushbutton	5XTA152UEECAGPN	XA1485A		OBSOLETE	(SEE XA1485P)
Pushbutton	5XTA152UEECAGPN	XA1485P		OBSOLETE	
Pushbutton	1XTA000303TA12GRY2UEE	XA1526A		OBSOLETE	AAGPN
Pushbutton	1XTA000303TA12GRY2UEE	XA1526P		OBSOLETE	AAGPN
Pushbutton	4XTA12.5TAGWHT2UGR	XA1605A		OBSOLETE	AAGPN (SEE XA1605P)
Pushbutton	4XTA12.5TAGWHT2UGRAAGPN	XA1605P		OBSOLETE	
Pushbutton	4XTA12.5TAGWHT2UGR	XA1606A		OBSOLETE	AAGPN (SEE XA1606P)
Pushbutton	4XTA12.5TAGWHT2UGRAAGPN	XA1606P		OBSOLETE	
Pushbutton	TA2UEEAAGPNTAGBLK	XA1634A		OBSOLETE	(SEE XA1634P)
Pushbutton	TA2UEEAAGPNTAGBLK	XA1634P		OBSOLETE	
Pushbutton	4XTA12.5TAGBLK2UGR	XA1646A		OBSOLETE	AAUPN (SEE XA1646P)
Pushbutton	4XTA12.5TAGBLK2UGRAAUPN	XA1646P		OBSOLETE	
Pushbutton	4XTA102UGRAAGPN	XA1698P		OBSOLETE	
Pushbutton	1XTA000300TH201WHT4UEE	XA1724A		OBSOLETE	AAUVN SEE XA1724P
Pushbutton	1XTA000300TH201WHT4UEE	XA1724P		OBSOLETE	AAUVN
Pushbutton	4XTA20TH201WHT10UGRAA	XA1980A		OBSOLETE	GPN (SEE XA1980P)
Pushbutton	4XTA20TH201WHT10UGR	XA1980P		OBSOLETE	AAGPN
Pushbutton	4XTA102UEEAAGPN	XA1984A		OBSOLETE	WITH CUT EARS (XA1984P)
Pushbutton	4XTA102UEEAAGPN	XA1984P		OBSOLETE	WITH CUT EARS
Pushbutton	7XTA15TABWHT2UGRAGVN	XA1986A		OBSOLETE	(SEE XA1986P)
Pushbutton	7XTA15TABWHT2UGRAGVN	XA1986P		OBSOLETE	
Pushbutton	2XTA12.5TA12WHT2UEEAG	XA1989A		OBSOLETE	(SEE XA1989P)
Pushbutton	2XTA12.5TA12WHT2UEEAG	XA1989P		OBSOLETE	
Pushbutton	9XTA152UGRAAGPN	XA1991A		OBSOLETE	(SEE XA1991P)
Pushbutton	9XTA152UGRAAGPN	XA1991P		OBSOLETE	
Pushbutton	4XTA12.5TAGWHT8UGRBA	XA1993A		OBSOLETE	UPN (SEE XA1993P)
Pushbutton	4XTA12.5TAGWHT8UGRB	XA1993P		OBSOLETE	AUPN
Pushbutton	14XTA17.5MMTAEBLK16U	XA1995A		OBSOLETE	GRAAGPN (SEE XA1995P)
Pushbutton	14XTA17.5MMTAEBLK16UGRA	XA1995P		OBSOLETE	AGPN
Pushbutton	1XTA0003032UEEAAGPN	XA1996A		OBSOLETE	(SEE XA1996P)
Pushbutton	1XTA0003032UEEAAGPN	XA1996P		OBSOLETE	
Pushbutton	6XTA15TABWHT4UGRAAUVN	XA1997A		OBSOLETE	HORIZONTAL (SEE XA1997P)
Pushbutton	6XTA15TABWHT4UGRAAUVN	XA1997P		OBSOLETE	HORIZONTAL
Pushbutton	6XTA15TABWHT4UGRAAUVN	XA1998A		OBSOLETE	VERTICAL (SEE XA1998P)
Pushbutton	6XTA15TABWHT4UGRAAUVN	XA1998P		OBSOLETE	VERTICAL
Pushbutton	4XTA104UEEAAGPN	XA2000A		OBSOLETE	STA 1 = EE, STA 2-4 = GR
Pushbutton	4XTA104UEEAAGPN	XA2000P		OBSOLETE	STA 1 = EE, STA 2-4 = GR
Pushbutton	2XTA20TAGBLK2UEEAAGPN	XA2001A		OBSOLETE	(SEE XA2001P)
Pushbutton	2XTA20TAGBLK2UEEAAGPN	XA2001P		OBSOLETE	
Pushbutton	11XTA104UGRAAGPN	XA2002A		OBSOLETE	(SEE XA2002P)
Pushbutton	11XTA104UGRAAGPN	XA2002P		OBSOLETE	
Pushbutton	4XTA12.5TABBLK2UGRAA	XA2003A		OBSOLETE	GPN (SEE XA2003P)
Pushbutton	4XTA12.5TABBLK2UGRAAGPN	XA2003P		OBSOLETE	
Pushbutton	5XTA12.5TABBLK2UGRAA	XA2004A		OBSOLETE	GPN (SEE XA2004P)
Pushbutton	5XTA12.5TABBLK2UGRAAGPN	XA2004P		OBSOLETE	
Pushbutton	6XTA12.5TABBLK2UGRAA	XA2005A		OBSOLETE	GPN (SEE XA2005P)
Pushbutton	6XTA12.5TABBLK2UGRAAGPN	XA2005P		OBSOLETE	
Pushbutton	TA2UEEAAGPNTAGGRY	XA2007A		OBSOLETE	(SEE XA2007P)
Pushbutton	TA2UEEAAGPNTAGGRY	XA2007P		OBSOLETE	
Pushbutton	7XTA10TACRED2UEEAGPN	XA2008A		OBSOLETE	(SEE XA2008P)
Pushbutton	7XTA10TACRED2UEEAGPN	XA2008P		OBSOLETE	
Pushbutton	6XTA15TABRED8UEEAAGP	XA2009A		OBSOLETE	(SEE XA2009P)
Pushbutton	6XTA15TABRED8UEEAAGP	XA2009P		OBSOLETE	
Pushbutton	6XTA15TABWHT8UEEAAGPN	XA2011A		OBSOLETE	(SEE XA2011P)
Pushbutton	6XTA15TABWHT8UEEAAGPN	XA2011P		OBSOLETE	
Pushbutton	4XLT12.5TAMBLK4UGRAA	XA2012A		OBSOLETE	GPN (SEE XA2012P)
Pushbutton	4XLT12.5TAMBLK4UGRAAGPN	XA2012P		OBSOLETE	
Pushbutton	5XTA12.5TABWHT4UGRAAG	XA2013A		OBSOLETE	(SEE XA2013P)
Pushbutton	5XTA12.5TABWHT4UGRAAG	XA2013P		OBSOLETE	
Pushbutton	8XTA20TH201BW2UGRAAGP	XA2014A		OBSOLETE	(SEE XA2014P)
Pushbutton	8XTA20TH201BW2UGRAAGP	XA2014P		OBSOLETE	
Pushbutton	9XTA154UEEAAGPN	XA2015A		OBSOLETE	(SEE XA2015P)
Pushbutton	9XTA154UEEAAGPN	XA2015P		OBSOLETE	
Pushbutton	12XTA10TAGBLK4UGRAAGPN	XA2016A		OBSOLETE	(SEE XA2016P)
Pushbutton	12XTA10TAGBLK4UGRAAGPN	XA2016P		OBSOLETE	
Pushbutton	3XTA154UEEAUVN	XA2017A		OBSOLETE	(SEE XA2017P)



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Pushbutton	3XTA154UEECAUVN	XA2017P		OBSOLETE	
Pushbutton	3XTA154UGRCAUPN	XA2018A		OBSOLETE	(SEE XA2018P)
Pushbutton	3XTA154UGRCAUPN	XA2018P		OBSOLETE	
Pushbutton	6XTA102UGRAAGPN	XA2020A		OBSOLETE	(WITHOUT THE CUT MOUNTIN
Pushbutton	6XTA102UGRAAGPN	XA2020P		OBSOLETE	(WITHOUT THE CUT MOUNTIN
Pushbutton	TA16UEEBAUPNTACRED	XA2021A		OBSOLETE	(SEE XA2021P)
Pushbutton	TA16UEEBAUPNTACRED	XA2021P		OBSOLETE	
Pushbutton	1XTA000303TH100BLKORG	XA2022A		OBSOLETE	2UEEAAGPN (SEE XA2022P)
Pushbutton	1XTA000303TH100BLKORG2	XA2022P		OBSOLETE	UEEAAGPN
Pushbutton	5XTA12.5TADBLK2UGRFAU	XA2025A		OBSOLETE	(SEE XA2025P)
Pushbutton	5XTA12.5TADBLK2UGRFAU	XA2025P		OBSOLETE	
Pushbutton	4XTA20TAEBLK2UGR	XA2026A		OBSOLETE	HORIZONTAL (SEE XA2026P)
Pushbutton	4XTA20TAEBLK2UGR	XA2026P		OBSOLETE	HORIZONTAL
Pushbutton	5XTA12.5TADBLK2UGRAA	XA2027A		OBSOLETE	UPN (SEE XA2027P)
Pushbutton	5XTA12.5TADBLK2UGRAAUPN	XA2027P		OBSOLETE	
Pushbutton	1XTA000300TH201BLKBLU	XA2028A		OBSOLETE	6UEECAGVN (SEE XA2028P)
Pushbutton	1XTA000300TH201BLKBLU	XA2028P		OBSOLETE	6UEECAGVN
Pushbutton	3XTA15TABWHT2UGRAAUPN	XA2030A		OBSOLETE	(SEE XA2030P)
Pushbutton	3XTA15TABWHT2UGRAAUPN	XA2030P		OBSOLETE	
Pushbutton	4XTA15TABWHT2UGRAAUPN	XA2031A		OBSOLETE	(SEE XA2031P)
Pushbutton	4XTA15TABWHT2UGRAAUPN	XA2031P		OBSOLETE	
Pushbutton	2XTA15TABBLK2UEEAUPS	XA2032A		OBSOLETE	(SEE XA2032P)
Pushbutton	2XTA15TABBLK2UEEAUPS	XA2032P		OBSOLETE	
Pushbutton	4XTA12.5TACBLK2UGRCAG	XA2034A		OBSOLETE	(SEE XA2034P)
Pushbutton	4XTA12.5TACBLK2UGRCAG	XA2034P		OBSOLETE	
Pushbutton	4XTA15.MMTABBLK2UG	XA2036A		OBSOLETE	(SEE XA2036P)
Pushbutton	4XTA15.MMTABBLK2UG	XA2036P		OBSOLETE	
Pushbutton	4XTA17.5TH201GRN4UGRA	XA2037A		OBSOLETE	
Pushbutton	4XTA17.5TH201GRN4UGRA	XA2037P		OBSOLETE	
Pushbutton	3XTA154UGRAAGPN	XA2038A		OBSOLETE	(SEE XA2038P)
Pushbutton	3XTA154UGRAAGPN	XA2038P		OBSOLETE	
Pushbutton	8XTA12.5MMTADBLK2U	XA2039A		OBSOLETE	(SEE XA2039P)
Pushbutton	8XTA12.5MMTADBLK2U	XA2039P		OBSOLETE	
Pushbutton	1XTA000300TH201BLKGRN6U	XA2041A		OBSOLETE	EAAAGPN HORIZONTAL MOUNT
Pushbutton	1XTA000300TH201BLKGRN6U	XA2041P		OBSOLETE	EAAAGPN HORIZONTAL MOUNT
Pushbutton	1XTA000302TACBLK10UEEA	XA2042A		OBSOLETE	AG (SEE XA2042P)
Pushbutton	1XTA000302TACBLK10UEE	XA2042P		OBSOLETE	AAG
Pushbutton	7XTA12.5TH120BLKWHT4UO	XA2048A		OBSOLETE	
Pushbutton	7XTA12.5TH120BLKWHT4UO	XA2048P		OBSOLETE	ABAGPN
Pushbutton	1XTA00300TAGGRY2UEEAA	XA2049A		OBSOLETE	
Pushbutton	1XTA00300TAGGRY2UEEAA	XA2049P		OBSOLETE	
Pushbutton	8XTA20TA8UGRAAGPN	XA2051A		OBSOLETE	
Pushbutton	8XTA20TA8UGRAAGPN	XA2051P		OBSOLETE	
Pushbutton	2XTA12.52UEEAAGPS	XA2052A		OBSOLETE	
Pushbutton	2XTA12.52UEEAAGPS	XA2052P		OBSOLETE	
Pushbutton	1XTA0003-00TH120BLU6U	XA2054A		OBSOLETE	EEA
Pushbutton	1XTA0003-00TH120BLU6U	XA2054P		OBSOLETE	EEA
Pushbutton	6XTA152UGRAAGPN	XA2055A		OBSOLETE	
Pushbutton	6XTA152UGRAAGPN	XA2055P		OBSOLETE	
Pushbutton	4XTA152UGRAAGPN	XA2056A		OBSOLETE	
Pushbutton	4XTA152UGRAAGPN	XA2056P		OBSOLETE	
Pushbutton	6XTA12.56UGRAAGPNTABBLK	XA2057A		OBSOLETE	
Pushbutton	3XTA15TABBLK2UGRAAGPN	XA2059A		OBSOLETE	
Pushbutton	3XTA15TABBLK2UGRAAGPN	XA2059P		OBSOLETE	
Pushbutton	TA6UOACAGPNTADBLK	XA2062A		OBSOLETE	
Pushbutton	TA6UOACAGPNTADBLK	XA2062P		OBSOLETE	
Pushbutton	1XTA0003006UEEAAGPN	XA2063A		OBSOLETE	
Pushbutton	1XTA0003006UEEAAGPN	XA2063P		OBSOLETE	
Pushbutton	8XTA20TAEBLK2UGRAAGPN	XA2065A		OBSOLETE	
Pushbutton	8XTA20TAEBLK2UGRAAGPN	XA2065P		OBSOLETE	
Pushbutton	4XMT12.52UOAN	XA2069A		OBSOLETE	CUT EARS (SEE XA2069P)
Pushbutton	4XMT12.52UOAN	XA2069P		OBSOLETE	CUT EARS
Pushbutton	6XTA12.54UGRAAGPN	XA2070A		OBSOLETE	(SEE XA2070P)
Pushbutton	6XTA12.54UGRAAGPN	XA2070P		OBSOLETE	
Pushbutton	4XTA17.5TABWHT4UGRAAUPN	XA2071A		OBSOLETE	(SEE XA20710P)
Pushbutton	4XTA17.5TABWHT4UGRAAUPN	XA2071P		OBSOLETE	
Pushbutton	9XTA10TAMGRY2UEEAUPN	XA2072A		OBSOLETE	
Pushbutton	9XTA10TAMGRY2UEEAUPN	XA2072P		OBSOLETE	
Pushbutton	1XTA0003002UEEAAGPN	XA2073A		OBSOLETE	
Pushbutton	1XTA0003002UEEAAGPN	XA2073P		OBSOLETE	
Pushbutton	TA2UEEAAGPNTAGRED	XA2074A		OBSOLETE	(SEE XA2074P)
Pushbutton	TA2UEEAAGPNTAGRED	XA2074P		OBSOLETE	
Pushbutton	1XTA000302TH201BLKBLU6U	XA2075A		OBSOLETE	EECAGVN
Pushbutton	3XMT151CBLK2UOANAGX	XA2076A		OBSOLETE	
Pushbutton	3XMT151CBLK2UOANAGX	XA2076P		OBSOLETE	
Pushbutton	1XTA000300TH201BLKYEL4	XA2077A		OBSOLETE	UEEAAGPN
Pushbutton	1XTA000300TH201BLKYEL4	XA2077P		OBSOLETE	UEEAAGPN
Pushbutton	3XTA12.52UGRAAGPN	XA2078A		OBSOLETE	(SEE XA2078P)
Pushbutton	3XTA12.52UGRAAGPN	XA2078P		OBSOLETE	
Pushbutton	3XTA17.5TA12CHR2UGRAAU	XA2079A		OBSOLETE	PN (SEE XA2079P)



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Pushbutton	3XTA17.5TA12CHR2UGRAA	XA2079P		OBSOLETE	UPN
Pushbutton	5XTA17.52UEEAAGPN	XA2080A		OBSOLETE	(SEE XA2080P)
Pushbutton	5XTA17.52UEEAAGPN	XA2080P		OBSOLETE	
Pushbutton	3XTA12.52UEEAAGPN	XA2085A		OBSOLETE	(SEE XA2085P)
Pushbutton	3XTA12.52UEEAAGPN	XA2085P		OBSOLETE	
Pushbutton	LT2UOAAAGPSTAMBLK	XA2086A		OBSOLETE	
Pushbutton	7XTA17.5TAMWHT2UOACAG	XA2089A		OBSOLETE	PN (SEE XA2089P)
Pushbutton	7XTA17.5TAMWHT2UOACAGPN	XA2089P		OBSOLETE	
Pushbutton	TA2UEECAGPNTAMGRY	XA2091A		OBSOLETE	
Pushbutton	TA2UEECAGPNTAMGRY	XA2091P		OBSOLETE	
Pushbutton	5XMT101DWHT2UGRN	XA2093A		OBSOLETE	(SEE XA2093P)
Pushbutton	5XMT101DWHT2UGRN	XA2093P		OBSOLETE	
Pushbutton	6XTA12.52UEECAGPN	XA2094A		OBSOLETE	SPECIAL 2.38MM HOLE
Pushbutton	6XTA12.52UEECAGPN	XA2094P		OBSOLETE	
Pushbutton	6XTA15.02UEECAGPN	XA2095A		OBSOLETE	
Pushbutton	6XTA15.02UEECAGPN	XA2095P		OBSOLETE	
Pushbutton	LT2UEEAAGPN	A009990		OBSOLETE	
Pushbutton	LT2UEEAAGPNR	A009991		OBSOLETE	(RETENTIVE PINS)
Pushbutton	LT2UEECAGPN	A009992		OBSOLETE	
Pushbutton	LT2UEECAUPN	A009993		OBSOLETE	
Pushbutton	LT2UEEAUPN	A009994		OBSOLETE	
Pushbutton	LT2UEECAGPNWITHHOLE	A009995		OBSOLETE	
Pushbutton	LT2UEECAUPS	A009999		OBSOLETE	
Pushbutton	TA2UEEAAGPN	A010001		OBSOLETE	
Pushbutton	TA2UEEBAGPN	A010002		OBSOLETE	
Pushbutton	TA2UEECAGPN	A010003		OBSOLETE	
Pushbutton	TA2UEEEAGPN	A010005		OBSOLETE	
Pushbutton	TA2UEEC1AGPN	A010006		OBSOLETE	PINS=1.12/1.17 DIA HOLE
Pushbutton	TA2UEEAAGVN	A010007		OBSOLETE	
Pushbutton	LT2UEECAGVN	A010008		OBSOLETE	
Pushbutton	TA2UEECAGVN	A010009		OBSOLETE	
Pushbutton	TA2UEEAUPN	A010013		OBSOLETE	
Pushbutton	TA2UEECAUPN	A010015		OBSOLETE	
Pushbutton	TA2UOACAUPS	A010017		OBSOLETE	
Pushbutton	TA2UEEAUVN	A010019		OBSOLETE	
Pushbutton	TA2UEEC2AGPN	A010020		OBSOLETE	
Pushbutton	TA2UEEC2AGPS	A010021		OBSOLETE	
Pushbutton	TA2UEECAUPS	A010023		OBSOLETE	
Pushbutton	TA2UEEAAGPS	A010025		OBSOLETE	
Pushbutton	TA2UEEAUPS	A010027		OBSOLETE	
Pushbutton	LT2UOAAAGPNR	A010028		OBSOLETE	(RETENTIVE PINS)
Pushbutton	LT2UEEC1AGPN	A010029		OBSOLETE	PINS=1.12/1.17 DIA HOLE
Pushbutton	TA2UOAAAGPS	A010032		OBSOLETE	
Pushbutton	LT2UEEC3AGPN	A010035		OBSOLETE	PINS=1.12/1.17 DIA HOLE
Pushbutton	LT4UEEC3AGPN	A010036		OBSOLETE	PINS=1.12/1.17 DIA HOLE
Pushbutton	TA2UEEC1AGPNWITHHOLE	A010037		OBSOLETE	
Pushbutton	LT2UOAAAGPS	A010038		OBSOLETE	
Pushbutton	LT2UOACAGPN	A010049		OBSOLETE	
Pushbutton	LT2UOAAAGPN	A010050		OBSOLETE	
Pushbutton	TA2UOAAAGPN	A010051		OBSOLETE	
Pushbutton	TA2UOABAGPN	A010052		OBSOLETE	
Pushbutton	TA2UOACAGPN	A010053		OBSOLETE	
Pushbutton	TA2UOAEAGPN	A010055		OBSOLETE	
Pushbutton	TA2UOAAAGVN	A010057		OBSOLETE	
Pushbutton	TA2UOAAAGVNCUL88	A010058		OBSOLETE	
Pushbutton	LT10UEEAUPN	A010059		OBSOLETE	
Pushbutton	TA2UEEC1AGVNUL94V0	A010060		OBSOLETE	
Pushbutton	TA2UOAAUPN	A010063		OBSOLETE	
Pushbutton	LT2UOACAUPN	A010064		OBSOLETE	
Pushbutton	LT2UOAAUPN	A010066		OBSOLETE	
Pushbutton	TA2UOABAUPN	A010067		OBSOLETE	
Pushbutton	TA2UOAAUVN	A010069		OBSOLETE	
Pushbutton	LT2UOAFAGPN	A010070		OBSOLETE	
Pushbutton	TA2UOAFAGPN	A010079		OBSOLETE	
Pushbutton	LTPB2UAORAGLD	A010080		OBSOLETE	
Pushbutton	TA2UOAWITHTIFMOD	A010085		OBSOLETE	
Pushbutton	LT4UEEAUPN	A010089		OBSOLETE	
Pushbutton	LT4UEECAUPN	A010090		OBSOLETE	
Pushbutton	LT4UEEAUPS	A010091		OBSOLETE	
Pushbutton	LT2UAORCAGPN	A010094		OBSOLETE	
Pushbutton	TA4UEEAAGPN	A010101		OBSOLETE	
Pushbutton	TA4UEEBAGPN	A010102		OBSOLETE	
Pushbutton	TA4UEECAGPN	A010103		OBSOLETE	
Pushbutton	TA4UEEEAGPN	A010105		OBSOLETE	
Pushbutton	TA4UEEAAGVN	A010107		OBSOLETE	
Pushbutton	TA4UEEAUPN	A010113		OBSOLETE	
Pushbutton	TA4UEEAUVN	A010116		OBSOLETE	
Pushbutton	LT4UEEC1AGPN	A010118		OBSOLETE	
Pushbutton	TA4UEECAGVN	A010120		OBSOLETE	
Pushbutton	TA4UEECAUVN	A010121		OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Pushbutton	TA4UEEAUPS	A010124		OBSOLETE	
Pushbutton	TA4UEEAAGPS	A010125		OBSOLETE	
Pushbutton	LT4UEEAAGPN	A010127		OBSOLETE	
Pushbutton	LT4UEECAGPN	A010129		OBSOLETE	
Pushbutton	LT4UEEBAGPN	A010131		OBSOLETE	
Pushbutton	LT4UEEBAGPS	A010132		OBSOLETE	
Pushbutton	LTPB2UEELTPB4UEEEC2R	A010136		OBSOLETE	RETENTIVE PINS
Pushbutton	LTPB2UEELTPB6UEEC2R	A010137		OBSOLETE	RETENTIVE PINS
Pushbutton	LTPB4UEE8UEEC2UL94V0	A010138		OBSOLETE	
Pushbutton	LT4UOAAAUPN	A010140		OBSOLETE	
Pushbutton	LT4UOACAGPN	A010141		OBSOLETE	
Pushbutton	LT4UOACAUPN	A010142		OBSOLETE	
Pushbutton	TA4UOAAAGPN	A010151		OBSOLETE	
Pushbutton	TA4UOABAGPN	A010152		OBSOLETE	
Pushbutton	TA4UOACAGPN	A010153		OBSOLETE	
Pushbutton	TA4UOACAUPS	A010154		OBSOLETE	
Pushbutton	TA4UOAAAAGVN	A010157		OBSOLETE	
Pushbutton	TA4UOABAGVN	A010158		OBSOLETE	
Pushbutton	TA4UOABAUPN	A010159		OBSOLETE	
Pushbutton	TA4UOAAAUPN	A010163		OBSOLETE	
Pushbutton	TA4UOAAAUVN	A010169		OBSOLETE	
Pushbutton	LT4UOAAAGPN	A010179		OBSOLETE	
Pushbutton	LT4UEECAUVN	A010182		OBSOLETE	
Pushbutton	TA6UEEAAGPN	A010201		OBSOLETE	
Pushbutton	TA6UEEBAGPN88	A010202		OBSOLETE	
Pushbutton	TA6UEECAGPN	A010203		OBSOLETE	
Pushbutton	TA6UEECAUPN	A010204		OBSOLETE	
Pushbutton	TA6UEEEAUPN	A010209		OBSOLETE	
Pushbutton	TA6UEEAAGPS	A010210		OBSOLETE	
Pushbutton	TA6UEEAUPN	A010213		OBSOLETE	
Pushbutton	TA6UEECAGVN	A010223		OBSOLETE	
Pushbutton	LT6UEECAUPN	A010227		OBSOLETE	
Pushbutton	LT6UEEEAUPN	A010228		OBSOLETE	
Pushbutton	LT6UEECAGPN	A010232		OBSOLETE	
Pushbutton	TA6UOAAAGPN	A010251		OBSOLETE	WITH 1/2 STAPLE
Pushbutton	TA6UOABAGPN	A010254		OBSOLETE	WITH 1/2 STAPLE
Pushbutton	TA6UOABAUPN	A010255		OBSOLETE	WITH 1/2 STAPLE
Pushbutton	TA6UOAAAUPN	A010263		OBSOLETE	WITH 1/2 STAPLE
Pushbutton	LT6UOAAAGPN	A010264		OBSOLETE	WITH 1/2 STAPLE
Pushbutton	LT6UOAAAUPN	A010265		OBSOLETE	WITH 1/2 STAPLE
Pushbutton	LT6UOACAUPN	A010267		OBSOLETE	WITH 1/2 STAPLE
Pushbutton	LT8UEECAUPN	A010398		OBSOLETE	
Pushbutton	TA8UEEAAGPN	A010401		OBSOLETE	
Pushbutton	TA8UEECAGPN	A010403		OBSOLETE	
Pushbutton	LT8UEEAAGVN	A010405		OBSOLETE	
Pushbutton	TA8UEEBAUPN	A010406		OBSOLETE	
Pushbutton	TA8UEEAAGVN	A010407		OBSOLETE	
Pushbutton	TA8UEEAAGVNU94V0	A010408		OBSOLETE	
Pushbutton	TA8UEECAGVN	A010409		OBSOLETE	
Pushbutton	TA8UEEEAGPN	A010410		OBSOLETE	
Pushbutton	TA8UEEEAUPN	A010413		OBSOLETE	
Pushbutton	TA8UOAAAGPN	A010451		OBSOLETE	WITH 1/2 STAPLE
Pushbutton	TA8UOABAGPN	A010452		OBSOLETE	WITH 1/2 STAPLE
Pushbutton	LT8UOAAAUPN	A010462		OBSOLETE	WITH 1/2 STAPLE
Pushbutton	TA8UOABAUPN	A010464		OBSOLETE	WITH 1/2 STAPLE
Pushbutton	TA8UOACAUPNWITHPINCUTS	A010466		OBSOLETE	
Pushbutton	TA8UOAFAGPN	A010469		OBSOLETE	WITH 1/2 STAPLE
Pushbutton	TA10UOACAGPN	A010599		OBSOLETE	
Pushbutton	TA10UEEAAGPN	A010600		OBSOLETE	
Pushbutton	TA10UEECAGPN	A010603		OBSOLETE	
Pushbutton	TA10UEECAUPN	A010605		OBSOLETE	
Pushbutton	TA10UEECAUPS	A010606		OBSOLETE	
Pushbutton	TA10UOAAAGPN	A010650		OBSOLETE	WITH 1/2 STAPLE
Pushbutton	TA10UOAAAUPN	A010662		OBSOLETE	WITH 1/2 STAPLE
Pushbutton	TA16UEEAAGPN	A011200		OBSOLETE	
Pushbutton	TA16UEECAUPN	A011203		OBSOLETE	
Pushbutton	TA16UOAAAGPN	A011250		OBSOLETE	WITH 1/2 STAPLE
Pushbutton	TA16UOAFAGPN	A011251		OBSOLETE	WITH 1/2 STAPLE
Pushbutton	TA16UOACAGPN	A011252		OBSOLETE	
Pushbutton	TA16UOAAAUPN	A011260		OBSOLETE	
Pushbutton	NE182UEE	A019030		OBSOLETE	
Pushbutton	LTPB2UEELTPB4UEEAGPN	A020901		OBSOLETE	
Pushbutton	LTPB2UEELTPB6UEEER	A020902		OBSOLETE	PIGGYBACK w/RETENT
Pushbutton	LTPB2UEELTPB4UEEAGPS	A020904		OBSOLETE	
Pushbutton	LTPB2UEE4UEE	A020906		OBSOLETE	SPECIAL TIMING
Pushbutton	LTPB2U4UEEPIGGYBACK	A090204		OBSOLETE	WITH HOLE
Pushbutton	TH201BLKORG94V0	A800180		OBSOLETE	
Pushbutton	TH100BLKBLKOPQ	A800215		OBSOLETE	
Pushbutton	TA101BLKYELUS	A900104		OBSOLETE	
Pushbutton	TA101BLKWHTBLU	A900107		OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Pushbutton	TA101BLKBLKWH	A900108		OBSOLETE	
Pushbutton	HPTA2UEEFAGVNWTH000304	A990006		OBSOLETE	CHAS-Without Black Epoxy
Pushbutton	5XTA102UEECAGPN	XA0012B		OBSOLETE	W/CUT MOUNTING EARS
Pushbutton	5XTA102UEECAGPN	XA0012P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	1XTA0003002UOAAAGPN	XA0024A		OBSOLETE	(SEE XA0024P)
Pushbutton	1XTA0003002UOAAAGPN	XA0024P		OBSOLETE	
Pushbutton	7XTA15TH201BLKYL16U	XA0033D		OBSOLETE	GRAAGPN (SEE XA0033P)
Pushbutton	7XTA15TH201BLKYL16U	XA0033P		OBSOLETE	GRAAGPN
Pushbutton	5XTA12.5TH201BLKGRY2UE	XA0097C		OBSOLETE	EAAGPN (SEE XA0097P)
Pushbutton	5XTA12.5TH201BLKGRY2UE	XA0097P		OBSOLETE	EAAGPN
Pushbutton	TA2UEEAAGPNTAGWHT	XA0098A		OBSOLETE	(SEE XA0098P)
Pushbutton	TA2UEEAAGPNTAGWHT	XA0098P		OBSOLETE	
Pushbutton	TA2UEECAGPNTAGBLK	XA0138A		OBSOLETE	(SEE XA0138P)
Pushbutton	TA2UEECAGPNTAGBLK	XA0138P		OBSOLETE	
Pushbutton	3XTA12.5TH201BLKYL2UE	XA0215D		OBSOLETE	EAAGPN (SEE XA0215P)
Pushbutton	3XTA12.5TH201BLKYL2UE	XA0215P		OBSOLETE	EAAGPN
Pushbutton	9XTA17.5TH100BLKBLU2UE	XA0225C		OBSOLETE	EAAGPN (SEE XA0225P)
Pushbutton	9XTA17.5TH100BLKBLU2UE	XA0225P		OBSOLETE	EAAGPN
Pushbutton	3XTA102UGRCAGPN	XA0226A		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	3XTA102UGRCAGPN	XA0226P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	6XTA202UGR	XA0274A		OBSOLETE	(SEE XA0274P)
Pushbutton	6XTA202UGR	XA0274P		OBSOLETE	
Pushbutton	4XTA15201BLKWH2UGR	XA0323B		OBSOLETE	(SEE XA0323P)
Pushbutton	4XTA15201BLKWH2UGR	XA0323P		OBSOLETE	
Pushbutton	4XTA15201BLKWH2UGR	XA0324B		OBSOLETE	(SEE XA0324P)
Pushbutton	4XTA15201BLKWH2UGR	XA0324P		OBSOLETE	
Pushbutton	1XTA0003TH201BLKORG	XA0341B		OBSOLETE	EEAGPN (XA0341P/XA1956P)
Pushbutton	1XTA0003TH201BLKORG	XA0341P		OBSOLETE	EEAGPN (SEE XA1956P)
Pushbutton	TA2UEETAGRED	XA0352A		OBSOLETE	(SEE XA0352P)
Pushbutton	TA2UEETAGRED	XA0352P		OBSOLETE	
Pushbutton	3XL17.5TADBLK2UAORC	XA0362P		OBSOLETE	AGPN
Pushbutton	12XTA17.5TH100BKGR6U	XA0373P		OBSOLETE	GRAAGPN
Pushbutton	6XTA154UGR	XA0400B		OBSOLETE	(SEE XA0400P)
Pushbutton	6XTA154UGR	XA0400P		OBSOLETE	
Pushbutton	3XTA10TACBLK2UGRAAGPN	XA0406A		OBSOLETE	VERTICAL (SEE XA0406P)
Pushbutton	3XTA10TACBLK2UGRAAGPN	XA0406P		OBSOLETE	VERTICAL
Pushbutton	7XTA10TACBLK4UGR	XA0407A		OBSOLETE	(SEE XA0407P)
Pushbutton	7XTA10TACBLK4UGR	XA0407P		OBSOLETE	
Pushbutton	13XTA15201BLKGRN4UEE	XA0434C		OBSOLETE	AUPN (SEE XA0434P)
Pushbutton	13XTA15201BLKGRN4UEE	XA0434P		OBSOLETE	AUPN
Pushbutton	TA0003TAGBLK4UEE	XA0480A		OBSOLETE	(SEE XA0480P)
Pushbutton	TA0003TAGBLK4UEE	XA0480P		OBSOLETE	
Pushbutton	5XTA102UGRB	XA0496P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	2XLTPB102UEEC	XA0497C		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	2XLTPB102UEEC	XA0497P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	4XTA152UEEAAGPN	XA0500A		OBSOLETE	(SEE XA0500P)
Pushbutton	4XTA152UEEAAGPN	XA0500P		OBSOLETE	
Pushbutton	3XTA102UGRA.125FB	XA0507B		OBSOLETE	(SEE XA0507P)
Pushbutton	3XTA102UGRA.125FB	XA0507P		OBSOLETE	
Pushbutton	1XTA00034UEEE	XA0512A		OBSOLETE	(SEE XA0512P)
Pushbutton	1XTA00034UEEE	XA0512P		OBSOLETE	
Pushbutton	9XTA12.5TA12BLK4UGRC	XA0600A		OBSOLETE	AUPN (SEE XA0600P)
Pushbutton	9XTA12.5TA12BLK4UGRC	XA0600P		OBSOLETE	AUPN
Pushbutton	9XTA12.5TA12BLK4UGRC	XA0603A		OBSOLETE	AUPN (SEE XA0603P)
Pushbutton	9XTA12.5TA12BLK4UGRC	XA0603P		OBSOLETE	AUPN
Pushbutton	7XTA12.5TA12BLK8UGRB	XA0604A		OBSOLETE	AUPN (SEE XA0604P)
Pushbutton	7XTA12.5TA12BLK8UGRB	XA0604P		OBSOLETE	AUPN
Pushbutton	7XTA12.5TA12BLK8UGRA	XA0605A		OBSOLETE	AUPN (SEE XA0605P)
Pushbutton	7XTA12.5TA12BLK8UGRA	XA0605P		OBSOLETE	AUPN
Pushbutton	3XLTPB102UEEC	XA0656A		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	3XLTPB102UEEC	XA0656P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	1XTA00036UEEE	XA0658A		OBSOLETE	(SEE XA0658P)
Pushbutton	1XTA00036UEEE	XA0658P		OBSOLETE	
Pushbutton	SPSGLTH201BO94V02UEE	XA0668D		OBSOLETE	CAGVN (SEE XA0668P)
Pushbutton	SPSGLTH201BO94V02UEE	XA0668P		OBSOLETE	CAGVN
Pushbutton	1XTA0003TEKTRONIX2UEEE	XA0721A		OBSOLETE	(SEE XA0721P)
Pushbutton	1XTA0003TEKTRONIX2UEEE	XA0721P		OBSOLETE	
Pushbutton	TA8UEECTAGBLK	XA0726A		OBSOLETE	(SEE XA0726P)
Pushbutton	TA8UEECTAGBLK	XA0726P		OBSOLETE	
Pushbutton	10XTA154UGRA	XA0761A		OBSOLETE	(SEE XA0761P)
Pushbutton	10XTA154UGRA	XA0761P		OBSOLETE	
Pushbutton	4XL17.5TADRED2UOACAGP	XA0806P		OBSOLETE	N
Pushbutton	TA4UEECTAGBLK	XA0848A		OBSOLETE	(SEE XA0848P)
Pushbutton	TA4UEECTAGBLK	XA0848P		OBSOLETE	
Pushbutton	2XTA17.52UGRAAGPN	XA0868A		OBSOLETE	(SEE XA0868P)
Pushbutton	2XTA17.52UGRAAGPN	XA0868P		OBSOLETE	
Pushbutton	5XTA17.54UGRA	XA0869A		OBSOLETE	(SEE XA0869P)
Pushbutton	5XTA17.54UGRA	XA0869P		OBSOLETE	
Pushbutton	1XTA0003022UEEAAGPN	XA0877B		OBSOLETE	4/40T&E FRONT & BOTTOM
Pushbutton	1XTA00032UEEA	XA0877P		OBSOLETE	4/40 TAP FRONT & BOTTOM



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Pushbutton	1XTA00034UEEATE	XA0878B		OBSOLETE	4/40 FRONT & BOTTOM
Pushbutton	1XTA00034UEEATE	XA0878P		OBSOLETE	4/40 FRONT & BOTTOM
Pushbutton	4XTA102UOA	XA0888F		OBSOLETE	(SEE XA0888P)
Pushbutton	4XTA102UOA	XA0888P		OBSOLETE	
Pushbutton	1A2UEETAMGRAY	XA0899P		OBSOLETE	
Pushbutton	6XTA106UGRAAGPN	XA0911P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	1XTA02TADBLK2UEEAAU	XA0938A		OBSOLETE	(SEE XA0938P)
Pushbutton	1XTA02TADBLK2UEEAAU	XA0938P		OBSOLETE	
Pushbutton	3XTA104UGRB	XA0942B		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	3XTA104UGRB	XA0942P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	4XTA102UGRB	XA0943B		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	4XTA102UGRB	XA0943P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	2XTA152UGRB	XA0944B		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	2XTA152UGRBAGPN	XA0944P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	2XTA204UGRB	XA0945B		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	2XTA204UGRB	XA0945P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	5XTA102UGRB	XA0946C		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	5XTA102UGRB	XA0946P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	4XTA102UGRB	XA0947C		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	4XTA102UGRB	XA0947P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	3XTA102UGRB	XA0948B		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	3XTA102UGRB	XA0948P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	5XTA102UGRB	XA0949B		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	5XTA102UGRB	XA0949P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	4XTA104UEEB	XA0950C		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	4XTA104UEEB	XA0950P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	6XTA152UGRB	XA0951B		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	6XTA152UGRB	XA0951P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	6XTA104UGRB	XA0952B		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	6XTA104UGRB	XA0952P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	8XTA104UGRB	XA0953C		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	8XTA104UGRB	XA0953P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	1XTA00032UEEA	XA0954E		OBSOLETE	(SEE XA0954P)
Pushbutton	1XTA00032UEEA	XA0954P		OBSOLETE	
Pushbutton	2XTA202UGRB	XA0955B		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	2XTA202UGRB	XA0955P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	4XTA102UOARB	XA0956C		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	4XTA102UARORB	XA0956P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	8XTA102UEEB	XA0957C		OBSOLETE	(SEE XA0957)
Pushbutton	8XTA102UEEB	XA0957P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	3XTA104UGRB	XA0958C		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	3XTA104UGRB	XA0958P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	2XTA102UOABAGPN	XA0960B		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	2XTA102UOABAGPN	XA0960P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	2XTA102UOAB	XA0961C		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	2XTA102UOAB	XA0961P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	3XTA102UGRB	XA0962C		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	3XTA102UGRB	XA0962P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	7XTA152UGRBAGPN	XA0963B		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	7XTA152UGRB	XA0963P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	5XTA152UGRBAGPN	XA0964B		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	5XTA152UGRBAGPN	XA0964P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	1XTA0036UOAAAGPN	XA0988A		OBSOLETE	(SEE XA0988P)
Pushbutton	1XTA0036UOAAAGPN	XA0988P		OBSOLETE	
Pushbutton	2XTA12.54UEEB	XA0998A		OBSOLETE	(SEE XA0998P)
Pushbutton	2XTA12.54UEEB	XA0998P		OBSOLETE	
Pushbutton	9XTA102UEEVALOXA	XA1010C		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	9XTA102UEEVALOXA	XA1010P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	8XTA20TA101BLKYEL2UGR	XA1012B		OBSOLETE	AAGPN** (SEE XA1012P)
Pushbutton	8XTA20TA101BLKYEL2UGR	XA1012P		OBSOLETE	AAGPN (SEE XA2087P)
Pushbutton	8XTA17.5TA101BLKWHTBLU	XA1013A		OBSOLETE	4UGRAAGPN (SEE XA1013P)
Pushbutton	8XTA17.5TA101BLKWHTBLU	XA1013P		OBSOLETE	4UGRAAGPN
Pushbutton	3XTA152UGRAAGPN	XA1031A		OBSOLETE	(SEE XA1031P)
Pushbutton	3XTA152UGRAAGPN	XA1031P		OBSOLETE	
Pushbutton	7XTA12.5TH201GRN2UEEA	XA1042A		OBSOLETE	(SEE XA1042P)
Pushbutton	7XTA12.5TH201GRN2UEEA	XA1042P		OBSOLETE	
Pushbutton	3XTA20TACBLK2UOAA	XA1060A		OBSOLETE	(SEE XA1060P)
Pushbutton	3XTA20TACBLK2UOAA	XA1060P		OBSOLETE	
Pushbutton	8XTA12.5TA122UOAA	XA1078A		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	8XTA12.5TA122UOAA	XA1078P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	TA8UEECTAGBLK	XA1082B		OBSOLETE	(SEE XA1082P)
Pushbutton	TA8UEECTAGBLK	XA1082P		OBSOLETE	
Pushbutton	1XTA0003.1254UEEF	XA1103A		OBSOLETE	(SEE XA1103P)
Pushbutton	1XTA0003.1254UEEF	XA1103P		OBSOLETE	
Pushbutton	6XTA8UGRB	XA1109A		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	6XTA8UGRB	XA1109P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	2XTA154UGRBAGPN	XA1110A		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	2XTA154UGRB	XA1110P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	4XTA20TAGBLK2UEEAAGPN	XA1111A		OBSOLETE	(SEE XA1111P)
Pushbutton	4XTA20TAGBLK2UEEAAGPN	XA1111P		OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Pushbutton	7XTA15TABRED2UOAFAGPN	XA1150A		OBSOLETE	(SEE XA1150P)
Pushbutton	7XTA15TABRED2UOAFAGPN	XA1150P		OBSOLETE	
Pushbutton	3XTA152UGRB	XA1166A		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	3XTA152UGRB	XA1166P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	7XTA10TAARED4UGRAAGPN	XA1173A		OBSOLETE	(SEE XA1173P)
Pushbutton	7XTA10TAARED4UGRAAGPN	XA1173P		OBSOLETE	
Pushbutton	6XTA10TAAGRY4UEEAAGPN	XA1177A		OBSOLETE	(SEE XA1177P)
Pushbutton	6XTA10TAAGRY4UEEAAGPN	XA1177P		OBSOLETE	
Pushbutton	1XTA00TAGBLK2UOAF	XA1199A		OBSOLETE	TAPPED FOR 4/40 SCREWS
Pushbutton	1XTA00TAGBLK2UOAF	XA1199P		OBSOLETE	TAPPED FOR 4/40 SCREWS
Pushbutton	5XTA15TABLK4UEEA	XA1203B		OBSOLETE	(SEE XA1203P)
Pushbutton	5XTA15TABLK4UEEAAGPN	XA1203P		OBSOLETE	
Pushbutton	3XTA10TH120BLKWHT10U	XA1218A		OBSOLETE	GRAAGPN (SEE XA1218P)
Pushbutton	3XTA10TH120BLKWHT10U	XA1218P		OBSOLETE	GRAAGPN
Pushbutton	10XTA104UGRIBAGPN	XA1220C		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	10XTA104UGRIBAGPN	XA1220P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	2XTA12.52UEEA	XA1238A		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	2XTA12.52UEEA	XA1238P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	LT2UEECTAGBLK	XA1264A		OBSOLETE	(SEE XA1264P)
Pushbutton	LT2UEECTAGBLK	XA1264P		OBSOLETE	
Pushbutton	TA2UEEAAGVNGDCTACBLK	XA1271A		OBSOLETE	94V0** (SEE XA1271P)
Pushbutton	TA2UEEAAGVNGDCTACBLK	XA1271P		OBSOLETE	94V0 E LOGO
Pushbutton	TA2UOAAAGVNGDCTACBLK	XA1273A		OBSOLETE	94V0** (SEE XA1273P)
Pushbutton	TA2UOAAAGVNGDCTACBLK	XA1273P		OBSOLETE	94V0 E LOGO
Pushbutton	TA4UEEAAGVNGDCTACBLK	XA1275A		OBSOLETE	94V0** (SEE XA1275P)
Pushbutton	TA4UEEAAGVNGDCTACBLK	XA1275P		OBSOLETE	94V0
Pushbutton	TA4UOAAAGVNGDCTACBLK	XA1277A		OBSOLETE	94V0 (SEE XA1277P)
Pushbutton	TA4UOAAAGVNGDCTACBLK	XA1277P		OBSOLETE	94V0
Pushbutton	6XTA12.52UEE	XA1289A		OBSOLETE	(SEE XA1289P)
Pushbutton	6XTA12.52UEE	XA1289P		OBSOLETE	
Pushbutton	9XTA152UOAAAUPN3.2	XA1318A		OBSOLETE	(SEE XA1318P)
Pushbutton	9XTA152UOAAAUPN3.2	XA1318P		OBSOLETE	
Pushbutton	3XTA17.5TH100BLKBLU2U	XA1326A		OBSOLETE	GRAAGPN (SEE XA1326P)
Pushbutton	3XTA17.5TH100BLKBLU2U	XA1326P		OBSOLETE	GRAAGPN
Pushbutton	8XTA102UGRCAGPN	XA1339A		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	8XTA102UGRCAGPN	XA1339P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	9XTA102UGRCAGPN	XA1340A		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	9XTA102UGRCAGPN	XA1340P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	7XLT17.54UEEAAGPN	XA1344A		OBSOLETE	(SEE XA1344P)
Pushbutton	7XLT17.54UEEAAGPN	XA1344P		OBSOLETE	
Pushbutton	4XTA102UEECAGPN	XA1347A		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	4XTA102UEECAGPN	XA1347P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	14XLT20TAGWHT2UEEAAGPN	XA1367A		OBSOLETE	(SEE XA1367P)
Pushbutton	14XLT20TAGWHT2UEEAAGPN	XA1367P		OBSOLETE	
Pushbutton	7XLT10TAGREDNE182UEE	XA1368A		OBSOLETE	(SEE XA1368P)
Pushbutton	7XLT10TAGREDNE182UEE	XA1368P		OBSOLETE	
Pushbutton	10XTA10TAMWHT2UEEC	XA1389A		OBSOLETE	AUPN-CE (SEE XA1389P)
Pushbutton	10XTA10TAMWHT2UEEC	XA1389P		OBSOLETE	AUPN-CE
Pushbutton	8XTA12.5TH120BW8UGRB	XA1390A		OBSOLETE	AUPN-CE (SEE XA1390P)
Pushbutton	8XTA12.5TH120BW8UGRB	XA1390P		OBSOLETE	AUPN-CE
Pushbutton	1XTA0003TH100BLKYL4U	XA1393P		OBSOLETE	EAAAGPN
Pushbutton	TA10UEECAGPNTA2800BLK	XA1415A		OBSOLETE	
Pushbutton	TA8UEEAAGPNTAGBLK	XA1416B		OBSOLETE	
Pushbutton	TA8UEEAAGPNTAGBLK	XA1416P		OBSOLETE	
Pushbutton	TA8UEECAGVNTACBLK	XA1418A		OBSOLETE	UL94V0**
Pushbutton	TA8UEECAGVNTACBLKUL	XA1418P		OBSOLETE	94V0
Pushbutton	4XTA12.5TA12BLK2UGRA	XA1429A		OBSOLETE	AGPN (SEE XA1429P)
Pushbutton	4XTA12.5TA12BLK2UGRA	XA1429P		OBSOLETE	AGPN
Pushbutton	TA2UEEAAGPNTA12BLK	XA1430A		OBSOLETE	(SEE XA1430P)
Pushbutton	TA2UEEAAGPNTA12BLK	XA1430P		OBSOLETE	
Pushbutton	10XTA17.5TH100BLKORG	XA1436A		OBSOLETE	6UGRAAGPN (SEE XA1436P)
Pushbutton	10XTA17.5TH100BLKORG	XA1436P		OBSOLETE	6UGRAAGPN
Pushbutton	4XTA15TAGCHR4UGRAAGPN	XA1445A		OBSOLETE	(SEE XA1445P)
Pushbutton	4XTA15TAGCHR4UGRAAGPN	XA1445P		OBSOLETE	
Pushbutton	3XTA17.5TAGBLK2UOAA	XA1447A		OBSOLETE	AGPN (SEE XA1447P)
Pushbutton	3XTA17.5TAGBLK2UOAAAGPN	XA1447P		OBSOLETE	
Pushbutton	TA2UEEAUPNTAABLK	XA1469A		OBSOLETE	(SEE XA1469P)
Pushbutton	TA2UEEAUPNTAABLK	XA1469P		OBSOLETE	
Pushbutton	17XTA10MM2UGRAAGPN	XA1476A		OBSOLETE	(SEE XA1476P)
Pushbutton	17XTA10MM2UGRAAGPN	XA1476P		OBSOLETE	
Pushbutton	8XTA10TAAGRY2UGRA	XA1484A		OBSOLETE	(SEE XA1484P)
Pushbutton	8XTA10TAAGRY2UGRA	XA1484P		OBSOLETE	
Pushbutton	6XTA102UGRAAGPN	XA1513A		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	6XTA102UGRAAGPN	XA1513P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	2XTA102UEEAAGPN	XA1514A		OBSOLETE	(SEE XA1514P)
Pushbutton	2XTA102UEEAAGPN	XA1514P		OBSOLETE	
Pushbutton	TA2UEEAAGPNTACBLK	XA1521A		OBSOLETE	(SEE XA1521P)
Pushbutton	TA2UEEAAGPNTACBLK	XA1521P		OBSOLETE	
Pushbutton	TA16UEEAAGPNTACBLK	XA1528A		OBSOLETE	(SEE XA1528P)
Pushbutton	TA16UEEAAGPNTACBLK	XA1528P		OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Pushbutton	1XTA000302TAGWHT2UEE	XA1531A		OBSOLETE	AAGPN (SEE XA1531P)
Pushbutton	1XTA000302TAGWHT2UEE	XA1531P		OBSOLETE	AGPN
Pushbutton	12XTA12.510UGRCAGPN	XA1536A		OBSOLETE	(SEE XA1536P)
Pushbutton	12XTA12.510UGRCAGPN	XA1536P		OBSOLETE	
Pushbutton	3XTA10TACBLK2UGRAAGPN	XA1547A		OBSOLETE	HORIZONTAL (SEE XA1547P)
Pushbutton	3XTA10TACBLK2UGRAAGPN	XA1547P		OBSOLETE	HORIZONTAL
Pushbutton	6XTA106UGRBAGPN	XA1557A		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	6XTA106UGRBAGPN	XA1557P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	1XTA10UEECAGPN	XA1563A		OBSOLETE	TAPPED FOR 4/40 SCREWS
Pushbutton	1XTA10UEECAGPN	XA1563P		OBSOLETE	TAPPED FOR 4/40 SCREWS
Pushbutton	3XTA156UGRBAGPN	XA1564A		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	3XTA156UGRBAGPN	XA1564P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	3XTA158UGRPN	XA1565A		OBSOLETE	(SEE XA1565P)
Pushbutton	3XTA158UGRPN	XA1565P		OBSOLETE	
Pushbutton	3XTA10TACBLK2UGRA	XA1566A		OBSOLETE	(SEE XA1566P)
Pushbutton	3XTA10TACBLK2UGRA	XA1566P		OBSOLETE	
Pushbutton	12XTA15TA12WHT16UGRA	XA1568A		OBSOLETE	(SEE XA1568P)
Pushbutton	12XTA15TA12WHT16UGRA	XA1568P		OBSOLETE	
Pushbutton	TA2UEEC1AGPNTAUDGR	XA1573A		OBSOLETE	
Pushbutton	TA2UEEC1AGPNTAUDGR	XA1573P		OBSOLETE	
Pushbutton	5XTA17.5100BLKWHT10U	XA1574A		OBSOLETE	GRAAUPN / STA 1&5=BLANK
Pushbutton	5XTA17.5100BLKWHT10U	XA1574P		OBSOLETE	GRAAUPN / STA 1&5=BLANK
Pushbutton	8XTA102UEEAAGPN	XA1593A		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	8XTA102UEEAAGPN	XA1593P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	1XTA000300201BW4UEEC	XA1600A		OBSOLETE	AGPN
Pushbutton	1XTA000300201BW4UEEC	XA1600P		OBSOLETE	AGPN
Pushbutton	1XTEK2UEEAAGPN	XA1603A		OBSOLETE	
Pushbutton	1XTEK2UEEAAGPN	XA1603P		OBSOLETE	
Pushbutton	4XTA17.52UGRAAGPN	XA1608A		OBSOLETE	(SEE XA1608P)
Pushbutton	4XTA17.52UGRAAGPN	XA1608P		OBSOLETE	
Pushbutton	3XTA17.52UEEAAGPN	XA1611A		OBSOLETE	(SEE XA1611P)
Pushbutton	3XTA17.52UEEAAGPN	XA1611P		OBSOLETE	
Pushbutton	2XTA102UOAAAGPN	XA1616A		OBSOLETE	(SEE XA1616P)
Pushbutton	2XTA102UOAAAGPN	XA1616P		OBSOLETE	
Pushbutton	TA2UOAAAGVNTAGRED	XA1618A		OBSOLETE	(SEE XA1618P)
Pushbutton	TA2UOAAAGVNTAGRED	XA1618P		OBSOLETE	
Pushbutton	TA2UEEAAGPNTAMGRY	XA1621A		OBSOLETE	(SEE XA1621P)
Pushbutton	TA2UEEAAGPNTAMGRY	XA1621P		OBSOLETE	
Pushbutton	TA6UEECAGPNTAGWHT	XA1622A		OBSOLETE	(SEE XA1622P)
Pushbutton	TA6UEECAGPNTAGWHT	XA1622P		OBSOLETE	
Pushbutton	1XLT0003022UEEAAGPN	XA1632A		OBSOLETE	(SEE XA1632P)
Pushbutton	1XLT0003022UEEAAGPN	XA1632P		OBSOLETE	
Pushbutton	TA2UOAAAGPNTA12BLK	XA1636A		OBSOLETE	(SEE XA1636P)
Pushbutton	TA2UOAAAGPNTA12BLK	XA1636P		OBSOLETE	
Pushbutton	8XTA12.5TAGBLK2UGR	XA1647A		OBSOLETE	AAUPN (SEE XA1647P)
Pushbutton	8XTA12.5TAGBLK2UGRAAUPN	XA1647P		OBSOLETE	
Pushbutton	TA2UEECAGPNTAGRED	XA1654A		OBSOLETE	(SEE XA1654P)
Pushbutton	TA2UEECAGPNTAGRED	XA1654P		OBSOLETE	
Pushbutton	1XTA000302TH201BLKGRN	XA1658A		OBSOLETE	4UEEA (SEE XA1658P)
Pushbutton	1XTA000302TH201BLKGRN	XA1658P		OBSOLETE	4UEEA
Pushbutton	1XTA000302TAGBLK2UOA	XA1659A		OBSOLETE	AAGPN (SEE XA1659P)
Pushbutton	1XTA000302TAGBLK2UOA	XA1659P		OBSOLETE	AAGPN
Pushbutton	TA8UEEAUPNTAGBLK	XA1660A		OBSOLETE	(SEE XA1660P)
Pushbutton	TA8UEEAUPNTAGBLK	XA1660P		OBSOLETE	
Pushbutton	2XTA102UOAAAGPN	XA1662A		OBSOLETE	W/TAPE (SEE XA1662P)
Pushbutton	2XTA102UOAAAGPN	XA1662P		OBSOLETE	W/TAPE
Pushbutton	3XTA10TACBLK4UGRB	XA1669A		OBSOLETE	(SEE XA1669P)
Pushbutton	3XTA10TACBLK4UGRB	XA1669P		OBSOLETE	
Pushbutton	TA2UEEAAGPNTA1BLK	XA1672A		OBSOLETE	(SEE XA1672P)
Pushbutton	TA2UEEAAGPNTA1BLK	XA1672P		OBSOLETE	
Pushbutton	4XTA17.5TH100GRN2UGRF	XA1680A		OBSOLETE	AGPN (SEE XA1680P)
Pushbutton	4XTA17.5TH100GRN2UGRF	XA1680P		OBSOLETE	AGPN
Pushbutton	2XTA12.5TH201BLU2UEEA	XA1683A		OBSOLETE	AUVN (SEE XA1683P)
Pushbutton	2XTA12.5TH201BLU2UEE	XA1683P		OBSOLETE	AUVN
Pushbutton	5XTA12.5TH201BLWHT4UEEA	XA1684A		OBSOLETE	AUVN(TH201/GRN+2REL BAR)
Pushbutton	5XTA12.5TH201BLWHT4UEE	XA1684P		OBSOLETE	AUVN
Pushbutton	5XTA12.5TH201WHT4UEEA	XA1686A		OBSOLETE	AUVN (SEE XA1686P)
Pushbutton	5XTA12.5TH201WHT4UEE	XA1686P		OBSOLETE	AUVN
Pushbutton	1XTA000300TAGRED2UOA	XA1688A		OBSOLETE	AAGPN (SEE XA1688P)
Pushbutton	1XTA000300TAGRED2UO	XA1688P		OBSOLETE	AAAGPN
Pushbutton	LT2UEEC2AUPNTAGGRY	XA1690P		OBSOLETE	
Pushbutton	1XTA000302TH201BLKGRN	XA1691A		OBSOLETE	2UEEAAGPN (SEE XA1691P)
Pushbutton	1XTA000302TH201BLKGRN	XA1691P		OBSOLETE	2UEEAAGPN
Pushbutton	1XTA000302TH201BLKGRN	XA1692A		OBSOLETE	2UOAAAGPN (SEE XA1692P)
Pushbutton	1XTA000302TH201BLKGRN	XA1692P		OBSOLETE	2UOAAAGPN
Pushbutton	4XTA102UGRAAGPN	XA1698A		OBSOLETE	(SEE XA1698P)
Pushbutton	4XTA17.5TH100WHT2UGRF	XA1701A		OBSOLETE	AGPN SEE XA1701P
Pushbutton	4XTA17.5TH100WHT2UGRF	XA1701P		OBSOLETE	AGPN
Pushbutton	TA2UEECAGVNTADBLK	XA1703A		OBSOLETE	SEE XA1703P
Pushbutton	TA2UEECAGVNTADBLK	XA1703P		OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Pushbutton	4XTA12.5TA12BLK16UGRC	XA1704A		OBSOLETE	SEE XA1704P
Pushbutton	4XTA12.5TA12BLK16UGRC	XA1704P		OBSOLETE	
Pushbutton	2XTA12.5TH120GRN2UGRA	XA1710A		OBSOLETE	AGPN SEE XA1710P
Pushbutton	2XTA12.5TH120GRN2UGRA	XA1710P		OBSOLETE	AGPN
Pushbutton	5XTA152UGRCAGPN	XA1726A		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	5XTA152UGRCAGPN	XA1726P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	7XTA15MM2UGRCAGPN	XA1727A		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	7XTA15MM2UGRCAGPN	XA1727P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	8XTA15MM2UGRCAGPN	XA1728A		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	8XTA15MM2UGRCAGPN	XA1728P		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	6XTA15MM2UGRCAGPN	XA1733A		OBSOLETE	WITH CUT MOUNTING EARS
Pushbutton	6XTA15MM2UGRCAGPN	XA1733P		OBSOLETE	W/CUT MOUNTING EARS
Pushbutton	6XTA20TAAWHT2UGRAAGPN	XA1734A		OBSOLETE	SEE XA1734P
Pushbutton	6XTA20TAAWHT2UGRAAGPN	XA1734P		OBSOLETE	
Pushbutton	12XTA17.5TH100BLKORG	XA1736A		OBSOLETE	6UGRAAGPN SEE XA1736P
Pushbutton	12XTA17.5TH100BLKORG	XA1736P		OBSOLETE	6UGRAAGPN
Pushbutton	12XLT12.5TAMBLK2UGRAA	XA1741A		OBSOLETE	SEE XA1741P
Pushbutton	12XLT12.5TAMBLK2UGRAA	XA1741P		OBSOLETE	
Pushbutton	LT4UEECAUPSTAMWHT	XA1742A		OBSOLETE	SEE XA1742P
Pushbutton	LT4UEECAUPSTAMWHT	XA1742P		OBSOLETE	
Pushbutton	4XTA17.5TAGBLK6UGRAA	XA1747A		OBSOLETE	UPN SEE XA1747P
Pushbutton	4XTA17.5TAGBLK6UGRAAUPN	XA1747P		OBSOLETE	
Pushbutton	4XTA15TABBLK2UGRAAGPN	XA1750A		OBSOLETE	SEE XA1750P
Pushbutton	4XTA15TABBLK2UGRAAGPN	XA1750P		OBSOLETE	
Pushbutton	1XTA000300TH201GRN10U	XA1755A		OBSOLETE	EAAAGPN SEE XA1755P
Pushbutton	1XTA000300TH201GRN10UEE	XA1755P		OBSOLETE	AAGPN
Pushbutton	LT4UEECAGPNTAGBLK	XA1757A		OBSOLETE	SEE XA1757P
Pushbutton	LT4UEECAGPNTAGBLK	XA1757P		OBSOLETE	
Pushbutton	4XTA15TAGBLK2UEEFAGPN	XA1759A		OBSOLETE	SEE XA1759P
Pushbutton	4XTA15TAGBLK2UEEFAGPN	XA1759P		OBSOLETE	
Pushbutton	16XTA15TABBLK2UGRFAUPN	XA1760A		OBSOLETE	SEE XA1760P
Pushbutton	16XTA15TABBLK2UGRFAUPN	XA1760P		OBSOLETE	
Pushbutton	TA2UEECAGVNTAGBLK	XA1763A		OBSOLETE	SEE XA1763P
Pushbutton	TA2UEECAGVNTAGBLK	XA1763P		OBSOLETE	
Pushbutton	4XTA12.5TH120GRN4UGRA	XA1765A		OBSOLETE	AUPN SEE XA1765P
Pushbutton	4XTA12.5TH120GRN4UGRA	XA1765P		OBSOLETE	AUPN
Pushbutton	1XTA0003032UOAFAGPN	XA1767A		OBSOLETE	SEE XA1767P
Pushbutton	1XTA0003032UOAFAGPN	XA1767P		OBSOLETE	
Pushbutton	LTPB4UEE8UEE94VOTAMBLK	XA1768A		OBSOLETE	94V0 CIS SEE XA1768P
Pushbutton	LTPB4UEE8UEE94V0	XA1768P		OBSOLETE	TAM/BLK 94V0 CIS
Pushbutton	LT2UOAAAGPNTABBLK	XA1769A		OBSOLETE	SEE XA1769P
Pushbutton	LT2UOAAAGPNTABBLK	XA1769P		OBSOLETE	
Pushbutton	6XTA12.5TA12BLK2UEEA	XA1770A		OBSOLETE	SEE XA1770P
Pushbutton	6XTA12.5TA12BLK2UEE	XA1770P		OBSOLETE	AAGPN
Pushbutton	12XTA12.5TH201ORG4UEE	XA1771A		OBSOLETE	AAUPN SEE XA1771P
Pushbutton	12XTA12.5TH201ORG4UEE88	XA1771P		OBSOLETE	AAUPN
Pushbutton	4XTA12.5TA12BLK4UGRA	XA1772A		OBSOLETE	AGPN / BUTTONS ON HORIZ.
Pushbutton	4XTA12.5TA12BLK4UGRA	XA1772P		OBSOLETE	AGPN / BUTTONS ON HORIZ.
Pushbutton	3XTA12.5TA12BLK2UGRA	XA1773A		OBSOLETE	AGPN / BUTTONS ON VERT.
Pushbutton	3XTA12.5TA12BLK2UGRA	XA1773P		OBSOLETE	AGPN / BUTTONS ON VERT.
Pushbutton	6XTA12.5TA12BLK2UGR	XA1775A		OBSOLETE	AAGPN SEE XA1775P
Pushbutton	6XTA12.5TA12BLK2UGR	XA1775P		OBSOLETE	AAGPN
Pushbutton	6XTA12.5TAKBLK2UGR	XA1776A		OBSOLETE	AAGPN
Pushbutton	4XTA10TAMBLK2UGRAAGPN	XA1777A		OBSOLETE	SEE XA1777P
Pushbutton	4XTA10TAMBLK2UGRAAGPN	XA1777P		OBSOLETE	
Pushbutton	2XTA12.52UEEAAGPN	XA1779A		OBSOLETE	
Pushbutton	2XTA12.52UEEA	XA1779P		OBSOLETE	
Pushbutton	TA2UOAAAGPNTAGRED	XA1783A		OBSOLETE	SEE XA1783P
Pushbutton	TA2UOAAAGPNTAGRED	XA1783P		OBSOLETE	
Pushbutton	4XTA15TAGBLK2UGRFAGPN	XA1784A		OBSOLETE	SEE XA1784P
Pushbutton	4XTA15TAGBLK2UGRFAGPN	XA1784P		OBSOLETE	
Pushbutton	TA2UEEAAGPNTA12RED	XA1785A		OBSOLETE	SEE XA1785P
Pushbutton	TA2UEEAAGPNTA12RED	XA1785P		OBSOLETE	
Pushbutton	4XTA10TAABLK6UEEAAGPN	XA1786A		OBSOLETE	SEE XA1786P
Pushbutton	4XTA10TAABLK6UEEAAGPN	XA1786P		OBSOLETE	
Pushbutton	7XTA17.5TH201ORG2UEEA	XA1788A		OBSOLETE	AGPN SEE XA1788P
Pushbutton	7XTA17.5TH201ORG2UEE	XA1788P		OBSOLETE	AAGPN
Pushbutton	7XLT154UGRAAGPN	XA1789A		OBSOLETE	SEE XA1789P
Pushbutton	7XLT154UGRAAGPN	XA1789P		OBSOLETE	
Pushbutton	LT8UEEAAGPNTAGBLK	XA1792A		OBSOLETE	SEE XA1792P
Pushbutton	LT8UEEAAGPNTAGBLK	XA1792P		OBSOLETE	
Pushbutton	5XLT12.5TAGBLK4UGR	XA1794A		OBSOLETE	AAGPN (SEE XA1794P)
Pushbutton	5XLT12.5TAGBLK4UGR	XA1794P		OBSOLETE	AAGPN
Pushbutton	5XTA152UOAAAGPN	XA1795A		OBSOLETE	SEE XA1795P
Pushbutton	5XTA152UOAAAGPN	XA1795P		OBSOLETE	
Pushbutton	6XTA15TAGBLK4UGR	XA1800A		OBSOLETE	SEE XA1800P
Pushbutton	6XTA15TAGBLK4UGR	XA1800P		OBSOLETE	
Pushbutton	TA2UOAAAGPNTAGBLK	XA1801A		OBSOLETE	SEE XA1801P
Pushbutton	TA2UOAAAGPNTAGBLK	XA1801P		OBSOLETE	
Pushbutton	2XTA10TH120WHT16UGRC	XA1803A		OBSOLETE	AGPN (SEE XA1803P)



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Pushbutton	2XTA10TH120WHT16UGR	XA1803P		OBSOLETE	CAGPN
Pushbutton	4XTA17.5TH100ORG2UEEA	XA1804A		OBSOLETE	AGPN (SEE XA1804P)
Pushbutton	4XTA17.5TH100ORG2UEE	XA1804P		OBSOLETE	AAGPN
Pushbutton	4XTA17.5TH100ORG2UGRA	XA1805A		OBSOLETE	AGPN (SEE XA1805P)
Pushbutton	4XTA17.5TH100ORG2UGR	XA1805P		OBSOLETE	AAGPN
Pushbutton	5XTA152UGRAAGPN	XA1806A		OBSOLETE	STA #2 & #4 BLANK
Pushbutton	5XTA152UGRAAGPN	XA1806P		OBSOLETE	
Pushbutton	8XTA102UGRAAGPS	XA1808A		OBSOLETE	(SEE XA1808P)
Pushbutton	8XTA102UGRAAGPS	XA1808P		OBSOLETE	
Pushbutton	10XTA15TABBLK2UGRCAUPS	XA1811A		OBSOLETE	SEE XA1811P
Pushbutton	10XTA15TABBLK2UGRCAUPS	XA1811P		OBSOLETE	
Pushbutton	8XTA15TABBLK2UGRCAUPS	XA1812A		OBSOLETE	SEE XA1812P
Pushbutton	8XTA15TABBLK2UGRCAUPS	XA1812P		OBSOLETE	
Pushbutton	7XTA15TABBLK2UGRCAUPS	XA1813A		OBSOLETE	SEE XA1813P
Pushbutton	7XTA15TABBLK2UGRCAUPS	XA1813P		OBSOLETE	
Pushbutton	2XTA15TAABLK4UGRBAUPN	XA1814A		OBSOLETE	SEE XA1814P
Pushbutton	2XTA15TAABLK4UGRBAUPN	XA1814P		OBSOLETE	
Pushbutton	5XTA12.5TA12WHT2UGRA	XA1819A		OBSOLETE	AGPS (SEE XA1819P)
Pushbutton	5XTA12.5TA12WHT2UGR	XA1819P		OBSOLETE	AAGPS
Pushbutton	8XTA17.52UGRAAGPN	XA1820A		OBSOLETE	SEE XA1820P
Pushbutton	8XTA17.52UGRAAGPN	XA1820P		OBSOLETE	
Pushbutton	3XLT152UEE4UGR	XA1821A		OBSOLETE	PIGGYBACK (SEE XA1821P)
Pushbutton	3XLT152UEE4UGR	XA1821P		OBSOLETE	PIGGYBACK
Pushbutton	TA2UEEC1AGVNTAUDGR94VO	XA1822A		OBSOLETE	(SEE XA1822P)
Pushbutton	TA2UEEC1AGVNTAUDGR	XA1822P		OBSOLETE	94VO
Pushbutton	4XLT10TH120GRN2UGRF	XA1823A		OBSOLETE	AGPN (SEE XA1823P)
Pushbutton	4XLT10TH120GRN2UGRFAGPN	XA1823P		OBSOLETE	
Pushbutton	5XTA15TH201BLU4UOAA	XA1824A		OBSOLETE	GPN 0.125 INCH CHASSIS
Pushbutton	5XTA15TH201BLU4UOAAAGPN	XA1824P		OBSOLETE	0.125 INCH CHASSIS HOLES
Pushbutton	4XLT102UEECAGPN	XA1825A		OBSOLETE	(2-4=4UEE / CUT EARS)
Pushbutton	4XLT102UEECAGPN	XA1825P		OBSOLETE	(2-4=4UEE / CUT EARS)
Pushbutton	4XLT20TAGBLK2UGRA	XA1826A		OBSOLETE	SEE XA1826P
Pushbutton	4XLT20TAGBLK2UGRA	XA1826P		OBSOLETE	
Pushbutton	1XTA000303TAGBLK2UEE	XA1827A		OBSOLETE	AGPN (SEE XA1827P)
Pushbutton	1XTA000303TAGBLK2UEE	XA1827P		OBSOLETE	AGPN
Pushbutton	6XTA15TH201BLKYEL4UEE	XA1828A		OBSOLETE	AAUPN (SEE XA1828P)
Pushbutton	6XTA15TH201BLKYEL4UEE	XA1828P		OBSOLETE	AAUPN
Pushbutton	13XTA15TH201BLKYEL4UEE	XA1829A		OBSOLETE	AAUPN (SEE XA1829P)
Pushbutton	13XTA15TH201BLKYEL4UEE	XA1829P		OBSOLETE	AAUPN
Pushbutton	3XTA17.5TH100BLKORG4U	XA1830A		OBSOLETE	EAAAUPN (SEE XA1830P)
Pushbutton	3XTA17.5TH100BLKORG4UEE	XA1830P		OBSOLETE	AAUPN
Pushbutton	4XTA12.52UEEAAGPN	XA1831A		OBSOLETE	SEE XA1831P
Pushbutton	4XTA12.52UEEAAGPN	XA1831P		OBSOLETE	
Pushbutton	10XTA12.5TH100BY2UGR	XA1832A		OBSOLETE	AUPN (SEE XA1832P)
Pushbutton	10XTA12.5TH100BY2UGR	XA1832P		OBSOLETE	AUPN
Pushbutton	8XTA12.52UEEAAGPN	XA1833A		OBSOLETE	SEE XA1833P
Pushbutton	8XTA12.52UEEAAGPN	XA1833P		OBSOLETE	
Pushbutton	2XLT102UEECAGPN	XA1834A		OBSOLETE	SEE XA1834P
Pushbutton	2XLT102UEECAGPN	XA1834P		OBSOLETE	
Pushbutton	2XTA12.5TA2800RED8UOAF	XA1835A		OBSOLETE	
Pushbutton	1XTA000300TA2800BLK8	XA1836A		OBSOLETE	UOAF
Pushbutton	4XTA12.5TA2800RED16UGRF	XA1839A		OBSOLETE	
Pushbutton	12XTA12.5TA2800BLK2UGF	XA1840A		OBSOLETE	
Pushbutton	4XTA15TADBLK2UGRA	XA1841A		OBSOLETE	TAPPED FOR 4/40 SCREWS
Pushbutton	4XTA15TADBLK2UGRA	XA1841P		OBSOLETE	TAPPED FOR 4/40 SCREWS
Pushbutton	4XTA15TADBLK2UGRA	XA1842A		OBSOLETE	WITH P228 (SEE XA1842P)
Pushbutton	4XTA15TADBLK2UGRA	XA1842P		OBSOLETE	WITH P228
Pushbutton	5XLT12.52UGRAAGPN	XA1843A		OBSOLETE	SEE XA1843P
Pushbutton	5XLT12.52UGRAAGPN	XA1843P		OBSOLETE	
Pushbutton	8XLT12.52UGRAAGPN	XA1844A		OBSOLETE	SEE XA1844P
Pushbutton	8XLT12.52UGRAAGPN	XA1844P		OBSOLETE	
Pushbutton	4XLT17.5TAEBLK6UEE	XA1845A		OBSOLETE	AAGPN (SEE XA1845P)
Pushbutton	4XLT17.5TAEBLK6UEE	XA1845P		OBSOLETE	AAGPN
Pushbutton	7XTA152UGRB	XA1847A		OBSOLETE	SEE XA1847P
Pushbutton	7XTA152UGRB	XA1847P		OBSOLETE	
Pushbutton	5XTA152UGRB	XA1848A		OBSOLETE	SEE XA1848P
Pushbutton	5XTA152UGRB	XA1848P		OBSOLETE	
Pushbutton	TA2UEECAGVNTACBLK	XA1849A		OBSOLETE	SEE XA1849P
Pushbutton	TA2UEECAGVNTACBLK	XA1849P		OBSOLETE	
Pushbutton	TA000300TH201WHT2UEEF	XA1850A		OBSOLETE	AGPN (SEE XA1850P)
Pushbutton	TA000300TH201WHT2UEEF	XA1850P		OBSOLETE	AGPN
Pushbutton	6XTA154UGRF	XA1851A		OBSOLETE	SEE XA1851P
Pushbutton	6XTA154UGRF	XA1851P		OBSOLETE	
Pushbutton	8XTA17.5TH100WHT10UGR	XA1852A		OBSOLETE	AAUPN (SEE XA1852P)
Pushbutton	8XTA17.5TH100WHT10UGR	XA1852P		OBSOLETE	AAUPN
Pushbutton	TA4UOAAUPNTA2800BLK	XA1856A		OBSOLETE	
Pushbutton	TA4UOAAUPNTA2800RED	XA1857A		OBSOLETE	
Pushbutton	3XTA15TADWHT2UOAFAGPN	XA1860A		OBSOLETE	SEE XA1860P
Pushbutton	3XTA15TADWHT2UOAFAGPN	XA1860P		OBSOLETE	
Pushbutton	5XTA15TADWHT4UGRFAGPN	XA1861A		OBSOLETE	SEE XA1861P



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Pushbutton	5XTA15TADWHT4UGRF	XA1861P		OBSOLETE	AGPN
Pushbutton	4XLT17.5TADWHT2UOAC	XA1862P		OBSOLETE	AGPN
Pushbutton	3XLT17.5TADWHT2UOAR	XA1863P		OBSOLETE	CAGPN
Pushbutton	12XTA104UGRCAGPN	XA1872A		OBSOLETE	SEE XA1872P
Pushbutton	12XTA104UGRCAGPN	XA1872P		OBSOLETE	
Pushbutton	LT4UEECAUVNTAGBLK94V0	XA1878A		OBSOLETE	SEE XA1878P
Pushbutton	LT4UEECAUVNTAGBLK	XA1878P		OBSOLETE	
Pushbutton	TA10UEEAAGPNTAGBLK	XA1879A		OBSOLETE	SEE XA1879P
Pushbutton	TA10UEEAAGPNTAGBLK	XA1879P		OBSOLETE	
Pushbutton	13XTA20MMTAAGRY6UGR	XA1880A		OBSOLETE	AAUPN (SEE XA1880P)
Pushbutton	13XTA20MMTAAGRY6UGR	XA1880P		OBSOLETE	AAUPN
Pushbutton	5XTA15TADBLK2UGRAAGPN	XA1881A		OBSOLETE	SEE XA1881P
Pushbutton	5XTA15TADBLK2UGRAAGPN	XA1881P		OBSOLETE	
Pushbutton	4XTA15TH201BW2UGRBAGPN	XA1886A		OBSOLETE	SEE XA1886P
Pushbutton	4XTA15TH201BW2UGRBAGPN	XA1886P		OBSOLETE	
Pushbutton	4XTA20TH201YEL2UOAAAGPN	XA1887A		OBSOLETE	SEE XA1887P
Pushbutton	4XTA20TH201YEL2UOAAAGPN	XA1887P		OBSOLETE	
Pushbutton	3XTA20TH201YEL2UGRAA	XA1888A		OBSOLETE	GPN (SEE XA1888P)
Pushbutton	3XTA20TH201YEL2UGRAAGPN	XA1888P		OBSOLETE	
Pushbutton	2XTA20TH201WHT2UEE	XA1889A		OBSOLETE	AAGPN (SEE XA1889P)
Pushbutton	2XTA20TH201WHT2UEEAAGPN	XA1889P		OBSOLETE	
Pushbutton	3XTA20TH101YEL2UO	XA1890A		OBSOLETE	AAAGPN (SEE XA1890P)
Pushbutton	3XTA20TH101YEL2UOAAAGPN	XA1890P		OBSOLETE	
Pushbutton	3XTA20TH201YEL2UGR	XA1891A		OBSOLETE	AAGPN (SEE XA1891P)
Pushbutton	3XTA20TH201YEL2UGRAAGPN	XA1891P		OBSOLETE	
Pushbutton	4XTA20TH201YEL2UEE	XA1892A		OBSOLETE	AAGPN (SEE XA1892P)
Pushbutton	4XTA20TH201YEL2UEEAAGPN	XA1892P		OBSOLETE	
Pushbutton	1XTA000300TA2800RED4UEEA	XA1893A		OBSOLETE	AU
Pushbutton	LT2UEEAAGPNTA12BLU	XA1894P		OBSOLETE	
Pushbutton	LT2UOAAAGPNTAARED	XA1895P		OBSOLETE	
Pushbutton	LT2UOAAAGPNTA12BLU	XA1896P		OBSOLETE	
Pushbutton	1XTA000302TAGBLK2UEE	XA1897A		OBSOLETE	CAGVN (SEE XA1897P)
Pushbutton	1XTA000302TAGBLK2UEEC	XA1897P		OBSOLETE	AGVN
Pushbutton	TA2UEEAAGPNTAABLK	XA1898A		OBSOLETE	SEE XA1898P
Pushbutton	TA2UEEAAGPNTAABLK	XA1898P		OBSOLETE	
Pushbutton	1XLT0003032UOAAAGPN	XA1899A		OBSOLETE	SEE XA1899P
Pushbutton	1XLT0003032UOAAAGPN	XA1899P		OBSOLETE	
Pushbutton	6XTA102UGRAAGPNYT	XA1900A		OBSOLETE	
Pushbutton	3XLT15TH120WHT4UEE	XA1901A		OBSOLETE	CAUPN (SEE XA1901P)
Pushbutton	3XLT15TH120WHT4UEEC	XA1901P		OBSOLETE	AUPN
Pushbutton	6XTA20NONE10UGRAAGPN	XA1904A		OBSOLETE	SEE XA1904P
Pushbutton	6XTA20NONE10UGRAAGPN	XA1904P		OBSOLETE	
Pushbutton	12XTA20TH201WHT8UGR	XA1905A		OBSOLETE	AAGPN (SEE XA1905P)
Pushbutton	12XTA20TH201WHT8UGR	XA1905P		OBSOLETE	AAGPN
Pushbutton	3XTA20TA2800RED4U	XA1906A		OBSOLETE	GRVBAGPN**
Pushbutton	4XTA20TH201GRN2UEE	XA1907A		OBSOLETE	AAGPN (SEE XA1907P)
Pushbutton	4XTA20TH201GRN2UEE	XA1907P		OBSOLETE	AAGPN
Pushbutton	4XTA12.5TH120GRN4UGR	XA1908A		OBSOLETE	AAUPS (SEE XA1908P)
Pushbutton	4XTA12.5TH120GRN4UGR	XA1908P		OBSOLETE	AAUPS
Pushbutton	1XTA0003032UOAAAGPN	XA1910A		OBSOLETE	SEE XA1910P
Pushbutton	1XTA0003032UOAAAGPN	XA1910P		OBSOLETE	
Pushbutton	1XTA000303TAGRED2UO	XA1911A		OBSOLETE	AFAGPN (SEE XA1911P)
Pushbutton	1XTA000303TAGRED2UOAF	XA1911P		OBSOLETE	AGPN
Pushbutton	TA2UOACAGPNTAGRED	XA1912A		OBSOLETE	SEE XA1912P
Pushbutton	TA2UOACAGPNTAGRED	XA1912P		OBSOLETE	
Pushbutton	1XTA000300TAGBLK8UEE	XA1913A		OBSOLETE	AAGPN (SEE XA1913P)
Pushbutton	1XTA000300TAGBLK8UEE	XA1913P		OBSOLETE	AAGPN
Pushbutton	1XTA000300TADGRY4UEE	XA1914A		OBSOLETE	AAUPS (SEE XA1914P)
Pushbutton	1XTA000300TADGRY4UEE	XA1914P		OBSOLETE	AAUPS
Pushbutton	6XTA15TAGBLK8UGRAAGPN	XA1915P		OBSOLETE	
Pushbutton	2XTA20TAAWHT4UGRBAGPN	XA1917A		OBSOLETE	SEE XA1917P
Pushbutton	2XTA20TAAWHT4UGRBAGPN	XA1917P		OBSOLETE	
Pushbutton	11XTA12.5TADBLK2UGR	XA1918A		OBSOLETE	AAGPN (SEE XA1918P)
Pushbutton	11XTA12.5TADBLK2UGR	XA1918P		OBSOLETE	AAGPN
Pushbutton	8XLT12.5TAMBLK2UGR	XA1919A		OBSOLETE	AAGPS (SEE XA1919P)
Pushbutton	8XLT12.5TAMBLK2UGRAAGP	XA1919P		OBSOLETE	S
Pushbutton	12XLT12.5TAMBLK2UGR	XA1920A		OBSOLETE	AAGPS (SEE XA1920P)
Pushbutton	12XLT12.5TAMBLK2UGR	XA1920P		OBSOLETE	AAGPS
Pushbutton	4XLT202UEEAUPN	XA1921A		OBSOLETE	SEE XA1921P
Pushbutton	4XLT202UEEAUPN	XA1921P		OBSOLETE	
Pushbutton	1XTA000302TH201WHT4U	XA1922A		OBSOLETE	EAAAUPN (SEE XA1922P)
Pushbutton	1XTA000302TH201WHT4	XA1922P		OBSOLETE	EAAAUPN
Pushbutton	8XTA102UGRAAGPS	XA1923A		OBSOLETE	SEE XA1923P
Pushbutton	8XTA102UGRAAGPS	XA1923P		OBSOLETE	
Pushbutton	1XTA003TH201BLKORG2UO	XA1926A		OBSOLETE	AFAGPN (SEE XA1926P)
Pushbutton	1XTA003TH201BLKORG2	XA1926P		OBSOLETE	UOAFAGPN
Pushbutton	11XTA102UGRAAGPN	XA1927P		OBSOLETE	
Pushbutton	TA4UEECAGPNTAGCHR	XA1929A		OBSOLETE	SEE XA1929P
Pushbutton	TA4UEECAGPNTAGCHR	XA1929P		OBSOLETE	
Pushbutton	3XTA15TACRED6UGRAAUPN	XA1930A		OBSOLETE	SEE XA1930P



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Pushbutton	3XTA15TACRED6UGRAAUPN	XA1930P		OBSOLETE	
Pushbutton	4XTA12.5TADBLK2UGR	XA1931A		OBSOLETE	SEE XA1931P
Pushbutton	4XTA12.5TADBLK2UGR	XA1931P		OBSOLETE	
Pushbutton	8XTA12.5TADBLK2UGRAAGP	XA1932A		OBSOLETE	N (SEE XA1932P)
Pushbutton	8XTA12.5TADBLK2UGRAAGPN	XA1932P		OBSOLETE	
Pushbutton	20XTA12.5TADBLK2UGR	XA1933A		OBSOLETE	SEE XA1933P
Pushbutton	20XTA12.5TADBLK2UGR	XA1933P		OBSOLETE	
Pushbutton	12XTA20TH201WHT10UGRA	XA1935A		OBSOLETE	AGPN (SEE XA1935P)
Pushbutton	12XTA20TH201WHT10UGR	XA1935P		OBSOLETE	AAGPN
Pushbutton	3XTA17.5TH100GRN2UGR	XA1936A		OBSOLETE	AAGPN (SEE XA1936P)
Pushbutton	3XTA17.5TH100GRN2UGR	XA1936P		OBSOLETE	AAGPN
Pushbutton	7XMT101DBLK2UGRN	XA1941A		OBSOLETE	SEE XA1941P
Pushbutton	7XMT101DBLK2UGRN	XA1941P		OBSOLETE	
Pushbutton	1XL00030022UEECAGPN	XA1943A		OBSOLETE	SEE XA1943P
Pushbutton	1XL00030022UEECAGPN	XA1943P		OBSOLETE	
Pushbutton	4XTA15TABBLK2UGRA	XA1944A		OBSOLETE	WITH P228 (SEE XA1944P)
Pushbutton	4XTA15TABBLK2UGRA	XA1944P		OBSOLETE	WITH P228
Pushbutton	4XTA15TABBLK2UGRATE	XA1945A		OBSOLETE	TAPPED FOR 4/40 SCREWS
Pushbutton	4XTA15TABBLK2UGRAAGPN	XA1945P		OBSOLETE	TAPPED FOR 4/40 SCREWS
Pushbutton	3XL154UGRAAGPN	XA1947A		OBSOLETE	SEE XA1947P
Pushbutton	3XL154UGRAAGPN	XA1947P		OBSOLETE	
Pushbutton	12XTA20TH201BLKWH10U	XA1948A		OBSOLETE	GRAAGPN (SEE XA1948P)
Pushbutton	12XTA20TH201BLKWH10UG	XA1948P		OBSOLETE	RAAGPN
Pushbutton	9XTA20TADBLK4UGRBAUPN	XA1949A		OBSOLETE	(SEE XA1949P)
Pushbutton	9XTA20TADBLK4UGRBAUPN	XA1949P		OBSOLETE	
Pushbutton	10XTA20TADBLK8UGRBAUPN	XA1950A		OBSOLETE	(SEE XA1950P)
Pushbutton	10XTA20TADBLK8UGRBAUPN	XA1950P		OBSOLETE	
Pushbutton	3XTA20TADBLK2UGRBAUPN	XA1951A		OBSOLETE	(SEE XA1951P)
Pushbutton	3XTA20TADBLK2UGRBAUPN	XA1951P		OBSOLETE	
Pushbutton	6XTA12.5TAGGRN2UGRAAGPN	XA1953P		OBSOLETE	
Pushbutton	4XL12.52UGRCAGPN	XA1954A		OBSOLETE	(SEE XA1954P)
Pushbutton	4XL12.52UGRCAGPN	XA1954P		OBSOLETE	
Pushbutton	1XTA0003TH201ORG4UE	XA1956P		OBSOLETE	EAGPN**
Pushbutton	4XL17.5TAEBLK6UGRAPN	XA1957A		OBSOLETE	(SEE XA1957P)
Pushbutton	4XL17.5TAEBLK6UGRAPN	XA1957P		OBSOLETE	
Pushbutton	8XTA102UGRAAGPN	XA1958A		OBSOLETE	(SEE XA1958P)
Pushbutton	8XTA102UGRAAGPN	XA1958P		OBSOLETE	
Pushbutton	3XTA12.5TA12WHT2UEEAA	XA1960A		OBSOLETE	GPN (SEE XA1960P)
Pushbutton	3XTA12.5TA12WHT2UEE	XA1960P		OBSOLETE	AAGPN
Pushbutton	1XTA4UEECAGPNTH201BLU	XA1961A		OBSOLETE	(SEE XA1961P)
Pushbutton	1XTA4UEECAGPNTH201BLU	XA1961P		OBSOLETE	
Pushbutton	12XTA252UGRAAGPN	XA1962A		OBSOLETE	(SEE XA1962P)
Pushbutton	12XTA252UGRAAGPN	XA1962P		OBSOLETE	
Pushbutton	1XTA000300TACBLK2UOAA	XA1966A		OBSOLETE	AGPN (SEE XA1966P)
Pushbutton	1XTA000300TACBLK2UO	XA1966P		OBSOLETE	AAAGPN
Pushbutton	TA2UOACAGPNTAGWHT	XA1967A		OBSOLETE	(SEE XA1967P)
Pushbutton	TA2UOACAGPNTAGWHT	XA1967P		OBSOLETE	
Pushbutton	11XTA12.5TADBLK2UGRAA	XA1968A		OBSOLETE	GPN (SEE XA1968P)
Pushbutton	11XTA12.5TADBLK2UGR	XA1968P		OBSOLETE	AAGPN
Pushbutton	TA4UOACAGPNTADBLK	XA1969A		OBSOLETE	(SEE XA1969P)
Pushbutton	TA4UOACAGPNTADBLK	XA1969P		OBSOLETE	
Pushbutton	2XTA12.52UEEAAGVN	XA1970A		OBSOLETE	(SEE XA1970P)
Pushbutton	2XTA12.52UEEAAGVN	XA1970P		OBSOLETE	
Pushbutton	5XTA12.5TA4UEEAUVN	XA1971A		OBSOLETE	(SEE XA1971P)
Pushbutton	5XTA12.54UEEAUVN	XA1971P		OBSOLETE	
Pushbutton	4XTA102UEEAAGPN	XA1972A		OBSOLETE	(SEE XA1972P)
Pushbutton	TA2UEEC1AGVNTAUBLK94V0	XA1974A		OBSOLETE	(SEE XA1974P)
Pushbutton	TA2UEEC1AGVNTAUBLK94V0	XA1974P		OBSOLETE	
Pushbutton	1XTA000300TAGBLK16UOA	XA1977A		OBSOLETE	AAGPN (SEE XA1977P)
Pushbutton	1XTA000300TAGBLK16UO	XA1977P		OBSOLETE	AAAGPN
Pushbutton	5XTA206UGRCAUPN	XA1985A		OBSOLETE	(SEE XA1985P)
Pushbutton	5XTA206UCAUPN	XA1985P		OBSOLETE	
Pushbutton	6XTA12.5TAGBLK2UGRAGPN	XA1987A		OBSOLETE	(SEE XA1987P)
Pushbutton	6XTA12.5TAGBLK2UGRAGPN	XA1987P		OBSOLETE	
Pushbutton	4XL12.5TABBLK6UEEAA	XA1990A		OBSOLETE	GPN (SEE XA1990P)
Pushbutton	4XL12.5TABBLK6UEEAGPN	XA1990P		OBSOLETE	
Pushbutton	5XL12.5TAGBLK4UEEAGP	XA2045A		OBSOLETE	
Pushbutton	5XL12.5TAGBLK4UEEAGP	XA2045P		OBSOLETE	
Pushbutton	3XL152UGRAAGPN	XA2058A		OBSOLETE	
Pushbutton	3XL152UGRAAGPN	XA2058P		OBSOLETE	
Pushbutton	8XTA202UGRAAGPN	XA2087P		OBSOLETE	
Pushbutton	5XTA15TADBLK2UGRAAGPN	XA2096A		OBSOLETE	SEE XA2096P
Pushbutton	5XTA15TADBLK2UGRAAGPN	XA2096P		OBSOLETE	
Pushbutton	1XTA000302TH201BLKYEL6U	XA2097A		OBSOLETE	EAAAGPN
Pushbutton	1XTA000302TH201BLKYEL6U	XA2097P		OBSOLETE	EAAAGPN
Pushbutton	4XTA12.5TABBLK4UGRAAUPN	XA2098A		OBSOLETE	(SEE XA2098P)
Pushbutton	4XTA12.5TABBLK4UGRAAUPN	XA2098P		OBSOLETE	
Pushbutton	TD1105B	D200016		OBSOLETE	
Pushbutton	TL1100AF16QSSDOME	D301097		OBSOLETE	
Pushbutton	TL1100EF160QSSDOME	D301098		OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Pushbutton	TL1100CF160QACT3.8sq	D301108		OBSOLETE	
Pushbutton	TL1100BF160Q	P001113	2015	OBSOLETE	
Pushbutton	TL1100BF260Q	P001114	2015	OBSOLETE	
Pushbutton	TL1100HF260Q	P001163		OBSOLETE	L = 8.8mm
Pushbutton	TL1100F850Q	P001177		OBSOLETE	
Pushbutton	TL1100E4.554PLUNGER	P001200		OBSOLETE	SEE P001113
Pushbutton	TL1100CF160Q.08BLK	XD0038A		OBSOLETE	SEE XP0038A
Pushbutton	TL1100C.08BLK	XD0374A		OBSOLETE	
Pushbutton	TL1100CF160Q.08GRY	XD0389A		OBSOLETE	
Pushbutton	TL1100CF160Q4JRED	XD0394A		OBSOLETE	SEE MASTER COMMENTS
Pushbutton	TL1100CF160Q4JGRY	XD0395A		OBSOLETE	SEE MASTER COMMENTS
Pushbutton	TL1100AF160R220CBLK	XD0397A		OBSOLETE	
Pushbutton	TL1100AF160R220CBLK	XD0397P		OBSOLETE	
Pushbutton	TL1100AF160Q220CBLK	XD0399A		OBSOLETE	
Pushbutton	TL1100CF160SJBK	XP0091A		OBSOLETE	(SEE XP0091P)
Pushbutton	TL1100CF160Q6JBK	XP0100P		OBSOLETE	SEE XP0100A
Pushbutton	TL1100CF260Q.08RED	XP0225A		OBSOLETE	
Pushbutton	TL1100F160QTA2800BLK	XP0272A		OBSOLETE	
Pushbutton	TL1101F160Q	P001098		OBSOLETE	
Pushbutton	TL1103W	E011W03		OBSOLETE	
Pushbutton	TL1103E4.554PLUNGER	P001097		OBSOLETE	L = 4.554mm
Pushbutton	TL1105AF500QYELSTEM	D300104		OBSOLETE	
Pushbutton	TL1105DF160QWHTACTUATOR	D310025		OBSOLETE	
Pushbutton	TL1105BF160QRED	D310044		OBSOLETE	RED ACTUATOR
Pushbutton	TLE1105PF160Q	D310111		OBSOLETE	
Pushbutton	TLE1105AF100Q	D310116		OBSOLETE	
Pushbutton	TLE1105GF250Q	D310117		OBSOLETE	
Pushbutton	TLE1105HF160Q	D310119		OBSOLETE	
Pushbutton	TLE1105LF250Q	D310123		OBSOLETE	
Pushbutton	GOLDDOMETL1100OP160	D310199		OBSOLETE	
Pushbutton	TL1105JF160QSSDOMEBLKA	D320202		OBSOLETE	
Pushbutton	TL1105AF500QBLKSTEM	D330104		OBSOLETE	
Pushbutton	TL1105F520QYELSTEM	D330105		OBSOLETE	
Pushbutton	TL1105F520Q	N010204		OBSOLETE	
Pushbutton	TL1105CF160Q	P010004		OBSOLETE	SEE D310004
Pushbutton	TL1105DF250Q	P010015		OBSOLETE	
Pushbutton	TL1105EF250Q	P010016		OBSOLETE	
Pushbutton	TL1105AF100Q	P010019		OBSOLETE	
Pushbutton	TL1105BF100R	P010026		OBSOLETE	(P990006 GOLD DOME)
Pushbutton	TL1105PF100Q	P010028	2017	OBSOLETE	
Pushbutton	TL1105BF160R	P010029		OBSOLETE	(P990005)
Pushbutton	TL1105CF160QSPICIAL	P010031		OBSOLETE	BLACK ACTUATOR
Pushbutton	TL1105AF100R	P010036		OBSOLETE	
Pushbutton	TL1105LF160RREDSTEM	P010039		OBSOLETE	(P990005 GOLD DOME)
Pushbutton	TL1105DF160RREDSTEM	P010040		OBSOLETE	(P990005 GOLD DOME)
Pushbutton	TL1105QF100Q	P010041		OBSOLETE	
Pushbutton	TL1105JAF100R	P010047		OBSOLETE	(P990006 GOLD DOME)
Pushbutton	TL1105JAF250R	P010049		OBSOLETE	(P990004 GOLD DOME)
Pushbutton	TL1105GF250Q	P010073		OBSOLETE	SEE P010043
Pushbutton	TLE1105TF160Q	P010106		OBSOLETE	
Pushbutton	TLE1105CF250Q	P010113		OBSOLETE	
Pushbutton	TLE1105GF160Q	P010118		OBSOLETE	SEE J100118
Pushbutton	TLE1105LF250Q	P010123		OBSOLETE	SEE D310123
Pushbutton	TL1105FF160QZBRCKT	P010202		OBSOLETE	
Pushbutton	TL1105SPF250Q	P010206		OBSOLETE	
Pushbutton	TL1105YF160Q	P010208		OBSOLETE	
Pushbutton	TL1105JAF250R	P010218		OBSOLETE	
Pushbutton	TL1105RF160QZBRACKET	P010222		OBSOLETE	
Pushbutton	TL1105JAF160R	P010235		OBSOLETE	SEE P010048
Pushbutton	TL1105SF160RZBRACKET	P010302		OBSOLETE	(P990005 GOLD DOME)
Pushbutton	TL1105F160R	P010308		OBSOLETE	(P990005 GOLD DOME)
Pushbutton	TL1105SF160RUL94VO	P010388		OBSOLETE	(P990005 GOLD DOME)
Pushbutton	TL1105SF250QZBRACKET	P011300		OBSOLETE	
Pushbutton	TL1105MF250Q	P020226		OBSOLETE	
Pushbutton	TL1105NF100R	P020233		OBSOLETE	(P990006 GOLD DOME)
Pushbutton	TL1105QF250R	P156001		OBSOLETE	(P990004 GOLD DOME)
Pushbutton	TL1105SP1CGRY	XD0382A		OBSOLETE	DO NOT ORDER
Pushbutton	TL1105LF160Q1RBLK	XD0398A		OBSOLETE	
Pushbutton	TL1105SP1RBLK	XP0029A		OBSOLETE	SEE XP0053
Pushbutton	TL1105SPF160Q1RBLK	XP0053P		OBSOLETE	
Pushbutton	TL1105JAF160Q1SWHT	XP0114P		OBSOLETE	SEE XP0114A
Pushbutton	TL1105JAF160Q1SBLK	XP0165P		OBSOLETE	ORDER XP0165A
Pushbutton	TL1105NF160Q1RBLK	XP0182A		OBSOLETE	
Pushbutton	TL1105LF160Q1RBLK94VO	XP0183A		OBSOLETE	
Pushbutton	TL1105JAF160Q1DBLU	XP0187A		OBSOLETE	
Pushbutton	TL1105JAF160Q1DBLU	XP0187P		OBSOLETE	
Pushbutton	TL1105JAF160Q1RBLK	XP0189P		OBSOLETE	ORDER XP0189A
Pushbutton	TL1105JAF250R1SBLK	XP0255A		OBSOLETE	
Pushbutton	TLE1105SPF160R1DBLK	XP0296A		OBSOLETE	
Pushbutton	TLE1105SPF160R1DRED	XP0297A		OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Pushbutton	TLE1105SPF160R1RWHT	XP0305A		OBSOLETE	
Pushbutton	TL1107BF180WR	P010331		OBSOLETE	(P990007 GOLD DOME)
Pushbutton	TL1107AF180CQ	P010387		OBSOLETE	DO NOT ORDER
Pushbutton	TL1210F260Q	P010800		OBSOLETE	
Pushbutton	TL1230AF160QE	P010343		OBSOLETE	(PROCESS SEALED)
Pushbutton	TLE1230AF160QE	P010368		OBSOLETE	(PROCESS SEALED)
Pushbutton	TL1236VF160QE	P010335		OBSOLETE	(PROCESS SEALED)
Pushbutton	TL1237F100QG	P010320		OBSOLETE	
Pushbutton	TLE1237F100QG	P010322		OBSOLETE	
Pushbutton	TL1240WQ	P010420		OBSOLETE	
Pushbutton	TL1240R1JCLR	XP0002A		OBSOLETE	
Pushbutton	TL1240RQ1JCLR	XP0002P		OBSOLETE	
Pushbutton	TL1240R2JBLK	XP0041P		OBSOLETE	
Pushbutton	TL1240BQ1JCLR	XP0059P		OBSOLETE	SEE - XP0059A
Pushbutton	TL1240REDQ2JRED	XP0175A		OBSOLETE	(SEE XP0175P)
Pushbutton	TL1240RQ2JRED	XP0175P		OBSOLETE	SEE XP0294P
Pushbutton	TL1240Y2JRED	XP0194A		OBSOLETE	(SEE XP0194P)
Pushbutton	TL1240BICOLORSPECIAL	XP0264P		OBSOLETE	
Pushbutton	TL1240RQ2JRED	XP0294P		OBSOLETE	SEE XP0294A
Pushbutton	TL1240BQ2JBLK	XP0314P		OBSOLETE	SEE - XP0314A
Pushbutton	TL1240WQ1JCLR	XP0315P		OBSOLETE	
Pushbutton	TL1250F280WRN	P010824	2018	OBSOLETE	(GOLD DOME P990004)
Pushbutton	TL1250F180ARN	P010840	2018	OBSOLETE	(GOLD DOME P990005)
Pushbutton	TL1250F180RQN	P010855	2018	OBSOLETE	(LED Z000011)
Pushbutton	TL1250F280AQRBLK	P010856	2018	OBSOLETE	
Pushbutton	TL1250F280YQRCCLR	P010859	2018	OBSOLETE	
Pushbutton	TL1260GYQC3CG2CPWRVERT	B200054		OBSOLETE	
Pushbutton	TL1260GYQC3CG2CPWRHORIZ	B200055		OBSOLETE	
Pushbutton	TL1260BQC3CG2CIDVERT	B200056		OBSOLETE	
Pushbutton	TL1260BQC3CG2CIDHORIZ	B200057		OBSOLETE	
Pushbutton	TL1290AF400BR	B210000		OBSOLETE	
Pushbutton	TL1290AF400RR	B210001		OBSOLETE	
Pushbutton	TL1290AF400GR	B210002		OBSOLETE	
Pushbutton	TL1290AF400WR	B210003		OBSOLETE	
Pushbutton	TL1290AF400GRR	B210004		OBSOLETE	(BI-COLOR-GRN/RED)
Pushbutton	TL1290AF400GYR	B210005		OBSOLETE	
Pushbutton	TL1290AF400YR	B210006		OBSOLETE	
Pushbutton	TL1290AF400NR	B210007		OBSOLETE	
Pushbutton	TL1290AF400BARSPECIAL	B210008		OBSOLETE	
Pushbutton	TL22CISCO	XP0192A		OBSOLETE	
Pushbutton	TL22CISCO	XP0192P		OBSOLETE	
Pushbutton	TL2201OAYBGF250	P010359		OBSOLETE	
Pushbutton	TL2201OAYAW/CLICK	P010364	2017	OBSOLETE	
Pushbutton	TL2201EEYAE	P010708		OBSOLETE	WITH EPOXY
Pushbutton	TL2201OAYAEWITHEPOXY	P010776		OBSOLETE	
Pushbutton	TL2201EEZA1CBLK	XP0008A		OBSOLETE	(LATCHING)
Pushbutton	TL2201EEXA1DFWHT	XP0019A		OBSOLETE	
Pushbutton	TL2201EEXA1CFRED	XP0069A		OBSOLETE	
Pushbutton	TL2201OAXA1CFBLK	XP0097A		OBSOLETE	
Pushbutton	TL2201EEXA1DFWHT	XP0136A		OBSOLETE	
Pushbutton	TL2201OAXA1CFGRY	XP0143A		OBSOLETE	
Pushbutton	TL2201OAXA1CFRED	XP0168A		OBSOLETE	
Pushbutton	TL2201OAXA1CFBLU	XP0169A		OBSOLETE	
Pushbutton	TL2201EEXA1CFGRY	XP0198A		OBSOLETE	
Pushbutton	TL2201EEXB1CFGRY	XP0210A		OBSOLETE	
Pushbutton	TL2201EEYB.094GRY	XP0246A		OBSOLETE	
Pushbutton	TL2201OAYB.094GRY	XP0247A	2013	OBSOLETE	procure switch TL2201OAYB and cap 320.09Gry (B043502) seperately
Pushbutton	TL2201OAYA8JBLK	XP0262A		OBSOLETE	
Pushbutton	TL2201OAYA8JBLK	XP0262P		OBSOLETE	
Pushbutton	TL2201OAXA1DFBLK	XP0269A		OBSOLETE	
Pushbutton	TL2201EEXA1DFDGR	XP0270A		OBSOLETE	
Pushbutton	TL2201OAZA1RDGR	XSP001P		OBSOLETE	
Pushbutton	TL2202OAYA4JBLK	XP0303A		OBSOLETE	
Pushbutton	TL2202EEYA4JBLK	XP0304A	2020	OBSOLETE	
Pushbutton	TL2203OAF250	D300605	2012	OBSOLETE	reference active drawing for slight cosmetic differences
Pushbutton	TL2203EEF250Q	D300608	2013	OBSOLETE	No replacement
Pushbutton	TL2203EEF150Q	D310404	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Pushbutton	TL2203EEF180	D310406	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Pushbutton	TL2203OAF180	D310407	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Pushbutton	TL2203OA	P010407	2015	OBSOLETE	no sales so no longer producing
Pushbutton	TL2230OAF100Q	D310403	2013	OBSOLETE	reference active drawing for slight cosmetic differences
Pushbutton	TL2230EEF200Q	D310408	2013	OBSOLETE	replacement has 230 gram force
Pushbutton	TL2230OAF200Q	D310409	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Pushbutton	TL2230OAF140R	D310420	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Pushbutton	TL2230OAF230	P010409		OBSOLETE	
Pushbutton	TL2230EEF1001DBLK	XD0370A		OBSOLETE	DO NOT ORDER
Pushbutton	TL2230EEF1001DRED	XD0371A		OBSOLETE	DO NOT ORDER
Pushbutton	TL2230EEF1001CBLK	XD0372A	2013	OBSOLETE	Cap not compatible with switch, use std. base switch TL2230EEF100 (P010402)
Pushbutton	TL2230OAF1001CBLK	XD0373A	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Pushbutton	TL2230EEF200Q1CLGR	XD0391A	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Pushbutton	TL2230OAF200Q1CLGR	XD0392A	2013	OBSOLETE	Cap not compatible with switch, use std. base switch TL2230OAF100 (P010403)
Pushbutton	TL2230OAF1401CBLK	XP0103A		OBSOLETE	DO NOT SELL
Pushbutton	TL2230EEF1401DRED	XP0176A		OBSOLETE	OBSOLETE
Pushbutton	TL2230OAF1401DBLK	XP0239A		OBSOLETE	
Pushbutton	TL2230EEF200Q1CLGR	XSP002P		OBSOLETE	
Pushbutton	TL2230OAF200Q1CLGR	XSP003P		OBSOLETE	
Pushbutton	TL2253ABF160Q	P010412		OBSOLETE	
Pushbutton	TL2285OAF200	D310450	2013	OBSOLETE	use std. part TL2285OA (Q228500)
Pushbutton	TL2285EE300Q	D310453	2013	OBSOLETE	use std. part TL2285EE (Q228501) , this is 300 gram force
Pushbutton	TL2285EE	P010451		OBSOLETE	NOT AVAILABLE
Pushbutton	TL2285OAWITHCLICK	P010452		OBSOLETE	
Pushbutton	TL2285EE1SBLK	XP0170A		OBSOLETE	NOT AVAILABLE
Pushbutton	TL2285OA1SBLK	XP0193A		OBSOLETE	
Pushbutton	TL2285OA1CWHT	XP0223A		OBSOLETE	CAP DOESN'T FIT PROPERLY
Pushbutton	TL2285OA1CRED	XP0224A		OBSOLETE	CAP DOESN'T FIT PROPERLY
Pushbutton	TL2285OA1CBLU	XP0230A		OBSOLETE	CAP DOESN'T FIT PROPERLY
Pushbutton	TL2285OAF1801DDGR	XP0240A		OBSOLETE	NOT AVAILABLE
Pushbutton	TL2285OA1DRED	XP0263A		OBSOLETE	CAP DOESN'T FIT PROPERLY
Pushbutton	TL2286OAF200Q	P010500	2013	OBSOLETE	No Replacement
Pushbutton	TL2286EEF200Q	P010501	2013	OBSOLETE	No Replacement
Pushbutton	TL2286AEEF200Q	P010511	2013	OBSOLETE	No Replacement
Pushbutton	TL2301TQ2301	E230001		OBSOLETE	
Pushbutton	TL2801TP2801	E280001		OBSOLETE	
Pushbutton	TL3240F160G	N324001	2019	OBSOLETE	Replaced by N324022
Pushbutton	TL3240F160B	N324002	2019	OBSOLETE	Replaced by N324023
Pushbutton	TL3240F100R	N324003	2019	OBSOLETE	Replaced by N324024
Pushbutton	TL3240F100G	N324004	2019	OBSOLETE	Replaced by N324025
Pushbutton	TL3240F100B	N324005	2019	OBSOLETE	Replaced by N324026
Pushbutton	TL3240F260R	N324006	2019	OBSOLETE	Replaced by N324027
Pushbutton	TL3240F260G	N324007	2019	OBSOLETE	REPLACED BY N324016
Pushbutton	TL3240F260B	N324008	2019	OBSOLETE	REPLACED BY N324017
Pushbutton	TL3240F160Y	N324009	2019	OBSOLETE	Replaced by N324028
Pushbutton	TL3240F100Y	N324010	2019	OBSOLETE	Replaced by N324029
Pushbutton	TL3240F260Y	N324011	2019	OBSOLETE	Replaced by N324030
Pushbutton	TL3240F160GYHF	N324015	2017	OBSOLETE	SPECIAL
Pushbutton	TL3301LF160QG (BULK)	D310533		OBSOLETE	
Pushbutton	TL3301CF250RG	D310629		OBSOLETE	(SEE D310519) (D990004)
Pushbutton	TL3301CF160QGBULK	P010502		OBSOLETE	
Pushbutton	TL3301CF160QG	P010503		OBSOLETE	
Pushbutton	TL3301FF160QGBULK	P010505		OBSOLETE	
Pushbutton	TL3301CF100RJ	P010506		OBSOLETE	(P990006 GOLD DOME)
Pushbutton	TL3301NF100QG	P010524		OBSOLETE	
Pushbutton	TL3301FF260QG	P010532		OBSOLETE	
Pushbutton	TL3301FF160QG	P010533		OBSOLETE	
Pushbutton	TL3301CF260QJ	P010540		OBSOLETE	
Pushbutton	TL3301PF160QG	P010594		OBSOLETE	TUBE
Pushbutton	TL3301SPF100RG	P010608		OBSOLETE	(TUBE PACK)
Pushbutton	TL3301DF100QG	P010614		OBSOLETE	
Pushbutton	TL3301CF260QJ	P010617		OBSOLETE	
Pushbutton	TL3301AF100RG	P010620		OBSOLETE	1200 PER REEL
Pushbutton	TL3301DF100RG	P010629		OBSOLETE	
Pushbutton	TL3301BF160QJ	P010650		OBSOLETE	
Pushbutton	TL3301BF100QG	P010687		OBSOLETE	
Pushbutton	TL3301EF260QJ	P010689		OBSOLETE	
Pushbutton	TL3301BF160RG	P010692		OBSOLETE	TAPE & REEL
Pushbutton	TL3301TF160QG	P010784		OBSOLETE	SEE D310784
Pushbutton	TL3301SPF160QGTUBE	P010785		OBSOLETE	
Pushbutton	TL3301TF260QGTUBE	P010787		OBSOLETE	SEE D310787
Pushbutton	TL3301SPF160QG	P010793		OBSOLETE	TAPE & REEL
Pushbutton	TL3301TF160RG	P010797		OBSOLETE	SEE D310792
Pushbutton	TL3301SPF260QJ	P010826		OBSOLETE	SEE D310826
Pushbutton	TL3301SPF160QG1RBLK	XD0403A		OBSOLETE	
Pushbutton	TL3301SPF160QG1RBLK	XP0213A		OBSOLETE	
Pushbutton	TL3303F100QG	P010427		OBSOLETE	DUPLICATE SEE P010425
Pushbutton	TL3303F160QGSSDOME	P010430		OBSOLETE	
Pushbutton	TLE3303F160RG	P010527		OBSOLETE	(GOLD CONTACTS)P990005
Pushbutton	TLE3303AF260QG	P010657		OBSOLETE	(RED ACTUATOR)
Pushbutton	TL3304NF160QJ	P010542		OBSOLETE	
Pushbutton	TL3310F100QG	L900000		OBSOLETE	
Pushbutton	TL3310F200QG	L900001		OBSOLETE	
Pushbutton	TL3320BF160Q	D320006	2008	OBSOLETE	SEE D320010
Pushbutton	TL3326AF100	P010547		OBSOLETE	
Pushbutton	TL3342F120QG	P010591		OBSOLETE	TAPE & REEL
Pushbutton	TL3342F160QG	P010595		OBSOLETE	TAPE & REEL
Pushbutton	TL3342F160QG	P010596		OBSOLETE	500K LIFE CYCLE
Pushbutton	TL3342F260RG	P010621		OBSOLETE	
Pushbutton	TL3350AF100Q	P010685		OBSOLETE	
Pushbutton	TL3700AF160QG	P003000	2019	OBSOLETE	(M)
Pushbutton	TL3700AF100QG	P003001	2019	OBSOLETE	(M)
Pushbutton	TL3750AF100QG	P003100	2017	OBSOLETE	SEE P003022



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Pushbutton	TL3750AF180QG	P003101	2017	OBSOLETE	SEE P003023
Pushbutton	TL3750AF240QG	P003102	2017	OBSOLETE	SEE P003020
Pushbutton	TL3901TP2901	E350000		OBSOLETE	
Pushbutton	TL4201OAZA	P010882		OBSOLETE	
Pushbutton	TL4201EEXB1CFDGR	XP0208A		OBSOLETE	
Pushbutton	TL5100BODYGRY	BECG101		OBSOLETE	
Pushbutton	TL5100BLKCAP	BECG201		OBSOLETE	
Pushbutton	TL53CF160QUL94VO	P010630		OBSOLETE	
Pushbutton	TL53F160Q	P010649		OBSOLETE	
Pushbutton	TL53HNONE	P010910		OBSOLETE	
Pushbutton	5XTL56CF100QA	D300011		OBSOLETE	
Pushbutton	4XTL56BF160Q	J021105		OBSOLETE	
Pushbutton	6XTL56CF160Q	P010576		OBSOLETE	
Pushbutton	3XTL56BF160Q10MM	P200010		OBSOLETE	
Pushbutton	5XTL56CF100QA	P200011		OBSOLETE	
Pushbutton	TL58VF100Q	P010580		OBSOLETE	(SEE P010583 FOR RP)
Pushbutton	TL58XF260Q	P010639		OBSOLETE	
Pushbutton	TL58VF260Q	P010647		OBSOLETE	
Pushbutton	TL59FF160QWHITESTEM	D310569		OBSOLETE	
Pushbutton	TL59EF100QSPECIAL	D310570		OBSOLETE	
Pushbutton	TL59EF100QBULK	D310575		OBSOLETE	
Pushbutton	TL59TF160Q	D310587		OBSOLETE	SEE P010570
Pushbutton	TL59FF100Q7.0MMSTEM	D310611		OBSOLETE	
Pushbutton	HTL59F160Q	H010200		OBSOLETE	
Pushbutton	TL59BF160Q	P010567		OBSOLETE	SEE J100567
Pushbutton	TL59BF260Q	P010568		OBSOLETE	
Pushbutton	TL59TF160Q	P010570		OBSOLETE	
Pushbutton	TL59AF100QBULK	P010598		OBSOLETE	
Pushbutton	TL59FF100Q7.0MMSTEM	P010611		OBSOLETE	
Pushbutton	TL53HF160QUL94VO	P010624		OBSOLETE	
Pushbutton	TL59AF260QWIREASSEMBLY	XD0401P		OBSOLETE	(D310621)
Pushbutton	TL59AF260QWIREASSEMBLY	XD0404P		OBSOLETE	NO CONTACTS
Pushbutton	TL6304AF160RG	D310702		OBSOLETE	
Pushbutton	TL6304BF160RG	D310703		OBSOLETE	
Pushbutton	TL6304AF160QJ	D310705		OBSOLETE	
Pushbutton	TL6304BF300QG	D310739		OBSOLETE	
Pushbutton	TL6304BF160QJ	D310743		OBSOLETE	
Pushbutton	TL6304BF200QJ	D310744		OBSOLETE	
Pushbutton	TL6304CF300QGSSDOMEDOME	D310745		OBSOLETE	
Pushbutton	TL6304CF160QGSSDOMEDOME	D310746		OBSOLETE	
Pushbutton	TL6304NF300QJ	D310747		OBSOLETE	
Pushbutton	TL6304GF160Q	J100118	2018	OBSOLETE	
Pushbutton	TL2201EEXA1CFWHT	XA1737A		OBSOLETE	
Pushbutton	TSSPOAWCRGR	B893001		OBSOLETE	
Pushbutton	TSSPHLUNGER	B894000		OBSOLETE	
Pushbutton	TSSPHDIFFUSER	B894001		OBSOLETE	
Pushbutton	TSSPHCLEARLENS	B894002		OBSOLETE	
Pushbutton	TSSPHCAPASSEMBLY	B894010		OBSOLETE	
Pushbutton	TT4400F160GS	L400400		OBSOLETE	
Pushbutton	TT4405F160QG	L400401		OBSOLETE	
Pushbutton	ULP12EEM1QSSCL1BLURED	B800002		OBSOLETE	
Pushbutton	ULP12OAM1RSSCL1GRNRED	B800003		OBSOLETE	
Pushbutton	ULP22EEP1QSSCL1REDNIL	B800004	2019	OBSOLETE	Lack of activity
Pushbutton	ULP12OAP1RSSCL1BLURED	B800005	2019	OBSOLETE	
Pushbutton	ULP22OAP1QSSCL1GRNRED	B800007	2019	OBSOLETE	Lack of activity
Pushbutton	ULP22OAP1RSSCL1GRNRED	B800008	2019	OBSOLETE	Lack of activity
Pushbutton	ULP22EEP1RSSCL1GRNRED	B800009	2019	OBSOLETE	Lack of activity
Pushbutton	ULP22EEP1RSSCL1GRNRED SPECIAL	B800010	2019	OBSOLETE	Lack of activity
Pushbutton	ULP22EEP1RSSCL1GRNNIL	B800011	2019	OBSOLETE	Lack of activity
Pushbutton	ULP12OAP1RSSCL1NILNIL	B800012	2019	OBSOLETE	
Pushbutton	ULP12EEP1QSSCL1REDGRN	B800014	2019	OBSOLETE	
Pushbutton	ULP22OAM1QPMCL1BLURED	B800018	2019	OBSOLETE	Lack of activity
Pushbutton	ULP12EEP1RSSCL1BLUGRN	B800019	2019	OBSOLETE	
Pushbutton	ULP12OAP1RSSCL1BLUNIL	B800020	2019	OBSOLETE	
Pushbutton	ULP12OAP1QSSCL1YELNIL	B800021	2019	OBSOLETE	
Pushbutton	ULP22OAP1QSSCL1YELVEL	B800024	2019	OBSOLETE	Lack of activity
Pushbutton	ULP12OAP1RSSCL1REDNIL	B800025	2019	OBSOLETE	
Pushbutton	ULP12OAP1RSSCL1GRNNIL	B800026	2019	OBSOLETE	
Pushbutton	ULP22EEP1RSSCL1WHTRED	B800028	2019	OBSOLETE	Lack of activity
Pushbutton	ULP12OAP1QSSCL1NILNIL	B800030	2019	OBSOLETE	
Pushbutton	ULP12EEP1QSSCL1GRNNIL	B800031	2019	OBSOLETE	
Pushbutton	ULP12OAM1RPMCL1YELPGRN	B800034	2019	OBSOLETE	
Pushbutton	ULP12OAP1RSFCL1YELGRN	B800035	2019	OBSOLETE	
Pushbutton	ULP12OAP1RSFCL1REDPGRN	B800036	2019	OBSOLETE	
Pushbutton	ULP12OAP1RSFCL1YELPGRN	B800037	2019	OBSOLETE	
Pushbutton	ULP12EEP1RSSCL1BLU1GRN3	B800050	2019	OBSOLETE	Lack of activity
Pushbutton	ULP22OAP1QRFL1REDGRN	B800051	2019	OBSOLETE	Lack of activity
Pushbutton	ULP22OAP1QSFL1REDGRN	B800052	2019	OBSOLETE	Lack of activity
Pushbutton	ULP12OAP1RSFCL1NILNIL	B800054	2019	OBSOLETE	Lack of activity
Pushbutton	ULP22OAP1RRFL1NILNIL	B800055	2019	OBSOLETE	Lack of activity



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Pushbutton	ULP22EEM1QPMCL1BLURED	B800056	2019	OBSOLETE	Lack of activity
Pushbutton	ULP22OAM1RPMCL1REDBLU	B800057	2019	OBSOLETE	Lack of activity
Pushbutton	ULP12OAPQSSCL1REDGRN	B800059	2019	OBSOLETE	Lack of activity
Pushbutton	ULP12OAP1QSFL1BLUNIL	B800061	2019	OBSOLETE	Lack of activity
Pushbutton	ULP12EEP1QSCL1RGB	B800062	2019	OBSOLETE	Lack of activity
Pushbutton	ULP12OAM1QPMCL1REDNIL	B800065	2019	OBSOLETE	Lack of activity
Pushbutton	ULP22OAP1QSSOP1NILNIL	B800066	2019	OBSOLETE	Lack of activity
Pushbutton	ULP22EEP1RSFCL1YELRED	B800067	2019	OBSOLETE	Lack of activity
Pushbutton	ULP22EEP1QSFL1YELRED	B800068	2019	OBSOLETE	Lack of activity
Pushbutton	ULP12OAP1RSOP1NILNIL	B800100	2019	OBSOLETE	Lack of activity
Pushbutton	ULP12OAP1QSFL1REDGRN	B810000	2019	OBSOLETE	Lack of activity
Pushbutton	ULP12OAP1QLSCL1REDGRN	B810010	2019	OBSOLETE	Lack of activity
Pushbutton	ULP12OAP1QRFL1REDGRN	B810020	2019	OBSOLETE	Lack of activity
Pushbutton	ULP12EEP1QPMCL1REDGRN	B810031	2019	OBSOLETE	Lack of activity
Pushbutton	ULP12OAP1QSFL1BLUBLU	B810036	2019	OBSOLETE	Lack of activity
Pushbutton	ULP12OAP1QPMCL1REDYEL	B810037		OBSOLETE	
Pushbutton	ULP12OAP1QPMCL1GRNNIL	B810038		OBSOLETE	
Pushbutton	ULP12OAM1QPMOP1NILNIL	B810039	2019	OBSOLETE	Lack of activity
Pushbutton	ULP12OAM1RPMCL1BLURED	B810042	2019	OBSOLETE	Lack of activity
Pushbutton	WT1105VF220100RGOLD	P010370		OBSOLETE	(P010199 GOLD DOME)
Pushbutton	P16OAT12	F040501		OBSOLETE	
Pushbutton	5001001IP65SPRAYCOVER	F050100		OBSOLETE	DUPLICATE SEE F051001
Pushbutton	DO NOT ORDER	F053211		OBSOLETE	50012110
Pushbutton	MDP16OAT41R	F084100		OBSOLETE	
RA1066	RA1066CFH	P300108		OBSOLETE	
RA1066	RA1066CFK	P300109		OBSOLETE	
RA1066	RA1066CFX	P300110		OBSOLETE	
RA1066	RA1066ASX	P300200		OBSOLETE	
RA1066	RA1066ASF	P300206		OBSOLETE	
RA1066	RA1066ASH	P300208		OBSOLETE	
RA1066	RA1066CSX	P300300		OBSOLETE	
RA1066A	RA1066ASPACTSIDEWHT	P300212		OBSOLETE	
RA1066C	RA1066CSH	P300308		OBSOLETE	
RA1066C	RA1066CSRX	P300312		OBSOLETE	
RC1073	RC1073X	P301000		OBSOLETE	SEE P301500
RC1073	RC1073A	P301001		OBSOLETE	SEE P301501
RC1073	RC1073B	P301002		OBSOLETE	SEE P301502
RC1073	RC1073C	P301003		OBSOLETE	SEE P301503
RC1073	RC1073F	P301006		OBSOLETE	(SEE P301504)
RC1073	RC1073H	P301008		OBSOLETE	SEE P301505
RC1073	RC1073J	P301010		OBSOLETE	SEE P301506
RC1073	RC1073K	P301011		OBSOLETE	SEE P301508
RC1083	RC1083BBLKBLKLF	P301501	2020	OBSOLETE	OBSOLETE
RC1083	RC1083BBLKBLKLF	P301502		OBSOLETE	OBSOLETE
RC1083	RC1083BBLKBLKIF	P301504		OBSOLETE	
RC1083	RC1083BBLKBLKFF0	P301507		OBSOLETE	(SEE P301508)
RC1083	RC1083BBLKBLKIS0	P301510		OBSOLETE	
RC1083	RC1083BBLKBLKIPO	P301511		OBSOLETE	(SEE MASTER COMMENTS)
RC1083	RC1083BWHWHTWHTF	P301513		OBSOLETE	
RC1083	RC1083BWHWHTWHTIF	P301514		OBSOLETE	
RC1083	RC1083BGRYGRYEFO	P301515		OBSOLETE	
Rocker	400CWMDP1R1BLKM61QE	T450100		OBSOLETE	
Rocker	1201-M2S3AV2QE2	17-1201M2S3AV2QE2		OBSOLETE	
Rocker	300AWSP1J1GRVVS2QE	T301016	2017	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Rocker	300AWSP1J1BLKM75QE	T301019	2017	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Rocker	300AWSP1J1VS2REIO	T301021	2017	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Rocker	300AWDP1J1VS2RE	T301022	2017	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Rocker	300AWSP1J5M7QE	T301023	2017	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Rocker	300AWSP4J2WHTM2RE	T301034	2017	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Rocker	300AWDP1J1BLKM7RE	T301040	2017	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Rocker	300AWSP3J5M7QE	T301041	2017	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Rocker	300AWSP1J1VS21RE	T301051	2017	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Rocker	300AWSP1J1BLKM6RE	T301053	2017	OBSOLETE	See T301029
Rocker	300AWSP4J2WHTM1QE	T301401	2017	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Rocker	300AWSP4J4WHTM1QE	T301402	2017	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Rocker	300AWSP4J6WHTM1QE	T301403	2017	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Rocker	300AWSP4J3VS2R	T301404	2017	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Rocker	300AWSP5J6VS2RE	T301502	2017	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Rocker	300AWDP7R2BLKM1QE	T302020	2017	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Rocker	300AWDP8R2BLKM1QE	T302021	2017	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Rocker	300AWDP2J6BLKVS3QE	T302022	2019	OBSOLETE	Lack of sales
Rocker	300AWDP1J4BLKM3QE	T302106	2017	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Rocker	300AWDP3J3M6QE	T302107	2019	OBSOLETE	No activity
Rocker	300AWDP3R1M3Q	T302109	2017	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Rocker	300AWDP4R1M2QE	T302412	2017	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Rocker	400MSP1R1REDM7QE	T411014		OBSOLETE	
Rocker	400MSP1R6BLKVS2QE	T411028		OBSOLETE	
Rocker	400MSP3R1BLKM71QE	T413113		OBSOLETE	CRIMPED
Rocker	400MSP4R6BLKVS21RE	T414004		OBSOLETE	
Rocker	400MSP4R1BLKM7QE	T414103		OBSOLETE	SEE - M414013



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Rocker	400MSP5R1BLKM7QE	T415013		OBSOLETE	
Rocker	400MSP6R6BLKM6RE	T416011		OBSOLETE	
Rocker	400MSP6R1BLKM7QE	T416013		OBSOLETE	
Rocker	400MSP6R1WHTM6QE	T416111		OBSOLETE	
Rocker	400MSP6R1BLKM71QE	T416113		OBSOLETE	CRIMPED
Rocker	400AWMDP1R1BLKVS2RE	M450306		OBSOLETE	SEE - T450306
Rocker	400AWMDP5R1BLKVS2RE	T403005		OBSOLETE	
Rocker	400AWMDP5R1BLKVSSCBRE	T403006		OBSOLETE	
Rocker	400AWMDP3R1M6RE	T450302		OBSOLETE	
Rocker	5101-LT2ZQE	17-5101LT2ZQE		OBSOLETE	
Rocker	5101-MDZQE	17-5101MDZQE		OBSOLETE	
Rocker	5101-PSD9ABE	17-5101PSD9ABE		OBSOLETE	
Rocker	5101-SYZQE	17-5101SYZQE		OBSOLETE	
Rocker	5103-J1ABE2	17-5103J1ABE2		OBSOLETE	
Rocker	5107-SYZQE	17-5107SYZQE		OBSOLETE	
Rocker	5108-SYZQE	17-5108SYZQE		OBSOLETE	
Rocker	5201-J61Z3QE22	17-5201J61Z3QE22		OBSOLETE	
Rocker	5201-SYZQE	17-5201SYZQE		OBSOLETE	
Rocker	5303-SYZQE	17-5303SYZQE		OBSOLETE	
Rocker	8161-J81ZGE22	17-8161J81ZGE22		OBSOLETE	
Rocker	8161-SH9ABE	17-8161SH9ABE		OBSOLETE	
Rocker	8161-SHZGE	17-8161SHZGE		OBSOLETE	
Rocker	8261-J81ZGE22	17-8261J81ZGE22		OBSOLETE	
Rocker	8261-J81ZQE22	17-8261J81ZQE22		OBSOLETE	
Rocker	R13405A	F130405		OBSOLETE	
Rocker	R1349BREDWHTDOT	F130407		OBSOLETE	ACTUATOR=RED w/WHT DOT
Rocker	R13508ALRED	F130508		OBSOLETE	
Rocker	R13508ALAMBER	F130510		OBSOLETE	
Rocker	R1966ABLKBLKIPGRN	M300002	2017	OBSOLETE	
Rocker	R1966ABLKBLKHF	M300003	2017	OBSOLETE	
Rocker	R1966CBKBLKSPF	M300004	2017	OBSOLETE	
Rocker	R1966ABLKBLKAG	M300005	2017	OBSOLETE	
Rocker	R1966ABLKBLKF	M300006	2017	OBSOLETE	
Rocker	R1966ABLKWHTESYEL	M300009	2017	OBSOLETE	(W/GOLD CONTACTS)
Rocker	R1966ABLKREDESRED	M300010	2017	OBSOLETE	(GOLD CONTACTS)
Rocker	R1966ABLKBLKAS	M300011	2017	OBSOLETE	
Rocker	R1966ABLKBLKFR	M300012		OBSOLETE	(GOLD CONTACTS)
Rocker	R1966ABLKREDIG	M300013	2017	OBSOLETE	
Rocker	R1966ABLKBLKFF	M300015	2017	OBSOLETE	(w/Gold Contacts)
Rocker	R1966HBLKREDEL	M300016	2017	OBSOLETE	
Rocker	R1966ABLKBLKEFR	M300100		OBSOLETE	SEE M309200
Rocker	R1966ABLKBLKPEYEL	M300103	2017	OBSOLETE	
Rocker	R1966ABLKBLUEPGRN	M300300		OBSOLETE	DO NOT ORDER
Rocker	R1966ABLKGRYEPGRN	M301104	2017	OBSOLETE	
Rocker	R1966ABLKBLKFF	M301105	2017	OBSOLETE	
Rocker	R1966ABLKBLKISRED	M301107	2017	OBSOLETE	
Rocker	R1966AWHTWHTFRED	M301108	2017	OBSOLETE	
Rocker	R1966AWHTWHTESGRN	M301110	2017	OBSOLETE	
Rocker	R1966AWHTWHTAFBLKDOT	M301113	2017	OBSOLETE	
Rocker	R1966ABLKWHTE	M301114	2017	OBSOLETE	
Rocker	R1966AWHTWHTWC	M301116	2017	OBSOLETE	
Rocker	R1966ABLKREDESRED	M301117	2017	OBSOLETE	RED LED
Rocker	R1966ABLKGRYESYEL	M301118	2017	OBSOLETE	
Rocker	R1966ABLKBLKESGRSTANDBY	M301121	2017	OBSOLETE	SYMBOL***
Rocker	R1966AWHTWHTFGRN	M301122	2017	OBSOLETE	
Rocker	R1966ABLKWHHTFFGRN	M301123	2017	OBSOLETE	
Rocker	R1966ABLKWHTEFO	M301134	2017	OBSOLETE	
Rocker	R1966ABLKBLKEL	M301135	2017	OBSOLETE	
Rocker	R1966AWHTWHTESRED	M301151	2017	OBSOLETE	
Rocker	R1966AWHTWHTEPGRN	M301152	2017	OBSOLETE	
Rocker	R1966ABLKWHTEPGRN	M301153	2017	OBSOLETE	
Rocker	R1966ABLKBLKIR	M301200	2017	OBSOLETE	
Rocker	R1966ABLKBLKES	M301203		OBSOLETE	(SEE M301211)
Rocker	R1966AGRYGRYGF	M301219	2017	OBSOLETE	
Rocker	R1966ABLKBLKIFRED	M301225	2017	OBSOLETE	
Rocker	R1966AWHTWHTGTF	M301226	2017	OBSOLETE	
Rocker	R1966JBLKBLKHR	M301227	2017	OBSOLETE	
Rocker	R1966HWHTWHTF	M301233	2017	OBSOLETE	
Rocker	R1966AWHTWHTIF	M301235	2017	OBSOLETE	
Rocker	R1966HBLKBLKHS	M301237	2017	OBSOLETE	
Rocker	R1966AWHTWHTAF	M301239	2017	OBSOLETE	
Rocker	R1966AWHTWHTLF	M301240	2017	OBSOLETE	
Rocker	R1966HBLKBLKEL	M301241	2017	OBSOLETE	
Rocker	R1966AWHTBLKGS	M301251	2017	OBSOLETE	
Rocker	R1966AWHTWHTIR	M301252	2017	OBSOLETE	
Rocker	R1966EBLKREDF	M301253	2017	OBSOLETE	
Rocker	R1966GBLKBLKES	M301254	2017	OBSOLETE	
Rocker	R1966EBLKREDEF	M301255	2017	OBSOLETE	
Rocker	R5JBLKBLKEFO	M301256		OBSOLETE	OBSOLETE
Rocker	R5JBLKWHTFO	M301260		OBSOLETE	OBSOLETE



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Rocker	R1966HBLKREDCF	M301261		OBSOLETE	
Rocker	R1966ABLKBLKESBLU	M301270	2017	OBSOLETE	
Rocker	R1966ABLKBLKESRED	M301990	2017	OBSOLETE	GOLD CONTACTS
Rocker	R1966CBLKBLKAF	M302196	2017	OBSOLETE	
Rocker	R1966CBLKBLKES	M302201	2017	OBSOLETE	
Rocker	R1966CBLKBLKFR	M302202	2017	OBSOLETE	
Rocker	R1966CBLKBLKBP	M302206	2017	OBSOLETE	
Rocker	R1966CBLKBLKGR	M302207	2017	OBSOLETE	
Rocker	R1966CBLKBLKBS	M302208	2017	OBSOLETE	
Rocker	R1966CBLKBLKFL	M302209	2017	OBSOLETE	
Rocker	R1966CBLKBLKER	M302211	2017	OBSOLETE	
Rocker	R1966CBLKREDER	M302212	2017	OBSOLETE	
Rocker	R1966CBLKBLKIR	M302213	2017	OBSOLETE	
Rocker	R1966CGRYGRYGF	M302410	2017	OBSOLETE	
Rocker	R1966CWHTWHTFF	M302420	2017	OBSOLETE	
Rocker	R1966CBLKREDIP	M302421	2017	OBSOLETE	
Rocker	R1966CWHTWHTFS	M302422	2017	OBSOLETE	
Rocker	R1966IBLKBLKBR	M302423	2017	OBSOLETE	
Rocker	R1966HBLKBLKBR	M302424	2017	OBSOLETE	
Rocker	R1966GBLKBLKFR	M302425	2017	OBSOLETE	
Rocker	R1966IBLKBLKFR	M302426	2017	OBSOLETE	
Rocker	R1966FBLKBLKAP	M302429	2017	OBSOLETE	
Rocker	R1966IBLKWHITES	M302430	2017	OBSOLETE	
Rocker	R1966IBLKREDES	M302431	2017	OBSOLETE	
Rocker	R1966CBLKREDEF	M302432	2017	OBSOLETE	
Rocker	R1966HBLKBLKFR	M302433	2017	OBSOLETE	
Rocker	R1966FBLKBLKFS	M304204	2017	OBSOLETE	
Rocker	R1966FWHTWHTAF	M304209	2017	OBSOLETE	
Rocker	R1966GBLKGRYEF	M304210	2017	OBSOLETE	
Rocker	R1966FBLKBLKFP	M304211	2017	OBSOLETE	
Rocker	R1966FBLKBLKEP	M304212	2017	OBSOLETE	
Rocker	R1966GBLKBLKFF	M304213	2017	OBSOLETE	
Rocker	R1966FBLKREDEF	M305203	2017	OBSOLETE	
Rocker	R1966EBLKBLKES	M305205	2017	OBSOLETE	
Rocker	R1966EBLKBLKAF	M305206	2017	OBSOLETE	
Rocker	R1966CWHTWHTFFWIREASSY	M305211		OBSOLETE	250MM LEADS
Rocker	R1966CWHTWHTFFWIREASSY	M305212		OBSOLETE	750MM LEADS
Rocker	R1966FBLKBLUEF	M305213	2017	OBSOLETE	
Rocker	R1966IBLKBLKGS	M306206	2017	OBSOLETE	
Rocker	R1966GBLKREDEF	M306209	2017	OBSOLETE	
Rocker	R1966IBLKBLKBF	M306211	2017	OBSOLETE	
Rocker	R1966IBLKBLKAF	M306212	2017	OBSOLETE	
Rocker	R1966IBLKBLKHG	M306214		OBSOLETE	
Rocker	R1966AWHTWHTFEF	M306217	2017	OBSOLETE	
Rocker	R1966WHTWHTHF	M306218	2017	OBSOLETE	
Rocker	R1966ABLKGRYESGRN	M309201	2017	OBSOLETE	
Rocker	R1966ABLKREDEFGRN	M309203	2017	OBSOLETE	
Rocker	R1966ABLKREDEFRED	M309204	2017	OBSOLETE	
Rocker	R1966ABLKREDFG	M309206	2017	OBSOLETE	
Rocker	R1966ABLKWHTEFRED	M309207	2017	OBSOLETE	
Rocker	R1966ABLKWHTEFGRN	M309208	2017	OBSOLETE	
Rocker	R1966DBLKBLKER	M309307	2017	OBSOLETE	
Rocker	R1966DBLKREDER	M309309	2017	OBSOLETE	
Rocker	R1966DBLKBLKHP	M309311	2017	OBSOLETE	
Rocker	R1966AWHTWHTERGRN	M309316	2017	OBSOLETE	
Rocker	R1966EBLKBLKAS	M309318	2017	OBSOLETE	
Rocker	R1966DBLKBLKAS	M309319	2017	OBSOLETE	
Rocker	R1966DBLKREDEP	M309320	2017	OBSOLETE	
Rocker	R1966DBLKWHTBS	M309322	2017	OBSOLETE	
Rocker	R1966GBLKGRYEF	M309324		OBSOLETE	SEE - M304210
Rocker	R1966CBLKBLKER	M309325		OBSOLETE	SEE M302211
Rocker	R1966DBLKREDIP	M309326	2017	OBSOLETE	
Rocker	R1966IBLKREDHP	M309327	2017	OBSOLETE	
Rocker	R1966CGRYGRYFF	M309328	2017	OBSOLETE	
Rocker	R1966DBLKBLUIP	M309330	2017	OBSOLETE	
Rocker	R1966EBLKBLKEG	M309331	2017	OBSOLETE	
Rocker	R1966CBLKBLKFS	M309332	2017	OBSOLETE	
Rocker	R1966DBLKBLKHS	M309334	2017	OBSOLETE	W/GRNARROWS&REDDOT
Rocker	R1966CBLKBLKGP	M309335	2017	OBSOLETE	
Rocker	R1966FBLKWHTEP	M309337	2017	OBSOLETE	
Rocker	R1966EBLKBLUEP	M309338	2017	OBSOLETE	
Rocker	R1966ABLKBLKELGRN	M309339	2017	OBSOLETE	
Rocker	R1966ABLKBLKGP	M309341	2017	OBSOLETE	
Rocker	R1973ABLKREDEF3	M400027	2020	OBSOLETE	
Rocker	R1973ABLKREDEF3	M400027	2020	OBSOLETE	
Rocker	R1973ABLKRILEF4	M400028		OBSOLETE	SEE M400064
Rocker	R1973BBLKGRNEF3	M400037	2020	OBSOLETE	
Rocker	R1973BBLKGRNEF3	M400037	2020	OBSOLETE	
Rocker	R1973BBLKGRNEF4	M400038	2020	OBSOLETE	
Rocker	R1973BBLKGRNEF4	M400038	2020	OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Rocker	R1973BBLKYELEF4	M400043	2020	OBSOLETE	
Rocker	R1973BBLKYELEF4	M400043	2020	OBSOLETE	
Rocker	R1973ABLKGRNEF3	M400045		OBSOLETE	SEE M400084
Rocker	R1973BKMFF2	M400047		OBSOLETE	
Rocker	R1973ABLKGRNEF	M400053	2020	OBSOLETE	
Rocker	R1973ABLKYELEF4	M400055	2020	OBSOLETE	
Rocker	R1973ABLKYELEF4	M400055	2020	OBSOLETE	
Rocker	R1973ABLKGRNIF3	M400056	2020	OBSOLETE	
Rocker	R1973ABLKGRNIF3	M400056	2020	OBSOLETE	
Rocker	R1973AWHTGILEF3	M400062	2020	OBSOLETE	
Rocker	R1973AWHTGILEF3	M400062	2020	OBSOLETE	
Rocker	R1973ABLKRLIF3	M400077	2020	OBSOLETE	
Rocker	R1973ABLKRLIF3	M400077	2020	OBSOLETE	
Rocker	R1973BWHTGILFF4	M400087	2020	OBSOLETE	
Rocker	R1973ABLKOLBF4	M400122	2020	OBSOLETE	
Rocker	R3070AFXBLKBLKI	M530709		OBSOLETE	SEE R4 FOR REPLACEMENT
Rocker	R3070AFXBLKBLKE	M530710		OBSOLETE	SEE R4 FOR REPLACEMENT
Rocker	R3070BF1BLKREDE	M530714		OBSOLETE	SEE R4 FOR REPLACEMENT
Rocker	R3070BF1BLKREDI	M530715		OBSOLETE	SEE R4 FOR REPLACEMENT
Rocker	R3070BF4KME	M530717		OBSOLETE	SEE R4 FOR REPLACEMENT
Rocker	R3070BF4KDE	M530718		OBSOLETE	SEE R4 FOR REPLACEMENT
Rocker	R3070BF3KMF	M530719		OBSOLETE	SEE R4 FOR REPLACEMENT
Rocker	R3070BF1WHTGRNE	M530720		OBSOLETE	SEE R4 FOR REPLACEMENT
Rocker	R3070BF1WYE	M530722		OBSOLETE	SEE R4 FOR REPLACEMENT
Rocker	R3070BF1KME	M530723		OBSOLETE	SEE R4 FOR REPLACEMENT
Rocker	R3070BS1KME	M530726		OBSOLETE	SEE R4 FOR REPLACEMENT
Rocker	R3070BF3KME	M530733		OBSOLETE	SEE R4 FOR REPLACEMENT
Rocker	R3070AFXBLKREDE	M530734		OBSOLETE	SEE R4 FOR REPLACEMENT
Rocker	R3070BF1BLKREDF	M530735		OBSOLETE	SEE R4 FOR REPLACEMENT
Rocker	R3070BF4BLKGRNG	M530736		OBSOLETE	SEE R4 FOR REPLACEMENT
Rocker	R3070BF3BLKREDI	M530737		OBSOLETE	SEE R4 FOR REPLACEMENT
Rocker	R3070FFXBLKBLKF	M530743		OBSOLETE	SEE R4 FOR REPLACEMENT
Rocker	R3070CFXBLKREDE	M530744		OBSOLETE	SEE R4 FOR REPLACEMENT
Rocker	R3070DFXBLKWHTE	M530747		OBSOLETE	SEE R4 FOR REPLACEMENT
Rocker	R3070CFXBLKBLKG	M530748		OBSOLETE	SEE R4 FOR REPLACEMENT
Rocker	R3070AFXBLKREDI	M530751		OBSOLETE	SEE R4 FOR REPLACEMENT
Rocker	R3070BF4BLKYELF	M530752		OBSOLETE	SEE R4 FOR REPLACEMENT
Rocker	R3070GFXBLKBLKE	M530775		OBSOLETE	SEE R4 FOR REPLACEMENT
Rocker	R4BWHTREDREDEF2	M040127	2019	OBSOLETE	Factory no longer produces white option
Rocker	R4BLKWHTCLREF3	M040128	2019	OBSOLETE	Factory no longer produces white option
Rocker	R4ABLKWHTF0	M040131	2019	OBSOLETE	Factory no longer produces white option
Rocker	R4DBLKWHTF0	M040133	2019	OBSOLETE	Factory no longer produces white option
Rocker	R4ABLKWHTIF0	M040134	2019	OBSOLETE	Factory no longer produces white option
Rocker	R4GBLKWHTIF0	M040142	2019	OBSOLETE	Active in QAD - Factory no longer produces white option
Rocker	R4GBLKWHTHF0	M040143	2019	OBSOLETE	Factory no longer produces white option
Rocker	R4FWHTWHTF0	M040209	2019	OBSOLETE	Factory no longer produces white option
Rocker	R4GWHTWHTF0	M040210	2019	OBSOLETE	Active in QAD - Factory no longer produces white option
Rocker	R4DWHTWHTHF0	M040214	2019	OBSOLETE	Factory no longer produces white option
Rocker	R4GBLKWHTF0	M040216	2019	OBSOLETE	Active in QAD - Factory no longer produces white option
Rocker	R4BWHTWHTREF1	M041008	2019	OBSOLETE	Factory no longer produces white option
Rocker	R4BBLKBLKGRNEF4SPECIAL	M401125	2016	OBSOLETE	Can't be manufactured consistently, no replacement at this time
Rocker	R5BBLKWHTFF1	M050230	2019	OBSOLETE	Factory no longer produces white option
Rocker	R5AWHTWHTFF0	M050245	2019	OBSOLETE	Factory no longer produces white option
Rocker	R5BBLKWHTF2	M050252	2019	OBSOLETE	Factory no longer produces white option
Rocker	R5EWHTWHTFF0	M050253	2019	OBSOLETE	Factory no longer produces white option
Rocker	R5BWHTGRNFF1	M050260	2019	OBSOLETE	Factory no longer produces white option
Rocker	R5GWHTWHTHF0	M050264	2019	OBSOLETE	Factory no longer produces white option
Rocker	R5CBLKWHTF0	M050266	2019	OBSOLETE	Factory no longer produces white option
Rocker	ACC-C23-2	03-ACC232	2015	OBSOLETE	Use seal cover ACC-P01 for the active RA1 configurations
Rocker	ACC-P01	03-ACCP01	2015	OBSOLETE	Use 38-ACCP01 Silicone rubber seal cover for RA1 series rockers
Rocker	RA11131100	03-RA11131100		OBSOLETE	SEE 03-RA111A1100
Rocker	RA11131100-nr	03-RA11131100NR		OBSOLETE	
Rocker	RA11131121	03-RA11131121		OBSOLETE	SEE 03-RA111A1121
Rocker	RA11131123	03-RA11131123		OBSOLETE	SEE 03-RA111A1123
Rocker	RA1113112R	03-RA1113112R		OBSOLETE	SEE 03-RA111A112R
Rocker	RA11131185	03-RA11131185		OBSOLETE	SEE 03-RA111A1185
Rocker	RA11132200	03-RA11132200		OBSOLETE	SEE 03-RA111A2200
Rocker	RA111A1100	03-RA111A1100	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA111A1121	03-RA111A1121	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA111A1123	03-RA111A1123	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA111A112R	03-RA111A112R	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA111A1185	03-RA111A1185	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA111A2200	03-RA111A2200	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA111C1100	03-RA111C1100		OBSOLETE	SEE 03-RA111E1100
Rocker	RA111C1121	03-RA111C1121		OBSOLETE	SEE 03-RA111E1121
Rocker	RA111C1123	03-RA111C1123		OBSOLETE	SEE 03-RA111E1123
Rocker	RA111C1A81	03-RA111C1A81		OBSOLETE	SEE 03-RA111E1A81
Rocker	RA111E1100	03-RA111E1100	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA111E1121	03-RA111E1121	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA111E1123	03-RA111E1123	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Rocker	RA111E1A81	03-RA111E1A81	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA11331100	03-RA11331100	2010	OBSOLETE	SEE 03-RA113A1100
Rocker	RA113A1100	03-RA113A1100	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA113A2200	03-RA113A2200	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA11431100	03-RA11431100		OBSOLETE	SEE 03-RA114A1100
Rocker	RA1143112H	03-RA1143112H		OBSOLETE	SEE 03-RA114A112H
Rocker	RA1143112K	03-RA1143112K		OBSOLETE	SEE 03-RA114A112K
Rocker	RA1143112M	03-RA1143112M		OBSOLETE	SEE 03-RA114A112M
Rocker	RA1143112N	03-RA1143112N		OBSOLETE	SEE 03-RA114A112N
Rocker	RA1143112Q	03-RA1143112Q		OBSOLETE	SEE 03-RA114A112Q
Rocker	RA114A1100	03-RA114A1100		OBSOLETE	
Rocker	RA114A112H	03-RA114A112H	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA114A112K	03-RA114A112K	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA114A112M	03-RA114A112M	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA114A112N	03-RA114A112N	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA114A112Q	03-RA114A112Q	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA11531100	03-RA11531100		OBSOLETE	SEE 03-RA115A1100
Rocker	RA11531129	03-RA11531129		OBSOLETE	SEE 03-RA115A1129
Rocker	RA115A1100	03-RA115A1100	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA115A1129	03-RA115A1129	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA11C31100	03-RA11C31100		OBSOLETE	SEE 03-RA11CA1100
Rocker	RA11CA1100	03-RA11CA1100	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA11CA192S	03-RA11CA192S	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA11D31100	03-RA11D31100		OBSOLETE	SEE 03-RA11DA1100
Rocker	RA11DA1100	03-RA11DA1100	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA12131100	03-RA12131100		OBSOLETE	SEE 03-RA121A1100
Rocker	RA12131121	03-RA12131121		OBSOLETE	SEE 03-RA121A1121
Rocker	RA12131911	03-RA12131911		OBSOLETE	SEE 03-RA121A1911
Rocker	RA121A1100	03-RA121A1100	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA121A1121	03-RA121A1121	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA121A112R	03-RA121A112R	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA121A1911	03-RA121A1911	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA121E1100	03-RA121E1100	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA12331100	03-RA12331100		OBSOLETE	SEE 03-RA123A1100
Rocker	RA12331121	03-RA12331121		OBSOLETE	SEE 03-RA123A1121
Rocker	RA12331900	03-RA12331900		OBSOLETE	SEE 03-RA123A1900
Rocker	RA123A1100	03-RA123A1100	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA123A1121	03-RA123A1121	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA123A1900	03-RA123A1900	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA12532200	03-RA12532200		OBSOLETE	SEE 03-RA125A2200
Rocker	RA125A1129	03-RA125A1129	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA125A2200	03-RA125A2200	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA12AC1100	03-RA12AC1100		OBSOLETE	SEE 03-RA12AE1100
Rocker	RA12AE1100	03-RA12AE1100	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA12C31100	03-RA12C31100		OBSOLETE	SEE 03-RA12CA1100
Rocker	RA12CA1100	03-RA12CA1100	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA12D31100	03-RA12D31100		OBSOLETE	SEE 03-RA12DA1100
Rocker	RA12DA1100	03-RA12DA1100	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA12DA1122	03-RA12DA1122	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA131A1100	03-RA131A1100	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA133E1100	03-RA133E1100	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA11131000-144	38-RA11131000144	2018	OBSOLETE	
Rocker	RA111C1021-117	38-RA111C1021117	2018	OBSOLETE	
Rocker	RA111C1021-124	38-RA111C1021124	2018	OBSOLETE	
Rocker	RA111C1100	38-RA111C1100	2018	OBSOLETE	
Rocker	RA111C1100-nr	38-RA111C1100NR		OBSOLETE	
Rocker	RA111C1121-nr	38-RA111C1121NR		OBSOLETE	
Rocker	RA111C112R	38-RA111C112R	2018	OBSOLETE	
Rocker	RA114C1121	38-RA114C1121	2018	OBSOLETE	
Rocker	RA11532200	38-RA11532200	2018	OBSOLETE	
Rocker	RA115C112S	38-RA115C112S	2018	OBSOLETE	
Rocker	RA12132285	38-RA12132285	2018	OBSOLETE	
Rocker	RA121C1100	38-RA121C1100	2018	OBSOLETE	
Rocker	RA13131100	38-RA13131100	2018	OBSOLETE	
Rocker	RA13131121	38-RA13131121	2018	OBSOLETE	
Rocker	RA1A14A31100-nr	38-RA1A14A31100NR		OBSOLETE	
Rocker	RA1C3131100	38-RA1C3131100	2018	OBSOLETE	
Rocker	RA1H331100-nr	38-RA1H331100NR		OBSOLETE	
Rocker	RA1H331123	38-RA1H331123	2018	OBSOLETE	
Rocker	RA1H3C1123	38-RA1H3C1123	2018	OBSOLETE	
Rocker	RA111C1121/ACC-P01	38-RA1S00142	2018	OBSOLETE	
Rocker	RA11AC11Z22R/ACC-P01	38-RA1S00268		OBSOLETE	
Rocker	RA 1066A-F-X	P300000	2020	OBSOLETE	EOL - Not on Website
Rocker	RA1066AFX	P300000	2020	OBSOLETE	
Rocker	RA1066AFA	P300001	2020	OBSOLETE	EOL - Not on Website
Rocker	RA1066AFA	P300001	2020	OBSOLETE	
Rocker	RA1066AFB	P300002	2020	OBSOLETE	EOL - Not on Website
Rocker	RA1066AFB	P300002	2020	OBSOLETE	
Rocker	RA1066AFC	P300003	2020	OBSOLETE	EOL - Not on Website
Rocker	RA1066AFC	P300003	2020	OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Rocker	RA1066AFF	P300006	2020	OBSOLETE	EOL - Not on Website
Rocker	RA1066AFF	P300006	2020	OBSOLETE	
Rocker	RA1066AFH	P300008	2020	OBSOLETE	EOL - Not on Website
Rocker	RA1066AFH	P300008	2020	OBSOLETE	
Rocker	RA1066AFK	P300011	2020	OBSOLETE	EOL - Not on Website
Rocker	RA1066AFK	P300011	2020	OBSOLETE	
Rocker	RA1066ASX	P300200	2012	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA1066ASA	P300201	2020	OBSOLETE	
Rocker	RA1066ASA	P300201	2020	OBSOLETE	
Rocker	RA1066ASG	P300207	2020	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA1066ASG	P300207	2020	OBSOLETE	
Rocker	RA1066ASI	P300209	2020	OBSOLETE	
Rocker	RA1066ASI	P300209	2020	OBSOLETE	
Rocker	RA1066ASK	P300211	2020	OBSOLETE	
Rocker	RA1066ASK	P300211	2020	OBSOLETE	
Rocker	RA21131100	38-RA21131100	2018	OBSOLETE	
Rocker	RA41131121	38-RA41131121	2018	OBSOLETE	
Rocker	RA411C1123	38-RA411C1123	2018	OBSOLETE	EXTRA TERM HOLES OPEN
Rocker	RA411C1123Z111	38-RA411C1123Z111	2018	OBSOLETE	EXTRA TERM HOLES FILLED
Rocker	RA41234421	38-RA41234421	2018	OBSOLETE	
Rocker	RA412C1000-107	38-RA412C1000107	2018	OBSOLETE	
Rocker	RA412C1121-nr	38-RA412C1121NR		OBSOLETE	
Rocker	RA416C1100	38-RA416C1100	2018	OBSOLETE	
Rocker	RA41GC1121	38-RA41GC1121	2018	OBSOLETE	
Rocker	RA43231123	38-RA43231123	2018	OBSOLETE	
Rocker	RA432C1123	38-RA432C1123	2018	OBSOLETE	EXTRA TERM HOLES OPEN
Rocker	RA432C1123Z111	38-RA432C1123Z111	2018	OBSOLETE	EXTRA TERM HOLES FILLED
Rocker	RA43631129	38-RA43631129	2018	OBSOLETE	
Rocker	RA45131100	38-RA45131100	2018	OBSOLETE	
Rocker	RA456C1129	38-RA456C1129	2018	OBSOLETE	Decreasing demand, stream line series
Rocker	RA456C112S	38-RA456C112S	2018	OBSOLETE	
Rocker	RA456C112Z74	38-RA456C112Z74	2018	OBSOLETE	
Rocker	RA45A31100	38-RA45A31100	2018	OBSOLETE	
Rocker	RA45HC1121	38-RA45HC1121	2018	OBSOLETE	
Rocker	RA45HC1911	38-RA45HC1911	2015	OBSOLETE	SEE 38-RA45HC1921
Rocker	RA48231121	38-RA48231121	2018	OBSOLETE	Decreasing demand, stream line series
Rocker	RA4P1GC1100	38-RA4P1GC1100	2018	OBSOLETE	
Rocker	RA811C1100	03-RA811C1100		OBSOLETE	SEE 03-RA811E1100
Rocker	RA811C1121	03-RA811C1121		OBSOLETE	SEE 03-RA811E1121
Rocker	RA812C1100	03-RA812C1100		OBSOLETE	SEE 03-RA812E1100
Rocker	RA812C1121	03-RA812C1121		OBSOLETE	SEE 03-RA812E1121
Rocker	RA812C1A81	03-RA812C1A81		OBSOLETE	SEE 03-RA812E1A81
Rocker	RA812E1121	03-RA812E1121	2015	OBSOLETE	see R1966 or configure with RA8 or RA1 using 3=11Amp or C=16Amp contact
Rocker	RA81131000-134	38-RA81131000134	2018	OBSOLETE	
Rocker	RA811C1000-127	38-RA811C1000127	2018	OBSOLETE	
Rocker	RA811C1021-117	38-RA811C1021117	2018	OBSOLETE	
Rocker	RA811C1100-nr	38-RA811C1100NR		OBSOLETE	
Rocker	RA811C1121-nr	38-RA811C1121NR		OBSOLETE	
Rocker	RA811C1121Z111	38-RA811C1121Z111	2018	OBSOLETE	EXTRA TERM HOLES FILLED
Rocker	RA811C1921	38-RA811C1921	2018	OBSOLETE	
Rocker	RA811C3300	38-RA811C3300	2018	OBSOLETE	
Rocker	RA811CQQ00	38-RA811CQQ00	2018	OBSOLETE	
Rocker	RA81231000-137	38-RA81231000137	2018	OBSOLETE	
Rocker	RA81231018-137	38-RA81231018137	2018	OBSOLETE	
Rocker	RA81231021-116	38-RA81231021116	2018	OBSOLETE	
Rocker	RA81231028-137	38-RA81231028137	2018	OBSOLETE	
Rocker	RA8123421R	38-RA8123421R	2018	OBSOLETE	
Rocker	RA812C1000-114	38-RA812C1000114	2018	OBSOLETE	
Rocker	RA812C1000-116	38-RA812C1000116	2018	OBSOLETE	
Rocker	RA812C1021-116	38-RA812C1021116	2018	OBSOLETE	
Rocker	RA812C1028-136	38-RA812C1028136	2018	OBSOLETE	
Rocker	RA812C102R-147	38-RA812C102R147	2018	OBSOLETE	
Rocker	RA812C1100	38-RA812C1100	2018	OBSOLETE	
Rocker	RA812C1124	38-RA812C1124	2018	OBSOLETE	
Rocker	RA85131021-136	38-RA85131021136	2018	OBSOLETE	
Rocker	RA851C1021-134	38-RA851C1021134	2018	OBSOLETE	
Rocker	RA851C1100-nr	38-RA851C1100NR		OBSOLETE	
Rocker	RA851C1121-nr	38-RA851C1121NR		OBSOLETE	
Rocker	RA852C1000-117	38-RA852C1000117	2018	OBSOLETE	
Rocker	RA852C1000-127	38-RA852C1000127	2018	OBSOLETE	
Rocker	RA852C1021-137	38-RA852C1021137	2018	OBSOLETE	
Rocker	RA852C1021-137-nr	38-RA852C1021137NR		OBSOLETE	
Rocker	RA852C1028-137	38-RA852C1028137	2018	OBSOLETE	
Rocker	RA852C1100-nr	38-RA852C1100NR		OBSOLETE	
Rocker	RA852C1121-nr	38-RA852C1121NR		OBSOLETE	
Rocker	RA852C112R	38-RA852C112R	2018	OBSOLETE	
Rocker	RB141D1021-116	14-RB141D1021116	2017	OBSOLETE	
Rocker	RB141D1021-117	14-RB141D1021117	2017	OBSOLETE	
Rocker	RB141D1100	14-RB141D1100	2017	OBSOLETE	
Rocker	RB141D1100-246	14-RB141D1100246	2017	OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Rocker	RB141D2000-136	14-RB141D2000136	2017	OBSOLETE	
Rocker	RB141D3000-136	14-RB141D3000136	2017	OBSOLETE	
Rocker	RB145D1900	14-RB145D1900		OBSOLETE	
Rocker	RB14CE1100	14-RB14CE1100	2017	OBSOLETE	
Rocker	RB191D1900	14-RB191D1900	2017	OBSOLETE	
Rocker	RB141D1021-137/ACC-F01-1	14-RB1S00028	2017	OBSOLETE	***
Rocker	RB141D1021-136/ACC-F01-1	14-RB1S00029	2017	OBSOLETE	***
Rocker	RB141D1021-134/ACC-F01-1	14-RB1S00030	2017	OBSOLETE	***
Rocker	RB141D1021-117/ACC-F01-1	14-RB1S00031	2017	OBSOLETE	***
Rocker	RB141D1021-116/ACC-F01-1	14-RB1S00032	2017	OBSOLETE	***
Rocker	RB141D1021-114/ACC-F01-1	14-RB1S00033	2017	OBSOLETE	***
Rocker	RB141D1000-137/ACC-F01-1	14-RB1S00034	2017	OBSOLETE	***
Rocker	RB141D1000-136/ACC-F01-1	14-RB1S00035	2017	OBSOLETE	***
Rocker	RB141D1000-134/ACC-F01-1	14-RB1S00036	2017	OBSOLETE	***
Rocker	RB141D1000-117/ACC-F01-1	14-RB1S00037	2017	OBSOLETE	***
Rocker	RB141D1000-114/ACC-F01-1	14-RB1S00039	2017	OBSOLETE	***
Rocker	RB141D1000-104/ACC-F01-1	14-RB1S00056	2017	OBSOLETE	***
Rocker	RB141D1000-11A/ACC-F01-1	14-RB1S00057	2017	OBSOLETE	***
Rocker	RB141D1021-11A/ACC-F01-1	14-RB1S00058	2017	OBSOLETE	***
Rocker	RB141D1000-10A/ACC-F01-1	14-RB1S00059	2017	OBSOLETE	***
Rocker	RB14BD1100/ACC-F01-1	14-RB1S00086	2017	OBSOLETE	
Rocker	RB14AD1100/ACC-F01-1	14-RB1S00087	2017	OBSOLETE	
Rocker	RB143D1100/ACC-F01-1	14-RB1S00088	2017	OBSOLETE	
Rocker	RB141D1123/ACC-F01-1	14-RB1S00089	2017	OBSOLETE	
Rocker	RB141D1100/ACC-F01-1	14-RB1S00091	2017	OBSOLETE	
Rocker	RB144D1100/ACC-F01-1	14-RB1S00097	2017	OBSOLETE	
Rocker	RB141D1021-147/ACC-F01-1	14-RB1S00144	2017	OBSOLETE	***
Rocker	RB141D1200/ACC-F01-1	14-RB1S00147	2017	OBSOLETE	
Rocker	RB143D1200/ACC-F01-1	14-RB1S00148	2017	OBSOLETE	
Rocker	RB141D1000-116/ACC-F01-1	14-RB1S00157	2017	OBSOLETE	***
Rocker	RB14CE1100/ACC-F01-1	14-RB1S00231	2017	OBSOLETE	
Rocker	RB111C1100	38-RB111C1100	2018	OBSOLETE	
Rocker	RB111C1121	38-RB111C1121	2018	OBSOLETE	
Rocker	RB141C2200-216	38-RB111C2200216		OBSOLETE	SEE 38-RB141C2200216
Rocker	RB111C2200-217	38-RB111C2200217	2017	OBSOLETE	
Rocker	RB111C2211	38-RB111C2211	2018	OBSOLETE	
Rocker	RB14001000-117	38-RB14001000117	2018	OBSOLETE	
Rocker	RB14001000-136	38-RB14001000136	2018	OBSOLETE	
Rocker	RB141C1000-116	38-RB141C1000116	2017	OBSOLETE	
Rocker	RB141C1000-117-nr	38-RB141C1000117NR		OBSOLETE	
Rocker	RB141C1000-134	38-RB141C1000134	2018	OBSOLETE	
Rocker	RB141C1000-136	38-RB141C1000136	2018	OBSOLETE	
Rocker	RB141C1000-144	38-RB141C1000144	2017	OBSOLETE	
Rocker	RB141C1021-116	38-RB141C1021116	2017	OBSOLETE	
Rocker	RB141C1021-137	38-RB141C1021137	2018	OBSOLETE	
Rocker	RB141C1121	38-RB141C1121	2018	OBSOLETE	
Rocker	RB141C1123	38-RB141C1123	2017	OBSOLETE	
Rocker	RB141C1211	38-RB141C1211	2018	OBSOLETE	
Rocker	RB141C2200-216	38-RB141C2200216	2017	OBSOLETE	
Rocker	RB141C2200-217	38-RB141C2200217	2017	OBSOLETE	
Rocker	RB141C2211	38-RB141C2211	2018	OBSOLETE	
Rocker	RB141C4400	38-RB141C4400	2018	OBSOLETE	
Rocker	RB143C112R	38-RB143C112R	2018	OBSOLETE	
Rocker	RB143C112Z38	38-RB143C112Z38	2018	OBSOLETE	
Rocker	RB145C2219	38-RB145C2219	2017	OBSOLETE	
Rocker	RB145C3319	38-RB145C3319	2017	OBSOLETE	
Rocker	RB145C4400	38-RB145C4400	2018	OBSOLETE	
Rocker	RB1F45C1100	38-RB1F45C1100	2018	OBSOLETE	
Rocker	RB141C1000-104/ACC-F01-1	38-RB1S00027	2017	OBSOLETE	***
Rocker	RB141C1021-137/ACC-F01-1	38-RB1S00041	2017	OBSOLETE	***
Rocker	RB141C1121/ACC-F01-2	38-RB1S00151	2017	OBSOLETE	
Rocker	RB141C1021-117/ACC-F01-1	38-RB1S00170	2017	OBSOLETE	***
Rocker	RB143C112Z51/ACC-F01-1	38-RB1S00238	2018	OBSOLETE	
Rocker	RB24G01100-204	03-RB24G01100204	2015	OBSOLETE	redundant set up, use std. R5CBkBlkef for DDPDT (On-On) drawing M050204
Rocker	RB241D1000-146	14-RB241D1000146	2017	OBSOLETE	
Rocker	RB241D9000-116	14-RB241D9000116	2017	OBSOLETE	
Rocker	RB242D1000-125	14-RB242D1000125		OBSOLETE	
Rocker	RB242D1000-136	14-RB242D1000136	2017	OBSOLETE	
Rocker	RB242D101R-137	14-RB242D101R137	2017	OBSOLETE	
Rocker	RB242D1021-116	14-RB242D1021116	2017	OBSOLETE	
Rocker	RB242D1021-117	14-RB242D1021117	2017	OBSOLETE	
Rocker	RB242D1021-126	14-RB242D1021126	2017	OBSOLETE	
Rocker	RB242D1021-146	14-RB242D1021146	2017	OBSOLETE	
Rocker	RB242D1024-117	14-RB242D1024117	2017	OBSOLETE	
Rocker	RB242D1800	14-RB242D1800	2017	OBSOLETE	
Rocker	RB242D1821	14-RB242D1821	2017	OBSOLETE	
Rocker	RB242D1900	14-RB242D1900	2017	OBSOLETE	
Rocker	RB242D4011-107	14-RB242D4011107	2017	OBSOLETE	
Rocker	RB245E1900	14-RB245E1900	2017	OBSOLETE	
Rocker	RB246E1100	14-RB246E1100	2017	OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Rocker	RB246E1125	14-RB246E1125	2017	OBSOLETE	
Rocker	RB24ED1100	14-RB24ED1100	2017	OBSOLETE	
Rocker	RB24GD1100	14-RB24GD1100	2017	OBSOLETE	
Rocker	RB24HD1100	14-RB24HD1100	2017	OBSOLETE	
Rocker	RB24KE1100	14-RB24KE1100	2017	OBSOLETE	
Rocker	RB265E1125	14-RB265E1125	2017	OBSOLETE	
Rocker	RB242D1000-136/ACC-F02-1	14-RB2500008	2017	OBSOLETE	***
Rocker	RB242D1011-126/ACC-F02-1	14-RB2500040	2017	OBSOLETE	***
Rocker	RB242D1021-126/ACC-F02-1	14-RB2500044	2017	OBSOLETE	***
Rocker	RB242D1011-116/ACC-F04-1	14-RB2500046	2016	OBSOLETE	EOL 3-7-16 PCR 22177
Rocker	RB242D1011-116/ACC-F04-1	14-RB2500046	2016	OBSOLETE	guard accessory no longer compatible with RB2 housing design, no replacement
Rocker	RB241D1021-116/ACC-F02-1	14-RB2500049	2017	OBSOLETE	***
Rocker	RB242D1000-116/ACC-F02-1	14-RB2500051	2017	OBSOLETE	***
Rocker	RB242D1021-137/ACC-F02-1	14-RB2500054	2017	OBSOLETE	***
Rocker	RB242D1021-136/ACC-F02-1	14-RB2500055	2017	OBSOLETE	***
Rocker	RB24GD1100/ACC-F02-1	14-RB2500095	2017	OBSOLETE	
Rocker	RB242D1100/ACC-F02-1	14-RB2500102	2017	OBSOLETE	
Rocker	RB242D1123/ACC-F02-1	14-RB2500104	2017	OBSOLETE	
Rocker	RB244D1121/ACC-F02-1	14-RB2500143	2017	OBSOLETE	
Rocker	RB242D1011-147/ACC-F02-1	14-RB2500145	2017	OBSOLETE	***
Rocker	RB246E1100/ACC-F02-1	14-RB2500154	2017	OBSOLETE	
Rocker	RB241D1121/ACC-F02-1	14-RB2500155	2017	OBSOLETE	
Rocker	RB246E1100/ACC-F04-1	14-RB2500173	2016	OBSOLETE	guard accessory no longer compatible with RB2 housing design, no replacement
Rocker	RB242D1211-ACC-F02-1	14-RB2500177	2017	OBSOLETE	
Rocker	RB242D1000-125-ACC-F02-1	14-RB2500185	2015	OBSOLETE	
Rocker	RB246E1122-ACCF02-1	14-RB2500207	2017	OBSOLETE	
Rocker	RB2F41C1021-126/ACC-F021	14-RB2500222	2017	OBSOLETE	***
Rocker	RB211D1021-136/ACC-F02-1	14-RB2500237	2017	OBSOLETE	***
Rocker	RB212C1000-126	38-RB212C1000126	2017	OBSOLETE	
Rocker	RB212C1000-127	38-RB212C1000127	2017	OBSOLETE	
Rocker	RB212C1011-134	38-RB212C1011134	2018	OBSOLETE	
Rocker	RB212C101295-127	38-RB212C101295127	2018	OBSOLETE	
Rocker	RB216C1129	38-RB216C1129	2017	OBSOLETE	
Rocker	RB24001000-114	38-RB24001000114	2017	OBSOLETE	
Rocker	RB241C1021-114	38-RB241C1021114		OBSOLETE	SEE 38-RB242C1021114
Rocker	RB241C1100	38-RB241C1100	2018	OBSOLETE	
Rocker	RB241C1121	38-RB241C1121	2017	OBSOLETE	
Rocker	RB241C1123	38-RB241C1123	2018	OBSOLETE	
Rocker	RB241C2200	38-RB241C2200	2017	OBSOLETE	
Rocker	RB241C2213	38-RB241C2213	2017	OBSOLETE	
Rocker	RB242C1000-116	38-RB242C1000116	2018	OBSOLETE	
Rocker	RB242C1000-134	38-RB242C1000134	2017	OBSOLETE	
Rocker	RB242C1000-136	38-RB242C1000136	2017	OBSOLETE	
Rocker	RB242C1011-127	38-RB242C1011127	2017	OBSOLETE	
Rocker	RB242C101R-137	38-RB242C101R137	2018	OBSOLETE	
Rocker	RB242C1021-117	38-RB242C1021117	2018	OBSOLETE	
Rocker	RB242C1021-137	38-RB242C1021137	2018	OBSOLETE	
Rocker	RB242C1023-135	38-RB242C1023135	2017	OBSOLETE	
Rocker	RB242C102R-137	38-RB242C102R137	2018	OBSOLETE	
Rocker	RB242C1100	38-RB242C1100	2017	OBSOLETE	
Rocker	RB242C1100-217	38-RB242C1100217	2017	OBSOLETE	
Rocker	RB242C1100-234	38-RB242C1100234	2017	OBSOLETE	
Rocker	RB242C1100-237	38-RB242C1100237	2017	OBSOLETE	
Rocker	RB242C1100-nr	38-RB242C1100NR		OBSOLETE	
Rocker	RB242C1121	38-RB242C1121	2017	OBSOLETE	
Rocker	RB242C1121-nr	38-RB242C1121NR		OBSOLETE	
Rocker	RB242C1700-nr	38-RB242C1700NR		OBSOLETE	
Rocker	RB243C1100	38-RB243C1100	2018	OBSOLETE	
Rocker	RB245C1125	38-RB245C1125	2017	OBSOLETE	
Rocker	RB246C1219	38-RB246C1219	2018	OBSOLETE	
Rocker	RB24DC1100	38-RB24DC1100	2017	OBSOLETE	
Rocker	RB24GC1100	38-RB24GC1100	2018	OBSOLETE	
Rocker	RB24GC1200	38-RB24GC1200	2018	OBSOLETE	
Rocker	RB24KC2200	38-RB24KC2200	2017	OBSOLETE	
Rocker	RB2F42C1021-117	38-RB2F42C1021117	2018	OBSOLETE	
Rocker	RB2F42C1021-127	38-RB2F42C1021127	2018	OBSOLETE	
Rocker	RB2F42C1021-147	38-RB2F42C1021147	2017	OBSOLETE	
Rocker	RB2F52C1023-134	38-RB2F52C1023134	2017	OBSOLETE	
Rocker	RB2FBKC1122	38-RB2FBKC1122	2017	OBSOLETE	
Rocker	RB242C1100-216/ACC-F02-1	38-RB2500007	2018	OBSOLETE	**
Rocker	RB2F42C1000117/ACC-F02-1	38-RB2500015	2017	OBSOLETE	***
Rocker	RB2F42C1000-116ACCF021	38-RB2500016	2017	OBSOLETE	
Rocker	RB2F42C1000-107ACCF021	38-RB2500017	2017	OBSOLETE	
Rocker	RB242C1000-106ACCF021	38-RB2500018	2017	OBSOLETE	
Rocker	RB242C1100-217/ACC-F02-1	38-RB2500043	2018	OBSOLETE	**
Rocker	RB242C1921/ACC-F02-1	38-RB2500092	2018	OBSOLETE	
Rocker	RB24GC1100ACCF021	38-RB2500093	2018	OBSOLETE	
Rocker	RB2461125ACCF021	38-RB2500112	2017	OBSOLETE	
Rocker	RB246C1100ACCF021	38-RB2500113	2017	OBSOLETE	
Rocker	RB245C1125-ACCF02-1	38-RB2500208	2017	OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Rocker	RB411C1100-217	38-RB411C1100217	2018	OBSOLETE	
Rocker	RB411C112(Y)+(W)	38-RB411C112YW	2018	OBSOLETE	
Rocker	RB411C2200-217	38-RB411C2200217	2018	OBSOLETE	
Rocker	RB411C221(Y)+(W)	38-RB411C221YW	2018	OBSOLETE	
Rocker	RB441C1021-114	38-RB441C1021114	2018	OBSOLETE	
Rocker	RB441C1023-116	38-RB441C1023116	2018	OBSOLETE	
Rocker	RB4B1C1023-116	38-RB4B1C1023116	2018	OBSOLETE	
Rocker	RB4B1C2023-116	38-RB4B1C2023116	2018	OBSOLETE	
Rocker	RB4F41C101R-117	38-RB4F41C101R117	2018	OBSOLETE	
Rocker	RB4F41C9(024-117)+(124)	38-RB4F500253	2018	OBSOLETE	*
Rocker	RB411C112(Y-217)+(W-217)	38-RB4S00149	2018	OBSOLETE	**
Rocker	RB411C221(Y-217)+(W-217)	38-RB4S00150	2018	OBSOLETE	**
Rocker	RB44(001000-135+1C1121)	38-RB4S00153	2018	OBSOLETE	DC24V**
Rocker	RB44(1C1121)+(00102Z78)	38-RB4S00176	2018	OBSOLETE	-126)**
Rocker	RB44(001000-126)+(4C112Z	38-RB4S00177	2018	OBSOLETE	79)**
Rocker	RB44(3C1123)+(1C1123)	38-RB4S00188	2018	OBSOLETE	
Rocker	RB4B(1C1021-116+1C1100)	38-RB4S00225	2018	OBSOLETE	*
Rocker	RC1083BBLKBLKEF	P301500	2020	OBSOLETE	No replacement
Rocker	RC1083BBLKBLKEF	P301500	2020	OBSOLETE	
Rocker	RC1083BBLKBLKAF	P301501	2020	OBSOLETE	No replacement
Rocker	RC1083BBLKBLKAF	P301501	2020	OBSOLETE	
Rocker	RC1083BBLKBLKCF	P301503	2020	OBSOLETE	No replacement
Rocker	RC1083BBLKBLKCF	P301503	2020	OBSOLETE	
Rocker	RC1083BBLKBLKIF	P301504	2009	OBSOLETE	No replacement
Rocker	RC1083BBLKBLKGF0	P301505	2020	OBSOLETE	No replacement
Rocker	RC1083BBLKBLKGF0	P301505	2020	OBSOLETE	
Rocker	RC1083BBLKBLKJF	P301506	2020	OBSOLETE	No replacement
Rocker	RC1083BBLKBLKJF	P301506	2020	OBSOLETE	
Rocker	RC1083BBLKBLKFF0	P301508	2020	OBSOLETE	No replacement
Rocker	RC1083BBLKBLKFF0	P301508	2020	OBSOLETE	
Rocker	RC1083BBLKWHTFF0	P301509	2020	OBSOLETE	No replacement
Rocker	RC1083BBLKWHTFF0	P301509	2020	OBSOLETE	
Rocker	RC1083BBLKREDF0	P301516	2020	OBSOLETE	No replacement
Rocker	RC1083BBLKREDF0	P301516	2020	OBSOLETE	
Rocker	RD11131200	38-RD11131200	2018	OBSOLETE	
Rocker	RD11131921	38-RD11131921	2018	OBSOLETE	
Rocker	RD151C1100	38-RD151C1100	2018	OBSOLETE	
Rocker	RD151C2200	38-RD151C2200	2018	OBSOLETE	
Rocker	RD151C221F	38-RD151C221F	2018	OBSOLETE	
Rocker	RE11131000-117	38-RE11131000117	2018	OBSOLETE	
Rocker	RE11131011-134	38-RE11131011134	2018	OBSOLETE	
Rocker	RE11131023-135	38-RE11131023135	2018	OBSOLETE	
Rocker	RE111C1000-116	38-RE111C1000116	2018	OBSOLETE	
Rocker	RE111C1100	38-RE111C1100	2018	OBSOLETE	
Rocker	RE111C112Z56	38-RE111C112Z56	2018	OBSOLETE	
Rocker	RE11331100	38-RE11331100	2018	OBSOLETE	
Rocker	RE11534929	38-RE11534929	2018	OBSOLETE	
Rocker	RE115C1100	38-RE115C1100	2018	OBSOLETE	
Rocker	RE15131121	38-RE15131121	2018	OBSOLETE	
Rocker	RE1513221R	38-RE1513221R	2018	OBSOLETE	
Rocker	RE15134024-145	38-RE15134024145	2018	OBSOLETE	
Rocker	RE15531125	38-RE15531125	2018	OBSOLETE	
Rocker	RF142C1100	38-RF142C1100	2018	OBSOLETE	
Rocker	RF142C1121	38-RF142C1121	2018	OBSOLETE	
Rocker	RR11001000-114	38-RR11001000114	2018	OBSOLETE	
Rocker	RR11001000-117	38-RR11001000117	2018	OBSOLETE	
Rocker	RR11001000-144	38-RR11001000144	2018	OBSOLETE	
Rocker	RR11002000-117	38-RR11002000117	2018	OBSOLETE	
Rocker	RR1100Q000-117	38-RR1100Q000117	2018	OBSOLETE	
Rocker	RR11131000-116	38-RR11131000116	2018	OBSOLETE	
Rocker	RR11131000-134	38-RR11131000134	2018	OBSOLETE	
Rocker	RR11131000-136	38-RR11131000136	2018	OBSOLETE	
Rocker	RR11131100-217	38-RR11131100217	2018	OBSOLETE	
Rocker	RR11131100-236	38-RR11131100236	2018	OBSOLETE	
Rocker	RR11131100-244	38-RR11131100244	2018	OBSOLETE	
Rocker	RR11131100-247	38-RR11131100247	2018	OBSOLETE	
Rocker	RR11131121	38-RR11131121	2018	OBSOLETE	
Rocker	RR11131123	38-RR11131123	2018	OBSOLETE	
Rocker	RR1113112R	38-RR1113112R	2018	OBSOLETE	
Rocker	RR11131921-nr	38-RR11131921NR		OBSOLETE	
Rocker	RR11132200-nr	38-RR11132200NR		OBSOLETE	
Rocker	RR111C1000-126	38-RR111C1000126	2018	OBSOLETE	
Rocker	RR111C1021-117	38-RR111C1021117	2018	OBSOLETE	
Rocker	RR111C1021-126	38-RR111C1021126	2018	OBSOLETE	
Rocker	RR111C1021-134	38-RR111C1021134	2018	OBSOLETE	
Rocker	RR111C1021-136	38-RR111C1021136	2018	OBSOLETE	
Rocker	RR111C1023-116	38-RR111C1023116	2018	OBSOLETE	
Rocker	RR111C1100	38-RR111C1100	2018	OBSOLETE	
Rocker	RR111C1100-214	38-RR111C1100214	2018	OBSOLETE	
Rocker	RR111C1100-216	38-RR111C1100216	2018	OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Rocker	RR111C1100-245	38-RR111C1100245	2018	OBSOLETE	
Rocker	RR111C1100-246	38-RR111C1100246	2018	OBSOLETE	
Rocker	RR111C1100-247	38-RR111C1100247	2018	OBSOLETE	
Rocker	RR111C1100-nr	38-RR111C1100NR		OBSOLETE	
Rocker	RR111C1123	38-RR111C1123	2018	OBSOLETE	
Rocker	RR111C1123-nr	38-RR111C1123NR		OBSOLETE	
Rocker	RR111C1900	38-RR111C1900	2018	OBSOLETE	
Rocker	RR111C2000-117	38-RR111C2000117	2018	OBSOLETE	
Rocker	RR111C2023-116	38-RR111C2023116	2018	OBSOLETE	
Rocker	RR111C2200-216	38-RR111C2200216	2018	OBSOLETE	
Rocker	RR111C2200-217	38-RR111C2200217	2018	OBSOLETE	
Rocker	RR111C2200-234	38-RR111C2200234	2018	OBSOLETE	
Rocker	RR111C2200-236	38-RR111C2200236	2018	OBSOLETE	
Rocker	RR111C2200-237	38-RR111C2200237	2018	OBSOLETE	
Rocker	RR111C2211	38-RR111C2211	2018	OBSOLETE	
Rocker	RR11331123	38-RR11331123	2018	OBSOLETE	
Rocker	RR113C1121	38-RR113C1121	2018	OBSOLETE	
Rocker	RR113C2200	38-RR113C2200	2018	OBSOLETE	
Rocker	RR113C221Z47	38-RR113C221Z47	2018	OBSOLETE	
Rocker	RR11431100	38-RR11431100	2018	OBSOLETE	
Rocker	RR1143112Z02	38-RR1143112Z02	2018	OBSOLETE	
Rocker	RR11431800	38-RR11431800	2018	OBSOLETE	
Rocker	RR11431900	38-RR11431900	2018	OBSOLETE	
Rocker	RR1143221Z02	38-RR1143221Z02	2018	OBSOLETE	
Rocker	RR1143QQ1Z02	38-RR1143QQ1Z02	2018	OBSOLETE	
Rocker	RR114C1200	38-RR114C1200	2018	OBSOLETE	
Rocker	RR114C1800	38-RR114C1800	2018	OBSOLETE	
Rocker	RR11531100	38-RR11531100	2018	OBSOLETE	
Rocker	RR11534400	38-RR11534400	2018	OBSOLETE	
Rocker	RR115C1125	38-RR115C1125	2018	OBSOLETE	
Rocker	RR115C112Z17	38-RR115C112Z17	2018	OBSOLETE	
Rocker	RR115C112Z41	38-RR115C112Z41	2018	OBSOLETE	
Rocker	RR11C31100	38-RR11C31100	2018	OBSOLETE	
Rocker	RR11C31125	38-RR11C31125	2018	OBSOLETE	
Rocker	RR11C32200	38-RR11C32200	2018	OBSOLETE	
Rocker	RR11C32215	38-RR11C32215	2018	OBSOLETE	
Rocker	RR11C3QQ00	38-RR11C3QQ00	2018	OBSOLETE	
Rocker	RR11C3QQ15	38-RR11C3QQ15	2018	OBSOLETE	
Rocker	RR15431900	38-RR15431900	2018	OBSOLETE	
Rocker	RR15534429	38-RR15534429	2018	OBSOLETE	
Rocker	RR15C34429	38-RR15C34429	2018	OBSOLETE	
Rocker	RR18001000-146	38-RR18001000146	2018	OBSOLETE	
Rocker	RR18131100-214	38-RR18131100214	2018	OBSOLETE	
Rocker	RR18131100-246	38-RR18131100246	2018	OBSOLETE	
Rocker	RR183C1900	38-RR183C1900	2018	OBSOLETE	
Rocker	RR185C1919	38-RR185C1919	2018	OBSOLETE	
Rocker	RR111C1921/ACC-P03	38-RR1500126	2018	OBSOLETE	
Rocker	RR1202C31125	38-RR1202C31125	2018	OBSOLETE	
Rocker	RR1202C32215	38-RR1202C32215	2018	OBSOLETE	
Rocker	RR1202C3QQ15	38-RR1202C3QQ15	2018	OBSOLETE	
Rocker	RR3112BBLKBLKGRNNEF1	F130451		OBSOLETE	SEE F130458
Rocker	RR3112LBLKBLKGRNNEF	F130453		OBSOLETE	SEE F130456
Rocker	RR534D2200	14-RR534D2200		OBSOLETE	
Rocker	RR81131021-126	38-RR81131021126	2018	OBSOLETE	
Rocker	RR81131100	38-RR81131100	2018	OBSOLETE	
Rocker	RR811C1021-146	38-RR811C1021146	2018	OBSOLETE	
Rocker	RR811C1023-136	38-RR811C1023136	2018	OBSOLETE	
Rocker	RR81231000-117	38-RR81231000117	2018	OBSOLETE	
Rocker	RR81231000-146	38-RR81231000146	2018	OBSOLETE	
Rocker	RR8123102R-134	38-RR8123102R134		OBSOLETE	
Rocker	RR81231100-nr	38-RR81231100NR		OBSOLETE	
Rocker	RR812C1000-136	38-RR812C1000136	2018	OBSOLETE	
Rocker	RR812C1011-137	38-RR812C1011137	2018	OBSOLETE	
Rocker	RR812C1021-144	38-RR812C1021144	2018	OBSOLETE	
Rocker	RR812C1021-146	38-RR812C1021146	2018	OBSOLETE	
Rocker	RR812C1021-147	38-RR812C1021147	2018	OBSOLETE	
Rocker	RR812C1100	38-RR812C1100	2018	OBSOLETE	
Rocker	RR812C1123	38-RR812C1123	2018	OBSOLETE	
Rocker	RR85231000-117-nr	38-RR85231000117NR		OBSOLETE	
Rocker	RR85231100-nr	38-RR85231100NR		OBSOLETE	
Rocker	RR85231121-nr	38-RR85231121NR		OBSOLETE	
Rocker	RR85234421	38-RR85234421	2018	OBSOLETE	
Rocker	RR852C1100-nr	38-RR852C1100NR		OBSOLETE	
Rocker	RR812C1121/ACC-P03	38-RR8500127	2018	OBSOLETE	
Rocker	RRA12C1000-106	38-RRA12C1000106	2018	OBSOLETE	
Rocker	RRA12C1000-126	38-RRA12C1000126	2018	OBSOLETE	
Rocker	RRA12C1000-144	38-RRA12C1000144	2018	OBSOLETE	
Rocker	RRA12C1000-145	38-RRA12C1000145	2018	OBSOLETE	
Rocker	RRA12C1000-146	38-RRA12C1000146	2018	OBSOLETE	
Rocker	RRA12C1011-106	38-RRA12C1011106	2018	OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Rocker	RRA12C1023-126	38-RRA12C1023126	2018	OBSOLETE	
Rocker	RRA12C102R-146	38-RRA12C102R146	2018	OBSOLETE	
Rocker	RRA15C112S	38-RRA15C112S	2018	OBSOLETE	
Rocker	RRA1634429	38-RRA1634429	2018	OBSOLETE	
Rocker	RRA1G32200	38-RRA1G32200	2018	OBSOLETE	
Rocker	RRG3113112Z101	38-RRG3113112Z101	2018	OBSOLETE	
Rocker	RRG31431100	38-RRG31431100	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG31432200	38-RRG31432200	2018	OBSOLETE	
Rocker	RRG314C1200	38-RRG314C1200	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG31C32200	38-RRG31C32200	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG31C3QQ00	38-RRG31C3QQ00	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG38131121	38-RRG38131121	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3813112Z35	38-RRG3813112Z35	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3813112Z68	38-RRG3813112Z68	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3813112Z69	38-RRG3813112Z69	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3813112Z76	38-RRG3813112Z76	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3813112Z81	38-RRG3813112Z81	2018	OBSOLETE	
Rocker	RRG3813112Z82	38-RRG3813112Z82	2018	OBSOLETE	
Rocker	RRG381311Z02Z11	38-RRG381311Z02Z11	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG381311Z05Z11	38-RRG381311Z05Z11	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG381311Z05Z13	38-RRG381311Z05Z13	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG381311Z07Z15	38-RRG381311Z07Z15	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG381311Z09Z35	38-RRG381311Z09Z35	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG381311Z13Z35	38-RRG381311Z13Z35	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG381311Z13Z40	38-RRG381311Z13Z40	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG381311Z13Z53	38-RRG381311Z13Z53	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG381311Z13Z54	38-RRG381311Z13Z54	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG381311Z16Z35	38-RRG381311Z16Z35	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG381311Z16Z57	38-RRG381311Z16Z57	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG381311Z17Z35	38-RRG381311Z17Z35	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG381311Z17Z57	38-RRG381311Z17Z57	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG381311Z29Z82	38-RRG381311Z29Z82	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG381311Z29Z83	38-RRG381311Z29Z83	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG381311Z29Z84	38-RRG381311Z29Z84	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG381311Z29Z85	38-RRG381311Z29Z85	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG381311Z31Z85	38-RRG381311Z31Z85	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG381311Z31Z88	38-RRG381311Z31Z88	2018	OBSOLETE	BLACK COLOR 20MM GLOSSY
Rocker	RRG3813121Z68	38-RRG3813121Z68	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3813121Z69	38-RRG3813121Z69	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG381321Z76	38-RRG381321Z76	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3813221Z35	38-RRG3813221Z35	2018	OBSOLETE	(20 mm GLOSSY)
Rocker	RRG3813221Z68	38-RRG3813221Z68	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3813221Z69	38-RRG3813221Z69	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3813221Z76 20mm	38-RRG3813221Z76	2018	OBSOLETE	GLOSSY
Rocker	RRG3813221Z82	38-RRG3813221Z82	2018	OBSOLETE	20MM GLOSSY
Rocker	RRG381322Z03Z11	38-RRG381322Z03Z11	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG381322Z03Z13	38-RRG381322Z03Z13	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG381322Z04Z13	38-RRG381322Z04Z13	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG381322Z05Z13	38-RRG381322Z05Z13	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG381322Z06Z15	38-RRG381322Z06Z15	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG381322Z10Z35	38-RRG381322Z10Z35	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG381322Z12Z35	38-RRG381322Z12Z35	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG381322Z12Z40	38-RRG381322Z12Z40	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG381333Z05Z13	38-RRG381333Z05Z13	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG381333Z07Z15	38-RRG381333Z07Z15	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3813QQ00	38-RRG3813QQ00	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3813QQ0Z05Z13	38-RRG3813QQ0Z05Z13	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3813QQ0Z07Z15	38-RRG3813QQ0Z07Z15	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3813QQZ11Z35	38-RRG3813QQZ11Z35	2018	OBSOLETE	BISQUE COLOR 20MM GLOSS
Rocker	RRG3813QQZ11Z82	38-RRG3813QQZ11Z82	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3813QQZ14Z35	38-RRG3813QQZ14Z35	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3813QQZ14Z40	38-RRG3813QQZ14Z40	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3813QQZ15Z35	38-RRG3813QQZ15Z35	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3813QQZ15Z57	38-RRG3813QQZ15Z57	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3813QQZ16Z35	38-RRG3813QQZ16Z35	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3813QQZ16Z57	38-RRG3813QQZ16Z57	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3813QQZ17Z35	38-RRG3813QQZ17Z35	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3813QQZ17Z57	38-RRG3813QQZ17Z57	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3813QQZ18Z35	38-RRG3813QQZ18Z35	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3813QQZ18Z57	38-RRG3813QQZ18Z57	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3813QQZ23Z35	38-RRG3813QQZ23Z35	2018	OBSOLETE	20mm GLOSSY BISQUE COLOR
Rocker	RRG3813QQZ23Z57	38-RRG3813QQZ23Z57	2018	OBSOLETE	20mm GLOSSY BISQUE COLOR
Rocker	RRG3813QQZ24Z35	38-RRG3813QQZ24Z35	2018	OBSOLETE	20mm GLOSSY BISQUE COLOR
Rocker	RRG3813QQZ24Z81	38-RRG3813QQZ24Z81	2018	OBSOLETE	BISQUE COLOR 20MM GLOSSY
Rocker	RRG3813QQZ30Z82	38-RRG3813QQZ30Z82	2018	OBSOLETE	BISQUE COLOR 20MM GLOSSY
Rocker	RRG3813QQZ30Z83	38-RRG3813QQZ30Z83	2018	OBSOLETE	BISQUE COLOR 20MM GLOSSY
Rocker	RRG3813QQZ30Z84	38-RRG3813QQZ30Z84	2018	OBSOLETE	BISQUE COLOR 20MM GLOSSY
Rocker	RRG3813QQZ32Z84	38-RRG3813QQZ32Z84	2018	OBSOLETE	BISQUE COLOR 20MM GLOSSY



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Rocker	RRG3813QQZ32285	38-RRG3813QQZ32285	2018	OBSOLETE	BISQUE COLOR 20MM GLOSSY
Rocker	RRG3813QQZ35288	38-RRG3813QQZ35288	2018	OBSOLETE	BISQUE COLOR 20MM GLOSSY
Rocker	RRG3813Z04Z0400	38-RRG3813Z04Z0400	2018	OBSOLETE	20MM GLOSSY
Rocker	RRG3813Z07Z0700	38-RRG3813Z07Z0700	2018	OBSOLETE	
Rocker	RRG381C1100	38-RRG381C1100	2018	OBSOLETE	BLACK COLOR 20mm GLOSSY
Rocker	RRG381C1121	38-RRG381C1121	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG383C1100	38-RRG383C1100	2018	OBSOLETE	BLACK COLOR 20mm GLOSSY
Rocker	RRG3843112212	38-RRG3843112212	2018	OBSOLETE	BLACK COLOR 20mm GLOSSY
Rocker	RRG3843112236	38-RRG3843112236	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG384311202202	38-RRG384311202202	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG384311202211	38-RRG384311202211	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG384311203202	38-RRG384311203202	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG384311204212	38-RRG384311204212	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG384311205212	38-RRG384311205212	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG384311207214	38-RRG384311207214	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG384311209236	38-RRG384311209236	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG38432200	38-RRG38432200	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG38432202202	38-RRG38432202202	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG38432203202	38-RRG38432203202	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG38432204212	38-RRG38432204212	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG38432206214	38-RRG38432206214	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG38432210236	38-RRG38432210236	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG38433300	38-RRG38433300	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG384333205212	38-RRG384333205212	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG384333207214	38-RRG384333207214	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3843QQ00	38-RRG3843QQ00	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3843QQ1Z12	38-RRG3843QQ1Z12	2018	OBSOLETE	BISQUE COLOR 20mm GLOSSY
Rocker	RRG3843QQZ03202	38-RRG3843QQZ03202	2018	OBSOLETE	BISQUE COLOR 20MM GLOSSY
Rocker	RRG3843QQZ07214	38-RRG3843QQZ07214	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3843QQZ11Z36	38-RRG3843QQZ11Z36	2018	OBSOLETE	BISQUE COLOR 20MM GLOSSY
Rocker	RRG3853112235	38-RRG3853112235	2018	OBSOLETE	20MM GLOSSY
Rocker	RRG3853112257	38-RRG3853112257	2018	OBSOLETE	
Rocker	RRG3853112135	38-RRG3853112135	2018	OBSOLETE	
Rocker	RRG385311213240	38-RRG385311213240	2018	OBSOLETE	20mm GLOSSY BLACK
Rocker	RRG385311233288	38-RRG385311233288	2018	OBSOLETE	BLACK COLOR 20mm GLOSSY
Rocker	RRG385311233289	38-RRG385311233289	2018	OBSOLETE	BLACK COLOR 20mm GLOSSY
Rocker	RRG3853QQ00	38-RRG3853QQ00	2018	OBSOLETE	20MM GLOSSY
Rocker	RRG3853QQZ24235	38-RRG3853QQZ24235	2018	OBSOLETE	20MM GLOSSY
Rocker	RRG3853QQZ24257	38-RRG3853QQZ24257	2018	OBSOLETE	20MM GLOSSY
Rocker	RRG3853QQZ35235	38-RRG3853QQZ35235	2018	OBSOLETE	BISQUE COLOR 20MM GLOSSY
Rocker	RRG3853QQZ35288	38-RRG3853QQZ35288	2018	OBSOLETE	BISQUE COLOR 20mm GLOSSY
Rocker	RRG3853QQZ35289	38-RRG3853QQZ35289	2018	OBSOLETE	BISQUE COLOR 20mm GLOSSY
Rocker	RRG3853Z04Z0415	38-RRG3853Z04Z0415	2018	OBSOLETE	
Rocker	RRG385C1100	38-RRG385C1100	2018	OBSOLETE	BLACK COLOR 20mm GLOSSY
Rocker	RRG38A31500	38-RRG38A31500	2018	OBSOLETE	BLACK COLOR 20mm GLOSSY
Rocker	RRG3813Z07Z07223235-F1	38-RRG3500002	2018	OBSOLETE	WHITE PLASTIC # 1251
Rocker	RRG3813Z07Z07223257-F1	38-RRG3500003	2018	OBSOLETE	WHITE PLASTIC # 1251
Rocker	RRG3813Z04Z041257	38-RRG3500011	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3813Z07Z07215257-F1	38-RRG3500013	2018	OBSOLETE	WHITE PLASTIC # 1251
Rocker	RRG3813Z07Z07215235-F1	38-RRG3500014	2018	OBSOLETE	WHITE PLASTIC # 1251
Rocker	RRG3813Z07Z07216257-F1	38-RRG3500023	2018	OBSOLETE	WHITE PLASTIC #1251
Rocker	RRG3843Z07Z07203202-F1	38-RRG3500024	2018	OBSOLETE	WHITE PLASTIC #1251
Rocker	RRG3813Z07Z07218235-F1	38-RRG3500025	2018	OBSOLETE	WHITE PLASTIC #1251
Rocker	RRG3813Z07Z07218257-F1 8	38-RRG3500026	2018	OBSOLETE	WHITE PLASTIC #1251**
Rocker	RRG3843Z05Z05203202	38-RRG3500062	2018	OBSOLETE	
Rocker	RRG3813Z05Z05212235	38-RRG3500063	2018	OBSOLETE	
Rocker	RRG3813Z05Z05212240	38-RRG3500064	2018	OBSOLETE	
Rocker	RRG3813Z05Z05212253	38-RRG3500065	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3813Z05Z05212254	38-RRG3500066	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3Z02C3Z04Z0400	38-RRG3500100	2018	OBSOLETE	
Rocker	RRG3813Z07Z07203211-F1	38-RRG3500156	2018	OBSOLETE	WHITE PLASTIC #1251
Rocker	RRG3813Z07Z07203213-F1	38-RRG3500159	2018	OBSOLETE	WHITE PLASTIC #1251
Rocker	RRG3813C3Z07Z07212240-F1	38-RRG3500168	2018	OBSOLETE	WHITE PLASTIC # 1251**
Rocker	RRG31C3Z07Z0700-F1	38-RRG3500169	2018	OBSOLETE	WHITE PLASTIC #1251
Rocker	RRG3853Z07Z0700-F1	38-RRG3500171	2018	OBSOLETE	WHITE PLASTIC #1251
Rocker	RRG3813Z04Z041240	38-RRG3500178	2018	OBSOLETE	20MM GLOSSY GREY
Rocker	RRG3853Z04Z041240	38-RRG3500179	2018	OBSOLETE	20MM GLOSSY GREY
Rocker	RRG3813Z04Z042280	38-RRG3500181	2018	OBSOLETE	
Rocker	RRG3853Z04Z042281	38-RRG3500183	2018	OBSOLETE	
Rocker	RRG3813Z07Z071Z82-F1	38-RRG3500186	2018	OBSOLETE	
Rocker	RRG3813Z04Z04221Z82	38-RRG3500187	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3853Z07Z07212257	38-RRG3500188	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3853Z07Z07212257-F1	38-RRG3500189	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3813Z07Z07212281-F1	38-RRG3500190	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3853Z07Z07212235-F1	38-RRG3500191	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3813Z07Z07229283-F1	38-RRG3500202	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3813Z07Z07229282-F1	38-RRG3500204	2018	OBSOLETE	20mm GLOSSY
Rocker	RRG3853Z07Z07234Z89-F1	38-RRG3500212	2018	OBSOLETE	WHITE COLOR 20mm GLOSSY
Rocker	RRG3853Z07Z07234Z88-F1	38-RRG3500213	2018	OBSOLETE	WHITE COLOR 20mm GLOSSY
Rocker	RRG3813Z07Z07234Z88-F1	38-RRG3500214	2018	OBSOLETE	WHITE COLOR 20MM GLOSSY



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Rocker	RRG3813112372104	38-RRG3500254	2018	OBSOLETE	
Rocker	RRG3813207207Z38Z104	38-RRG3500255	2018	OBSOLETE	
Rocker	RRG3813QQZ242104	38-RRG3500256	2018	OBSOLETE	
Rocker	RRG3853112372105	38-RRG3500258	2018	OBSOLETE	
Rocker	RRG3853207207Z38Z105	38-RRG3500259	2018	OBSOLETE	
Rocker	RRG3853QQZ242105	38-RRG3500260	2018	OBSOLETE	
Rocker	RRGA1131100	38-RRGA1131100	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA14C1200	38-RRGA14C1200	2017	OBSOLETE	22mm GLOSSY
Rocker	RRGA1C31100	38-RRGA1C31100	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA1C32200	38-RRGA1C32200	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA5131121	38-RRGA5131121	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA8131100	38-RRGA8131100	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA8131121	38-RRGA8131121	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA81311209293	38-RRGA81311209293	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA81311228207	38-RRGA81311228207	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA81311236285	38-RRGA81311236285		OBSOLETE	SEE 38-RRGA81311236290
Rocker	RRGA81311236290	38-RRGA81311236290	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA8132200	38-RRGA8132200	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA813QQ00	38-RRGA813QQ00	2018	OBSOLETE	
Rocker	RRGA813QQZ11235	38-RRGA813QQZ11235	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA813QQZ12235	38-RRGA813QQZ12235	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA813QQZ28207	38-RRGA813QQZ28207	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA813QQZ28209	38-RRGA813QQZ28209	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA81320720700	38-RRGA81320720700	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA81321421400	38-RRGA81321421400	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA81321621600	38-RRGA81321621600	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA81321721700	38-RRGA81321721700	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA81C1121	38-RRGA81C1121	2017	OBSOLETE	22mm GLOSSY
Rocker	RRGA8431100	38-RRGA8431100	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA84311228209	38-RRGA84311228209	2017	OBSOLETE	22mm GLOSSY
Rocker	RRGA84311236236	38-RRGA84311236236	2012	OBSOLETE	SEE 38-RRGA84311236291
Rocker	RRGA84311236291	38-RRGA84311236291	2018	OBSOLETE	
Rocker	RRGA843QQ00	38-RRGA843QQ00	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA843QQZ03202	38-RRGA843QQZ03202	2018	OBSOLETE	22mm BISQUE
Rocker	RRGA843QQZ11236	38-RRGA843QQZ11236	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA843QQZ28207	38-RRGA843QQZ28207	2012	OBSOLETE	See 38-RRGA813QQZ28207
Rocker	RRGA843QQZ28209	38-RRGA843QQZ28209	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA84321421400	38-RRGA84321421400	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA84321621600	38-RRGA84321621600	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA8C31100	38-RRGA8C31100	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA8C320720700	38-RRGA8C320720700	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA8C321421400	38-RRGA8C321421400	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA8C321621600	38-RRGA8C321621600	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA843207207Z26Z09	38-RRGA500200	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA813207207Z26Z07	38-RRGA500201	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA833215Z15Z11Z10	38-RRGA500218	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA8132142141207	38-RRGA500219	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA8432162161294	38-RRGA500229	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA8132162161292	38-RRGA500230	2018	OBSOLETE	22mm GLOSSY
Rocker	RRGA843207207Z03Z202	38-RRGA500233	2018	OBSOLETE	WHITE PLASTIC # 1251
Rocker	RSC14001000-137	14-RSC14001000137	2018	OBSOLETE	
Rocker	RSC141D1000-114	14-RSC141D1000114	2018	OBSOLETE	
Rocker	RSC141D1000-117	14-RSC141D1000117	2018	OBSOLETE	
Rocker	RSC141D1000-124	14-RSC141D1000124	2018	OBSOLETE	
Rocker	RSC141D1000-126	14-RSC141D1000126		OBSOLETE	SEE 38-RSC141D1000126
Rocker	RSC141D1000-127	14-RSC141D1000127	2018	OBSOLETE	
Rocker	RSC141D1123	14-RSC141D1123	2018	OBSOLETE	
Rocker	RSC141D1200	14-RSC141D1200	2018	OBSOLETE	
Rocker	RSC141D1900	14-RSC141D1900		OBSOLETE	SEE 38-RSC141D1900
Rocker	RSC141D1A00	14-RSC141D1A00	2018	OBSOLETE	
Rocker	RSC141D1A23	14-RSC141D1A23	2018	OBSOLETE	
Rocker	RSC141D2000-106	14-RSC141D2000106	2018	OBSOLETE	
Rocker	RSC141D2200	14-RSC141D2200	2018	OBSOLETE	
Rocker	RSC141D2C83	14-RSC141D2C83	2018	OBSOLETE	
Rocker	RSC143D1100	14-RSC143D1100	2018	OBSOLETE	
Rocker	RSC191D1021-136	14-RSC191D1021136	2018	OBSOLETE	
Rocker	RSC191D1021-144	14-RSC191D1021144	2018	OBSOLETE	
Rocker	RSC191D1121	14-RSC191D1121	2018	OBSOLETE	
Rocker	RSC241C1000116	14-RSC241C1000116	2018	OBSOLETE	
Rocker	RSC241D1000-137	14-RSC241D1000137	2018	OBSOLETE	
Rocker	RSC241D1021-116	14-RSC241D1021116	2018	OBSOLETE	
Rocker	RSC241D1021-133	14-RSC241D1021133	2018	OBSOLETE	
Rocker	RSC241D1023-135	14-RSC241D1023135	2018	OBSOLETE	
Rocker	RSC241D1A00	14-RSC241D1A00	2018	OBSOLETE	
Rocker	RSC241D1A8L	14-RSC241D1A8L	2018	OBSOLETE	
Rocker	RSC241D2013-105	14-RSC241D2013105	2018	OBSOLETE	
Rocker	RSC341D1000-116	14-RSC341D1000116	2018	OBSOLETE	
Rocker	RSC341D1000-117	14-RSC341D1000117	2018	OBSOLETE	
Rocker	RSC341D1123	14-RSC341D1123	2018	OBSOLETE	
Rocker	RSC341D1A23	14-RSC341D1A23	2018	OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Rocker	RSC441D1000-136	14-RSC441D1000136	2018	OBSOLETE	
Rocker	RSC441D1121	14-RSC441D1121	2018	OBSOLETE	
Rocker	RSC441D1A2R	14-RSC441D1A2R	2018	OBSOLETE	
Rocker	RSC441D2211	14-RSC441D2211	2018	OBSOLETE	
Rocker	RSCHT14001000-117	14-RSCHT1400100011	2012	OBSOLETE	NO STAMP - SEE 14-RSCS00224
Rocker	RSC141C1000-116	38-RSC141C1000116	2018	OBSOLETE	
Rocker	RSC141C1900	38-RSC141C1900	2018	OBSOLETE	
Rocker	RSC141D1000-126	38-RSC141D1000126	2018	OBSOLETE	
Rocker	RSC141D1011-137	38-RSC141D1011137	2018	OBSOLETE	
Rocker	RSC141D1021-137	38-RSC141D1021137	2018	OBSOLETE	
Rocker	RSC141D1121	38-RSC141D1121	2018	OBSOLETE	
Rocker	RSC141D1900	38-RSC141D1900	2018	OBSOLETE	
Rocker	RSC144C1100	38-RSC144C1100	2018	OBSOLETE	
Rocker	RSC144C1900	38-RSC144C1900	2018	OBSOLETE	
Rocker	RSC145C112223	38-RSC145C112223	2018	OBSOLETE	
Rocker	RSC145C1900	38-RSC145C1900	2018	OBSOLETE	
Rocker	RSC145D1425	38-RSC145D1425	2018	OBSOLETE	
Rocker	RSC145D1900	38-RSC145D1900	2018	OBSOLETE	
Rocker	RSC241C1000-117	38-RSC241C1000117	2018	OBSOLETE	
Rocker	RSC241C1121	38-RSC241C1121	2018	OBSOLETE	
Rocker	RSC241C112R	38-RSC241C112R	2018	OBSOLETE	
Rocker	RSC241D4400	38-RSC241D4400	2018	OBSOLETE	
Rocker	RSC245D4400	38-RSC245D4400	2018	OBSOLETE	
Rocker	RSC293C1123	38-RSC293C1123	2018	OBSOLETE	
Rocker	RSC293C112HILO	38-RSC293C112HILO	2018	OBSOLETE	
Rocker	RSCF141D1100	38-RSCF141D1100	2018	OBSOLETE	
Rocker	RSCF141D1123	38-RSCF141D1123	2018	OBSOLETE	
Rocker	RSCF241D1000-126	38-RSCF241D1000126	2018	OBSOLETE	
Rocker	RVW12D1123	34-RVW12D1123	2017	OBSOLETE	
Rocker	RVW42D1100-116	34-RVW42D1100116	2017	OBSOLETE	
Rocker	RVW42D1100-117	34-RVW42D1100117	2017	OBSOLETE	
Rocker	RVW42D1100-126	34-RVW42D1100126	2017	OBSOLETE	
Rocker	RVW42D1100-137	34-RVW42D1100137	2017	OBSOLETE	
Rocker	RVW42D1100-nr	34-RVW42D1100NR		OBSOLETE	
Rocker	RVW42D1121	34-RVW42D1121	2017	OBSOLETE	
Rocker	RVW42D1121-nr	34-RVW42D1121NR		OBSOLETE	
Rocker	RVW42D1123-136	34-RVW42D1123136	2017	OBSOLETE	
Rocker	RVW43D1100	34-RVW43D1100	2017	OBSOLETE	
Rocker	RVW45D1100	34-RVW45D1100	2017	OBSOLETE	
Rocker	RVW46D1100-nr	34-RVW46D1100NR		OBSOLETE	
Rocker	RVWG41D1200	34-RVWG41D1200	2017	OBSOLETE	
Rocker	RVWG42D1200	34-RVWG42D1200	2017	OBSOLETE	
Rocker	RVWG46D1200	34-RVWG46D1200	2017	OBSOLETE	
Rocker	RVWG4ED1200	34-RVWG4ED1200	2017	OBSOLETE	
Rocker	RVWG4GD1100	34-RVWG4GD1100	2017	OBSOLETE	
Rocker	RVWG4GD1200	34-RVWG4GD1200	2017	OBSOLETE	
Rocker	WB24ED1100-nr	34-WB24ED1100NR		OBSOLETE	
Rocker	WB24ED1121-nr	34-WB24ED1121NR		OBSOLETE	
Rocker	WB24GD1100-nr	34-WB24GD1100NR		OBSOLETE	
Rocker	WB24KD1100-nr	34-WB24KD1100NR		OBSOLETE	
Rocker	WB24ED1100-ACC-KF05	34-WB2500223	2018	OBSOLETE	
Rocker	WB242D1100-ACC-KF05	34-WB2500227	2018	OBSOLETE	
Rocker	WB242D1121-ACC-KF05	34-WB2500228	2018	OBSOLETE	
Rotary	440458	12-440458	2017	OBSOLETE	Active in QAD - No longer manufactured
Rotary	4404B	12-4404B	2017	OBSOLETE	No longer manufactured
Rotary	44501	12-440501	2017	OBSOLETE	No longer manufactured
Rotary	46RCH7505	12-467505	2017	OBSOLETE	No longer manufactured
Rotary	48-0311	12-480311	2017	OBSOLETE	No longer manufactured
Rotary	48-03111	12-4803111	2017	OBSOLETE	No longer manufactured
Rotary	480510	12-480510	2017	OBSOLETE	No longer manufactured
Rotary	680307	12-680307	2017	OBSOLETE	No longer manufactured
Rotary	46RCH750516	12-750516	2017	OBSOLETE	No longer manufactured
Rotary	KC52A01NLS	C510240		OBSOLETE	
Rotary	K15B02NPF831.5WITHSL0T	C510252		OBSOLETE	
Rotary	KCBRASSNUT3/8-13.35AF	C510255		OBSOLETE	
Rotary	KC43A01NLS	C510270		OBSOLETE	
Rotary	KC10A01NPS	C510430		OBSOLETE	
Rotary	KC40A01NPS	C510472		OBSOLETE	
Rotary	KC26E01SPS	C510532		OBSOLETE	(NOFLAT)
Rotary	KC33C01	C510701		OBSOLETE	(SIMPSON06-115486)
Rotary	KC52A01NPF	C510761		OBSOLETE	
Rotary	KC52A01NPH	C510762		OBSOLETE	
Rotary	KC24E01SLS	C510897		OBSOLETE	
Rotary	KC26E01NLS	C523729		OBSOLETE	
Rotary	KC26E01NPS	C523730		OBSOLETE	
Rotary	KC15A01NLS	C527535		OBSOLETE	
Rotary	KC15E01NPF	C527536		OBSOLETE	
Rotary	KC30A01NLF	C527541		OBSOLETE	
Rotary	KC52E01NLF	C527551		OBSOLETE	PLEASE ORDER G510241
Rotary	KC14A01NPS10MM	C530164		OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Rotary	KC-25-A (7.5) -01-N-P-F	G510251	2021	OBSOLETE	
Rotary	KC-52-B-02-N-L-S	G510258	2021	OBSOLETE	
Rotary	KC52A30.001SLS	G510340		OBSOLETE	SEE - G510541
Rotary	KC26A13.001NPS	G510351		OBSOLETE	
Rotary	KC81A9.501NPS	G510353		OBSOLETE	
Rotary	KC26X01NLSNOTAB	G510401	2008	OBSOLETE	
Rotary	KC26B30.002NLS	G510403		OBSOLETE	
Rotary	KC43A01NPSB16.3MM	G510471	2017	OBSOLETE	Decreasing demand, stream line series
Rotary	KC42A9.501SLS	G510473		OBSOLETE	
Rotary	KC60B02NPS	G510590		OBSOLETE	
Rotary	KC56A13.001NPF	G510593		OBSOLETE	SEE G511001
Rotary	KC14E01NLS	G510714		OBSOLETE	SEE G511012
Rotary	KC14B02NLSEFULLFLAT	G510891		OBSOLETE	
Rotary	KC60A13.001NLS	G511008		OBSOLETE	W/NO STOPS
Rotary	KC50A12.501SLS	G530100		OBSOLETE	
Rotary	KC14A01NPS10.0MM	G530164		OBSOLETE	SEE G530166
Rotary	KC1901N	P010701	2011	OBSOLETE	N actuator requires 10k MOQ to produce, see std.KC1901A Active drawing P010700
Rotary	KC60RANCONPF2	XG0001P	2017	OBSOLETE	Custom materials no longer available
Rotary	KC60RANCONPF2WITHGASKET	XG0004A		OBSOLETE	AND HARDWARE
Rotary DIP	DR45-10R-B	06-DR4510RB		OBSOLETE	
Rotary DIP	SRJ-10	04-SRJ10	2017	OBSOLETE	
Rotary DIP	SRJ-10H	04-SRJ10H	2017	OBSOLETE	
Rotary DIP	SRJ-16	04-SRJ16	2017	OBSOLETE	
Rotary DIP	SRJ-16C	04-SRJ16C	2017	OBSOLETE	
Rotary DIP	SRJ-8H	04-SRJ8H	2017	OBSOLETE	
Rotary DIP	SRK-10	04-SRK10	2016	OBSOLETE	
Rotary DIP	SRK-10C	04-SRK10C	2016	OBSOLETE	
Rotary DIP	SRK-16C	04-SRK16C		OBSOLETE	SEE ENGR
Rotary DIP	SRK-16HC	04-SRK16HC	2016	OBSOLETE	
Rotary DIP	SRK-16-nr	04-SRK16NR		OBSOLETE	
Rotary DIP	SRM-10	04-SRM10	2017	OBSOLETE	
Rotary DIP	SRM-16CTTR	04-SRM16CTTR	2017	OBSOLETE	
Rotary DIP	SRM-16-nr	04-SRM16NR		OBSOLETE	
Rotary DIP	SRM-16TTR	04-SRM16TTR	2017	OBSOLETE	
Rotary DIP	SRT-10RA	04-SRT10RA	2017	OBSOLETE	
Rotary DIP	SRT16R	04-SRT16R	2017	OBSOLETE	SEE SRT16RA
Rotary DIP	SRT-16RA	04-SRT16RA	2017	OBSOLETE	
Rotary DIP	SRT-16RC	04-SRT16RC	2017	OBSOLETE	
Slide	5005SP251M1QEB	T512003		OBSOLETE	SEE - T531003
Slide	LDT1100SILVER	D010011		OBSOLETE	
Slide	LDT1100GOLD	D010012		OBSOLETE	
Slide	LDT1110SILVER	D010013		OBSOLETE	
Slide	LDT1100BLACKXX	D040101		OBSOLETE	
Slide	LDT1100BLKOO	D040111		OBSOLETE	
Slide	1110BLKWTH2LED	D040161		OBSOLETE	WINDOWS**
Slide	1300SILVER1.2	D010001		OBSOLETE	
Slide	1300GOLD1.2	D010002		OBSOLETE	
Slide	1300BLACKX	D040001		OBSOLETE	
Slide	1300BEIGEX	D040002		OBSOLETE	
Slide	1300BLACKO	D040021		OBSOLETE	
Slide	1300BEIGEO	D040022		OBSOLETE	
Slide	1350BLACKOO	D040061		OBSOLETE	
Slide	5005SP152M6REA	T110235		OBSOLETE	
Slide	5005SP152M7REA	T511037		OBSOLETE	SEE T511026
Slide	5005DP1S26.75mmM6QEA	T521015		OBSOLETE	SEE T521011
Slide	5005DP1S1M7QEA	T521024		OBSOLETE	SEE T521012
Slide	600DP3S1M2RE	T620002		OBSOLETE	
Slide	600DP3S1M2QE	T620304		OBSOLETE	
Slide	EG2601A	03-EG2601A	2015	OBSOLETE	No equivalent nor drop in replacements at this time
Slide	EG1260ASQ	D041200	2012	OBSOLETE	No replacement
Slide	EG1260BSQ	D041201	2012	OBSOLETE	No replacement
Slide	EG1260CSQ	D041202	2009	OBSOLETE	No replacement
Slide	EG1260ASR	D041203	2009	OBSOLETE	No replacement
Slide	EG1260BSR	D041204	2009	OBSOLETE	No replacement
Slide	EG1260CSR	D041205	2009	OBSOLETE	No replacement
Slide	EG1260ANQ	D041210	2009	OBSOLETE	No replacement
Slide	EG1260BNQ	D041211	2009	OBSOLETE	No replacement
Slide	EG1260CNQ	D041212	2009	OBSOLETE	No replacement
Slide	EG1260ANR	D041213	2009	OBSOLETE	No replacement
Slide	EG1260BNR	D041214	2009	OBSOLETE	No replacement
Slide	EG1260CNR	D041215	2009	OBSOLETE	No replacement
Slide	EG1300A	D041220	2012	OBSOLETE	No replacement
Slide	EG1300B	D041221	2012	OBSOLETE	No replacement
Slide	EG1400A	D041230	2012	OBSOLETE	No replacement
Slide	EG1400B	D041231	2012	OBSOLETE	No replacement
Slide	EG1390A	D041240	2012	OBSOLETE	No replacement
Slide	EG1390B	D041241	2012	OBSOLETE	No replacement
Slide	EG1380A	D041250	2012	OBSOLETE	No replacement
Slide	EG1381A	D041251	2012	OBSOLETE	No replacement
Slide	EG1201PC	P040012	2009	OBSOLETE	No replacement



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Slide	EG1201APC	P040013	2018	OBSOLETE	No longer manufactured
Slide	EG1302A	P040014	2009	OBSOLETE	No replacement
Slide	EG1201	P040015		OBSOLETE	SPECIAL HIGH FORCE
Slide	EG121394V0	P040031		OBSOLETE	
Slide	EG1230	P040032	2020	OBSOLETE	
Slide	EG1218CUTLEADS	P040041		OBSOLETE	
Slide	EG1302	P040050	2009	OBSOLETE	No replacement
Slide	EG1253	P040053	2009	OBSOLETE	No replacement
Slide	EG1307	P040056	2009	OBSOLETE	No replacement
Slide	EG2201C	P040073	2009	OBSOLETE	No replacement
Slide	EG2201AF650	P040075		OBSOLETE	
Slide	EG2202	P040080	2009	OBSOLETE	No replacement
Slide	EG2202A	P040081	2009	OBSOLETE	No replacement
Slide	EG2202B	P040082	2009	OBSOLETE	No replacement
Slide	EG2202SHORTING	P040083		OBSOLETE	
Slide	EG220594V0	P040085	2013	OBSOLETE	No replacement
Slide	EG2205	P040090	2009	OBSOLETE	No replacement
Slide	EG2205A	P040091	2013	OBSOLETE	No replacement
Slide	EG2210D	P040132	2009	OBSOLETE	No replacement
Slide	EG2215A	P040161	2017	OBSOLETE	Factory can no longer produce
Slide	EG2303	P040190	2013	OBSOLETE	No replacement
Slide	EG2303NODETENT	P040191	2013	OBSOLETE	No replacement
Slide	EG2305B	P040203	2009	OBSOLETE	9mm actuator discontinued, see EG2305 (4mm act), EG2305A (2mm act)
Slide	EG2308A SPECIAL	P040213	2013	OBSOLETE	No replacement
Slide	EG231094V0	P040232	2013	OBSOLETE	No replacement
Slide	EG2323	P040261	2009	OBSOLETE	No replacement
Slide	EG2323A	P040262	2015	OBSOLETE	No longer feasible to produce, No replacement
Slide	EG2324	P040265	2013	OBSOLETE	No replacement
Slide	EG2325	P040270	2009	OBSOLETE	No replacement
Slide	EG2325A	P040271	2018	OBSOLETE	Factory no longer produces
Slide	EG2325B	P040272		OBSOLETE	No replacement
Slide	EG001A42BANAUFC12B	P040276		OBSOLETE	GOLD**
Slide	EG001E22BANAGFC12B	P040277		OBSOLETE	
Slide	EG4208V0	P040282		OBSOLETE	NON SHORTING
Slide	EG2601	P040284	2014	OBSOLETE	No longer feasible to produce, No replacement
Slide	EG4311	P040285	2009	OBSOLETE	No replacement
Slide	EG4208GSS	P040286		OBSOLETE	
Slide	EG2601A	P040287		OBSOLETE	No longer feasible to produce, No replacement
Slide	EG2601C	P040288		OBSOLETE	No longer feasible to produce, No replacement
Slide	EG431994V0	P040292		OBSOLETE	
Slide	EG6203	P106200	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG1219	P112190	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG1220	P112200	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG1220A	P112201	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG2220B	P112202	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG2221D	P112212	2003	OBSOLETE	non-RoHS, no replacement
Slide	EG1222	P112220	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG1315	P113150	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG1317	P113170	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG1318	P113180	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG1319	P113190	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG2220	P122200	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG 2220A Non-Shorting	P122201	2021	OBSOLETE	
Slide	EG2221	P122210	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG2221C	P122215	2007	OBSOLETE	non-RoHS, no replacement
Slide	EG2223	P122230	2009	OBSOLETE	non-RoHS, no replacement
Slide	EG2225	P122250	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG 2228	P122280	2021	OBSOLETE	
Slide	EG 2229	P122290	2021	OBSOLETE	
Slide	EG2233	P122330	2003	OBSOLETE	non-RoHS, no replacement
Slide	EG 2235	P122350	2021	OBSOLETE	
Slide	EG2236A	P122361	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG2263	P122380	2021	OBSOLETE	
Slide	EG2326	P123260	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG2326A	P123261	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG 2327	P123270	2021	OBSOLETE	
Slide	EG 2335	P123350	2021	OBSOLETE	
Slide	EG2335A	P123351	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG2405	P124050	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG2405A	P124051	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG4211	P142110	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG 4211A	P142111	2021	OBSOLETE	
Slide	EG4212	P142120	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG4212A	P142121	2021	OBSOLETE	
Slide	EG4212B	P142122	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG4215	P142150	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG4216	P142160	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG4217A	P142171	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG4218	P142180	2021	OBSOLETE	
Slide	EG4302	P143020	2006	OBSOLETE	non-RoHS, no replacement



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Slide	EG4302A	P143021	2017	OBSOLETE	Factory no longer produces
Slide	EG4302B	P143022	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG4303A	P143031	2014	OBSOLETE	non-RoHS, no replacement
Slide	EG4303A	P143031	2021	OBSOLETE	
Slide	EG4304GUL94V0	P143039		OBSOLETE	
Slide	EG4304	P143040	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG4305	P143050	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG4306	P143060		OBSOLETE	SEE P143031
Slide	EG4401	P144010	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG4403	P144030	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG6202	P162020	2021	OBSOLETE	
Slide	EG6203TTAPPEDHOLES	P162031		OBSOLETE	(TIN ONLY CHASSIS)
Slide	EG6205	P162050	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG6301	P163010	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG6301AAU	P163011		OBSOLETE	5 MICRO-INCH GOLD
Slide	EG6301A	P163012	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG8202	P182020	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG8202A	P182021	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG8203	P182030	2006	OBSOLETE	non-RoHS, no replacement
Slide	EG8402	P184020	2017	OBSOLETE	No longer produced by Factory
Slide	EG4208GSTRAYED	XA1791A		OBSOLETE	
Slide	EG420894V0TINDIPPED	XP0030A		OBSOLETE	(SEE XP0030P)
Slide	EG2202SHORTINGSL	XP0067A		OBSOLETE	SPECIAL (SEE XP0067P)
Slide	EG2310TRAYED	XP0133A		OBSOLETE	(SEE XP0133P)
Slide	EG1213TRAYED	XP0134A		OBSOLETE	(SEE XP0134P)
Slide	EG1213TRAYED	XP0134P		OBSOLETE	SEE P040030 FOR ORDERS
Slide	EG8402TRAYED	XP0142A		OBSOLETE	(SEE XP0142P)
Slide	LSS-120312B4-G	03-LSS120312B4G	2015	OBSOLETE	No equivalent nor drop in replacements at this time
Slide	LSS-130511A7-G	03-LSS130511A7G	2015	OBSOLETE	No equivalent nor drop in replacements at this time
Slide	LSS-420101A5	03-LSS420101A5	2015	OBSOLETE	No replacement, 20k MOQ plus certification testing/filing fees required to re-activate
Slide	LSS-430101A5	03-LSS430101A5	2015	OBSOLETE	No replacement, 20k MOQ plus certification testing/filing fees required to re-activate
Slide	LSU11-120001A9	03-LSU11120001A9	2015	OBSOLETE	No replacement, 20k MOQ plus certification testing/filing fees required to re-activate
Slide	LSU11-120002A2	03-LSU11120002A2	2015	OBSOLETE	No replacement, 20k MOQ plus certification testing/filing fees required to re-activate
Slide	LSU11-120002A9	03-LSU11120002A9	2015	OBSOLETE	No equivalent nor drop in replacements at this time
Slide	LSU11-220001A9	03-LSU11220001A9	2015	OBSOLETE	No replacement, 20k MOQ plus certification testing/filing fees required to re-activate
Slide	LSU11-220002A9	03-LSU11220002A9	2015	OBSOLETE	No replacement, 20k MOQ plus certification testing/filing fees required to re-activate
Slide	LSU11-230101A3	03-LSU11230101A3	2015	OBSOLETE	No replacement, 20k MOQ plus certification testing/filing fees required to re-activate
Slide	LSU11-230101A8.6	03-LSU11230101A86	2015	OBSOLETE	No replacement, 20k MOQ plus certification testing/filing fees required to re-activate
Slide	LSU4-220201A35	03-LSU4220201A35	2015	OBSOLETE	No replacement, 20k MOQ plus certification testing/filing fees required to re-activate
Slide	SK-12G01-G3	03-SK12G01G3	2015	OBSOLETE	No equivalent nor drop in replacements at this time
Slide	SK-22F05-G7	03-SK22F05G7	2015	OBSOLETE	No equivalent nor drop in replacements at this time
Slide	SS-12E01-G(B)6-00	03-SS12E01GB600	2015	OBSOLETE	No equivalent nor drop in replacements at this time
Slide	SS-12F20-G(A)5	03-SS12F20GA5	2015	OBSOLETE	No equivalent nor drop in replacements at this time
Slide	SS-12F23-G(A)10	03-SS12F23GA10	2015	OBSOLETE	No equivalent nor drop in replacements at this time
Slide	SS-22F06-G5-A	03-SS22F06G5A	2015	OBSOLETE	No equivalent nor drop in replacements at this time
Slide	SS-22F18-T13	03-SS22F18T13	2015	OBSOLETE	No equivalent nor drop in replacements at this time
Slide	SS-23E01-T17	03-SS23E01T17	2015	OBSOLETE	No equivalent nor drop in replacements at this time
Slide	SS-24F08-G(A)5-#613	03-SS24F08GA5613	2015	OBSOLETE	No replacement, 20k MOQ plus certification testing/filing fees required to re-activate
Slide	SS-34G01-T(E)10	03-SS34G01TE10	2015	OBSOLETE	No equivalent nor drop in replacements at this time
Slide	U115S-11L05-G(C)0-00	03-U115S11L05GC000	2015	OBSOLETE	No equivalent nor drop in replacements at this time
Slide	U115S-22P01-G16-00	03-U115S22P01G1600	2015	OBSOLETE	No equivalent nor drop in replacements at this time
Slide	U135S-11L04-G(A)5-00-573	03-U135S000076	2015	OBSOLETE	No equivalent nor drop in replacements at this time
Slide	U165S-23N02-G9.5-#575	03-U165SS00117	2015	OBSOLETE	No equivalent nor drop in replacements at this time
Slide	U45S-12J17-G8.5-00	03-U45S12J17G8500	2015	OBSOLETE	No equivalent nor drop in replacements at this time
Slide	U45S-22G09-G10-00	03-U45S22G09G1000		OBSOLETE	SEE 03-U45S22G09G10
Slide	U8PS-12J04-G6-00	03-U8PS12J04G600	2015	OBSOLETE	No equivalent nor drop in replacements at this time
Slide	VS 2221	P000001	2020	OBSOLETE	EOL - Not on Website
Slide	VS 2221-1	P000002	2020	OBSOLETE	EOL - Not on Website
Slide	VS 2221 N	P000003	2020	OBSOLETE	EOL - Not on Website
Slide	VS 2221 (NO MARKING)	P000006	2020	OBSOLETE	EOL - Not on Website
Slide	VS2221NNOMARKING	P000007		OBSOLETE	
Slide	WS-22L24-G(B)7.5	03-WS22L24GB75	2015	OBSOLETE	No equivalent nor drop in replacements at this time
Snap Action	TLDM01	P030001		OBSOLETE	
Snap Action	DM0850101F045P1A	P030004		OBSOLETE	
Snap Action	DM0850100F060P1A-YEL	P030005		OBSOLETE	
Snap Action	DM0850101F015P1A	P030006		OBSOLETE	
Snap Action	DM0850301F045P1A	P030009		OBSOLETE	
Snap Action	DM0850300F125P1A	P030010		OBSOLETE	
Snap Action	DM085Q101F045P1A	P030011		OBSOLETE	
Snap Action	DM085R101F045P1A	P030012		OBSOLETE	
Snap Action	DM085Q103F055P1A	P030013		OBSOLETE	
Snap Action	DM01SPEC	P030015		OBSOLETE	
Snap Action	DM0850300F045P1A	P030016		OBSOLETE	
Snap Action	DM0850300F060P1A	P030017		OBSOLETE	
Snap Action	DM085R100F125P1A	P030018		OBSOLETE	(GOLD CONTACTS)
Snap Action	DM085Q102F050P1A	P030019		OBSOLETE	
Snap Action	DM085Q101F030P1A	P030020		OBSOLETE	
Snap Action	DM085Q100F060P1A	P030022		OBSOLETE	
Snap Action	DM085Q100F125P1A	P030023		OBSOLETE	
Snap Action	DM085R103F055P1A	P030024		OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Snap Action	DM085Q110F025P1A	P030025		OBSOLETE	
Snap Action	DM085R101F015P1A	P030026		OBSOLETE	
Snap Action	DM085R100F060P1A	P030027		OBSOLETE	
Snap Action	DM0850301F015V2A	P030028		OBSOLETE	
Snap Action	DM0850301F015V1A	P030029		OBSOLETE	
Snap Action	DM0850303F050P1A	P030030		OBSOLETE	
Snap Action	DM0850302F050V1A	P030031		OBSOLETE	
Snap Action	DM085R102F050P1A	P030032		OBSOLETE	
Snap Action	DM0850102F025P1A	P030033		OBSOLETE	
Snap Action	DM085Q102F025P1A	P030034		OBSOLETE	
Snap Action	DM0850100F125P1A	P030035		OBSOLETE	
Snap Action	EG2601A	03-EG2601A	2015	OBSOLETE	
Snap Action	LS0851509F060C1A	Q950007		OBSOLETE	
Snap Action	LS0851500F160C1A	Q950013		OBSOLETE	
Snap Action	LS0851500F050C1ASPECIAL	Q950069	2020	OBSOLETE	
Snap Action	LS0851500F__C1ASPECIAL	Q950070	2020	OBSOLETE	
Snap Action	LSS-420101A5	03-LSS420101A5		OBSOLETE	
Snap Action	LSU11-120001A9	03-LSU11120001A9	2014	OBSOLETE	
Snap Action	LSU11-120002A2	03-LSU11120002A2	2014	OBSOLETE	
Snap Action	LSU11-120002A9	03-LSU11120002A9	2014	OBSOLETE	
Snap Action	LSU11-220001A9	03-LSU11220001A9	2014	OBSOLETE	
Snap Action	LSU11-220002A9	03-LSU11220002A9	2014	OBSOLETE	
Snap Action	LSU11-230101A3	03-LSU11230101A3	2014	OBSOLETE	
Snap Action	LSU11-230101A8.6	03-LSU11230101A86	2014	OBSOLETE	
Snap Action	LSU4-220201A35	03-LSU4220201A35	2014	OBSOLETE	
Snap Action	MS0850502F050S1A	Q970003		OBSOLETE	(SEE Q970008)
Snap Action	MS0850501F070S1A	Q970025		OBSOLETE	
Snap Action	MS0850503F025S1A	XQ0007P		OBSOLETE	W/WIRE HARNESS
Snap Action	SMR1LOOP	A021265		OBSOLETE	
Snap Action	SM085Q105F038V1A	A970001		OBSOLETE	
Snap Action	SM0850500F130S1A	A970002		OBSOLETE	
Snap Action	SM085Q100F080C1A	A970003		OBSOLETE	
Snap Action	SM0850300F080C1A	A970004		OBSOLETE	(SEE A970005)
Snap Action	SM0850500F080C1A	A970005		OBSOLETE	
Snap Action	SM085Q100F080S1A	A970006		OBSOLETE	
Snap Action	SM085Q100F230S1A	A970007		OBSOLETE	
Snap Action	SM85Q102F038S1C	A970008		OBSOLETE	
Snap Action	SM085Q101F025S1A	A970009		OBSOLETE	
Snap Action	SM085Q102F020S1A	A970010		OBSOLETE	
Snap Action	SM085Q103F015S1A	A970011		OBSOLETE	
Snap Action	SM085Q104F020S1A	A970012		OBSOLETE	
Snap Action	SM085Q105F015S1A	A970013		OBSOLETE	
Snap Action	SM085Q106F020S1A	A970014		OBSOLETE	
Snap Action	SM085Q100F130S1A	A970015		OBSOLETE	
Snap Action	SM085Q101F035S1A	A970016		OBSOLETE	
Snap Action	SM085Q102F030S1A	A970017		OBSOLETE	
Snap Action	SM085Q103F020S1A	A970018		OBSOLETE	
Snap Action	SM085Q104F035S1A	A970019		OBSOLETE	
Snap Action	SM085Q105F030S1A	A970020		OBSOLETE	
Snap Action	SM085Q106F038S1A	A970021		OBSOLETE	
Snap Action	SM085Q100F160S1A	A970022		OBSOLETE	
Snap Action	SM085Q101F045S1A	A970023		OBSOLETE	
Snap Action	SM085Q102F038S1A	A970024		OBSOLETE	
Snap Action	SM085Q103F025S1A	A970025		OBSOLETE	
Snap Action	SM085Q104F045S1A	A970026		OBSOLETE	
Snap Action	SM085Q105F038S1A	A970027		OBSOLETE	
Snap Action	SM085Q106F040S1A	A970028		OBSOLETE	
Snap Action	SM085Q100F230S1A	A970029		OBSOLETE	
Snap Action	SM085Q101F065S1A	A970030		OBSOLETE	
Snap Action	SM085Q102F050S1A	A970031		OBSOLETE	
Snap Action	SM085Q103F045S1A	A970032		OBSOLETE	
Snap Action	SM085Q104F065S1A	A970033		OBSOLETE	
Snap Action	SM085Q105F055S1A	A970034		OBSOLETE	
Snap Action	SM085Q106F060S1A	A970035		OBSOLETE	
Snap Action	SM085Q101F025C1A	A970036		OBSOLETE	
Snap Action	SM085Q102F020C1A	A970037		OBSOLETE	
Snap Action	SM085Q103F015C1A	A970038		OBSOLETE	
Snap Action	SM085Q104F020C1A	A970039		OBSOLETE	
Snap Action	SM085Q105F015C1A	A970040		OBSOLETE	
Snap Action	SM085Q106F020C1A	A970041		OBSOLETE	
Snap Action	SM085Q100F130C1A	A970042		OBSOLETE	
Snap Action	SM085Q101F035C1A	A970043		OBSOLETE	
Snap Action	SM085Q102F030C1A	A970044		OBSOLETE	
Snap Action	SM085Q103F020C1A	A970045		OBSOLETE	
Snap Action	SM085Q104F035C1A	A970046		OBSOLETE	
Snap Action	SM085Q105F030C1A	A970047		OBSOLETE	
Snap Action	SM085Q106F038C1A	A970048		OBSOLETE	
Snap Action	SM085Q100F160C1A	A970049		OBSOLETE	
Snap Action	SM085Q101F045C1A	A970050		OBSOLETE	
Snap Action	SM085Q102F038C1A	A970051		OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Snap Action	SM085Q103F025C1A	A970052		OBSOLETE	
Snap Action	SM085Q104F045C1A	A970053		OBSOLETE	
Snap Action	SM085Q105F038C1A	A970054		OBSOLETE	
Snap Action	SM085Q106F040C1A	A970055		OBSOLETE	
Snap Action	SM085Q100F230C1A	A970056		OBSOLETE	
Snap Action	SM085Q101F065C1A	A970057		OBSOLETE	
Snap Action	SM085Q102F050C1A	A970058		OBSOLETE	
Snap Action	SM085Q103F045C1A	A970059		OBSOLETE	
Snap Action	SM085Q104F065C1A	A970060		OBSOLETE	
Snap Action	SM085Q105F055C1A	A970061		OBSOLETE	
Snap Action	SM085Q106F060C1A	A970062		OBSOLETE	
Snap Action	SM085Q100F080P1A	A970063		OBSOLETE	
Snap Action	SM085Q101F025P1A	A970064		OBSOLETE	
Snap Action	SM085Q102F020P1A	A970065		OBSOLETE	
Snap Action	SM085Q103F015P1A	A970066		OBSOLETE	
Snap Action	SM085Q104F020P1A	A970067		OBSOLETE	
Snap Action	SM085Q105F015P1A	A970068		OBSOLETE	
Snap Action	SM085Q106F020P1A	A970069		OBSOLETE	
Snap Action	SM085Q100F130P1A	A970070		OBSOLETE	
Snap Action	SM085Q101F035P1A	A970071		OBSOLETE	
Snap Action	SM085Q102F030P1A	A970072		OBSOLETE	
Snap Action	SM085Q103F020P1A	A970073		OBSOLETE	
Snap Action	SM085Q104F035P1A	A970074		OBSOLETE	
Snap Action	SM085Q105F030P1A	A970075		OBSOLETE	
Snap Action	SM085Q106F038P1A	A970076		OBSOLETE	
Snap Action	SM085Q100F160P1A	A970077		OBSOLETE	
Snap Action	SM085Q101F045P1A	A970078		OBSOLETE	
Snap Action	SM085Q102F038P1A	A970079		OBSOLETE	
Snap Action	SM085Q103F025P1A	A970080		OBSOLETE	
Snap Action	SM085Q104F045P1A	A970081		OBSOLETE	
Snap Action	SM085Q105F038P1A	A970082		OBSOLETE	
Snap Action	SM085Q106F040P1A	A970083		OBSOLETE	
Snap Action	SM085Q100F230P1A	A970084		OBSOLETE	
Snap Action	SM085Q101F065P1A	A970085		OBSOLETE	
Snap Action	SM085Q102F050P1A	A970086		OBSOLETE	
Snap Action	SM085Q103F045P1A	A970087		OBSOLETE	
Snap Action	SM085Q104F065P1A	A970088		OBSOLETE	
Snap Action	SM085Q105F055P1A	A970089		OBSOLETE	
Snap Action	SM085Q106F060P1A	A970090		OBSOLETE	
Snap Action	SM085Q100F080V1A	A970091		OBSOLETE	
Snap Action	SM085Q101F025V1A	A970092		OBSOLETE	
Snap Action	SM085Q102F020V1A	A970093		OBSOLETE	
Snap Action	SM085Q103F015V1A	A970094		OBSOLETE	
Snap Action	SM085Q104F020V1A	A970095		OBSOLETE	
Snap Action	SM085Q105F015V1A	A970096		OBSOLETE	
Snap Action	SM085Q106F020V1A	A970097		OBSOLETE	
Snap Action	SM085Q100F130V1A	A970098		OBSOLETE	
Snap Action	SM085Q101F035V1A	A970099		OBSOLETE	
Snap Action	SM085Q102F030V1A	A970100		OBSOLETE	
Snap Action	SM085Q103F020V1A	A970101		OBSOLETE	
Snap Action	SM085Q104F035V1A	A970102		OBSOLETE	
Snap Action	SM085Q105F030V1A	A970103		OBSOLETE	
Snap Action	SM085Q106F038V1A	A970104		OBSOLETE	
Snap Action	SM085Q100F160V1A	A970105		OBSOLETE	
Snap Action	SM085Q101F045V1A	A970106		OBSOLETE	
Snap Action	SM085Q102F038V1A	A970107		OBSOLETE	
Snap Action	SM085Q103F025V1A	A970108		OBSOLETE	
Snap Action	SM085Q104F045V1A	A970109		OBSOLETE	
Snap Action	SM085Q106F040V1A	A970110		OBSOLETE	
Snap Action	SM085Q100F230V1A	A970111		OBSOLETE	
Snap Action	SM085Q101F065V1A	A970112		OBSOLETE	
Snap Action	SM085Q102F050V1A	A970113		OBSOLETE	
Snap Action	SM085Q103F045V1A	A970114		OBSOLETE	
Snap Action	SM085Q104F065V1A	A970115		OBSOLETE	
Snap Action	SM085Q105F055V1A	A970116		OBSOLETE	
Snap Action	SM085Q106F060V1A	A970117		OBSOLETE	
Snap Action	SM0850300F080S1A	A970118		OBSOLETE	(SEE A970229)
Snap Action	SM0850301F025S1A	A970119		OBSOLETE	(SEE A970230)
Snap Action	SM0850302F020S1A	A970120		OBSOLETE	(SEE A970231)
Snap Action	SM0850303F015S1A	A970121		OBSOLETE	(SEE A970232)
Snap Action	SM0850304F020S1A	A970122		OBSOLETE	(SEE A970233)
Snap Action	SM0850305F015S1A	A970123		OBSOLETE	(SEE A970234)
Snap Action	SM0850306F020S1A	A970124		OBSOLETE	(SEE A970235)
Snap Action	SM0850300F130S1A	A970125		OBSOLETE	(SEE A970002)
Snap Action	SM0850301F035S1A	A970126		OBSOLETE	(SEE A970236)
Snap Action	SM0850302F030S1A	A970127		OBSOLETE	(SEE A970237)
Snap Action	SM0850303F020S1A	A970128		OBSOLETE	(SEE A970238)
Snap Action	SM0850304F035S1A	A970129		OBSOLETE	(SEE A970239)
Snap Action	SM0850305F030S1A	A970130		OBSOLETE	(SEE A970240)
Snap Action	SM0850306F038S1A	A970131		OBSOLETE	(SEE A970241)



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Snap Action	SM0850300F160S1A	A970132		OBSOLETE	(SEE A970242)
Snap Action	SM0850301F045S1A	A970133		OBSOLETE	(SEE A970243)
Snap Action	SM0850302F038S1A	A970134		OBSOLETE	(SEE A970244)
Snap Action	SM0850303F025S1A	A970135		OBSOLETE	(SEE A970245)
Snap Action	SM0850304F045S1A	A970136		OBSOLETE	(SEE A970246)
Snap Action	SM0850305F038S1A	A970137		OBSOLETE	(SEE A970247)
Snap Action	SM0850306F040S1A	A970138		OBSOLETE	(SEE A970248)
Snap Action	SM0850300F230S1A	A970139		OBSOLETE	(SEE A970249)
Snap Action	SM0850301F065S1A	A970140		OBSOLETE	(SEE A970250)
Snap Action	SM0850302F050S1A	A970141		OBSOLETE	(SEE A970251)
Snap Action	SM0850303F045S1A	A970142		OBSOLETE	(SEE A970252)
Snap Action	SM0850304F065S1A	A970143		OBSOLETE	(SEE A970253)
Snap Action	SM0850305F055S1A	A970144		OBSOLETE	(SEE A970254)
Snap Action	SM0850306F060S1A	A970145		OBSOLETE	(SEE A970255)
Snap Action	SM0850301F025C1A	A970146		OBSOLETE	(SEE A970256)
Snap Action	SM0850302F020C1A	A970147		OBSOLETE	(SEE A970257)
Snap Action	SM0850304F020C1A	A970148		OBSOLETE	(SEE A970259)
Snap Action	SM0850303F015C1A	A970149		OBSOLETE	(SEE A970258)
Snap Action	SM0850305F015C1A	A970150		OBSOLETE	(SEE A970260)
Snap Action	SM0850306F020C1A	A970151		OBSOLETE	(SEE A970261)
Snap Action	SM0850300F130C1A	A970152		OBSOLETE	(SEE A970262)
Snap Action	SM0850301F035C1A	A970153		OBSOLETE	(SEE A970263)
Snap Action	SM0850302F030C1A	A970154		OBSOLETE	(SEE A970264)
Snap Action	SM0850303F020C1A	A970155		OBSOLETE	(SEE A970265)
Snap Action	SM0850304F035C1A	A970156		OBSOLETE	(SEE A970266)
Snap Action	SM0850305F030C1A	A970157		OBSOLETE	(SEE A970267)
Snap Action	SM0850306F038C1A	A970158		OBSOLETE	(SEE A970268)
Snap Action	SM0850300F160C1A	A970159		OBSOLETE	(SEE A970269)
Snap Action	SM0850301F045C1A	A970160		OBSOLETE	(SEE A970270)
Snap Action	SM0850302F038C1A	A970161		OBSOLETE	(SEE A970271)
Snap Action	SM0850303F025C1A	A970162		OBSOLETE	(SEE A970272)
Snap Action	SM0850304F045C1A	A970163		OBSOLETE	(SEE A970274)
Snap Action	SM0850305F038C1A	A970164		OBSOLETE	(SEE A970273)
Snap Action	SM0850306F040C1A	A970165		OBSOLETE	(SEE A970275)
Snap Action	SM0850300F230C1A	A970166		OBSOLETE	(SEE A970276)
Snap Action	SM0850301F065C1A	A970167		OBSOLETE	(SEE A970277)
Snap Action	SM0850302F050C1A	A970168		OBSOLETE	(SEE A970278)
Snap Action	SM0850303F045C1A	A970169		OBSOLETE	(SEE A970279)
Snap Action	SM0850304F065C1A	A970170		OBSOLETE	(SEE A970280)
Snap Action	SM0850305F055C1A	A970171		OBSOLETE	(SEE A970281)
Snap Action	SM0850306F060C1A	A970172		OBSOLETE	(SEE A970282)
Snap Action	SM0850300F080P1A	A970173		OBSOLETE	(SEE A970283)
Snap Action	SM0850301F025P1A	A970174		OBSOLETE	(SEE A970284)
Snap Action	SM0850302F020P1A	A970175		OBSOLETE	(SEE A970285)
Snap Action	SM0850303F015P1A	A970176		OBSOLETE	(SEE A970286)
Snap Action	SM0850304F020P1A	A970177		OBSOLETE	(SEE A970287)
Snap Action	SM0850305F015P1A	A970178		OBSOLETE	(SEE A970288)
Snap Action	SM0850306F020P1A	A970179		OBSOLETE	(SEE A970289)
Snap Action	SM0850300F130P1A	A970180		OBSOLETE	(SEE A970290)
Snap Action	SM0850301F035P1A	A970181		OBSOLETE	(SEE A970291)
Snap Action	SM0850302F030P1A	A970182		OBSOLETE	(SEE A970292)
Snap Action	SM0850303F020P1A	A970183		OBSOLETE	(SEE A970293)
Snap Action	SM0850304F035P1A	A970184		OBSOLETE	(SEE A970294)
Snap Action	SM0850305F030P1A	A970185		OBSOLETE	(SEE A970295)
Snap Action	SM0850306F038P1A	A970186		OBSOLETE	(SEE A970296)
Snap Action	SM0850300F160P1A	A970187		OBSOLETE	(SEE A970297)
Snap Action	SM0850301F045P1A	A970188		OBSOLETE	(SEE A970298)
Snap Action	SM0850302F038P1A	A970189		OBSOLETE	(SEE A970299)
Snap Action	SM0850303F025P1A	A970190		OBSOLETE	(SEE A970300)
Snap Action	SM0850304F045P1A	A970191		OBSOLETE	(SEE A970301)
Snap Action	SM0850305F038P1A	A970192		OBSOLETE	(SEE A970302)
Snap Action	SM0850306F040P1A	A970193		OBSOLETE	(SEE A970303)
Snap Action	SM0850300F230P1A	A970194		OBSOLETE	(SEE A970304)
Snap Action	SM0850301F065P1A	A970195		OBSOLETE	(SEE A970305)
Snap Action	SM0850302F050P1A	A970196		OBSOLETE	(SEE A970306)
Snap Action	SM0850303F045P1A	A970197		OBSOLETE	(SEE A970307)
Snap Action	SM0850304F065P1A	A970198		OBSOLETE	(SEE A970308)
Snap Action	SM0850305F055P1A	A970199		OBSOLETE	(SEE A970309)
Snap Action	SM0850306F060P1A	A970200		OBSOLETE	(SEE A970310)
Snap Action	SM0850300F080V1A	A970201		OBSOLETE	(SEE A970311)
Snap Action	SM0850301F025V1A	A970202		OBSOLETE	(SEE A970312)
Snap Action	SM0850302F020V1A	A970203		OBSOLETE	(SEE A970313)
Snap Action	SM0850303F015V1A	A970204		OBSOLETE	(SEE A970314)
Snap Action	SM0850304F020V1A	A970205		OBSOLETE	(SEE A970315)
Snap Action	SM0850305F015V1A	A970206		OBSOLETE	(SEE A970316)
Snap Action	SM0850306F020V1A	A970207		OBSOLETE	(SEE A970317)
Snap Action	SM0850300F130V1A	A970208		OBSOLETE	(SEE A970318)
Snap Action	SM0850301F035V1A	A970209		OBSOLETE	(SEE A970319)
Snap Action	SM0850302F030V1A	A970210		OBSOLETE	(SEE A970320)
Snap Action	SM0850303F020V1A	A970211		OBSOLETE	(SEE A970321)



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Snap Action	SM0850304F035V1A	A970212		OBSOLETE	(SEE A970322)
Snap Action	SM0850305F030V1A	A970213		OBSOLETE	(SEE A970323)
Snap Action	SM0850306F038V1A	A970214		OBSOLETE	(SEE A970324)
Snap Action	SM0850300F160V1A	A970215		OBSOLETE	(SEE A970325)
Snap Action	SM0850301F045V1A	A970216		OBSOLETE	(SEE A970326)
Snap Action	SM0850302F038V1A	A970217		OBSOLETE	(SEE A970327)
Snap Action	SM0850303F025V1A	A970218		OBSOLETE	(SEE A970328)
Snap Action	SM0850304F045V1A	A970219		OBSOLETE	(SEE A970329)
Snap Action	SM0850305F038V1A	A970220		OBSOLETE	(SEE A970330)
Snap Action	SM0850306F040V1A	A970221		OBSOLETE	(SEE A970331)
Snap Action	SM0850300F230V1A	A970222		OBSOLETE	(SEE A970332)
Snap Action	SM0850301F065V1A	A970223		OBSOLETE	(SEE A970333)
Snap Action	SM0850302F050V1A	A970224		OBSOLETE	(SEE A970334)
Snap Action	SM0850303F045V1A	A970225		OBSOLETE	(SEE A970335)
Snap Action	SM0850304F065V1A	A970226		OBSOLETE	(SEE A970336)
Snap Action	SM0850305F055V1A	A970227		OBSOLETE	(SEE A970337)
Snap Action	SM0850306F060V1A	A970228		OBSOLETE	(SEE A970338)
Snap Action	SM0850500F080S1A	A970229		OBSOLETE	
Snap Action	SM0850501F025S1A	A970230		OBSOLETE	
Snap Action	SM0850502F020S1A	A970231		OBSOLETE	
Snap Action	SM0850503F010S1A	A970232		OBSOLETE	
Snap Action	SM0850504F020S1A	A970233		OBSOLETE	(Q970030)
Snap Action	SM0850505F015S1A	A970234		OBSOLETE	
Snap Action	SM0850506F020S1A	A970235		OBSOLETE	
Snap Action	SM0850501F035S1A	A970236		OBSOLETE	
Snap Action	SM0850502F030S1A	A970237		OBSOLETE	
Snap Action	SM0850503F020S1A	A970238		OBSOLETE	
Snap Action	SM0850504F035S1A	A970239		OBSOLETE	
Snap Action	SM0850505F030S1A	A970240		OBSOLETE	
Snap Action	SM0850506F040S1A	A970241		OBSOLETE	
Snap Action	SM0850500F160S1A	A970242		OBSOLETE	
Snap Action	SM0850501F045S1A	A970243		OBSOLETE	SEE A970346
Snap Action	SM0850502F040S1A	A970244		OBSOLETE	
Snap Action	SM0850503F025S1A	A970245		OBSOLETE	
Snap Action	SM0850504F045S1A	A970246		OBSOLETE	
Snap Action	SM0850505F040S1A	A970247		OBSOLETE	
Snap Action	SM0850506F050S1A	A970248		OBSOLETE	
Snap Action	SM0850500F230S1A	A970249		OBSOLETE	
Snap Action	SM0850501F065S1A	A970250		OBSOLETE	
Snap Action	SM0850502F050S1A	A970251		OBSOLETE	
Snap Action	SM0850503F035S1A	A970252		OBSOLETE	
Snap Action	SM0850504F065S1A	A970253		OBSOLETE	
Snap Action	SM0850505F055S1A	A970254		OBSOLETE	
Snap Action	SM0850506F065S1A	A970255		OBSOLETE	
Snap Action	SM0850501F025C1A	A970256		OBSOLETE	
Snap Action	SM0850502F020C1A	A970257		OBSOLETE	
Snap Action	SM0850503F010C1A	A970258		OBSOLETE	
Snap Action	SM0850504F035V1A	A970259		OBSOLETE	
Snap Action	SM0850505F015C1A	A970260		OBSOLETE	
Snap Action	SM0850506F020C1A	A970261		OBSOLETE	
Snap Action	SM0850500F130C1A	A970262		OBSOLETE	
Snap Action	SM0850501F035C1A	A970263		OBSOLETE	
Snap Action	SM0850502F030C1A	A970264		OBSOLETE	
Snap Action	SM0850503F020C1A	A970265		OBSOLETE	
Snap Action	SM0850504F035C1A	A970266		OBSOLETE	
Snap Action	SM0850505F030C1A	A970267		OBSOLETE	
Snap Action	SM0850506F040C1A	A970268		OBSOLETE	
Snap Action	SM0850500F160C1A	A970269		OBSOLETE	
Snap Action	SM0850501F045C1A	A970270		OBSOLETE	
Snap Action	SM0850502F040C1A	A970271		OBSOLETE	
Snap Action	SM0850503F025C1A	A970272		OBSOLETE	
Snap Action	SM0850505F040C1A	A970273		OBSOLETE	
Snap Action	SM0850504F045C1A	A970274		OBSOLETE	
Snap Action	SM0850506F050C1A	A970275		OBSOLETE	
Snap Action	SM0850500F230C1A	A970276		OBSOLETE	
Snap Action	SM0850501F065C1A	A970277		OBSOLETE	
Snap Action	SM0850502F050C1A	A970278		OBSOLETE	
Snap Action	SM0850503F035C1A	A970279		OBSOLETE	
Snap Action	SM0850504F065C1A	A970280		OBSOLETE	
Snap Action	SM0850505F055C1A	A970281		OBSOLETE	(Q970032)
Snap Action	SM0850506F065C1A	A970282		OBSOLETE	
Snap Action	SM0850500F080P1A	A970283		OBSOLETE	
Snap Action	SM0850501F025P1A	A970284		OBSOLETE	
Snap Action	SM0850502F020P1A	A970285		OBSOLETE	
Snap Action	SM0850503F010P1A	A970286		OBSOLETE	(Q970036)
Snap Action	SM0850504F020P1A	A970287		OBSOLETE	
Snap Action	SM0850505F015P1A	A970288		OBSOLETE	
Snap Action	SM0850506F020P1A	A970289		OBSOLETE	
Snap Action	SM0850500F130P1A	A970290		OBSOLETE	
Snap Action	SM0850501F035P1A	A970291		OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Snap Action	SM0850502F030P1A	A970292		OBSOLETE	(Q970028)
Snap Action	SM0850503F020P1A	A970293		OBSOLETE	
Snap Action	SM0850504F035P1A	A970294		OBSOLETE	
Snap Action	SM0850505F030P1A	A970295		OBSOLETE	
Snap Action	SM0850506F040P1A	A970296		OBSOLETE	
Snap Action	SM0850500F160P1A	A970297		OBSOLETE	
Snap Action	SM0850501F045P1A	A970298		OBSOLETE	
Snap Action	SM0850502F040P1A	A970299		OBSOLETE	
Snap Action	SM0850503F025P1A	A970300		OBSOLETE	(Q970042)
Snap Action	SM0850504F045P1A	A970301		OBSOLETE	(Q970029)
Snap Action	SM0850505F040P1A	A970302		OBSOLETE	
Snap Action	SM0850506F050P1A	A970303		OBSOLETE	
Snap Action	SM0850500F230P1A	A970304		OBSOLETE	
Snap Action	SM0850501F065P1A	A970305		OBSOLETE	
Snap Action	SM0850502F050P1A	A970306		OBSOLETE	
Snap Action	SM0850503F035P1A	A970307		OBSOLETE	
Snap Action	SM0850504F065P1A	A970308		OBSOLETE	
Snap Action	SM0850505F055P1A	A970309		OBSOLETE	
Snap Action	SM0850506F065P1A	A970310		OBSOLETE	
Snap Action	SM0850500F080V1A	A970311		OBSOLETE	
Snap Action	SM0850501F025V1A	A970312		OBSOLETE	
Snap Action	SM0850502F020V1A	A970313		OBSOLETE	
Snap Action	SM0850503F010V1A	A970314		OBSOLETE	
Snap Action	SM0850504F020V1A	A970315		OBSOLETE	
Snap Action	SM0850505F015V1A	A970316		OBSOLETE	
Snap Action	SM0850506F020V1A	A970317		OBSOLETE	
Snap Action	SM0850500F130V1A	A970318		OBSOLETE	
Snap Action	SM0850501F035V1A	A970319		OBSOLETE	
Snap Action	SM0850502F030V1A	A970320		OBSOLETE	
Snap Action	SM0850503F020V1A	A970321		OBSOLETE	
Snap Action	SM0850504F035V1A	A970322		OBSOLETE	
Snap Action	SM0850505F030V1A	A970323		OBSOLETE	
Snap Action	SM0850506F040V1A	A970324		OBSOLETE	
Snap Action	SM0850500F160V1A	A970325		OBSOLETE	
Snap Action	SM0850501F045V1A	A970326		OBSOLETE	
Snap Action	SM0850502F040V1A	A970327		OBSOLETE	
Snap Action	SM0850503F025V1A	A970328		OBSOLETE	
Snap Action	SM0850504F045V1A	A970329		OBSOLETE	
Snap Action	SM0850505F040V1A	A970330		OBSOLETE	
Snap Action	SM0850506F050V1A	A970331		OBSOLETE	
Snap Action	SM0850500F230V1A	A970332		OBSOLETE	
Snap Action	SM0850501F065V1A	A970333		OBSOLETE	
Snap Action	SM0850502F050V1A	A970334		OBSOLETE	
Snap Action	SM0850503F035V1A	A970335		OBSOLETE	
Snap Action	SM0850504F065V1A	A970336		OBSOLETE	
Snap Action	SM0850505F055V1A	A970337		OBSOLETE	
Snap Action	SM0850506F065V1A	A970338		OBSOLETE	
Snap Action	SM085Q100F200S1A	A970339		OBSOLETE	
Snap Action	SM0850500F160S1C	A970340		OBSOLETE	
Snap Action	SM0850503F025C1C	A970341		OBSOLETE	
Snap Action	SM0850500F160C1C	A970342		OBSOLETE	
Snap Action	SM0850501F065P1C	A970343		OBSOLETE	
Snap Action	SM0850500F160V2A	A970344		OBSOLETE	
Snap Action	SM085Q107F020V1A	A970345		OBSOLETE	
Snap Action	SM0850501F045S1A	A970346		OBSOLETE	
Snap Action	SM085Q107F020C1A	A970347		OBSOLETE	
Snap Action	SM085Q107F020S1A	A970348		OBSOLETE	
Snap Action	SM0850505F055C1C	A970349		OBSOLETE	
Snap Action	SM0850509F020C1A	A970400		OBSOLETE	
Snap Action	SM0850507F020S1A	A970407		OBSOLETE	
Snap Action	SM085R107F065S1B	A970408		OBSOLETE	
Snap Action	SM085R104F065P1A	A970409		OBSOLETE	
Snap Action	SM085R105F055P1B	A970410		OBSOLETE	
Snap Action	SM085R100F130V1C	A970411		OBSOLETE	
Snap Action	SM085R103F015S1C	A970412		OBSOLETE	
Snap Action	SM085R102F050P1A	A970413		OBSOLETE	
Snap Action	SM085R103F015S1B	A970418		OBSOLETE	
Snap Action	SM085Q104F020V1B	A970421		OBSOLETE	
Snap Action	SM0850500F130V1C	A970422		OBSOLETE	
Snap Action	SM0850505F055P1B	A970423		OBSOLETE	
Snap Action	SM085R103F015C1B	A970424		OBSOLETE	
Snap Action	SM085R105F038C1A	A970425		OBSOLETE	
Snap Action	SM085R104F045C1A	A970426		OBSOLETE	
Snap Action	SM085Q100F130V1C	A970428		OBSOLETE	
Snap Action	SM085R103F015V1B	A970429		OBSOLETE	
Snap Action	SM085Q104F045S1C	A970430		OBSOLETE	
Snap Action	SM085R104F035S1A	A970431		OBSOLETE	
Snap Action	SM085R100F160P1A	A970500		OBSOLETE	
Snap Action	SM085R100F080S1A	A970506		OBSOLETE	
Snap Action	SM085R101F025P1A	A970575		OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Snap Action	SM085R101F045P1A	A970576		OBSOLETE	
Snap Action	SM085R101F045P1C	A970578		OBSOLETE	
Snap Action	SM085Q101F065P1C	A970585		OBSOLETE	
Snap Action	SM085R101F035S1B	A970586		OBSOLETE	
Snap Action	SM085R100F080V1A	A970591		OBSOLETE	
Snap Action	SM1251000F230P1A	A970902		OBSOLETE	
Snap Action	SM0850503F020S1ABLACK	A970935		OBSOLETE	
Snap Action	SM1251000F230C1A	A980000		OBSOLETE	
Snap Action	SM1251004F065S1A	A980001		OBSOLETE	
Snap Action	SM0850508F012C1A	A990801		OBSOLETE	
Snap Action	SM0850508F040C1A	A990802		OBSOLETE	
Snap Action	SM0850508F055C1A	A990803		OBSOLETE	
Snap Action	SM0850508F012P1A	A990804		OBSOLETE	
Snap Action	SM085R101F065C1A	A990957		OBSOLETE	
Snap Action	SM085R101F065S1A	A990958		OBSOLETE	
Snap Action	SMP1L02S	J000001		OBSOLETE	
Snap Action	SMP1S06P	J000002		OBSOLETE	
Snap Action	SMP1L02S	J000003		OBSOLETE	
Snap Action	SMP1S04S	J000006		OBSOLETE	
Snap Action	SMP1S05F	J000009		OBSOLETE	
Snap Action	SM01L00P	J000010		OBSOLETE	
Snap Action	SM05S00S	J000012		OBSOLETE	
Snap Action	SM05S01S	J000013		OBSOLETE	
Snap Action	SM05S02S	J000014		OBSOLETE	
Snap Action	SM05S04F	J000016		OBSOLETE	
Snap Action	SM05H01P	J000038		OBSOLETE	
Snap Action	SM05S03V1WITHBRACKET	J000050		OBSOLETE	
Snap Action	SM05L01V1	J000053		OBSOLETE	
Snap Action	SMSERIES30MMLEVER	J000071		OBSOLETE	
Snap Action	SM0850519F050S1A	J000072		OBSOLETE	
Snap Action	SMR1S00P	J000100		OBSOLETE	
Snap Action	SM05S02V	J020000		OBSOLETE	
Snap Action	SM05S02F	J020001		OBSOLETE	
Snap Action	SM05S01F	J020002		OBSOLETE	
Snap Action	SM0850520F050S1A	R100000		OBSOLETE	
Snap Action	SM0850521F050S1A	R100001		OBSOLETE	
Snap Action	SM0850303F025S1A	XA1981P		OBSOLETE	WITH WIRE HARNESS
Snap Action	SS-12E01-G(B)6-00	03-SS12E01GB600		OBSOLETE	
Snap Action	SS-12F20-G(A)5	03-SS12F20GA5		OBSOLETE	
Snap Action	SS-12F23-G(A)10	03-SS12F23GA10		OBSOLETE	
Snap Action	SS-22F06-GS-A	03-SS22F06G5A	2015	OBSOLETE	
Snap Action	SS-22F18-T13	03-SS22F18T13	2015	OBSOLETE	
Snap Action	SS-23E01-T17	03-SS23E01T17	2015	OBSOLETE	
Snap Action	SS-34G01-T(E)10	03-SS34G01TE10		OBSOLETE	
Snap Action	WS-22L24-G(B)7.5	03-WS22L24GB75		OBSOLETE	
Snap Action	TS12M-7.3K3.8-160-TR	06-TS12M73K38160TR		OBSOLETE	SEE N301100
Snap Action	TS-4.3-160-nr	06-TS43160NR		OBSOLETE	
Snap Action	TS-5.0-260-nr	06-TS50260NR		OBSOLETE	
Snap Action	TSA-5.85G-130-nr	08-TSA585G130NR		OBSOLETE	
Snap Action	VMG120GFF10	A950002		OBSOLETE	WITH 120 DEGREE ACTUATOR
Snap Action	VM06S00D0	A950003		OBSOLETE	
Snap Action	VM085R1XXF120C1A	A950004		OBSOLETE	
Snap Action	VM0850606F060C1A	A950005		OBSOLETE	(SEE A950273)
Snap Action	VM0850600F020C2A	A950006		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM0850600F160C2A	A950007		OBSOLETE	(SEE A950253)
Snap Action	VM0851600F160C1C	A950008		OBSOLETE	
Snap Action	VM10120GF1001F10	A950009		OBSOLETE	
Snap Action	VM0851002F095C2C	A950010		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM0850605F160S1C	A950011		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM0850600F200C1C	A950012		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM0851006F075C2A	A950013		OBSOLETE	(SEE A950266)
Snap Action	VM0851005F200C2A	A950014		OBSOLETE	(SEE A950265)
Snap Action	VM085XX00F075200CIA	A950015		OBSOLETE	20u INCH GOLD
Snap Action	VM0851600F020C1C	A950016		OBSOLETE	
Snap Action	VM0851600F100C2C	A950017		OBSOLETE	
Snap Action	VM0851005F160C1C	A950018		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM0851005F200C1A	A950019		OBSOLETE	(SEE A950279)
Snap Action	VM0850600F200C2A	A950020		OBSOLETE	(SEE A950260)
Snap Action	VM085Q100F160S1A	A950021		OBSOLETE	SEE A950239
Snap Action	VM085Q101F160S1A	A950022		OBSOLETE	SEE A950240
Snap Action	VM085Q102F075S1A	A950023		OBSOLETE	SEE A950241
Snap Action	VM085Q103F040S1A	A950024		OBSOLETE	SEE A950242
Snap Action	VM085Q104F085S1A	A950025		OBSOLETE	SEE A950243
Snap Action	VM085Q105F160S1A	A950026		OBSOLETE	SEE A950244
Snap Action	VM085Q106F060S1A	A950027		OBSOLETE	SEE A950245
Snap Action	VM085Q100F200S1A	A950028		OBSOLETE	SEE A950246
Snap Action	VM085Q101F200S1A	A950029		OBSOLETE	SEE A950247
Snap Action	VM085Q102F095S1A	A950030		OBSOLETE	SEE A950248
Snap Action	VM085Q103F050S1A	A950031		OBSOLETE	SEE A950249
Snap Action	VM085Q104F105S1A	A950032		OBSOLETE	SEE A950250



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Snap Action	VM085Q105F200S1A	A950033		OBSOLETE	SEE A950251
Snap Action	VM085Q106F075S1A	A950034		OBSOLETE	SEE A950252
Snap Action	VM085Q100F160C2A	A950035		OBSOLETE	SEE A950253
Snap Action	VM085Q101F160C2A	A950036		OBSOLETE	
Snap Action	VM085Q102F075C2A	A950037		OBSOLETE	SEE A950255
Snap Action	VM085Q103F040C2A	A950038		OBSOLETE	SEE A950256
Snap Action	VM085Q104F085C2A	A950039		OBSOLETE	SEE A950257
Snap Action	VM085Q105F160C2A	A950040		OBSOLETE	SEE A950258
Snap Action	VM085Q106F060C2A	A950041		OBSOLETE	SEE A950259
Snap Action	VM085Q100F200C2A	A950042		OBSOLETE	SEE A950260
Snap Action	VM085Q101F200C2A	A950043		OBSOLETE	SEE A950261
Snap Action	VM085Q102F095C2A	A950044		OBSOLETE	SEE A950262
Snap Action	VM085Q103F050C2A	A950045		OBSOLETE	SEE A950263
Snap Action	VM085Q104F105C2A	A950046		OBSOLETE	SEE A950264
Snap Action	VM085Q105F200C2A	A950047		OBSOLETE	SEE A950265
Snap Action	VM085Q106F075C2A	A950048		OBSOLETE	SEE A950266
Snap Action	VM085Q100F160C1A	A950049		OBSOLETE	SEE A950267
Snap Action	VM085Q101F160C1A	A950050		OBSOLETE	SEE A950268
Snap Action	VM085Q102F075C1A	A950051		OBSOLETE	SEE A950269
Snap Action	VM085Q103F040C1A	A950052		OBSOLETE	SEE A950270
Snap Action	VM085Q104F085C1A	A950053		OBSOLETE	SEE A950271
Snap Action	VM085Q105F160C1A	A950054		OBSOLETE	SEE A950272
Snap Action	VM085Q106F060C1A	A950055		OBSOLETE	SEE A950273
Snap Action	VM085Q100F200C1A	A950056		OBSOLETE	SEE A950274
Snap Action	VM085Q101F200C1A	A950057		OBSOLETE	SEE A950275
Snap Action	VM085Q102F095C1A	A950058		OBSOLETE	SEE A950276
Snap Action	VM085Q103F050C1A	A950059		OBSOLETE	SEE A950277
Snap Action	VM085Q104F105C1A	A950060		OBSOLETE	SEE A950278
Snap Action	VM085Q105F200C1A	A950061		OBSOLETE	SEE A950279
Snap Action	VM085Q106F075C1A	A950062		OBSOLETE	SEE A950280
Snap Action	VM085Q100F160V1A	A950063		OBSOLETE	SEE A950281
Snap Action	VM085Q101F160V1A	A950064		OBSOLETE	SEE A950282
Snap Action	VM085Q102F075V1A	A950065		OBSOLETE	SEE A950283
Snap Action	VM085Q103F040V1A	A950066		OBSOLETE	SEE A950284
Snap Action	VM085Q104F085V1A	A950067		OBSOLETE	SEE A950285
Snap Action	VM085Q105F160V1A	A950068		OBSOLETE	SEE A950286
Snap Action	VM085Q106F060V1A	A950069		OBSOLETE	SEE A950287
Snap Action	VM085Q100F200V1A	A950070		OBSOLETE	SEE A950288
Snap Action	VM085Q101F200V1A	A950071		OBSOLETE	SEE A950289
Snap Action	VM085Q102F095V1A	A950072		OBSOLETE	SEE A950290
Snap Action	VM085Q103F050V1A	A950073		OBSOLETE	SEE A950291
Snap Action	VM085Q104F105V1A	A950074		OBSOLETE	SEE A950292
Snap Action	VM085Q105F200V1A	A950075		OBSOLETE	SEE A950293
Snap Action	VM085Q106F075V1A	A950076		OBSOLETE	SEE A950294
Snap Action	VM0850300F160S1A	A950077		OBSOLETE	
Snap Action	VM0850301F160S1A	A950078		OBSOLETE	(SEE A950240)
Snap Action	VM0850302F075S1A	A950079		OBSOLETE	(SEE A950241)
Snap Action	VM0850303F040S1A	A950080		OBSOLETE	(SEE A950242)
Snap Action	VM0850304F085S1A	A950081		OBSOLETE	(SEE A950243)
Snap Action	VM0850305F160S1A	A950082		OBSOLETE	(SEE A950244)
Snap Action	VM0850306F060S1A	A950083		OBSOLETE	(SEE A950245)
Snap Action	VM0850300F200S1A	A950084		OBSOLETE	(SEE A950246)
Snap Action	VM0850301F200S1A	A950085		OBSOLETE	(SEE A950247)
Snap Action	VM0850302F095S1A	A950086		OBSOLETE	(SEE A950248)
Snap Action	VM0850303F050S1A	A950087		OBSOLETE	(SEE A950249)
Snap Action	VM0850304F105S1A	A950088		OBSOLETE	(SEE A950250)
Snap Action	VM0850305F200S1A	A950089		OBSOLETE	(SEE A950251)
Snap Action	VM0850306F075S1A	A950090		OBSOLETE	(SEE A950252)
Snap Action	VM0850300F160C2A	A950091		OBSOLETE	(SEE A950253)
Snap Action	VM0850301F160C2A	A950092		OBSOLETE	(SEE A950254)
Snap Action	VM0850302F075C2A	A950093		OBSOLETE	(SEE A950255)
Snap Action	VM0850303F040C2A	A950094		OBSOLETE	(SEE A950256)
Snap Action	VM0850304F085C2A	A950095		OBSOLETE	(SEE A950257)
Snap Action	VM0850305F160C2A	A950096		OBSOLETE	(SEE A950258)
Snap Action	VM0850306F060C2A	A950097		OBSOLETE	(SEE A950259)
Snap Action	VM0850300F200C2A	A950098		OBSOLETE	
Snap Action	VM0850301F200C2A	A950099		OBSOLETE	(SEE A950261)
Snap Action	VM0850302F095C2A	A950100		OBSOLETE	(SEE A950262)
Snap Action	VM0850303F050C2A	A950101		OBSOLETE	(SEE A950263)
Snap Action	VM0850304F105C2A	A950102		OBSOLETE	(SEE A950264)
Snap Action	VM0850305F200C2A	A950103		OBSOLETE	(SEE A950265)
Snap Action	VM0850306F075C2A	A950104		OBSOLETE	(SEE A950266)
Snap Action	VM0850300F160C1A	A950105		OBSOLETE	(SEE A950267)
Snap Action	VM0850301F160C1A	A950106		OBSOLETE	(SEE A950268)
Snap Action	VM0850302F075C1A	A950107		OBSOLETE	(SEE A950269)
Snap Action	VM0850303F040C1A	A950108		OBSOLETE	(SEE A950270)
Snap Action	VM0850304F085C1A	A950109		OBSOLETE	(SEE A950271)
Snap Action	VM0850305F160C1A	A950110		OBSOLETE	(SEE A950272)
Snap Action	VM0850306F060C1A	A950111		OBSOLETE	(SEE A950273)
Snap Action	VM0850300F200C1A	A950112		OBSOLETE	(SEE A950274)



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Snap Action	VM0850301F200C1A	A950113		OBSOLETE	(SEE A950275)
Snap Action	VM0850302F095C1A	A950114		OBSOLETE	(SEE A950276)
Snap Action	VM0850303F050C1A	A950115		OBSOLETE	(SEE A950277)
Snap Action	VM0850304F105C1A	A950116		OBSOLETE	(SEE A950278)
Snap Action	VM0850305F200C1A	A950117		OBSOLETE	(SEE A950279)
Snap Action	VM0850306F075C1A	A950118		OBSOLETE	(SEE A950280)
Snap Action	VM0850300F160V1A	A950119		OBSOLETE	(SEE A950281)
Snap Action	VM0850301F160V1A	A950120		OBSOLETE	(SEE A950282)
Snap Action	VM0850302F075V1A	A950121		OBSOLETE	(SEE A950283)
Snap Action	VM0850303F040V1A	A950122		OBSOLETE	(SEE A950284)
Snap Action	VM0850304F085V1A	A950123		OBSOLETE	(SEE A950285)
Snap Action	VM0850305F160V1A	A950124		OBSOLETE	(SEE A950286)
Snap Action	VM0850306F060V1A	A950125		OBSOLETE	(SEE A950287)
Snap Action	VM0850300F200V1A	A950126		OBSOLETE	(SEE A950288)
Snap Action	VM0850301F200V1A	A950127		OBSOLETE	(SEE A950289)
Snap Action	VM0850302F095V1A	A950128		OBSOLETE	(SEE A950290)
Snap Action	VM0850303F050V1A	A950129		OBSOLETE	(SEE A950291)
Snap Action	VM0850304F105V1A	A950130		OBSOLETE	(SEE A950292)
Snap Action	VM0850305F200V1A	A950131		OBSOLETE	(SEE A950293)
Snap Action	VM0850306F075V1A	A950132		OBSOLETE	(SEE A950294)
Snap Action	VM0850600F160S1A	A950133		OBSOLETE	(SEE A950239)
Snap Action	VM0850601F160S1A	A950134		OBSOLETE	(SEE A950240)
Snap Action	VM0850602F075S1A	A950135		OBSOLETE	(SEE A950241)
Snap Action	VM0850603F040S1A	A950136		OBSOLETE	(SEE A950242)
Snap Action	VM0850604F085S1A	A950137		OBSOLETE	(SEE A950243)
Snap Action	VM0850605F160S1A	A950138		OBSOLETE	(SEE A950244)
Snap Action	VM0850606F060S1A	A950139		OBSOLETE	(SEE A950245)
Snap Action	VM0850600F200S1A	A950140		OBSOLETE	(SEE A950246)
Snap Action	VM0850601F200S1A	A950141		OBSOLETE	(SEE A950247)
Snap Action	VM0850602F095S1A	A950142		OBSOLETE	(SEE A950248)
Snap Action	VM0850603F050S1A	A950143		OBSOLETE	(SEE A950249)
Snap Action	VM0850604F105S1A	A950144		OBSOLETE	(SEE A950250)
Snap Action	VM0850605F200S1A	A950145		OBSOLETE	(SEE A950251)
Snap Action	VM0850606F075S1A	A950146		OBSOLETE	(SEE A950252)
Snap Action	VM0850601F160C2A	A950147		OBSOLETE	(SEE A950254)
Snap Action	VM0850602F075C2A	A950148		OBSOLETE	(SEE A950255)
Snap Action	VM0850603F040C2A	A950149		OBSOLETE	(SEE A950256)
Snap Action	VM0850604F085C2A	A950150		OBSOLETE	(SEE A950257)
Snap Action	VM0850605F160C2A	A950151		OBSOLETE	(SEE A950258)
Snap Action	VM0850606F060C2A	A950152		OBSOLETE	(SEE A950259)
Snap Action	VM0850601F200C2A	A950153		OBSOLETE	(SEE A950261)
Snap Action	VM0850602F095C2A	A950154		OBSOLETE	(SEE A950262)
Snap Action	VM0850603F050C2A	A950155		OBSOLETE	(SEE A950263)
Snap Action	VM0850604F105C2A	A950156		OBSOLETE	(SEE A950264)
Snap Action	VM0850605F200C2A	A950157		OBSOLETE	(SEE A950265)
Snap Action	VM0850606F075C2A	A950158		OBSOLETE	(SEE A950266)
Snap Action	VM0850600F160C1A	A950159		OBSOLETE	(SEE A950267)
Snap Action	VM0850601F160C1A	A950160		OBSOLETE	(SEE A950268)
Snap Action	VM0850602F075C1A	A950161		OBSOLETE	(SEE A950269)
Snap Action	VM0850603F040C1A	A950162		OBSOLETE	(SEE A950270)
Snap Action	VM0850604F085C1A	A950163		OBSOLETE	(SEE A950271)
Snap Action	VM0850605F160C1A	A950164		OBSOLETE	(SEE A950272)
Snap Action	VM0850600F200C1A	A950165		OBSOLETE	(SEE A950274)
Snap Action	VM0850601F200C1A	A950166		OBSOLETE	(SEE A950275)
Snap Action	VM0850602F095C1A	A950167		OBSOLETE	(SEE A950276)
Snap Action	VM0850603F050C1A	A950168		OBSOLETE	(SEE A950277)
Snap Action	VM0850604F105C1A	A950169		OBSOLETE	(SEE A950278)
Snap Action	VM0850605F200C1A	A950170		OBSOLETE	(SEE A950279)
Snap Action	VM0850606F075C1A	A950171		OBSOLETE	(SEE A950280)
Snap Action	VM0850600F160V1A	A950172		OBSOLETE	(SEE A950281)
Snap Action	VM0850601F160V1A	A950173		OBSOLETE	(SEE A950282)
Snap Action	VM0850602F075V1A	A950174		OBSOLETE	(SEE A950283)
Snap Action	VM0850603F040V1A	A950175		OBSOLETE	(SEE A950284)
Snap Action	VM0850604F085V1A	A950176		OBSOLETE	(SEE A950285)
Snap Action	VM0850605F160V1A	A950177		OBSOLETE	(SEE A950286)
Snap Action	VM0850606F060V1A	A950178		OBSOLETE	(SEE A950287)
Snap Action	VM0850600F200V1A	A950179		OBSOLETE	(SEE A950288)
Snap Action	VM0850601F200V1A	A950180		OBSOLETE	(SEE A950289)
Snap Action	VM0850602F095V1A	A950181		OBSOLETE	(SEE A950290)
Snap Action	VM0850603F050V1A	A950182		OBSOLETE	(SEE A950291)
Snap Action	VM0850604F105V1A	A950183		OBSOLETE	(SEE A950292)
Snap Action	VM0850605F200V1A	A950184		OBSOLETE	(SEE A950293)
Snap Action	VM0850606F075V1A	A950185		OBSOLETE	(SEE A950294)
Snap Action	VM0851000F160S1A	A950186		OBSOLETE	(SEE A950239)
Snap Action	VM0851001F160S1A	A950187		OBSOLETE	(SEE A950240)
Snap Action	VM0851002F075S1A	A950188		OBSOLETE	(SEE A950241)
Snap Action	VM0851003F040S1A	A950189		OBSOLETE	(SEE A950242)
Snap Action	VM0851004F085S1A	A950190		OBSOLETE	(SEE A950243)
Snap Action	VM0851005F160S1A	A950191		OBSOLETE	(SEE A950244)
Snap Action	VM0851006F060S1A	A950192		OBSOLETE	(SEE A950245)



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Snap Action	VM0851000F200S1A	A950193		OBSOLETE	(SEE A950246)
Snap Action	VM0851001F200S1A	A950194		OBSOLETE	(SEE A950247)
Snap Action	VM0851002F095S1A	A950195		OBSOLETE	(SEE A950248)
Snap Action	VM0851003F050S1A	A950196		OBSOLETE	(SEE A950249)
Snap Action	VM0851004F105S1A	A950197		OBSOLETE	(SEE A950250)
Snap Action	VM0851005F200S1A	A950198		OBSOLETE	(SEE A950251)
Snap Action	VM0851006F075S1A	A950199		OBSOLETE	(SEE A950252)
Snap Action	VM0851000F160C2A	A950200		OBSOLETE	(SEE A950253)
Snap Action	VM0851001F160C2A	A950201		OBSOLETE	(SEE A950254)
Snap Action	VM0851002F075C2A	A950202		OBSOLETE	(SEE A950255)
Snap Action	VM0851003F040C2A	A950203		OBSOLETE	(SEE A950256)
Snap Action	VM0851004F085C2A	A950204		OBSOLETE	(SEE A950257)
Snap Action	VM0851005F160C2A	A950205		OBSOLETE	(SEE A950258)
Snap Action	VM0851006F060C2A	A950206		OBSOLETE	(SEE A950259)
Snap Action	VM0851000F200C2A	A950207		OBSOLETE	(SEE A950260)
Snap Action	VM0851001F200C2A	A950208		OBSOLETE	(SEE A950261)
Snap Action	VM0851002F095C2A	A950209		OBSOLETE	(SEE A950262)
Snap Action	VM0851003F050C2A	A950210		OBSOLETE	(SEE A950263)
Snap Action	VM0851004F105C2A	A950211		OBSOLETE	(SEE A950264)
Snap Action	VM0851000F160C1A	A950212		OBSOLETE	(SEE A950267)
Snap Action	VM0851001F160C1A	A950213		OBSOLETE	(SEE A950268)
Snap Action	VM0851002F075C1A	A950214		OBSOLETE	(SEE A950269)
Snap Action	VM0851003F040C1A	A950215		OBSOLETE	(SEE A950270)
Snap Action	VM0851004F085C1A	A950216		OBSOLETE	(SEE A950271)
Snap Action	VM0851005F160C1A	A950217		OBSOLETE	(SEE A950272)
Snap Action	VM0851006F060C1A	A950218		OBSOLETE	(SEE A950273)
Snap Action	VM0851000F200C1A	A950219		OBSOLETE	(SEE A950274)
Snap Action	VM0851001F200C1A	A950220		OBSOLETE	(SEE A950275)
Snap Action	VM0851002F095C1A	A950221		OBSOLETE	(SEE A950276)
Snap Action	VM0851003F050C1A	A950222		OBSOLETE	(SEE A950277)
Snap Action	VM0851004F105C1A	A950223		OBSOLETE	(SEE A950278)
Snap Action	VM0851006F075C1A	A950224		OBSOLETE	(SEE A950280)
Snap Action	VM0851000F160V1A	A950225		OBSOLETE	(SEE A950281)
Snap Action	VM0851001F160V1A	A950226		OBSOLETE	(SEE A950282)
Snap Action	VM0851002F075V1A	A950227		OBSOLETE	(SEE A950283)
Snap Action	VM0851003F040V1A	A950228		OBSOLETE	(SEE A950284)
Snap Action	VM0851004F085V1A	A950229		OBSOLETE	(SEE A950285)
Snap Action	VM0851005F160V1A	A950230		OBSOLETE	(SEE A950286)
Snap Action	VM0851006F060V1A	A950231		OBSOLETE	(SEE A950287)
Snap Action	VM0851000F200V1A	A950232		OBSOLETE	(SEE A950288)
Snap Action	VM0851001F200V1A	A950233		OBSOLETE	(SEE A950289)
Snap Action	VM0851002F095V1A	A950234		OBSOLETE	(SEE A950290)
Snap Action	VM0851003F050V1A	A950235		OBSOLETE	(SEE A950291)
Snap Action	VM0851004F105V1A	A950236		OBSOLETE	(SEE A950292)
Snap Action	VM0851005F200V1A	A950237		OBSOLETE	(SEE A950293)
Snap Action	VM0851006F075V1A	A950238		OBSOLETE	(SEE A950294)
Snap Action	VM0851600F160S1A	A950239		OBSOLETE	
Snap Action	VM0851601F160S1A	A950240		OBSOLETE	
Snap Action	VM0851602F075S1A	A950241		OBSOLETE	
Snap Action	VM0851603F040S1A	A950242		OBSOLETE	
Snap Action	VM0851604F085S1A	A950243		OBSOLETE	
Snap Action	VM0851605F160S1A	A950244		OBSOLETE	
Snap Action	VM0851606F060S1A	A950245		OBSOLETE	
Snap Action	VM0851600F200S1A	A950246		OBSOLETE	
Snap Action	VM0851601F200S1A	A950247		OBSOLETE	
Snap Action	VM0851602F095S1A	A950248		OBSOLETE	
Snap Action	VM0851603F050S1A	A950249		OBSOLETE	
Snap Action	VM0851604F105S1A	A950250		OBSOLETE	
Snap Action	VM0851605F200S1A	A950251		OBSOLETE	
Snap Action	VM0851606F075S1A	A950252		OBSOLETE	
Snap Action	VM0851600F160C2A	A950253		OBSOLETE	
Snap Action	VM0851601F160C2A	A950254		OBSOLETE	
Snap Action	VM0851602F075C2A	A950255		OBSOLETE	
Snap Action	VM0851603F040C2A	A950256		OBSOLETE	
Snap Action	VM0851604F085C2A	A950257		OBSOLETE	
Snap Action	VM0851605F160C2A	A950258		OBSOLETE	
Snap Action	VM0851606F060C2A	A950259		OBSOLETE	
Snap Action	VM0851600F200C2A	A950260		OBSOLETE	
Snap Action	VM0851601F200C2A	A950261		OBSOLETE	
Snap Action	VM0851602F095C2A	A950262		OBSOLETE	
Snap Action	VM0851603F050C2A	A950263		OBSOLETE	
Snap Action	VM0851604F105C2A	A950264		OBSOLETE	
Snap Action	VM0851605F200C2A	A950265		OBSOLETE	
Snap Action	VM0851606F075C2A	A950266		OBSOLETE	
Snap Action	VM0851600F160C1A	A950267		OBSOLETE	
Snap Action	VM0851601F160C1A	A950268		OBSOLETE	
Snap Action	VM0851602F075C1A	A950269		OBSOLETE	
Snap Action	VM0851603F040C1A	A950270		OBSOLETE	
Snap Action	VM0851604F085C1A	A950271		OBSOLETE	
Snap Action	VM0851605F160C1A	A950272		OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Snap Action	VM0851606F060C1A	A950273		OBSOLETE	
Snap Action	VM0851600F200C1A	A950274		OBSOLETE	
Snap Action	VM0851601F200C1A	A950275		OBSOLETE	
Snap Action	VM0851602F095C1A	A950276		OBSOLETE	
Snap Action	VM0851603F050C1A	A950277		OBSOLETE	
Snap Action	VM0851604F105C1A	A950278		OBSOLETE	
Snap Action	VM0851605F200C1A	A950279		OBSOLETE	(Q950031)
Snap Action	VM0851606F075C1A	A950280		OBSOLETE	
Snap Action	VM0851600F160V1A	A950281		OBSOLETE	
Snap Action	VM0851601F160V1A	A950282		OBSOLETE	
Snap Action	VM0851602F075V1A	A950283		OBSOLETE	
Snap Action	VM0851603F040V1A	A950284		OBSOLETE	
Snap Action	VM0851604F085V1A	A950285		OBSOLETE	
Snap Action	VM0851605F160V1A	A950286		OBSOLETE	
Snap Action	VM0851606F060V1A	A950287		OBSOLETE	
Snap Action	VM0851600F200V1A	A950288		OBSOLETE	
Snap Action	VM0851601F200V1A	A950289		OBSOLETE	
Snap Action	VM0851602F095V1A	A950290		OBSOLETE	
Snap Action	VM0851603F050V1A	A950291		OBSOLETE	
Snap Action	VM0851604F105V1A	A950292		OBSOLETE	
Snap Action	VM0851605F200V1A	A950293		OBSOLETE	
Snap Action	VM0851606F075V1A	A950294		OBSOLETE	
Snap Action	VM085R100F160C1A	A950295		OBSOLETE	
Snap Action	VM0851602F095V2A	A950296		OBSOLETE	
Snap Action	VM0851000F160V1C	A950297		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM0850304F085V1C	A950298		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM1251607F095C1A	A950299		OBSOLETE	
Snap Action	VM0851600F160B1C	A950300		OBSOLETE	
Snap Action	VM0851607F120C1A	A950301		OBSOLETE	
Snap Action	VM085Q107F120C1A	A950302		OBSOLETE	SEE A950301
Snap Action	VM1251001F200C2A	A950303		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM1251005F200C2A	A950304		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM1251004F105C2A	A950305		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM1250602F095C1A	A950306		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM1251007F055C2A	A950307		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM0851602F095V1B	A950308		OBSOLETE	
Snap Action	VM0851602F095V2B	A950309		OBSOLETE	
Snap Action	VM0851007F120C1A	A950310		OBSOLETE	(SEE A950301)
Snap Action	VM085Q100F160C1C	A950311		OBSOLETE	
Snap Action	VM085R100F160C1A	A950312		OBSOLETE	
Snap Action	VM1251007F095C2A	A950313		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM0850601F100C1B	A950314		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM0850601F100C1B	A950315		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM0851000F160C1B	A950316		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM0851004F085S1C	A950317		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM0851007F095C2C	A950318		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM0851008F055C2C	A950319		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM085R105F160S1A	A950320		OBSOLETE	
Snap Action	VM0851002F030C1A	A950321		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM085R105F160C1A	A950322		OBSOLETE	
Snap Action	VM0851600F055C2A	A950323		OBSOLETE	
Snap Action	VM0851600F100C2A	A950324		OBSOLETE	
Snap Action	VM0851000F055C2A	A950325		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM0851000F100C2A	A950326		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM085R107F120C1A	A950327		OBSOLETE	GOLD P
Snap Action	VM0851000F055C1A	A950328		OBSOLETE	(SEE A950329)
Snap Action	VM0851600F055C1A	A950329		OBSOLETE	
Snap Action	VM0851002F075C1C	A950330		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM0850300F160C2C	A950331		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM0851003F040C1C	A950332		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM0851005F200C1C	A950333		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM0851000F200C1B	A950334		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM0851000F200C1A	A950335		OBSOLETE	SEE A950274
Snap Action	VM0851004F030C1C	A950336		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM085R100F055C1A	A950337		OBSOLETE	
Snap Action	VM085Q104F085C1B	A950338		OBSOLETE	
Snap Action	VM0851000F100C1A	A950339		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM085R105F055C1A	A950340		OBSOLETE	
Snap Action	VM0851600F200C2C	A950341		OBSOLETE	
Snap Action	VM0851604F055C1C	A950342		OBSOLETE	
Snap Action	VM0851601F055C2A	A950343		OBSOLETE	
Snap Action	VM0851600F160C2C	A950344		OBSOLETE	
Snap Action	VM0851602F075B1C	A950345		OBSOLETE	
Snap Action	VM0851600F350S1B	A950346		OBSOLETE	
Snap Action	VM0851605F160V2A	A950347		OBSOLETE	
Snap Action	VM0851605F200C1A	A950348		OBSOLETE	
Snap Action	VM0851600F100C1C	A950349		OBSOLETE	
Snap Action	VM0851600F160C2B	A950350		OBSOLETE	
Snap Action	VM0851602F095B1C	A950351		OBSOLETE	
Snap Action	VM0851602F075C1C	A950352		OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Snap Action	VM0851609F060C1A	A950353		OBSOLETE	
Snap Action	VM0851000F200C2B	A950500		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM0851000F350C2B	A950501		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM0851000F200C2C	A950502		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM0851000F350C2C	A950503		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM085R104F105B1A	A950557		OBSOLETE	
Snap Action	VM085R104F105S1A	A950558		OBSOLETE	
Snap Action	VM085R104F105C1A	A950559		OBSOLETE	
Snap Action	VM085R104F105C2A	A950560		OBSOLETE	
Snap Action	VM085R106075C2A	A950561		OBSOLETE	
Snap Action	VM085R106F075C1A	A950562		OBSOLETE	
Snap Action	VM085R105F160V1A	A950568		OBSOLETE	
Snap Action	VM085R100F160V1A	A950569		OBSOLETE	GOLD CONTACTS
Snap Action	VM085R100F160V2A	A950570		OBSOLETE	GOLD CONTACTS
Snap Action	VM0850605F055S1C	A950611		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM0850600F055C1A	A950659		OBSOLETE	(SEE A950329)
Snap Action	VM0851007F120C2A	A950713		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM1251600F200C2A	A950760		OBSOLETE	
Snap Action	VM0850600F160V2A	A990172		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM0851600F160V2A	A990225		OBSOLETE	
Snap Action	VM1251600F055C2A	A990323		OBSOLETE	
Snap Action	VM1251600F200C1A	A990324		OBSOLETE	
Snap Action	VM0850605F160V2A	A990501		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM0851005F160B1A	A990502		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM0851605F160B1A	A990503		OBSOLETE	
Snap Action	VM0851605F200B1A	A990504		OBSOLETE	
Snap Action	VM0851006F060B1A	A990602		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM0851606F060B1A	A990603		OBSOLETE	
Snap Action	VM10S00S0	J000032		OBSOLETE	
Snap Action	VM10S00F10	J000033		OBSOLETE	
Snap Action	VM10H03F10	J000034		OBSOLETE	
Snap Action	VM10S05F10	J000036		OBSOLETE	
Snap Action	VM06ACTUATOR	J000045		OBSOLETE	
Snap Action	VMCUSTOMLEVER	J000051		OBSOLETE	
Snap Action	VM05S06F0	J000055		OBSOLETE	
Snap Action	VMP1L05F10	J000056		OBSOLETE	
Snap Action	ARCLEVERACTUATOR	J000070		OBSOLETE	
Snap Action	VM10120GF00F10	R040200		OBSOLETE	
Snap Action	VM10120GF1001F10	R040202		OBSOLETE	
Snap Action	VM10120GFF10W10WITH132	R040203		OBSOLETE	ACT**
Snap Action	VM132ACTUATOR	R040204		OBSOLETE	
Snap Action	VMRGOLD120GFF10	R040210		OBSOLETE	w/120 ACTUATOR
Snap Action	VM085XXYYF075C1A	XA1903P		OBSOLETE	20u IN GOLD, 132dg LEVER
Snap Action	VM0851020F095V1C	XA1952P		OBSOLETE	REPLACED WITH 16AMP
Snap Action	VM0851602F050S1ABLU	XA2066P		OBSOLETE	BLKYE L**
Snap Action	VM0851602F050S1ARED	XA2067P		OBSOLETE	BLKORG**
Snap Action	VM0851602F050S1ABLK	XA2068P		OBSOLETE	BLKBLK** (XQ0013P)
Tact	901AGQ	D310961	2012	OBSOLETE	Part number & tooling change, use TL3901AGQF180 (P010961)
Tact	320.22E11BLK	XB0009A	2009	OBSOLETE	Actuator 320,22 tooling EOL
Tact	320.22E11BLK	XB0009P	2009	OBSOLETE	Actuator 320,22 tooling EOL
Tact	320.22E11RED	XB0012A	2009	OBSOLETE	Actuator 320,22 tooling EOL
Tact	320.22E11RED	XB0012P	2009	OBSOLETE	Actuator 320,22 tooling EOL
Tact	320.22E11ORG	XB0013A	2009	OBSOLETE	Actuator 320,22 tooling EOL
Tact	320.22E11ORG	XB0013P	2009	OBSOLETE	Actuator 320,22 tooling EOL
Tact	320.22E11GRY	XB0019A	2009	OBSOLETE	Actuator 320,22 tooling EOL
Tact	320.22E11GRY	XB0019P	2009	OBSOLETE	Actuator 320,22 tooling EOL
Tact	320.22E11YEL	XB0021A	2009	OBSOLETE	Actuator 320,22 tooling EOL
Tact	320.22E11YEL	XB0021P	2009	OBSOLETE	Actuator 320,22 tooling EOL
Tact	320.22E11WHT	XB0065A	2009	OBSOLETE	Actuator 320,22 tooling EOL
Tact	320.22E11BLKWHT125	XB0413A	2009	OBSOLETE	Actuator 320,22 tooling EOL
Tact	320.22E11BLKWHT250	XB0414A	2009	OBSOLETE	Actuator 320,22 tooling EOL
Tact	320.22E11BLKWHT500	XB0415A	2009	OBSOLETE	Actuator 320,22 tooling EOL
Tact	320.22E11BLKWHT750	XB0416A	2009	OBSOLETE	Actuator 320,22 tooling EOL
Tact	320.22E11BLKWHT1000	XB0417A	2009	OBSOLETE	Actuator 320,22 tooling EOL
Tact	320.22E11BLKWHT1500	XB0418A	2009	OBSOLETE	Actuator 320,22 tooling EOL
Tact	320.22E11BLKWHT2000	XB0419A	2009	OBSOLETE	Actuator 320,22 tooling EOL
Tact	320.22E11BLKWHT3000	XB0420A	2009	OBSOLETE	Actuator 320,22 tooling EOL
Tact	320.22E11BLKWHT4000	XB0421A	2009	OBSOLETE	Actuator 320,22 tooling EOL
Tact	320.22E11BLKWHT6000	XB0422A	2009	OBSOLETE	Actuator 320,22 tooling EOL
Tact	320.22E11BLKWHT8000	XB0423A	2009	OBSOLETE	Actuator 320,22 tooling EOL
Tact	320.22LEIGHTRONIX	XB0570A	2009	OBSOLETE	Actuator 320,22 tooling EOL
Tact	320.22E11BLKENTER	XB0695A	2009	OBSOLETE	Actuator 320,22 tooling EOL
Tact	320.22E11BLU	XB0766A	2009	OBSOLETE	Actuator 320,22 tooling EOL
Tact	320.22E11BLU	XB0766P	2009	OBSOLETE	Actuator 320,22 tooling EOL
Tact	320.22E11GRN	XB0776A	2009	OBSOLETE	Actuator 320,22 tooling EOL
Tact	320.22E11GRN	XB0776P	2009	OBSOLETE	Actuator 320,22 tooling EOL
Tact	320.22U11RED	XB0843A	2009	OBSOLETE	Actuator 320,22 tooling EOL
Tact	901NGQF160	D310962	2012	OBSOLETE	Part number & tooling change, use TL3901AGQF180 (P010961)
Tact	901AGQF160	P010960		OBSOLETE	(2000 T/R)
Tact	901NGQF160	P010962		OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Tact	GSR6.84F130QP	L300002	2017	OBSOLETE	No longer produced by Factory
Tact	GSR6.84F300QP	L300003		OBSOLETE	No longer produced by Factory
Tact	GSR6.84F160QP	L300004		OBSOLETE	No longer produced by Factory
Tact	KS-00Q-03	29-K500Q03	2017	OBSOLETE	Decreasing demand, stream line series
Tact	KS-01Q-03	29-K501Q03	2017	OBSOLETE	Decreasing demand, stream line series
Tact	KS-01Q-05	29-K501Q05	2017	OBSOLETE	Decreasing demand, stream line series
Tact	KS-03Q-03	29-K503Q03	2017	OBSOLETE	Decreasing demand, stream line series
Tact	KS-04Q-02	29-K504Q02	2017	OBSOLETE	Decreasing demand, stream line series
Tact	KS-04Q-03	29-K504Q03	2017	OBSOLETE	Decreasing demand, stream line series
Tact	LL1105F065Q	P090000	2009	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	LL3301BF065QG	P090005	2009	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	LL3301FF065QG	P090007	2009	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	LL3303F065QG	P090001	2009	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL1014BF180QG	D400000	2013	OBSOLETE	reference active drawing P410002 for slight cosmetic differences TL1014BF180QG
Tact	TL1014AF180QG	D400001	2013	OBSOLETE	reference active drawing P410000 for slight cosmetic differences TL1014AF180QG
Tact	TL1015BF160QG	D400100	2013	OBSOLETE	Stream line series options, removed boss option, use TL1015AF160QG with no boss
Tact	TL1100AF160R	D301094	2004	OBSOLETE	Ask E-Switch for quote, increased MOQ required for gold plated dome
Tact	TL1100AF160SSDOME	D301097	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL1100EF160QSSDOME	D301098	2013	OBSOLETE	SS(stainless steel) no longer offered, feasibility quote required, anticipate increased MOQ
Tact	TL1100DF160R	D301107	2013	OBSOLETE	Ask E-Switch for quote, increased MOQ required for gold plated dome
Tact	TL1100BF160R	D301114	2013	OBSOLETE	B actuator obsolete, low demand no need to replace mold/tool
Tact	TL1100F160QSSDOME	D330099	2013	OBSOLETE	SS(stainless steel) no longer offered, feasibility quote required, anticipate increased MOQ
Tact	TL1100F130Q	D330200	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL1100NF160Q	D330250	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL1100BF160Q	P001113	2015	OBSOLETE	B actuator obsolete, low demand no need to replace mold/tool
Tact	TL1100BF260Q	P001114	2015	OBSOLETE	B actuator obsolete, low demand no need to replace mold/tool
Tact	TL1100CF260R	P001116	2020	OBSOLETE	
Tact	TL1100F260R	P001173	2020	OBSOLETE	
Tact	TL1100TF260R	P001176	2020	OBSOLETE	
Tact	TL1100F850Q	P001177	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	8.5MM F260 GOLD DOME	P990001	2020	OBSOLETE	Piece part not on Website
Tact	TL1100C.08BLK	XD0374A	2013	OBSOLETE	Stream line series options, base switch & cap sold separately
Tact	TL1100CF160Q.08GRY	XD0389A	2013	OBSOLETE	Stream line series options, base switch & cap sold separately
Tact	TL1100CF160Q.4JRED	XD0394A	2013	OBSOLETE	Stream line series options, base switch & cap sold separately
Tact	TL1100CF160Q.4JGRY	XD0395A	2013	OBSOLETE	Stream line series options, base switch & cap sold separately
Tact	TL1100AF160R220CBLK	XD0397A	2008	OBSOLETE	Stream line series options, base switch & cap sold separately
Tact	TL1100AF160R220CBLK	XD0397P	2013	OBSOLETE	Stream line series options, base switch & cap sold separately
Tact	TL1100AF160Q220CBLK	XD0399A	2008	OBSOLETE	Stream line series options, base switch & cap sold separately
Tact	TL1100CF160Q.08RED	XD0402A	2013	OBSOLETE	Stream line series options, base switch & cap sold separately
Tact	TLE1105BF100Q	D301117	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL1105AF160QSSDOME	D310000	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL1105CF160Q	D310004	2013	OBSOLETE	reference active drawing for slight cosmetic differences
Tact	TL1105LF160QSSDOME	D310008	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL1105NF250R	D310022	2013	OBSOLETE	Ask E-Switch for quote, increased MOQ required for gold plated dome
Tact	TL1105SF250R	D310024	2013	OBSOLETE	Ask E-Switch for quote, increased MOQ required for gold plated dome
Tact	TL1105AF100RSSDOME	D310035	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL1105AF100R	D310036	2013	OBSOLETE	Ask E-Switch for quote, increased MOQ required for gold plated dome
Tact	TL1105GF100Q	D310071	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL1105HF250Q	D310076	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL1105KF100Q	D310077	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL1105KF160Q	D310078	2013	OBSOLETE	reference active drawing for slight cosmetic differences
Tact	TL1105KF250Q	D310079	2013	OBSOLETE	reference active drawing for slight cosmetic differences
Tact	TL1105YF100Q	D310080	2013	OBSOLETE	reference active drawing for slight cosmetic differences
Tact	TL1105YF160Q	D310081	2013	OBSOLETE	reference active drawing for slight cosmetic differences
Tact	TL1105YF250Q	D310082	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL1105NF250R	D310083	2013	OBSOLETE	Ask E-Switch for quote, increased MOQ required for gold plated dome
Tact	TL1105NF100Q	D310084	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL1105PF100R	D310091	2013	OBSOLETE	Ask E-Switch for quote, increased MOQ required for gold plated dome
Tact	TL1105YF250QSSDOME	D310092	2013	OBSOLETE	Ask E-Switch for quote, increased MOQ required for stainless steel dome
Tact	TLE1105PF160Q	D310111	2013	OBSOLETE	Stream line series options, TLE1105PF100Q still active if grounding termination required
Tact	TLE1105AF100Q	D310116	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TLE1105GF250Q	D310117	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TLE1105GF160Q	D310118	2013	OBSOLETE	reference active drawing for slight cosmetic differences
Tact	TLE1105HF160Q	D310119	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TLE1105LF250Q	D310123	2013	OBSOLETE	Stream line series options, TLE1105LF160Q still active if grounding termination required
Tact	TL1105BF160QSSDOME	D310207	2013	OBSOLETE	Ask E-Switch for quote, increased MOQ required for stainless steel dome
Tact	ST1105F100Q	D311100	2010	OBSOLETE	Customer specific actuator/terminals, see TL1105 series for closest options
Tact	ST1105FF100Q	D311101	2010	OBSOLETE	Customer specific actuator/terminals, see TL1105 series for closest options
Tact	TL1105JAF160QSSDOME	D320209	2013	OBSOLETE	Ask E-Switch for quote, increased MOQ required for stainless steel dome
Tact	TL1105CF160R	D330004	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL1105EF160R	D330006	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL1105CF160QSPECIAL	P010031	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL1105QF100Q	P010041	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL1105SF160Q94VO	P010385	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL1105SP1CGRY	XD0382A	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL1105LF160Q1RBLK	XD0398A	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL1105JAF160Q1RRED	XP0241A	2021	OBSOLETE	
Tact	TL1107BF100WQ	D310270	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL1107AF260WR	D310308	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL1107AF180WR	D310309	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Tact	TL1107BF180WR	D310318	2013	OBSOLETE	Ask E-Switch for quote, increased MOQ required for gold plated dome
Tact	TL1107BF130BQ	D310382	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL1107BF260BQ	D310384	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL1107VF180RQ	D310388	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL1107WF180RQ	D310389	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL1107VAF160RQ	D310390	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL1107BF180CQ	D310391	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL1107BF130CR	D310392	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL1107BF260EQ	D310685	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL1240WQ	P010420	2013	OBSOLETE	see std. illumination colors (Blue, Red, Green, Yellow)
Tact	TL1240RQ2JBLK	XP0041A	2021	OBSOLETE	
Tact	TL1240BICOLORSPECIAL	XP0264P	2013	OBSOLETE	Customer specific, end product EOL, non std. LED leads
Tact	TL1240WQ1JCLR	XP0315P	2013	OBSOLETE	see std. illumination colors (Blue, Red, Green, Yellow)
Tact	TL1290AF400BR	B210000	2014	OBSOLETE	Notified distributors who had procured in April 2014
Tact	TL1290AF400RR	B210001	2014	OBSOLETE	Notified distributors who had procured in April 2014
Tact	TL1290AF400GR	B210002	2014	OBSOLETE	Notified distributors who had procured in April 2014
Tact	TL1290AF400WR	B210003	2014	OBSOLETE	Notified distributors who had procured in April 2014
Tact	TL1290AF400GRR	B210004	2014	OBSOLETE	Notified distributors who had procured in April 2014
Tact	TL1290AF400GYR	B210005	2014	OBSOLETE	Notified distributors who had procured in April 2014
Tact	TL1290AF400YR	B210006	2014	OBSOLETE	Notified distributors who had procured in April 2014
Tact	TL1290AF400NR	B210007	2014	OBSOLETE	Notified distributors who had procured in April 2014
Tact	TL1290AF400BARSPECIAL	B210008	2014	OBSOLETE	Notified distributors who had procured in April 2014
Tact	TL3300F160QG	D311000	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL3301DF260QJ	D310393	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL3301CF160QSSDOME	D310503	2013	OBSOLETE	Ask E-Switch for quote, increased MOQ required for stainless steel dome
Tact	TL3301AF520QJ	D310505	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL3301DF160RJ	D310506	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL3301AF520QG	D310510	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL3301NF100QJ	D310512	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL3301CF250RG	D310519	2013	OBSOLETE	No replacement
Tact	TL3301CF100RG	D310521	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL3301LF160RG	D310530	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL3301LF260QG	D310534	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL3301AF100RG	D310620	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL3301SPF160RJ	D310675	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL3301NF250RJ	D310806	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL3301LF260QJ	D310833	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL3301TF250RG	D310896	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL3301CF160QGBULK	P010502	2013	OBSOLETE	only available tape & reel, 700pc pkg mults
Tact	TL3301PF260QG	P010512	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL3301BF160RG	P010692	2013	OBSOLETE	Stream line series options, just eliminating duplicate drawings
Tact	TL3301SPF160QG1RBLK	XD0403A	2013	OBSOLETE	procure std. switch TL3301SPF160QG (J100793) and cap 1RBlk separately
Tact	TL3310AF120QG	D370000	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL3310AF200QG	D370200	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL3320AF100Q	D320000	2013	OBSOLETE	No replacement, see similar size TL58 seris (radial leaded) or TL6110 (sealed thru-hole)
Tact	TL3320AF130Q	D320001	2013	OBSOLETE	No replacement, see similar size TL58 seris (radial leaded) or TL6110 (sealed thru-hole)
Tact	TL3320AF160Q	D320002	2013	OBSOLETE	No replacement, see similar size TL58 seris (radial leaded) or TL6110 (sealed thru-hole)
Tact	TL3320AF250Q	D320003	2013	OBSOLETE	No replacement, see similar size TL58 seris (radial leaded) or TL6110 (sealed thru-hole)
Tact	TL3320BF100Q	D320004	2013	OBSOLETE	No replacement, see similar size TL58 seris (radial leaded) or TL6110 (sealed thru-hole)
Tact	TL3320BF130Q	D320005	2013	OBSOLETE	No replacement, see similar size TL58 seris (radial leaded) or TL6110 (sealed thru-hole)
Tact	TL3320BF250Q	D320007	2013	OBSOLETE	No replacement, see similar size TL58 seris (radial leaded) or TL6110 (sealed thru-hole)
Tact	TL3320BF160Q	D320010	2013	OBSOLETE	No replacement, see similar size TL58 seris (radial leaded) or TL6110 (sealed thru-hole)
Tact	TL3350BF100Q	P010684	2013	OBSOLETE	No replacement
Tact	TL3350AF100Q	P010685	2013	OBSOLETE	No replacement
Tact	TL3700AF160QG	P003000	2019	OBSOLETE	End of Life
Tact	TL3700AF100QG	P003001	2019	OBSOLETE	End of Life
Tact	TL53CF160QUL94VO	P010630	2013	OBSOLETE	use standard TL53CF160Q, review material specifications, std. is not V-0
Tact	TL59EF100Q	D310561	2013	OBSOLETE	reference active drawing for slight cosmetic differences
Tact	TL59BF260Q	D310568	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL59NF100Q	D310580	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL59PF160Q	D310586	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL59NF520Q	D310591	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL59AF100QBULK	D310598	2013	OBSOLETE	Use standard TL59AF100Q; tape pkg only to protect radial leads
Tact	TL59AF160R	D310652	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TL59SPF160Q	P010585	2020	OBSOLETE	
Tact	TL6100CF160QPSSDOME	D350011	2013	OBSOLETE	SS(stainless steel) not necessary, use Std. TL6100CF130QP(T350016) or F300QP
Tact	TL6100AF130QPSSDOME	D350014	2013	OBSOLETE	SS(stainless steel) not necessary, use Std. TL6100AF130QP for extended life cycles
Tact	TL6100DF160QPSSDOME	D350019	2013	OBSOLETE	SS(stainless steel) not necessary, use Std. TL6100DF160QP for extended life cycles
Tact	TL6100DF300QPSSDOME	D350020	2013	OBSOLETE	SS(stainless steel) not necessary, use Std. TL6100DF300QP for extended life cycles
Tact	TL6100AF300QPSSDOME	D350022	2013	OBSOLETE	SS(stainless steel) not necessary, use Std. TL6100AF300QP for extended life cycles
Tact	TL6100DACTUATOR	D350026	2013	OBSOLETE	Customer specific, NCNR, no replacement
Tact	TL6110CF500QPSSDOME	D351015	2013	OBSOLETE	SS(stainless steel) not required, use Std. TL6110CF500QP for extended life cycles
Tact	TL6120BF160QSSDOME	D351507	2013	OBSOLETE	SS(stainless steel) not necessary, use Std. TL6120BF160QG for extended life cycles
Tact	TL6120AF300QSSDOME	D351519	2013	OBSOLETE	SS(stainless steel) not necessary, use Std. TL6120AF300QG for extended life cycles
Tact	TL6120AF160QSSDOME	D351520	2013	OBSOLETE	SS(stainless steel) not required, use Std. TL6120AF160QG for extended life cycles
Tact	TL6120AF130QSSDOME	D351521	2013	OBSOLETE	SS(stainless steel) not required, use Std. TL6120AF160QG for extended life cycles
Tact	TL6304AF300QG	D310700	2004	OBSOLETE	see TL6700 and TL6100 sealed tact offerings
Tact	TL6304AF160QG	D310701	2004	OBSOLETE	see TL6700 and TL6100 sealed tact offerings
Tact	TL6304AF160RG	D310702	2004	OBSOLETE	see TL6700 and TL6100 sealed tact offerings
Tact	TL6304BF160RG	D310703	2004	OBSOLETE	see TL6700 and TL6100 sealed tact offerings



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Tact	TL6304CF300QG	D310704	2004	OBSOLETE	see TL6700 and TL6100 sealed tact offerings
Tact	TL6304AF160QJ	D310705	2004	OBSOLETE	see TL6700 and TL6100 sealed tact offerings
Tact	TL6304BF160QG	D310738	2004	OBSOLETE	see TL6700 and TL6100 sealed tact offerings
Tact	TL6304BF300QG	D310739	2004	OBSOLETE	see TL6700 and TL6100 sealed tact offerings
Tact	TL6304BF160QJ	D310743	2004	OBSOLETE	see TL6700 and TL6100 sealed tact offerings
Tact	TL6304BF200QJ	D310744	2004	OBSOLETE	see TL6700 and TL6100 sealed tact offerings
Tact	TL6304CF300QSSDDOME	D310745	2004	OBSOLETE	see TL6700 and TL6100 sealed tact offerings and extended life cycles
Tact	TL6304CF160QSSDDOME	D310746	2004	OBSOLETE	see TL6700 and TL6100 sealed tact offerings and extended life cycles
Tact	TL6304NF300QJ	D310747	2004	OBSOLETE	see TL6700 and TL6100 sealed tact offerings
Tact	TL6304AF160QJSSDDOME	D320543	2004	OBSOLETE	see TL6700 and TL6100 sealed tact offerings and extended life cycles
Tact	TL9000F120Q	D390000	2013	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Tact	TLE1105TF160Q	P010106	2020	OBSOLETE	
Tact	TLE1105CF250Q	P010113	2020	OBSOLETE	
Tact	TLE1105GF160Q	P010118	2020	OBSOLETE	
Tact	TLE1105LF250Q	P010123	2020	OBSOLETE	
Tact	TLE1105SPF160R1DBLK	XP0296A	2013	OBSOLETE	use TLE1105SPF160R cap 1DBlk sold separately (drawing Q800420)
Tact	TLE1105SPF160R1DRED	XP0297A	2013	OBSOLETE	use TLE1105SPF160R cap 1DRed sold separately (drawing Q800422)
Tact	TLE1105SPF160R1RWHT	XP0305A	2013	OBSOLETE	use TLE1105SPF160R cap 1RWHR sold separately (drawing Q800301)
Tact	TLE3303AF260QG	P010657	2013	OBSOLETE	Low sales, TLE3303AF160QG still active with 12k MOQ to produce
Tact	TL1100CF160Q,08BLK	XD0038A	2013	OBSOLETE	Stream line series options, switch TL1100CF160Q (P001110) and Cap 320.08BLK
TD	TD1104	P200014	2019	OBSOLETE	
TD	TD1106	P200017		OBSOLETE	
TD	TD1146R	Q940001	2019	OBSOLETE	
Toggle	100SP1T8B13M7QE	ST111084	2016	OBSOLETE	
Toggle	1003P1T6B11M6REH	ST111608	2015	OBSOLETE	
Toggle	100SP3T2B3M64QE	ST113015	2018	OBSOLETE	No longer produced by Factory
Toggle	100DP8T7B13M1QE	ST128603		OBSOLETE	
Toggle	100DP1T1B4VS3RE	T110041	2020	OBSOLETE	
Toggle	100SP1T1B4M2QE	T111066		OBSOLETE	SEE T111597
Toggle	100SP1T8B13M7QE	T111084	2016	OBSOLETE	
Toggle	100SP1T1B2M71QE	T111118	2015	OBSOLETE	
Toggle	1003P1T6B11M6RE	T111608		OBSOLETE	
Toggle	100SP3T2B3M64QE	T113015	2018	OBSOLETE	No longer produced by Factory
Toggle	100SP2T8B13M2QE	T113050		OBSOLETE	
Toggle	100SP4T8B13M2QE	T114024		OBSOLETE	SEE T114031
Toggle	100SP5T2B3M2QE	T115002		OBSOLETE	
Toggle	100SP5T1V33RE	T115004		OBSOLETE	
Toggle	100DP1T8B13M1QE	T121065		OBSOLETE	NO INSERT
Toggle	100DP5T6B15M3RE	T121087		OBSOLETE	
Toggle	100DP1T6B11M1QE	T121137		OBSOLETE	SEE T121017
Toggle	100DP3T1B4M6QE	T123008		OBSOLETE	
Toggle	100DP3T6B12M7RE	T123027		OBSOLETE	SEE - T123038
Toggle	100DP3T4B9M2QE	T123034		OBSOLETE	
Toggle	100DP4T8B13M1G1E	T124013		OBSOLETE	BRASS TOGGLE AND BUSHING
Toggle	1003P1T6B12M6RE	T133006	2015	OBSOLETE	
Toggle	1003P3T2B9M7QE	T135012	2018	OBSOLETE	Stream line series, search our site or consult E-Switch for active options
Toggle	1004P1T8B13M1QE	T141020		OBSOLETE	SEE T112025
Toggle	1004P7T1B9M7QE	T147000		OBSOLETE	
Toggle	100AWSP1T1B1M6QE	ST101029	2016	OBSOLETE	
Toggle	100AWSP3T1B1M6QE	T013006		OBSOLETE	
Toggle	100AWSP1T1B1M6QE	T101029	2016	OBSOLETE	
Toggle	100AWSP3T1B4M6RE	T103007		OBSOLETE	
Toggle	100AWSP4T1B1M1QEBRASS	T104006		OBSOLETE	BRASS TOGGLE AND BUSHING
Toggle	100AWSP4T1B1M1REBRASS	T104008		OBSOLETE	BRASS TOGGLE AND BUSHING
Toggle	1360BLKXCAP	D051000		OBSOLETE	
Toggle	200MSP1T2B1M7QE	ST211000	2007	OBSOLETE	
Toggle	200MSP1T3B4M7QE	T211027		OBSOLETE	SEE T211029
Toggle	200MSP1T2B2M7RE	T211036		OBSOLETE	SEE T211028
Toggle	200MSP6T1B1M2QE	T211053		OBSOLETE	
Toggle	200MSP6T2B2M6QE	T211054		OBSOLETE	
Toggle	200MSP3T1B2M2QE	T211075		OBSOLETE	3K NOT AVAILABLE
Toggle	200MSP6T1B1M5R	T211086		OBSOLETE	(NO EPOXY)
Toggle	200MSP6T1B1M7QE	T211091		OBSOLETE	
Toggle	200US1T1A1M6RE	T227000	2010	OBSOLETE	REPLACED BY T250001
Toggle	200US3T1A1M6QE	T227100	2010	OBSOLETE	REPLACED BY T250007
Toggle	200US9T1A1M2RE	T227200	2010	OBSOLETE	REPLACED BY T250008
Toggle	200UDP1T1A1M2RE	T250006		OBSOLETE	SEE T250003 FOR ORDERING
Toggle	200BWMSP2T2A1SM6RE	T833033	2014	OBSOLETE	On-None-(On) function ' WMSP2 ' has been dropped, the 200B series is still active
Toggle	200BWMSP2T2A1SM6QE	T833035	2014	OBSOLETE	On-None-(On) function ' WMSP2 ' has been dropped, the 200B series is still active
Toggle	200BWMSP4T1A1SM6RE	T833044		OBSOLETE	SEE T833040
Toggle	200BWMSP5TBA1SM8RE	T833047	2019	OBSOLETE	No activity
Toggle	200MSP6T1B1M5RE	XT0112A		OBSOLETE	SEE ST211059
Toggle	200AWMSP1T2A1M6RE	T201112		OBSOLETE	(SEE T201208)
Toggle	200AWMSP1T1A1M2RE	T201203		OBSOLETE	SEE T201111
Toggle	200AWMSP3T2A1M6RE	T201243		OBSOLETE	No longer produced by Factory
Toggle	200AWMSP5T2A1M2QE	T201500	2018	OBSOLETE	
Toggle	300SP5J3BLKVS2QE	T307000		OBSOLETE	SEE T315003
Toggle	300SP4R1BLKM1QE	T307010		OBSOLETE	SEE T314011
Toggle	300SP1R1BLKM1QE	T307011		OBSOLETE	SEE T311018
Toggle	300SP1J1BLKM6QE	T311026		OBSOLETE	OBSOLETE-SEE T311010



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Toggle	300SP1R8VS2RE	T311037		OBSOLETE	
Toggle	300SP1J1BLKM71QE	T311064		OBSOLETE	
Toggle	3004P1RBLKM1QE	T314037		OBSOLETE	SEE T311020
Toggle	300SP5R8VS2RE	T315004		OBSOLETE	
Toggle	300DP1R6M1QE	T321001		OBSOLETE	SEE T321030
Toggle	300DP1R16WHTM1RE	T321059		OBSOLETE	
Toggle	300DP6J2M6QE	T326002		OBSOLETE	
Toggle	300DP7J1BLKM6RE	T331012		OBSOLETE	
Toggle	300DP7R6WHTM3QEWH	T331013		OBSOLETE	
Toggle	3003P1J3BLKM6QE	T331024	2015	OBSOLETE	
Toggle	3003P1J3REDM6QE	T331026	2015	OBSOLETE	
Toggle	3003P1J1BLKM6QE	T331031	2015	OBSOLETE	
Toggle	300AWSP1J1GRVVS2QE	T301016	2017	OBSOLETE	
Toggle	300AWSP1J1BLKM75QE	T301019	2017	OBSOLETE	
Toggle	300AWSP1J1VS2REIO	T301021	2017	OBSOLETE	MARKING 'G' = I/O
Toggle	300AWDP1J1VS2RE	T301022	2017	OBSOLETE	
Toggle	300AWSP1J1M7QE	T301023	2017	OBSOLETE	
Toggle	300AWDP1J1BLKM7RE	T301040	2017	OBSOLETE	
Toggle	300AWSP3J5M7QE	T301041	2017	OBSOLETE	
Toggle	300AWSP1J1VS21RE	T301051	2017	OBSOLETE	
Toggle	300AWSP1J1BLKM6RE	T301053	2017	OBSOLETE	see #T301029
Toggle	300AWSP4J2WHTM1QE	T301401	2017	OBSOLETE	
Toggle	300AWSP4J4WHTM1QE	T301402	2017	OBSOLETE	
Toggle	300AWSP4J6WHTM1QE	T301403	2017	OBSOLETE	
Toggle	300AWSP4J3VS2R	T301404	2017	OBSOLETE	
Toggle	300AWSP5J6VS2RE	T301502	2017	OBSOLETE	
Toggle	300AWDP7R2BLKM1QE	T302020	2017	OBSOLETE	
Toggle	300AWDP8R2BLKM1QE	T302021	2017	OBSOLETE	
Toggle	300AWDP2J6BLKVS3QE	T302022	2019	OBSOLETE	
Toggle	300AWDP1J4BLKM3QE	T302106	2017	OBSOLETE	
Toggle	300AWDP3J3M6QE	T302107	2019	OBSOLETE	
Toggle	300AWDP3R1M3Q	T302109	2017	OBSOLETE	
Toggle	300AWDP4R1M2QE	T302412	2017	OBSOLETE	
Toggle	43.1K.60.00.C4	01-431K6000C4		OBSOLETE	
Toggle	81.01.82.93.R3	01-81018293R3		OBSOLETE	
Toggle	81.01.82.95.1K	01-810182951K		OBSOLETE	
Toggle	81.01.82.95.9K	01-810182959K		OBSOLETE	
Toggle	81.03.82.95.9K	01-810382959K		OBSOLETE	
Toggle	81.04.82.91.A3	01-81048291A3		OBSOLETE	
Toggle	81.10.T2.10.G9	01-8110T210G9		OBSOLETE	
Toggle	81.20.82.95.9H	01-812082959H		OBSOLETE	
Toggle	81.F2.47.63.0K	01-81F247630K		OBSOLETE	
Toggle	81.F2.P0.61.0K	01-81F2P0610K		OBSOLETE	
Toggle	81.F2.T7.63.0K	01-81F2T7630K		OBSOLETE	
Toggle	82.01.82.95.1E	01-820182951E		OBSOLETE	
Toggle	82.04.82.95.5E	01-820482955E		OBSOLETE	
Toggle	82.11.82.78.1C	01-821182781C		OBSOLETE	
Toggle	82.11.T2.10.P9	01-8211T210P9		OBSOLETE	
Toggle	82.11.T2.20.B9	01-8211T220B9		OBSOLETE	
Toggle	82.40.82.94.A3	01-82408294A3		OBSOLETE	
Toggle	82.40.82.95.0E	01-824082950E		OBSOLETE	
Toggle	82.40.82.98.1E	01-824082981E		OBSOLETE	
Toggle	82.42.82.95.9E	01-824282959E		OBSOLETE	
Toggle	82.43.82.95.9E	01-824382959E		OBSOLETE	
Toggle	82.43.82.98.9E	01-824382989E		OBSOLETE	
Toggle	82.50.82.47.9G-nr	01-825082479GNR		OBSOLETE	
Toggle	82.F2.50.61.0E	01-82F250610E		OBSOLETE	
Toggle	83.CD.82.70.B7	01-83CD8270B7		OBSOLETE	
Toggle	8A.01.82.92.B3	01-8A018292B3		OBSOLETE	
Toggle	8A.01.82.95.9K	01-8A0182959K		OBSOLETE	
Toggle	8A.F2.V0.00.A1	01-8AF2V000A1		OBSOLETE	
Toggle	A4.50.82.70.U0	01-A4508270U0		OBSOLETE	
Toggle	C2.2A.24.48.2P	01-C22A24482P		OBSOLETE	
Toggle	ST125D00-nr	34-ST125D00NR		OBSOLETE	
Toggle	ST12DD00-nr	34-ST12DD00NR		OBSOLETE	
Toggle	ST143D00-nr	34-ST143D00NR		OBSOLETE	
Toggle	ST144D00-nr	34-ST144D00NR		OBSOLETE	
Toggle	ST145D00-nr	34-ST145D00NR		OBSOLETE	
Toggle	ST14DD00-nr	34-ST14DD00NR		OBSOLETE	
Toggle	ST163D00-nr	34-ST163D00NR		OBSOLETE	
Toggle	ST164D00-nr	34-ST164D00NR		OBSOLETE	
Toggle	ST165D00-nr	34-ST165D00NR		OBSOLETE	
Toggle	ST16DD00-nr	34-ST16DD00NR		OBSOLETE	
Toggle	ST222D00-nr	34-ST222D00NR		OBSOLETE	
Toggle	ST226D00-nr	34-ST226D00NR		OBSOLETE	
Toggle	ST22ED00-nr	34-ST22ED00NR		OBSOLETE	
Toggle	ST22KD00-nr	34-ST22KD00NR		OBSOLETE	
Toggle	ST22Z02D00-nr	34-ST22Z02D00NR		OBSOLETE	
Toggle	ST246D00-nr	34-ST246D00NR		OBSOLETE	
Toggle	ST24ED00-nr	34-ST24ED00NR		OBSOLETE	



PRODUCT CHANGE NOTIFICATIONS

SWITCH TYPE	DESCRIPTION	ITEM NUMBER	PCN YEAR	STATUS	E-SWITCH NOTES
Toggle	ST266D00-nr	34-ST266D00NR		OBSOLETE	
Toggle	ST26ED00-nr	34-ST26ED00NR		OBSOLETE	
Toggle	T101-J1V3GE2	17-T101J1V3GE2		OBSOLETE	
Toggle	T101-SHZGE	17-T101SHZGE		OBSOLETE	
Toggle	TP11-SH9AV2BE	17-TP11SH9AV2BE		OBSOLETE	
Toggle	TP11-SH9CBE	17-TP11SH9CBE		OBSOLETE	
Toggle	V8.40.42.95.1E	01-V84042951E		OBSOLETE	