

-----Original Message-----

From: Richard Cornell [mailto:Richard.Cornell@samtec.com]

Sent: Tuesday, January 06, 2009 11:21 AM

To: CustEN

Subject: Samtec Engineering Change Notification - Drawings Attached

<<Cad.zip>>

ECN Number: 102606

Part #: BTE-XXX-XX-X-D-EMX-XX

Date of Change: 01/05/09

ECN Changes:

PLATING SPECIFICATION: CHG "-L: LIGHT SELECTIVE GOLD" TO "-L: LIGHT SELECTIVE GOLD WITH MATTE TIN TAILS"; CHG "-F: FLASH SELECTIVE GOLD" TO "-F: FLASH SELECTIVE GOLD WITH MATTE TIN TAILS".

For inquiries concerning this notification please contact the Customer Service ECN group at [customerserviceECN@samtec.com](mailto:customerserviceECN@samtec.com)





- <SAMTEC\_PCN\_PARTS\_AFFECTED>  
<PART NAME="BTE-014-01-L-D-DP-A" />  
<PART NAME="BTE-020-01-D" />  
<PART NAME="BTE-020-01-D-.CR" />  
<PART NAME="BTE-020-01-D-A" />  
<PART NAME="BTE-020-01-D-A-.CR" />  
<PART NAME="BTE-020-01-D-A-FL" />  
<PART NAME="BTE-020-01-D-A-FL-.CR" />  
<PART NAME="BTE-020-01-D-EM2" />  
<PART NAME="BTE-020-01-D-EM2-GP" />  
<PART NAME="BTE-020-01-D-EM3" />  
<PART NAME="BTE-020-01-D-FL" />  
<PART NAME="BTE-020-01-D-FL-.CR" />  
<PART NAME="BTE-020-01-F-D" />  
<PART NAME="BTE-020-01-F-D-A" />  
<PART NAME="BTE-020-01-F-D-A-K" />  
<PART NAME="BTE-020-01-F-D-A-K-TR" />  
<PART NAME="BTE-020-01-F-D-A-TR" />  
<PART NAME="BTE-020-01-F-D-EM2" />  
<PART NAME="BTE-020-01-F-D-EM3-.CMC" />  
<PART NAME="BTE-020-01-H-D-A" />  
<PART NAME="BTE-020-01-H-D-A-.F/H" />  
<PART NAME="BTE-020-01-H-D-A-K-TR" />  
<PART NAME="BTE-020-01-L-D" />  
<PART NAME="BTE-020-01-L-D-A" />  
<PART NAME="BTE-020-01-L-D-A-.F/H" />  
<PART NAME="BTE-020-01-L-D-A-FL" />  
<PART NAME="BTE-020-01-L-D-A-K" />  
<PART NAME="BTE-020-01-L-D-A-K-TR" />  
<PART NAME="BTE-020-01-L-D-A-K-TR-.F/H" />  
<PART NAME="BTE-020-01-L-D-A-TR" />  
<PART NAME="BTE-020-01-L-D-EM2" />  
<PART NAME="BTE-020-01-L-D-EM2-GP" />  
<PART NAME="BTE-020-01-L-D-FL" />  
<PART NAME="BTE-020-01-L-D-TR" />  
<PART NAME="BTE-020-02-D" />  
<PART NAME="BTE-020-02-D-.CR" />  
<PART NAME="BTE-020-02-D-A" />  
<PART NAME="BTE-020-02-D-A-.CR" />  
<PART NAME="BTE-020-02-F-D-A" />  
<PART NAME="BTE-020-02-H-D-A" />  
<PART NAME="BTE-020-02-L-D" />  
<PART NAME="BTE-020-02-L-D-A" />  
<PART NAME="BTE-020-02-L-D-A-K" />  
<PART NAME="BTE-020-02-L-D-A-K-TR" />  
<PART NAME="BTE-020-03-D" />  
<PART NAME="BTE-020-03-D-.CR" />  
<PART NAME="BTE-020-03-D-A" />  
<PART NAME="BTE-020-03-D-A-.CR" />  
<PART NAME="BTE-020-03-F-D-A" />  
<PART NAME="BTE-020-03-F-D-A-TR" />  
<PART NAME="BTE-020-03-L-D-A" />

<PART NAME="BTE-020-03-L-D-A-K" />  
<PART NAME="BTE-020-03-L-D-A-K-TR" />  
<PART NAME="BTE-020-04-F-D-A" />  
<PART NAME="BTE-020-04-F-D-A-K" />  
<PART NAME="BTE-020-04-F-D-A-K-TR" />  
<PART NAME="BTE-020-04-L-D-A" />  
<PART NAME="BTE-020-04-L-D-A-K" />  
<PART NAME="BTE-020-04-L-D-A-TR" />  
<PART NAME="BTE-020-04-L-D-LC" />  
<PART NAME="BTE-020-05-F-D-A" />  
<PART NAME="BTE-020-05-F-D-A-K" />  
<PART NAME="BTE-020-05-L-D" />  
<PART NAME="BTE-020-05-L-D-A" />  
<PART NAME="BTE-020-05-L-D-A-K" />  
<PART NAME="BTE-020-06-F-D-A-K" />  
<PART NAME="BTE-020-06-L-D-A" />  
<PART NAME="BTE-020-06-L-D-A-K" />  
<PART NAME="BTE-020-07-F-D-A" />  
<PART NAME="BTE-020-07-F-D-A-.CLSC" />  
<PART NAME="BTE-020-07-L-D-A" />  
<PART NAME="BTE-020-08-L-D-A" />  
<PART NAME="BTE-020-09-L-D-A" />  
<PART NAME="BTE-040-01-C-D-A" />  
<PART NAME="BTE-040-01-D" />  
<PART NAME="BTE-040-01-D-.CR" />  
<PART NAME="BTE-040-01-D-A" />  
<PART NAME="BTE-040-01-D-A-.CR" />  
<PART NAME="BTE-040-01-D-EM2" />  
<PART NAME="BTE-040-01-D-EM2-GP" />  
<PART NAME="BTE-040-01-D-EM3" />  
<PART NAME="BTE-040-01-F-D" />  
<PART NAME="BTE-040-01-F-D-A" />  
<PART NAME="BTE-040-01-F-D-A-K" />  
<PART NAME="BTE-040-01-F-D-A-K-TR" />  
<PART NAME="BTE-040-01-F-D-A-TR" />  
<PART NAME="BTE-040-01-F-D-EM2" />  
<PART NAME="BTE-040-01-F-D-LC" />  
<PART NAME="BTE-040-01-H-D-A" />  
<PART NAME="BTE-040-01-L-D" />  
<PART NAME="BTE-040-01-L-D-A" />  
<PART NAME="BTE-040-01-L-D-A-.CR" />  
<PART NAME="BTE-040-01-L-D-A-.F/H" />  
<PART NAME="BTE-040-01-L-D-A-K" />  
<PART NAME="BTE-040-01-L-D-A-K-TR" />  
<PART NAME="BTE-040-01-L-D-EM2" />  
<PART NAME="BTE-040-01-L-D-EM2-GP" />  
<PART NAME="BTE-040-02-D-A" />  
<PART NAME="BTE-040-02-D-A-.CR" />  
<PART NAME="BTE-040-02-F-D-A" />  
<PART NAME="BTE-040-02-F-D-A-K" />  
<PART NAME="BTE-040-02-F-D-A-K-TR" />  
<PART NAME="BTE-040-02-F-D-A-TR" />

<PART NAME="BTE-040-02-H-D-A" />  
<PART NAME="BTE-040-02-L-D-A" />  
<PART NAME="BTE-040-02-L-D-A-K" />  
<PART NAME="BTE-040-02-L-D-A-K-TR" />  
<PART NAME="BTE-040-02-L-D-A-TR" />  
<PART NAME="BTE-040-03-D-A" />  
<PART NAME="BTE-040-03-D-A-.CR" />  
<PART NAME="BTE-040-03-F-D-A" />  
<PART NAME="BTE-040-03-F-D-A-K" />  
<PART NAME="BTE-040-03-F-D-A-K-TR" />  
<PART NAME="BTE-040-03-L-D-A" />  
<PART NAME="BTE-040-03-L-D-A-K" />  
<PART NAME="BTE-040-03-L-D-A-K-TR" />  
<PART NAME="BTE-040-04-F-D-A" />  
<PART NAME="BTE-040-04-F-D-A-K-TR" />  
<PART NAME="BTE-040-04-L-D-A" />  
<PART NAME="BTE-040-04-L-D-A-K" />  
<PART NAME="BTE-040-04-L-D-A-K-TR" />  
<PART NAME="BTE-040-05-F-D-A" />  
<PART NAME="BTE-040-05-F-D-A-K" />  
<PART NAME="BTE-040-05-L-D-A" />  
<PART NAME="BTE-040-05-L-D-A-.CR" />  
<PART NAME="BTE-040-05-L-D-A-K" />  
<PART NAME="BTE-040-06-F-D-A" />  
<PART NAME="BTE-040-06-L-D-A" />  
<PART NAME="BTE-040-06-L-D-A-K" />  
<PART NAME="BTE-040-07-F-D-A" />  
<PART NAME="BTE-040-07-L-D-A" />  
<PART NAME="BTE-040-08-F-D-A" />  
<PART NAME="BTE-040-08-L-D-A" />  
<PART NAME="BTE-040-09-F-D-A" />  
<PART NAME="BTE-040-09-L-D-A" />  
<PART NAME="BTE-060-01-C-D-A" />  
<PART NAME="BTE-060-01-D-A" />  
<PART NAME="BTE-060-01-D-A-.CR" />  
<PART NAME="BTE-060-01-D-EM2" />  
<PART NAME="BTE-060-01-D-EM2-GP" />  
<PART NAME="BTE-060-01-D-EM3" />  
<PART NAME="BTE-060-01-D-FL" />  
<PART NAME="BTE-060-01-D-FL-.CR" />  
<PART NAME="BTE-060-01-F-D-A" />  
<PART NAME="BTE-060-01-F-D-A-K" />  
<PART NAME="BTE-060-01-F-D-A-TR" />  
<PART NAME="BTE-060-01-F-D-EM2" />  
<PART NAME="BTE-060-01-F-D-EM2-GP" />  
<PART NAME="BTE-060-01-H-D-A" />  
<PART NAME="BTE-060-01-L-D-A" />  
<PART NAME="BTE-060-01-L-D-A-.CR" />  
<PART NAME="BTE-060-01-L-D-A-K" />  
<PART NAME="BTE-060-01-L-D-EM2" />  
<PART NAME="BTE-060-01-L-D-EM2-GP" />  
<PART NAME="BTE-060-01-L-D-FL" />

<PART NAME="BTE-060-02-D" />  
<PART NAME="BTE-060-02-D-.CR" />  
<PART NAME="BTE-060-02-D-A" />  
<PART NAME="BTE-060-02-D-A-.CR" />  
<PART NAME="BTE-060-02-F-D-A" />  
<PART NAME="BTE-060-02-F-D-A-K" />  
<PART NAME="BTE-060-02-F-D-A-TR" />  
<PART NAME="BTE-060-02-H-D-A" />  
<PART NAME="BTE-060-02-H-D-LC" />  
<PART NAME="BTE-060-02-L-D" />  
<PART NAME="BTE-060-02-L-D-A" />  
<PART NAME="BTE-060-02-L-D-A-K" />  
<PART NAME="BTE-060-02-L-D-A-K-TR" />  
<PART NAME="BTE-060-02-L-D-A-TR" />  
<PART NAME="BTE-060-03-D" />  
<PART NAME="BTE-060-03-D-.CR" />  
<PART NAME="BTE-060-03-D-A" />  
<PART NAME="BTE-060-03-D-A-.CR" />  
<PART NAME="BTE-060-03-F-D-A" />  
<PART NAME="BTE-060-03-F-D-A-K" />  
<PART NAME="BTE-060-03-F-D-A-K-TR" />  
<PART NAME="BTE-060-03-F-D-A-TR" />  
<PART NAME="BTE-060-03-H-D-A-K-TR" />  
<PART NAME="BTE-060-03-L-D-A" />  
<PART NAME="BTE-060-03-L-D-A-K" />  
<PART NAME="BTE-060-03-L-D-A-K-TR" />  
<PART NAME="BTE-060-04-F-D-A" />  
<PART NAME="BTE-060-04-F-D-A-K" />  
<PART NAME="BTE-060-04-H-D-A-K-TR" />  
<PART NAME="BTE-060-04-L-D-A" />  
<PART NAME="BTE-060-04-L-D-A-.CR" />  
<PART NAME="BTE-060-04-L-D-A-K" />  
<PART NAME="BTE-060-04-L-D-A-K-TR" />  
<PART NAME="BTE-060-05-F-D-A" />  
<PART NAME="BTE-060-05-F-D-A-K" />  
<PART NAME="BTE-060-05-F-D-LC" />  
<PART NAME="BTE-060-05-L-D-A" />  
<PART NAME="BTE-060-05-L-D-A-.CR" />  
<PART NAME="BTE-060-05-L-D-A-K" />  
<PART NAME="BTE-060-06-F-D-A" />  
<PART NAME="BTE-060-06-L-D-A" />  
<PART NAME="BTE-060-07-F-D-A" />  
<PART NAME="BTE-060-07-L-D-A" />  
<PART NAME="BTE-060-08-L-D-A" />  
<PART NAME="BTE-060-09-F-D-A" />  
<PART NAME="BTE-060-09-L-D-A" />  
<PART NAME="BTE-080-01-D-A" />  
<PART NAME="BTE-080-01-D-A-.CR" />  
<PART NAME="BTE-080-01-D-EM2" />  
<PART NAME="BTE-080-01-F-D-A" />  
<PART NAME="BTE-080-01-F-D-A-K" />  
<PART NAME="BTE-080-01-F-D-A-K-TR" />

<PART NAME="BTE-080-01-F-D-A-TR" />  
<PART NAME="BTE-080-01-F-D-EM2" />  
<PART NAME="BTE-080-01-H-D-EM2" />  
<PART NAME="BTE-080-01-L-D-A" />  
<PART NAME="BTE-080-01-L-D-A-.CR" />  
<PART NAME="BTE-080-01-L-D-A-K-TR" />  
<PART NAME="BTE-080-01-L-D-A-TR" />  
<PART NAME="BTE-080-01-L-D-EM2" />  
<PART NAME="BTE-080-02-D" />  
<PART NAME="BTE-080-02-D-.CR" />  
<PART NAME="BTE-080-02-D-A" />  
<PART NAME="BTE-080-02-D-A-.CR" />  
<PART NAME="BTE-080-02-F-D" />  
<PART NAME="BTE-080-02-F-D-A" />  
<PART NAME="BTE-080-02-F-D-A-K" />  
<PART NAME="BTE-080-02-L-D" />  
<PART NAME="BTE-080-02-L-D-A" />  
<PART NAME="BTE-080-02-L-D-A-.CR" />  
<PART NAME="BTE-080-03-D" />  
<PART NAME="BTE-080-03-D-A" />  
<PART NAME="BTE-080-03-D-A-.CR" />  
<PART NAME="BTE-080-03-F-D-A" />  
<PART NAME="BTE-080-03-F-D-A-K" />  
<PART NAME="BTE-080-03-L-D-A" />  
<PART NAME="BTE-080-03-L-D-A-.CR" />  
<PART NAME="BTE-080-03-L-D-A-K" />  
<PART NAME="BTE-080-04-F-D-A" />  
<PART NAME="BTE-080-04-F-D-A-K" />  
<PART NAME="BTE-080-04-F-D-A-K-TR" />  
<PART NAME="BTE-080-04-H-D" />  
<PART NAME="BTE-080-04-H-D-A" />  
<PART NAME="BTE-080-04-L-D-A" />  
<PART NAME="BTE-080-04-L-D-A-.CR" />  
<PART NAME="BTE-080-04-L-D-A-K" />  
<PART NAME="BTE-080-05-F-D-A" />  
<PART NAME="BTE-080-05-F-D-A-K" />  
<PART NAME="BTE-080-05-H-D-A-K" />  
<PART NAME="BTE-080-05-L-D-A" />  
<PART NAME="BTE-080-06-F-D-A" />  
<PART NAME="BTE-080-06-L-D-A" />  
<PART NAME="BTE-080-06-L-D-A-K" />  
<PART NAME="BTE-080-07-L-D-A" />  
<PART NAME="BTE-080-08-L-D-A" />  
<PART NAME="BTE-080-09-L-D" />  
<PART NAME="BTE-080-09-L-D-A" />  
<PART NAME="BTE-090-03-D-A" />  
<PART NAME="BTE-090-03-D-A-.CR" />  
<PART NAME="BTE-090-03-L-D-A" />  
<PART NAME="BTE-100-01-D-A" />  
<PART NAME="BTE-100-01-D-A-.CR" />  
<PART NAME="BTE-100-01-D-EM2" />  
<PART NAME="BTE-100-01-D-EM3" />



<PART NAME="BTE-100-01-D-FL" />  
<PART NAME="BTE-100-01-D-FL.CR" />  
<PART NAME="BTE-100-01-F-D-A" />  
<PART NAME="BTE-100-01-F-D-EM2" />  
<PART NAME="BTE-100-01-H-D-A" />  
<PART NAME="BTE-100-01-L-D-A" />  
<PART NAME="BTE-100-01-L-D-A.CR" />  
<PART NAME="BTE-100-01-L-D-A-K" />  
<PART NAME="BTE-100-01-L-D-EM2" />  
<PART NAME="BTE-100-01-L-D-FL" />  
<PART NAME="BTE-100-02-D-A" />  
<PART NAME="BTE-100-02-D-A.CR" />  
<PART NAME="BTE-100-02-F-D-A" />  
<PART NAME="BTE-100-02-F-D-A-K" />  
<PART NAME="BTE-100-02-L-D-A" />  
<PART NAME="BTE-100-02-L-D-A.CR" />  
<PART NAME="BTE-100-02-L-D-A-K" />  
<PART NAME="BTE-100-03-D" />  
<PART NAME="BTE-100-03-D-A" />  
<PART NAME="BTE-100-03-D-A.CR" />  
<PART NAME="BTE-100-03-F-D-A" />  
<PART NAME="BTE-100-03-F-D-A-K" />  
<PART NAME="BTE-100-03-L-D-A" />  
<PART NAME="BTE-100-03-L-D-A.CR" />  
<PART NAME="BTE-100-04-F-D-A" />  
<PART NAME="BTE-100-04-L-D-A" />  
<PART NAME="BTE-100-04-L-D-A.CR" />  
<PART NAME="BTE-100-04-L-D-A-K" />  
<PART NAME="BTE-100-05-F-D-A" />  
<PART NAME="BTE-100-05-L-D-A" />  
<PART NAME="BTE-100-05-L-D-A.CR" />  
<PART NAME="BTE-100-05-L-D-A-K" />  
<PART NAME="BTE-100-06-F-D-A" />  
<PART NAME="BTE-100-06-L-D-A" />  
<PART NAME="BTE-100-07-F-D-A" />  
<PART NAME="BTE-100-07-L-D-A" />  
<PART NAME="BTE-100-08-L-D-A" />  
<PART NAME="BTE-100-09-L-D-A" />  
<PART NAME="BTE-120-01-D" />  
<PART NAME="BTE-120-01-D-A" />  
<PART NAME="BTE-120-01-D-A.CR" />  
<PART NAME="BTE-120-01-D-EM2" />  
<PART NAME="BTE-120-01-D-EM3" />  
<PART NAME="BTE-120-01-D-FL" />  
<PART NAME="BTE-120-01-D-FL.CR" />  
<PART NAME="BTE-120-01-F-D-A" />  
<PART NAME="BTE-120-01-F-D-EM2" />  
<PART NAME="BTE-120-01-H-D-A-K" />  
<PART NAME="BTE-120-01-L-D-A" />  
<PART NAME="BTE-120-01-L-D-EM2" />  
<PART NAME="BTE-120-01-L-D-FL" />  
<PART NAME="BTE-120-02-D" />

<PART NAME="BTE-120-02-D-.CR" />  
<PART NAME="BTE-120-02-D-A" />  
<PART NAME="BTE-120-02-D-A-.CR" />  
<PART NAME="BTE-120-02-F-D" />  
<PART NAME="BTE-120-02-F-D-A" />  
<PART NAME="BTE-120-02-L-D" />  
<PART NAME="BTE-120-02-L-D-A" />  
<PART NAME="BTE-120-03-D" />  
<PART NAME="BTE-120-03-D-.CR" />  
<PART NAME="BTE-120-03-D-A" />  
<PART NAME="BTE-120-03-D-A-.CR" />  
<PART NAME="BTE-120-03-F-D-A" />  
<PART NAME="BTE-120-03-L-D-A" />  
<PART NAME="BTE-120-04-F-D" />  
<PART NAME="BTE-120-04-F-D-A" />  
<PART NAME="BTE-120-04-H-D-A" />  
<PART NAME="BTE-120-04-L-D-A" />  
<PART NAME="BTE-120-05-F-D-A" />  
<PART NAME="BTE-120-05-F-D-A-K" />  
<PART NAME="BTE-120-05-H-D-A" />  
<PART NAME="BTE-120-05-L-D-A" />  
<PART NAME="BTE-120-05-L-D-A-.ARROW" />  
<PART NAME="BTE-120-05-L-D-K" />  
<PART NAME="BTE-120-06-L-D-A" />  
<PART NAME="BTE-120-07-F-D-A" />  
<PART NAME="BTE-120-07-L-D" />  
<PART NAME="BTE-120-07-L-D-A" />  
<PART NAME="BTE-120-08-L-D-A" />  
<PART NAME="BTE-120-09-L-D-A" />  
</SAMTEC\_PCN\_PARTS\_AFFECTED>