

1 Products affected

Product hierarchy no. *				Part no.	SBU	Type / Description
SBU	PG	PUG	Type			
01	001	020	0000000050	See list	Circuit Protection	MSF 125
01	001	020	0000000051	See list	Circuit Protection	MSF 250
01	001	020	0000000052	See list	Circuit Protection	MST 250
01	001	020	0000000053	See list	Circuit Protection	MXT 250
01	001	020	0000000059	See list	Circuit Protection	MSTU 250
01	001	023	0000000064	See list	Circuit Protection	OMF 250
01	001	023	0000000080	See list	Circuit Protection	OMT
01	001	023	0000000082	See list	Circuit Protection	UMT 250
01	001	023	0000000094	See list	Circuit Protection	UMT-H
01	001	023	0000000094	See list	Circuit Protection	UMT-M
01	001	023	0000000106	See list	Circuit Protection	UMT-W
01	001	023	0000000350	See list	Circuit Protection	UMZ 250
01	001	023	0000000351	See list	Circuit Protection	UMF 250
01	001	023	0000000352	See list	Circuit Protection	UMK 250
01	001	023	0000000353	See list	Circuit Protection	HCSF
01	001	023	0000000354	See list	Circuit Protection	HCF
01	001	024	0000000060	See list	Circuit Protection	OMF 63
01	001	024	0000000061	See list	Circuit Protection	OMK 63
01	001	024	0000000062	See list	Circuit Protection	OMF 125
01	001	024	0000000063	See list	Circuit Protection	OMK 125
01	001	024	0000000079	See list	Circuit Protection	OMT 125
01	001	024	0000000081	See list	Circuit Protection	OMZ 125
01	001	025	0000000201	See list	Circuit Protection	MGA
01	001	025	0000000202	See list	Circuit Protection	MGA-S
01	001	025	0000000203	See list	Circuit Protection	MGA-A
01	001	025	0000000205	See list	Circuit Protection	USF 1206
01	001	025	0000000206	See list	Circuit Protection	USI 1206
01	001	025	0000000207	See list	Circuit Protection	UST 1206
01	001	025	0000000210	See list	Circuit Protection	USF 0603
01	001	025	0000000221	See list	Circuit Protection	USFF 1206
01	001	025	0000000230	See list	Circuit Protection	UAI 1206
01	022	001	0000000001	See list	Circuit Protection	RTS
01	022	001	0000000002	See list	Circuit Protection	USN 1206

*SBU (2-digit) / PG (3-digit) / PUG (3-digit) / Type (10-digit)

2 Type of change

- Modified label
- Improved identification product configuration code on the label

3 Detailed description of change

All product types listed in section 1 receive a new label layout.

To better visualize the changes, we have used colors and numbers to cluster information into the following sections (The colors and white numbers are not part of the new label layout):

Product identification section: To improve readability, we clustered all the information concerning product identification in this group. To increase clarity, we introduce our product configuration code into this area.

Product conformity section: Identical information was slightly rearranged.

Product logistics section: Label names changed. Information was slightly rearranged.

Product approval section: Identical information was slightly rearranged.

Interruption ratings section: Identical information was slightly rearranged.

Origin information section: Label for Factory Code was added. Information was slightly rearranged.

Product Change Notification					PCN Global Labeling Phase 1		
owner	creation date	release date	released by	change order no	rev	page	D10-049-195
schmidre	23.10.2020	23.10.2020	haeckima	2020834	A	1 of 2	

Old label	New label

4 Reason of change

We modernize our label printing process to increase standardization and harmonize processes throughout all SCHURTER factory locations.

5 Release date

Packaging labels will be changed earliest in week 47/2020 (Date code 2047 or higher on the label).

6 Impact of change and recommended action

Form	No	
Fit	No	
Function	No	
Manufacturing	No	
Label	Yes	No actions required since bar code & 2D-code are not affected by the change.
Packaging	No	

7 Reference Documents / Attachments

Kind of document	Remarks
List of affected articles	

Product Change Notification					PCN Global Labeling Phase 1		
owner	creation date	release date	released by	change order no	rev	page	D10-049-195
schmidre	23.10.2020	23.10.2020	haeckima	2020834	A	2 of 2	

Product Information Section

Part Number	Old Label Information		
P/N	Type	Part Name	Characteristics
3409.0006	HCSF	Sub-miniature fuse	4 A 125 VDC
3409.0006	HCSF	Sub-miniature fuse	4 A 125 VDC
3409.0006	HCSF	Sub-miniature fuse	4 A 125 VDC
3409.0007	HCSF	Sub-miniature fuse	5 A 125 VDC
3409.0008	HCSF	Sub-miniature fuse	6.3 A 125 VDC
3409.0008	HCSF	Sub-miniature fuse	6.3 A 125 VDC
3409.0008	HCSF	Sub-miniature fuse	6.3 A 125 VDC
3409.0009	HCSF	Sub-miniature fuse	7.5 A 125 VDC
3409.0011	HCSF	Sub-miniature fuse	10 A 125 VDC
3409.0015	HCSF	Sub-miniature fuse	15A 125 VDC
3410.0021.01	MGA	Sub-miniature fuse	200 mA 125VAC / DC
3410.0021.02	MGA	Sub-miniature fuse	200 mA 125VAC / DC
3410.0021.03	MGA	Sub-miniature fuse	200 mA 125VAC / DC
3410.0021.04	MGA	Sub-miniature fuse	200 mA 125VAC / DC
3410.0022.01	MGA	Sub-miniature fuse	250 mA 125VAC / DC
3410.0022.02	MGA	Sub-miniature fuse	250 mA 125VAC / DC
3410.0022.03	MGA	Sub-miniature fuse	250 mA 125VAC / DC
3410.0022.04	MGA	Sub-miniature fuse	250 mA 125VAC / DC
3410.0025.01	MGA	Sub-miniature fuse	375 mA 125VAC / DC
3410.0025.02	MGA	Sub-miniature fuse	375 mA 125VAC / DC
3410.0025.03	MGA	Sub-miniature fuse	375 mA 125VAC / DC
3410.0025.04	MGA	Sub-miniature fuse	375 mA 125VAC / DC
3410.0027.01	MGA	Sub-miniature fuse	500 mA 125VAC / DC
3410.0027.02	MGA	Sub-miniature fuse	500 mA 125VAC / DC
3410.0027.03	MGA	Sub-miniature fuse	500 mA 125VAC / DC
3410.0027.04	MGA	Sub-miniature fuse	500 mA 125VAC / DC
3410.0029.01	MGA	Sub-miniature fuse	750 mA 125VAC / DC
3410.0029.02	MGA	Sub-miniature fuse	750 mA 125VAC / DC
3410.0029.03	MGA	Sub-miniature fuse	750 mA 125VAC / DC
3410.0029.04	MGA	Sub-miniature fuse	750 mA 125VAC / DC
3410.0031.01	MGA	Sub-miniature fuse	1A 125VAC / DC
3410.0031.02	MGA	Sub-miniature fuse	1A 125VAC / DC
3410.0031.03	MGA	Sub-miniature fuse	1A 125VAC / DC
3410.0031.04	MGA	Sub-miniature fuse	1A 125VAC / DC
3410.0033.01	MGA	Sub-miniature fuse	1.5 A 125VAC / DC
3410.0033.02	MGA	Sub-miniature fuse	1.5 A 125VAC / DC
3410.0033.03	MGA	Sub-miniature fuse	1.5 A 125VAC / DC
3410.0033.04	MGA	Sub-miniature fuse	1.5 A 125VAC / DC
3410.0035.01	MGA	Sub-miniature fuse	2A 125VAC / DC
3410.0035.02	MGA	Sub-miniature fuse	2A 125VAC / DC
3410.0035.03	MGA	Sub-miniature fuse	2A 125VAC / DC
3410.0035.04	MGA	Sub-miniature fuse	2A 125VAC / DC
3410.0036.01	MGA	Sub-miniature fuse	2.5 A 125VAC / DC
3410.0036.02	MGA	Sub-miniature fuse	2.5 A 125VAC / DC
3410.0036.03	MGA	Sub-miniature fuse	2.5 A 125VAC / DC
3410.0036.04	MGA	Sub-miniature fuse	2.5 A 125VAC / DC
3410.0037.01	MGA	Sub-miniature fuse	3 A 125VAC / DC
3410.0037.02	MGA	Sub-miniature fuse	3 A 125VAC / DC
3410.0037.03	MGA	Sub-miniature fuse	3 A 125VAC / DC

[illegible]

3-103-131	MGA-A	Sub-miniature fuse	5A 125VAC / 125VDC
3-103-132	MGA-A	Sub-miniature fuse	5A 125VAC / 125VDC
3410.0310	MGA-S	Sub-miniature fuse	0.14 A 125 V
3410.0319	MGA-S	Sub-miniature fuse	2.1A 125 V
3410.0321	MGA-S	Sub-miniature fuse	3.5 A 32 V
3410.0321	MGA-S	Sub-miniature fuse	3.5 A 32 V
3410.0311	MGA-S	Sub-miniature fuse	0.175 A 125 V
3410.0317	MGA-S	Sub-miniature fuse	1.4 A 125 V
3410.0320	MGA-S	Sub-miniature fuse	2.8 A 63 V
3410.0312	MGA-S	Sub-miniature fuse	0.262A 125 V
3410.0320	MGA-S	Sub-miniature fuse	2.8 A 63 V
3410.0315	MGA-S	Sub-miniature fuse	0.7 A 125 V
3410.0316	MGA-S	Sub-miniature fuse	1.05 A 125 V
3410.0313	MGA-S	Sub-miniature fuse	0.35A 125 V
3410.0314	MGA-S	Sub-miniature fuse	0.525 A 125 V
3410.0318	MGA-S	Sub-miniature fuse	1.75 A 125 V
3410.0319	MGA-S	Sub-miniature fuse	2.1A 125 V
3410.0321	MGA-S	Sub-miniature fuse	3.5 A 32 V
0034.4641	MSF	MICROFUSE 125 V	F 1A 125V
0034.4641	MSF	MICROFUSE 125 V	F 1A 125V
0034.4209	MSF 125	Sub-miniature fuse-links	F 100mA 125VAC / DC
0034.4210	MSF 125	Sub-miniature fuse-links	F 125mA 125VAC / DC
0034.4211	MSF 125	Sub-miniature fuse-links	F 160mA 125VAC / DC
0034.4212	MSF 125	Sub-miniature fuse-links	F 200mA 125VAC / DC
0034.4213	MSF 125	Sub-miniature fuse-links	F 250mA 125VAC / DC
0034.4214	MSF 125	Sub-miniature fuse-links	F 315mA 125VAC / DC
0034.4215	MSF 125	Sub-miniature fuse-links	F 400mA 125VAC / DC
0034.4216	MSF 125	Sub-miniature fuse-links	F 500mA 125VAC / DC
0034.4217	MSF 125	Sub-miniature fuse-links	F 630mA 125VAC / DC
0034.4218	MSF 125	Sub-miniature fuse-links	F 710mA 125VAC / DC
0034.4219	MSF 125	Sub-miniature fuse-links	F 750mA 125VAC / DC
0034.4220	MSF 125	Sub-miniature fuse-links	F 800mA 125VAC / DC
0034.4221	MSF 125	Sub-miniature fuse-links	F 1A 125VAC / DC
0034.4222	MSF 125	Sub-miniature fuse-links	F 1.25A 125VAC / DC
0034.4223	MSF 125	Sub-miniature fuse-links	F 1.6A 125VAC / DC
0034.4224	MSF 125	Sub-miniature fuse-links	F 2A 125VAC / DC
0034.4225	MSF 125	Sub-miniature fuse-links	F 2.5A 125VAC / DC
0034.4226	MSF 125	Sub-miniature fuse-links	F 3.15A 125VAC / DC
0034.4227	MSF 125	Sub-miniature fuse-links	F 4A 125VAC / DC
0034.4228	MSF 125	Sub-miniature fuse-links	F 5A 125VAC / DC
0034.4239	MSF 125	Sub-miniature fuse-links	F 100mA 125VAC / DC
0034.4240	MSF 125	Sub-miniature fuse-links	F 125mA 125VAC / DC
0034.4241	MSF 125	Sub-miniature fuse-links	F 160mA 125V
0034.4242	MSF 125	Sub-miniature fuse-links	F 200mA 125VAC / DC
0034.4243	MSF 125	Sub-miniature fuse-links	F 250mA 125VAC / DC
0034.4244	MSF 125	Sub-miniature fuse-links	F 315mA 125VAC / DC
0034.4245	MSF 125	Sub-miniature fuse-links	F 400mA 125VAC / DC
0034.4246	MSF 125	Sub-miniature fuse-links	F 500mA 125VAC / DC
0034.4247	MSF 125	Sub-miniature fuse-links	F 630mA 125VAC / DC
0034.4248	MSF 125	Sub-miniature fuse-links	F 710mA 125VAC / DC
0034.4249	MSF 125	Sub-miniature fuse-links	F 750mA 125VAC / DC
0034.4250	MSF 125	Sub-miniature fuse-links	F 800mA 125VAC / DC
0034.4251	MSF 125	Sub-miniature fuse-links	F 1A 125VAC / DC
0034.4252	MSF 125	Sub-miniature fuse-links	F 1.25A 125VAC / DC
0034.4253	MSF 125	Sub-miniature fuse-links	F 1.6A 125VAC / DC

0034.4254	MSF 125	Sub-miniature fuse-links	F 2A 125VAC / DC
0034.4255	MSF 125	Sub-miniature fuse-links	F 2.5A 125VAC / DC
0034.4256	MSF 125	Sub-miniature fuse-links	F 3.15A 125VAC / DC
0034.4257	MSF 125	Sub-miniature fuse-links	F 4A 125VAC / DC
0034.4258	MSF 125	Sub-miniature fuse-links	F 5A 125VAC / DC
0034.4539	MSF 125	Sub-miniature fuse-links	F 100mA 125VAC / DC
0034.4540	MSF 125	Sub-miniature fuse-links	F 125mA 125VAC / DC
0034.4541	MSF 125	Sub-miniature fuse-links	F 160mA 125VAC / DC
0034.4542	MSF 125	Sub-miniature fuse-links	F 200mA 125VAC / DC
0034.4543	MSF 125	Sub-miniature fuse-links	F 250mA 125VAC / DC
0034.4544	MSF 125	Sub-miniature fuse-links	F 315mA 125VAC / DC
0034.4545	MSF 125	Sub-miniature fuse-links	F 400mA 125VAC / DC
0034.4546	MSF 125	Sub-miniature fuse-links	F 500mA 125VAC / DC
0034.4547	MSF 125	Sub-miniature fuse-links	F 630mA 125VAC / DC
0034.4548	MSF 125	Sub-miniature fuse-links	F 710mA 125VAC / DC
0034.4549	MSF 125	Sub-miniature fuse-links	F 750mA 125VAC / DC
0034.4550	MSF 125	Sub-miniature fuse-links	F 800mA 125VAC / DC
0034.4551	MSF 125	Sub-miniature fuse-links	F 1A 125VAC / DC
0034.4552	MSF 125	Sub-miniature fuse-links	F 1.25A 125VAC / DC
0034.4553	MSF 125	Sub-miniature fuse-links	F 1.6A 125VAC / DC
0034.4554	MSF 125	Sub-miniature fuse-links	F 2A 125VAC / DC
0034.4555	MSF 125	Sub-miniature fuse-links	F 2.5A 125VAC / DC
0034.4556	MSF 125	Sub-miniature fuse-links	F 3.15A 125VAC / DC
0034.4557	MSF 125	Sub-miniature fuse-links	F 4A 125VAC / DC
0034.4558	MSF 125	Sub-miniature fuse-links	F 5A 125VAC / DC
0034.6000	MSF 250	Sub-miniature fuse links	F 40mA / 250V
0034.6001	MSF 250	Sub-miniature fuse links	F 50mA / 250V
0034.6002	MSF 250	Sub-miniature fuse links	F 63mA / 250V
0034.6003	MSF 250	Sub-miniature fuse links	F 80mA / 250V
0034.6004	MSF 250	Sub-miniature fuse links	F 100mA / 250V
0034.6005	MSF 250	Sub-miniature fuse links	F 125mA / 250V
0034.6006	MSF 250	Sub-miniature fuse links	F 160mA / 250V
0034.6007	MSF 250	Sub-miniature fuse links	F 200mA / 250V
0034.6008	MSF 250	Sub-miniature fuse links	F 250mA / 250V
0034.6009	MSF 250	Sub-miniature fuse links	F 315mA / 250V
0034.6010	MSF 250	Sub-miniature fuse links	F 400mA / 250V
0034.6011	MSF 250	Sub-miniature fuse links	F 500mA / 250V
0034.6012	MSF 250	Sub-miniature fuse links	F 630mA / 250V
0034.6013	MSF 250	Sub-miniature fuse links	F 800mA / 250V
0034.6014	MSF 250	Sub-miniature fuse links	F 1A / 250VAC
0034.6015	MSF 250	Sub-miniature fuse links	F 1.25A / 250VAC
0034.6016	MSF 250	Sub-miniature fuse links	F 1.6A / 250VAC
0034.6017	MSF 250	Sub-miniature fuse links	F 2A / 250VAC
0034.6018	MSF 250	Sub-miniature fuse links	F 2.5A / 250VAC
0034.6019	MSF 250	Sub-miniature fuse links	F 3.15A / 250VAC
0034.6020	MSF 250	Sub-miniature fuse links	F 4A / 250VAC
0034.6021	MSF 250	Sub-miniature fuse links	F 5A / 250VAC
0034.6030	MSF 250	Sub-miniature fuse links	F 40mA / 250V
0034.6031	MSF 250	Sub-miniature fuse links	F 50mA / 250V
0034.6032	MSF 250	Sub-miniature fuse links	F 63mA / 250V
0034.6033	MSF 250	Sub-miniature fuse links	F 80mA / 250V
0034.6034	MSF 250	Sub-miniature fuse links	F 100mA / 250V
0034.6035	MSF 250	Sub-miniature fuse links	F 125mA / 250V
0034.6036	MSF 250	Sub-miniature fuse links	F 160mA / 250V
0034.6037	MSF 250	Sub-miniature fuse links	F 200mA / 250V

0034.6038	MSF 250	Sub-miniature fuse links	F 250mA / 250V
0034.6039	MSF 250	Sub-miniature fuse links	F 315mA / 250V
0034.6040	MSF 250	Sub-miniature fuse links	F 400mA / 250V
0034.6041	MSF 250	Sub-miniature fuse links	F 500mA / 250V
0034.6042	MSF 250	Sub-miniature fuse links	F 630mA / 250V
0034.6043	MSF 250	Sub-miniature fuse links	F 800mA / 250V
0034.6044	MSF 250	Sub-miniature fuse links	F 1A / 250VAC
0034.6045	MSF 250	Sub-miniature fuse links	F 1.25A / 250VAC
0034.6046	MSF 250	Sub-miniature fuse links	F 1.6A / 250VAC
0034.6047	MSF 250	Sub-miniature fuse links	F 2A / 250VAC
0034.6048	MSF 250	Sub-miniature fuse links	F 2.5A / 250VAC
0034.6049	MSF 250	Sub-miniature fuse links	F 3.15A / 250VAC
0034.6050	MSF 250	Sub-miniature fuse links	F 4A / 250VAC
0034.6051	MSF 250	Sub-miniature fuse links	F 5A / 250VAC
0034.6060	MSF 250	Sub-miniature fuse links	F 40mA / 250V
0034.6061	MSF 250	Sub-miniature fuse links	F 50mA / 250V
0034.6062	MSF 250	Sub-miniature fuse links	F 63mA / 250V
0034.6063	MSF 250	Sub-miniature fuse links	F 80mA / 250V
0034.6064	MSF 250	Sub-miniature fuse links	F 100mA / 250V
0034.6065	MSF 250	Sub-miniature fuse links	F 125mA / 250V
0034.6066	MSF 250	Sub-miniature fuse links	F 160mA / 250V
0034.6067	MSF 250	Sub-miniature fuse links	F 200mA / 250V
0034.6068	MSF 250	Sub-miniature fuse links	F 250mA / 250V
0034.6069	MSF 250	Sub-miniature fuse links	F 315mA / 250V
0034.6070	MSF 250	Sub-miniature fuse links	F 400mA / 250V
0034.6071	MSF 250	Sub-miniature fuse links	F 500mA / 250V
0034.6072	MSF 250	Sub-miniature fuse links	F 630mA / 250V
0034.6073	MSF 250	Sub-miniature fuse links	F 800mA / 250V
0034.6074	MSF 250	Sub-miniature fuse links	F 1A / 250VAC
0034.6075	MSF 250	Sub-miniature fuse links	F 1.25A / 250VAC
0034.6076	MSF 250	Sub-miniature fuse links	F 1.6A / 250VAC
0034.6077	MSF 250	Sub-miniature fuse links	F 2A / 250VAC
0034.6078	MSF 250	Sub-miniature fuse links	F 2.5A / 250VAC
0034.6079	MSF 250	Sub-miniature fuse links	F 3.15A / 250VAC
0034.6079.A	MSF 250	Sub-miniature fuse links	F 3.15A / 250VAC
0034.6080	MSF 250	Sub-miniature fuse links	F 4A / 250VAC
0034.6081	MSF 250	Sub-miniature fuse links	F 5A / 250VAC
0034.6768	MST 250	Sub-miniature fuse links	T 2A / 250VAC
0034.6868	MST 250	MICROFUSE	T 2A / 250VAC
0034.6817.A	MST 250	Sub-miniature fuse links	T 1.6A / 250VAC
0034.6868.A	MST 250	MICROFUSE	T 2A / 250VAC
0034.6815	MST 250	Sub-miniature fuse links	T 1A / 250VAC
0034.6816.BF	MST 250	Sub-miniature fuse links	T 1.25A / 250VAC
0034.6809.A	MST 250	Sub-miniature fuse links	T 250 mA / 250V
0034.6803.A	MST 250	Sub-miniature fuse links	T 63 mA / 250V
0034.6668	MST 250	Sub-miniature fuse links	T 2A / 250VAC
0034.6602	MST 250	Sub-miniature fuse links	T 50mA / 250V
0034.6603	MST 250	Sub-miniature fuse links	T 63mA / 250V
0034.6604	MST 250	Sub-miniature fuse links	T 80mA / 250V
0034.6605	MST 250	Sub-miniature fuse links	T 100mA / 250V
0034.6606	MST 250	Sub-miniature fuse links	T 125mA / 250V
0034.6607	MST 250	Sub-miniature fuse links	T 160mA / 250V
0034.6608	MST 250	Sub-miniature fuse links	T 200mA / 250V
0034.6609	MST 250	Sub-miniature fuse links	T 250mA / 250V
0034.6610	MST 250	Sub-miniature fuse links	T 315mA / 250V

[illegible]

[illegible]

0034.7117	MSTU 250	Sub-miniature fuse links	T 1.6A / 250VAC
0034.7120	MSTU 250	Sub-miniature fuse links	T 3.15A / 250VAC
0034.7123	MSTU 250	Sub-miniature fuse links	T 6.3A / 250VAC
0034.7209	MSTU 250	Sub-miniature fuse links	T 250mA / 250V
0034.7215	MSTU 250	Sub-miniature fuse links	T 1A / 250VAC
0034.7217	MSTU 250	Sub-miniature fuse links	T 1.6A / 250VAC
0034.7220	MSTU 250	Sub-miniature fuse links	T 3.15A / 250VAC
0034.7223	MSTU 250	Sub-miniature fuse links	T 6.3A / 250VAC
0034.7309	MSTU 250	Sub-miniature fuse links	T 250mA / 250V
0034.7315	MSTU 250	Sub-miniature fuse links	T 1A / 250VAC
0034.7317	MSTU 250	Sub-miniature fuse links	T 1.6A / 250VAC
0034.7320	MSTU 250	Sub-miniature fuse links	T 3.15A / 250VAC
0034.7323	MSTU 250	Sub-miniature fuse links	T 6.3A / 250VAC
0034.7124	MSTU 250	Sub-miniature fuse links	T 8A / 250VAC
0034.7224	MSTU 250	Sub-miniature fuse links	T 8A / 250VAC
0034.7324	MSTU 250	Sub-miniature fuse links	T 8A / 250VAC
0034.7324.A	MSTU 250	Sub-miniature fuse links	T 8A / 250VAC
0034.6924	MXT 250	Sub-miniature fuse-link	T 8A / 250VAC
0034.6925	MXT 250	Sub-miniature fuse-link	T 10A / 250VAC
0034.6954	MXT 250	Sub-miniature fuse-link	T 8A / 250VAC
0034.6955	MXT 250	Sub-miniature fuse-link	T 10A / 250VAC
0034.6984	MXT 250	Sub-miniature fuse-link	T 8A / 250VAC
0034.6984.A	MXT 250	Sub-miniature fuse-link	T 8A / 250VAC
0034.6985	MXT 250	Sub-miniature fuse-link	T 10A / 250VAC
0034.6914	MXT 250	Sub-miniature fuse-link	T 800mA / 250V
0034.6915	MXT 250	Sub-miniature fuse-link	T 1A / 250VAC
0034.6916	MXT 250	Sub-miniature fuse-link	T 1.25A / 250VAC
0034.6917	MXT 250	Sub-miniature fuse-link	T 1.6A / 250VAC
0034.6918	MXT 250	Sub-miniature fuse-link	T 2A / 250VAC
0034.6919	MXT 250	Sub-miniature fuse-link	T 2.5A / 250VAC
0034.6920	MXT 250	Sub-miniature fuse-link	T 3.15A / 250VAC
0034.6921	MXT 250	Sub-miniature fuse-link	T 4A / 250VAC
0034.6921.1	MXT 250	Sub-miniature fuse-link	T 4A / 250VAC
0034.6922	MXT 250	Sub-miniature fuse-link	T 5A / 250VAC
0034.6923	MXT 250	Sub-miniature fuse-link	T 6.3A / 250VAC
0034.6944	MXT 250	Sub-miniature fuse-link	T 800mA / 250V
0034.6945	MXT 250	Sub-miniature fuse-link	T 1A / 250VAC
0034.6946	MXT 250	Sub-miniature fuse-link	T 1.25A / 250VAC
0034.6947	MXT 250	Sub-miniature fuse-link	T 1.6A / 250VAC
0034.6948	MXT 250	Sub-miniature fuse-link	T 2A / 250VAC
0034.6949	MXT 250	Sub-miniature fuse-link	T 2.5A / 250VAC
0034.6950	MXT 250	Sub-miniature fuse-link	T 3.15A / 250VAC
0034.6951	MXT 250	Sub-miniature fuse-link	T 4A / 250VAC
0034.6952	MXT 250	Sub-miniature fuse-link	T 5A / 250VAC
0034.6953	MXT 250	Sub-miniature fuse-link	T 6.3A / 250VAC
0034.6974	MXT 250	Sub-miniature fuse-link	T 800mA / 250V
0034.6975	MXT 250	Sub-miniature fuse-link	T 1A / 250VAC
0034.6976	MXT 250	Sub-miniature fuse-link	T 1.25A / 250VAC
0034.6977	MXT 250	Sub-miniature fuse-link	T 1.6A / 250VAC
0034.6978	MXT 250	Sub-miniature fuse-link	T 2A / 250VAC
0034.6979	MXT 250	Sub-miniature fuse-link	T 2.5A / 250VAC
0034.6980	MXT 250	Sub-miniature fuse-link	T 3.15A / 250VAC
0034.6981	MXT 250	Sub-miniature fuse-link	T 4A / 250VAC
0034.6982	MXT 250	Sub-miniature fuse-link	T 5A / 250VAC
0034.6983	MXT 250	Sub-miniature fuse-link	T 6.3A / 250VAC

[illegible]

3404.0020.22	OMF 125	Sub-miniature fuse-links	F 8A 125VAC / DC
3404.0020.24	OMF 125	Sub-miniature fuse-links	F 8A 125VAC / DC
3404.0021.22	OMF 125	Sub-miniature fuse-links	F 10A 125VAC / DC
3404.0043.11	OMF 125	Sub-miniature fuse-links	F 350mA 125VAC / DC
3404.0043.22	OMF 125	Sub-miniature fuse-links	F 350mA 125VAC / DC
3404.0043.24	OMF 125	Sub-miniature fuse-links	F 350mA 125VAC / DC
3404.0044.11	OMF 125	Sub-miniature fuse-links	F 375mA 125VAC / DC
3404.0044.22	OMF 125	Sub-miniature fuse-links	F 375mA 125VAC / DC
3404.0044.24	OMF 125	Sub-miniature fuse-links	F 375mA 125VAC / DC
3404.0045.11	OMF 125	Sub-miniature fuse-links	F 500mA 125VAC / DC
3404.0045.22	OMF 125	Sub-miniature fuse-links	F 500mA 125VAC / DC
3404.0045.24	OMF 125	Sub-miniature fuse-links	F 500mA 125VAC / DC
3404.0046.11	OMF 125	Sub-miniature fuse-links	F 750mA 125VAC / DC
3404.0046.22	OMF 125	Sub-miniature fuse-links	F 750mA 125VAC / DC
3404.0046.24	OMF 125	Sub-miniature fuse-links	F 750mA 125VAC / DC
3404.0047.11	OMF 125	Sub-miniature fuse-links	F 1.5A 125VAC / DC
3404.0047.22	OMF 125	Sub-miniature fuse-links	F 1.5A 125VAC / DC
3404.0047.24	OMF 125	Sub-miniature fuse-links	F 1.5A 125VAC / DC
3404.0048.11	OMF 125	Sub-miniature fuse-links	F 3.15A 125VAC / DC
3404.0048.22	OMF 125	Sub-miniature fuse-links	F 3.15A 125VAC / DC
3404.0048.24	OMF 125	Sub-miniature fuse-links	F 3.15A 125VAC / DC
3404.0049.11	OMF 125	Sub-miniature fuse-links	F 125mA 125VAC / DC
3404.0049.22	OMF 125	Sub-miniature fuse-links	F 125mA 125VAC / DC
3404.0049.24	OMF 125	Sub-miniature fuse-links	F 125mA 125VAC / DC
3403.0012.24	OMF 250	Sub -miniature fuse-link	F 400mA L 250VAC / DC
3403.0010.11	OMF 250	Sub -miniature fuse-link	F 250mA L 250VAC / DC
3403.0010.24	OMF 250	Sub -miniature fuse-link	F 250mA L 250VAC / DC
3403.0011.11	OMF 250	Sub -miniature fuse-link	F 315mA L 250VAC / DC
3403.0011.24	OMF 250	Sub -miniature fuse-link	F 315mA L 250VAC / DC
3403.0012.11	OMF 250	Sub -miniature fuse-link	F 400mA L 250VAC / DC
3403.0013.11	OMF 250	Sub -miniature fuse-link	F 500mA L 250VAC / DC
3403.0013.24	OMF 250	Sub -miniature fuse-link	F 500mA L 250VAC / DC
3403.0014.11	OMF 250	Sub -miniature fuse-link	F 630mA L 250VAC / DC
3403.0014.24	OMF 250	Sub -miniature fuse-link	F 630mA L 250VAC / DC
3403.0015.11	OMF 250	Sub -miniature fuse-link	F 800mA L 250VAC / DC
3403.0015.24	OMF 250	Sub -miniature fuse-link	F 800mA L 250VAC / DC
3403.0016.11	OMF 250	Sub -miniature fuse-link	F 1A L 250VAC / DC
3403.0016.24	OMF 250	Sub -miniature fuse-link	F 1A L 250VAC / DC
3403.0017.11	OMF 250	Sub -miniature fuse-link	F 1.25A L 250VAC / DC
3403.0017.24	OMF 250	Sub -miniature fuse-link	F 1.25A L 250VAC / DC
3403.0018.11	OMF 250	Sub -miniature fuse-link	F 1.6A L 250VAC / DC
3403.0018.24	OMF 250	Sub -miniature fuse-link	F 1.6A L 250VAC / DC
3403.0019.11	OMF 250	Sub -miniature fuse-link	F 2A L 250VAC / DC
3403.0019.24	OMF 250	Sub -miniature fuse-link	F 2A L 250VAC / DC
3403.0020.11	OMF 250	Sub -miniature fuse-link	F 2.5A L 250VAC / DC
3403.0020.24	OMF 250	Sub -miniature fuse-link	F 2.5A L 250VAC / DC
3403.0021.11	OMF 250	Sub -miniature fuse-link	F 3.15A L 250VAC / DC
3403.0021.24	OMF 250	Sub -miniature fuse-link	F 3.15A L 250VAC / DC
3403.0022.11	OMF 250	Sub -miniature fuse-link	F 4A L 250VAC / DC
3403.0022.24	OMF 250	Sub -miniature fuse-link	F 4A L 250VAC / DC
3402.0049.24	OMF 63	Sub-miniature fuse-links	F 125mA 63VAC / DC
3402.0049.11	OMF 63	Sub-miniature fuse-links	F 125mA 63VAC / DC
3402.0049.22	OMF 63	Sub-miniature fuse-links	F 125mA 63VAC / DC
3402.0003.11	OMF 63	Sub-miniature fuse-links	F 63mA 63VAC / DC
3402.0003.22	OMF 63	Sub-miniature fuse-links	F 63mA 63VAC / DC

[illegible]

3402.0043.11	OMF 63	Sub-miniature fuse-links	F 350mA 63VAC / DC
3402.0043.22	OMF 63	Sub-miniature fuse-links	F 350mA 63VAC / DC
3402.0043.24	OMF 63	Sub-miniature fuse-links	F 350mA 63VAC / DC
3402.0044.11	OMF 63	Sub-miniature fuse-links	F 375mA 63VAC / DC
3402.0044.22	OMF 63	Sub-miniature fuse-links	F 375mA 63VAC / DC
3402.0044.24	OMF 63	Sub-miniature fuse-links	F 375mA 63VAC / DC
3402.0045.11	OMF 63	Sub-miniature fuse-links	F 500mA 63VAC / DC
3402.0045.22	OMF 63	Sub-miniature fuse-links	F 500mA 63VAC / DC
3402.0045.24	OMF 63	Sub-miniature fuse-links	F 500mA 63VAC / DC
3402.0046.11	OMF 63	Sub-miniature fuse-links	F 750mA 63VAC / DC
3402.0046.22	OMF 63	Sub-miniature fuse-links	F 750mA 63VAC / DC
3402.0046.24	OMF 63	Sub-miniature fuse-links	F 750mA 63VAC / DC
3402.0047.11	OMF 63	Sub-miniature fuse-links	F 1.5A 63VAC / DC
3402.0047.22	OMF 63	Sub-miniature fuse-links	F 1.5A 63VAC / DC
3402.0047.24	OMF 63	Sub-miniature fuse-links	F 1.5A 63VAC / DC
3402.0048.11	OMF 63	Sub-miniature fuse-links	F 3.15A 63VAC / DC
3402.0048.22	OMF 63	Sub-miniature fuse-links	F 3.15A 63VAC / DC
3402.0048.24	OMF 63	Sub-miniature fuse-links	F 3.15A 63VAC / DC
3404.2303.11	OMK 125	Fuseholder with fuse-links	F 63 mA 125 V
3404.2303.22	OMK 125	Fuseholder with fuse-links	F 63 mA 125 V
3404.2303.23	OMK 125	Fuseholder with fuse-links	F 63 mA 125 V
3404.2304.11	OMK 125	Fuseholder with fuse-links	F100 mA 125 V
3404.2304.22	OMK 125	Fuseholder with fuse-links	F 100 mA 125 V
3404.2304.23	OMK 125	Fuseholder with fuse-links	F 100 mA 125 V
3404.2305.11	OMK 125	Fuseholder with fuse-links	F160 mA 125 V
3404.2305.22	OMK 125	Fuseholder with fuse-links	F160 mA 125 V
3404.2305.23	OMK 125	Fuseholder with fuse-links	F 160 mA 125 V
3404.2306.11	OMK 125	Fuseholder with fuse-links	F 250 mA 125 V
3404.2306.22	OMK 125	Fuseholder with fuse-links	F 250 mA 125 V
3404.2306.23	OMK 125	Fuseholder with fuse-links	F 250 mA 125 V
3404.2307.11	OMK 125	Fuseholder with fuse-links	F 400 mA 125 V
3404.2307.22	OMK 125	Fuseholder with fuse-links	F 400 mA 125 V
3404.2307.23	OMK 125	Fuseholder with fuse-links	F 400 mA 125 V
3404.2308.11	OMK 125	Fuseholder with fuse-links	F 630 mA 125 V
3404.2308.22	OMK 125	Fuseholder with fuse-links	F 630 mA 125 V
3404.2308.23	OMK 125	Fuseholder with fuse-links	F 630 mA 125 V
3404.2309.11	OMK 125	Fuseholder with fuse-links	F 1A 125 V
3404.2309.22	OMK 125	Fuseholder with fuse-links	F 1A 125 V
3404.2309.23	OMK 125	Fuseholder with fuse-links	F 1A 125 V
3404.2310.11	OMK 125	Fuseholder with fuse-links	F 1.25A 125 V
3404.2310.22	OMK 125	Fuseholder with fuse-links	F 1.25A 125 V
3404.2310.23	OMK 125	Fuseholder with fuse-links	F 1.25A 125 V
3404.2311.11	OMK 125	Fuseholder with fuse-links	F 1.6 A 125 V
3404.2311.22	OMK 125	Fuseholder with fuse-links	F 1.6 A 125 V
3404.2311.23	OMK 125	Fuseholder with fuse-links	F 1.6 A 125 V
3404.2312.11	OMK 125	Fuseholder with fuse-links	F 2A 125 V
3404.2312.22	OMK 125	Fuseholder with fuse-links	F 2A 125 V
3404.2312.23	OMK 125	Fuseholder with fuse-links	F 2A 125 V
3404.2313.11	OMK 125	Fuseholder with fuse-links	F 2.5 A 125 V
3404.2313.22	OMK 125	Fuseholder with fuse-links	F 2.5 A 125 V
3404.2313.23	OMK 125	Fuseholder with fuse-links	F 2.5 A 125 V
3404.2314.11	OMK 125	Fuseholder with fuse-links	F 3 A 125 V
3404.2314.22	OMK 125	Fuseholder with fuse-links	F 3 A 125 V
3404.2314.23	OMK 125	Fuseholder with fuse-links	F 3 A 125 V
3404.2315.11	OMK 125	Fuseholder with fuse-links	F 3.5 A 125 V

3404.2315.22	OMK 125	Fuseholder with fuse-links	F 3.5 A 125 V
3404.2315.23	OMK 125	Fuseholder with fuse-links	F 3.5 A 125 V
3404.2316.11	OMK 125	Fuseholder with fuse-links	F 4 A 125 V
3404.2316.22	OMK 125	Fuseholder with fuse-links	F 4 A 125 V
3404.2316.23	OMK 125	Fuseholder with fuse-links	F 4 A 125 V
3404.2317.11	OMK 125	Fuseholder with fuse-links	F 5 A 125 V
3404.2317.22	OMK 125	Fuseholder with fuse-links	F 5 A 125 V
3404.2317.23	OMK 125	Fuseholder with fuse-links	F 5 A 125 V
3404.2343.11	OMK 125	Fuseholder with fuse-links	F 350 mA 125 V
3404.2343.22	OMK 125	Fuseholder with fuse-links	F 350 mA 125 V
3404.2343.23	OMK 125	Fuseholder with fuse-links	F 350 mA 125 V
3404.2344.11	OMK 125	Fuseholder with fuse-links	F 375 mA 125 V
3404.2344.22	OMK 125	Fuseholder with fuse-links	F 375 mA 125 V
3404.2344.23	OMK 125	Fuseholder with fuse-links	F 375 mA 125 V
3404.2345.11	OMK 125	Fuseholder with fuse-links	F 500 mA 125 V
3404.2345.22	OMK 125	Fuseholder with fuse-links	F 500 mA 125 V
3404.2345.23	OMK 125	Fuseholder with fuse-links	F 500 mA 125 V
3404.2346.11	OMK 125	Fuseholder with fuse-links	F 750 mA 125 V
3404.2346.22	OMK 125	Fuseholder with fuse-links	F 750 mA 125 V
3404.2346.23	OMK 125	Fuseholder with fuse-links	F 750 mA 125 V
3404.2347.11	OMK 125	Fuseholder with fuse-links	F 1.5 A 125 V
3404.2347.22	OMK 125	Fuseholder with fuse-links	F 1.5 A 125 V
3404.2347.23	OMK 125	Fuseholder with fuse-links	F 1.5 A 125 V
3404.2348.11	OMK 125	Fuseholder with fuse-links	F 3.15A 125 V
3404.2348.22	OMK 125	Fuseholder with fuse-links	F 3.15A 125 V
3404.2348.23	OMK 125	Fuseholder with fuse-links	F 3.15A 125 V
3404.2349.11	OMK 125	Fuseholder with fuse-links	F 125 mA 125 V
3404.2349.22	OMK 125	Fuseholder with fuse-links	F 125 mA 125 V
3404.2349.23	OMK 125	Fuseholder with fuse-links	F 125 mA 125 V
3422.0046.22	OMK 63	Fuseholder with fuse-links	F 750 mA 63V
3422.0049.23	OMK 63	Fuseholder with fuse-links	F 125 mA 63V
3422.0049.11	OMK 63	Fuseholder with fuse-links	F 125 mA 63V
3422.0003.11	OMK 63	Fuseholder with fuse-links	F 63 mA 63V
3422.0003.23	OMK 63	Fuseholder with fuse-links	F 63 mA 63V
3422.0004.11	OMK 63	Fuseholder with fuse-links	F 100 mA 63V
3422.0004.23	OMK 63	Fuseholder with fuse-links	F 100 mA 63V
3422.0005.11	OMK 63	Fuseholder with fuse-links	F 160 mA 63V
3422.0005.23	OMK 63	Fuseholder with fuse-links	F 160 mA 63V
3422.0006.11	OMK 63	Fuseholder with fuse-links	F 250 mA 63V
3422.0006.23	OMK 63	Fuseholder with fuse-links	F 250 mA 63V
3422.0007.11	OMK 63	Fuseholder with fuse-links	F 400mA 63V
3422.0007.23	OMK 63	Fuseholder with fuse-links	F 400mA 63V
3422.0008.11	OMK 63	Fuseholder with fuse-links	F 630 mA 63V
3422.0008.23	OMK 63	Fuseholder with fuse-links	F 630 mA 63V
3422.0009.11	OMK 63	Fuseholder with fuse-links	F 1A 63V
3422.0009.23	OMK 63	Fuseholder with fuse-links	F 1A 63V
3422.0010.11	OMK 63	Fuseholder with fuse-links	F 1.25 A 63V
3422.0010.23	OMK 63	Fuseholder with fuse-links	F 1.25 A 63V
3422.0011.11	OMK 63	Fuseholder with fuse-links	F 1.6 A 63V
3422.0011.23	OMK 63	Fuseholder with fuse-links	F 1.6 A 63V
3422.0012.11	OMK 63	Fuseholder with fuse-links	F 2A 63V
3422.0012.23	OMK 63	Fuseholder with fuse-links	F 2A 63V
3422.0013.11	OMK 63	Fuseholder with fuse-links	F 2.5 A 63V
3422.0013.23	OMK 63	Fuseholder with fuse-links	F 2.5 A 63V
3422.0014.11	OMK 63	Fuseholder with fuse-links	F 3 A 63V

3422.0014.23	OMK 63	Fuseholder with fuse-links	F 3 A 63V
3422.0015.11	OMK 63	Fuseholder with fuse-links	F 3.5 A 63V
3422.0015.23	OMK 63	Fuseholder with fuse-links	F 3.5 A 63V
3422.0016.11	OMK 63	Fuseholder with fuse-links	F 4 A 63V
3422.0016.23	OMK 63	Fuseholder with fuse-links	F 4 A 63V
3422.0017.11	OMK 63	Fuseholder with fuse-links	F 5 A 63V
3422.0017.23	OMK 63	Fuseholder with fuse-links	F 5 A 63V
3422.0043.11	OMK 63	Fuseholder with fuse-links	F 350 mA 63V
3422.0043.23	OMK 63	Fuseholder with fuse-links	F 350 mA 63V
3422.0044.11	OMK 63	Fuseholder with fuse-links	F 375 mA 63V
3422.0044.23	OMK 63	Fuseholder with fuse-links	F 375 mA 63V
3422.0045.11	OMK 63	Fuseholder with fuse-links	F 500 mA 63V
3422.0045.23	OMK 63	Fuseholder with fuse-links	F 500 mA 63V
3422.0046.11	OMK 63	Fuseholder with fuse-links	F 750 mA 63V
3422.0046.23	OMK 63	Fuseholder with fuse-links	F 750 mA 63V
3422.0047.11	OMK 63	Fuseholder with fuse-links	F 1.5A 63V
3422.0047.23	OMK 63	Fuseholder with fuse-links	F 1.5A 63V
3422.0048.11	OMK 63	Fuseholder with fuse-links	F 3.15A 63V
3422.0048.23	OMK 63	Fuseholder with fuse-links	F 3.15A 63V
3403.0116.11	OMT	Sub-miniature fuse-links	T 1A L 250VAC
3403.0116.24	OMT	Sub-miniature fuse-links	T 1A L 250VAC
3403.0117.11	OMT	Sub-miniature fuse-links	T 1.25A L 250VAC
3403.0117.24	OMT	Sub-miniature fuse-links	T 1.25A L 250VAC
3403.0119.11	OMT	Sub-miniature fuse-links	T 2A L AC250V / DC125V
3403.0119.24	OMT	Sub-miniature fuse-links	T 2A L 250VAC
3403.0120.11	OMT	Sub-miniature fuse-links	T 2.5A L 125VAC
3403.0120.24	OMT	Sub-miniature fuse-links	T 2.5A L 125VAC
3403.0122.11	OMT	Sub-miniature fuse-links	T 4A L 125VAC
3403.0122.24	OMT	Sub-miniature fuse-links	T 4A L 125VAC
3403.0129.11	OMT	Sub-miniature fuse-links	T 750mA L 250VAC
3403.0129.24	OMT	Sub-miniature fuse-links	T 750mA L 250VAC
3403.0130.11	OMT	Sub-miniature fuse-links	T 1.5A L 250VAC
3403.0130.24	OMT	Sub-miniature fuse-links	T 1.5A L 250VAC
3403.0131.11	OMT	Sub-miniature fuse-links	T 3A L 125VAC
3403.0131.24	OMT	Sub-miniature fuse-links	T 3A L 125VAC
3403.0132.11	OMT	Sub-miniature fuse-links	T 3.5A L 125VAC
3403.0132.24	OMT	Sub-miniature fuse-links	T 3.5A L 125VAC
3403.0123.11	OMT	Sub-miniature fuse-links	T 5A L 125VAC
3403.0123.24	OMT	Sub-miniature fuse-links	T 5A L 125VAC
3404.0112.22	OMT 125	Sub-miniature fuse links	T 500mA 125V
3404.0101.22	OMT 125	Sub-miniature fuse links	T 1.6A 125V
3404.0115.22	OMT 125	Sub-miniature fuse links	T 1.5A 125V
3404.0101.11	OMT 125	Sub-miniature fuse links	T 1.6A 125V
3404.0101.24	OMT 125	Sub-miniature fuse links	T 1.6A 125V
3404.0110.11	OMT 125	Sub-miniature fuse links	T 250mA 125V
3404.0110.22	OMT 125	Sub-miniature fuse links	T 250mA 125V
3404.0110.24	OMT 125	Sub-miniature fuse links	T 250mA 125V
3404.0111.11	OMT 125	Sub-miniature fuse links	T 375mA 125V
3404.0111.22	OMT 125	Sub-miniature fuse links	T 375mA 125V
3404.0111.24	OMT 125	Sub-miniature fuse links	T 375mA 125V
3404.0112.24	OMT 125	Sub-miniature fuse links	T 500mA 125V
3404.0113.11	OMT 125	Sub-miniature fuse links	T 750mA 125V
3404.0113.22	OMT 125	Sub-miniature fuse links	T 750mA 125V
3404.0113.24	OMT 125	Sub-miniature fuse links	T 750mA 125V
3404.0114.24	OMT 125	Sub-miniature fuse links	T 1A 125V

3404.0115.11	OMT 125	Sub-miniature fuse links	T 1.5A 125V
3404.0115.24	OMT 125	Sub-miniature fuse links	T 1.5A 125V
3404.0116.11	OMT 125	Sub-miniature fuse links	T 2A 125V
3404.0116.22	OMT 125	Sub-miniature fuse links	T 2A 125V
3404.0116.24	OMT 125	Sub-miniature fuse links	T 2A 125V
3404.0117.11	OMT 125	Sub-miniature fuse links	T 2.5A 125V
3404.0117.22	OMT 125	Sub-miniature fuse links	T 2.5A 125V
3404.0117.24	OMT 125	Sub-miniature fuse links	T 2.5A 125V
3404.0118.11	OMT 125	Sub-miniature fuse links	T 3A 125V
3404.0118.22	OMT 125	Sub-miniature fuse links	T 3A 125V
3404.0118.24	OMT 125	Sub-miniature fuse links	T 3A 125V
3404.0119.22	OMT 125	Sub-miniature fuse links	T 3.5A 125V
3404.0119.24	OMT 125	Sub-miniature fuse links	T 3.5A 125V
3404.0120.11	OMT 125	Sub-miniature fuse links	T 4A 125V
3404.0120.22	OMT 125	Sub-miniature fuse links	T 4A 125V
3404.0120.24	OMT 125	Sub-miniature fuse links	T 4A 125V
3404.0121.11	OMT 125	Sub-miniature fuse links	T 5A 125V
3404.0121.22	OMT 125	Sub-miniature fuse links	T 5A 125V
3404.0121.24	OMT 125	Sub-miniature fuse links	T 5A 125V
3404.0122.11	OMT 125	Sub-miniature fuse links	T 6.3A 125V
3404.0122.22	OMT 125	Sub-miniature fuse links	T 6.3A 125V
3404.0122.24	OMT 125	Sub-miniature fuse links	T 6.3A 125V
3404.0173.11	OMT 125	Sub-miniature fuse links	T 160mA 125V
3404.0173.22	OMT 125	Sub-miniature fuse links	T 160mA 125V
3404.0173.24	OMT 125	Sub-miniature fuse links	T 160mA 125V
3404.0112.11	OMT 125	Sub-miniature fuse links	T 500mA 125V
3404.0114.11	OMT 125	Sub-miniature fuse links	T 1A 125V
3404.0114.22	OMT 125	Sub-miniature fuse links	T 1A 125V
3404.0119.11	OMT 125	Sub-miniature fuse links	T 3.5A 125V
3404.0100.11	OMT 125	Sub-miniature fuse links	T 950mA 125V
3404.0100.22	OMT 125	Sub-miniature fuse links	T 950mA 125V
3404.0100.24	OMT 125	Sub-miniature fuse links	T 950mA 125V
3404.2325.22	OMZ 125 SICHERUNG 1.5A T	Fuseholder with fuse-links	
3404.2325.11	OMZ 125 SICHERUNG 1.5A T	Fuseholder with fuse-links	
3404.2325.23	OMZ 125 SICHERUNG 1.5A T	Fuseholder with fuse-links	
3404.2324.11	OMZ 125 SICHERUNG 1A T	Fuseholder with fuse-links	
3404.2324.22	OMZ 125 SICHERUNG 1A T	Fuseholder with fuse-links	
3404.2324.23	OMZ 125 SICHERUNG 1A T	Fuseholder with fuse-links	
3404.2327.11	OMZ 125 SICHERUNG 2.5A T	Fuseholder with fuse-links	
3404.2327.22	OMZ 125 SICHERUNG 2.5A T	Fuseholder with fuse-links	
3404.2327.23	OMZ 125 SICHERUNG 2.5A T	Fuseholder with fuse-links	
3404.2320.11	OMZ 125 SICHERUNG 250mA T	Fuseholder with fuse-links	
3404.2320.22	OMZ 125 SICHERUNG 250mA T	Fuseholder with fuse-links	
3404.2320.23	OMZ 125 SICHERUNG 250mA T	Fuseholder with fuse-links	
3404.2326.11	OMZ 125 SICHERUNG 2A T	Fuseholder with fuse-links	
3404.2326.22	OMZ 125 SICHERUNG 2A T	Fuseholder with fuse-links	
3404.2326.23	OMZ 125 SICHERUNG 2A T	Fuseholder with fuse-links	
3404.2329.11	OMZ 125 SICHERUNG 3.5A T	Fuseholder with fuse-links	
3404.2329.22	OMZ 125 SICHERUNG 3.5A T	Fuseholder with fuse-links	
3404.2329.23	OMZ 125 SICHERUNG 3.5A T	Fuseholder with fuse-links	
3404.2321.11	OMZ 125 SICHERUNG 375mA T	Fuseholder with fuse-links	
3404.2321.22	OMZ 125 SICHERUNG 375mA T	Fuseholder with fuse-links	
3404.2321.23	OMZ 125 SICHERUNG 375mA T	Fuseholder with fuse-links	
3404.2328.22	OMZ 125 SICHERUNG 3A T	Fuseholder with fuse-links	
3404.2328.23	OMZ 125 SICHERUNG 3A T	Fuseholder with fuse-links	

3404.2328.11	OMZ 125 SICHERUNG 3A T	Fuseholder with fuse-links	
3404.2330.11	OMZ 125 SICHERUNG 4A T	Fuseholder with fuse-links	
3404.2330.22	OMZ 125 SICHERUNG 4A T	Fuseholder with fuse-links	
3404.2330.23	OMZ 125 SICHERUNG 4A T	Fuseholder with fuse-links	
3404.2322.22	OMZ 125 SICHERUNG 500mA T	Fuseholder with fuse-links	
3404.2322.11	OMZ 125 SICHERUNG 500mA T	Fuseholder with fuse-links	
3404.2322.23	OMZ 125 SICHERUNG 500mA T	Fuseholder with fuse-links	
3404.2331.22	OMZ 125 SICHERUNG 5A T	Fuseholder with fuse-links	
3404.2331.11	OMZ 125 SICHERUNG 5A T	Fuseholder with fuse-links	
3404.2331.23	OMZ 125 SICHERUNG 5A T	Fuseholder with fuse-links	
3404.2323.22	OMZ 125 SICHERUNG 750mA T	Fuseholder with fuse-links	
3404.2323.11	OMZ 125 SICHERUNG 750mA T	Fuseholder with fuse-links	
3404.2323.23	OMZ 125 SICHERUNG 750mA T	Fuseholder with fuse-links	
3-103-382	RTS-AC100		
3-104-513	RTS-AC100 3. Gen		
3-104-514	RTS-AC100 3. Gen		
3-103-383	RTS-AS500		
3-119-589	RTS-AS500 3. Gen		
3-119-590	RTS-AS500 3. Gen		
3-110-065	UAI 1206	Surface mount fuse	F 5.3A / 63VAC / DC
3-110-066	UAI 1206	Surface mount fuse	F 7.5A / 63VAC / DC
3413.0420.11	UAI 1206	Surface mount fuse	F 7.5A / 63VAC / DC
3413.0420.22	UAI 1206	Surface mount fuse	F 7.5A / 63VAC / DC
3413.0420.24	UAI 1206	Surface mount fuse	F 7.5A / 63VAC / DC
3413.0420.25	UAI 1206	Surface mount fuse	F 7.5A / 63VAC / DC
3413.0421	UAI 1206	Surface mount fuse	F 5.3A / 63VAC / DC
3413.0421	UAI 1206	Surface mount fuse	F 5.3A / 63VAC / DC
3413.0421	UAI 1206	Surface mount fuse	F 5.3A / 63VAC / DC
3413.0421	UAI 1206	Surface mount fuse	F 5.3A / 63VAC / DC
3413.0421.11	UAI 1206	Surface mount fuse	F 5.3A / 63VAC / DC
3413.0421.22	UAI 1206	Surface mount fuse	F 5.3A / 63VAC / DC
3413.0421.24	UAI 1206	Surface mount fuse	F 5.3A / 63VAC / DC
3413.0421.25	UAI 1206	Surface mount fuse	F 5.3A / 63VAC / DC
3413.0421.25.D	UAI 1206	Surface mount fuse	F 5.3A / 63VAC / DC
3413.0421.25.E	UAI 1206	Surface mount fuse	F 5.3A / 63VAC / DC
3413.0421.25.S	UAI 1206	Surface mount fuse	F 5.3A / 63VAC / DC
3-108-641	UMF 250	UMF 250 SICHERUNG 15A	
3405.0163.11	UMF 250	Sub-miniature fuse-links	F 500mA L
3405.0163.24	UMF 250	Sub-miniature fuse-links	F 500mA L
3405.0164.11	UMF 250	Sub-miniature fuse-links	F 630mA L
3405.0164.24	UMF 250	Sub-miniature fuse-links	F 630mA L
3405.0165.11	UMF 250	Sub-miniature fuse-links	F 800mA L
3405.0165.24	UMF 250	Sub-miniature fuse-links	F 800mA L
3405.0166.11	UMF 250	Sub-miniature fuse-links	F 1A L
3405.0166.24	UMF 250	Sub-miniature fuse-links	F 1A L
3405.0167.11	UMF 250	Sub-miniature fuse-links	F 1.25A L
3405.0167.24	UMF 250	Sub-miniature fuse-links	F 1.25A L
3405.0168.11	UMF 250	Sub-miniature fuse-links	F 1.6A L
3405.0168.24	UMF 250	Sub-miniature fuse-links	F 1.6A L
3405.0169.11	UMF 250	Sub-miniature fuse-links	F 2A L
3405.0169.24	UMF 250	Sub-miniature fuse-links	F 2A L
3405.0170.11	UMF 250	Sub-miniature fuse-links	F 2.5A L
3405.0170.24	UMF 250	Sub-miniature fuse-links	F 2.5A L
3405.0171.11	UMF 250	Sub-miniature fuse-links	F 3.15A L
3405.0171.24	UMF 250	Sub-miniature fuse-links	F 3.15A L

3405.0172.11	UMF 250	Sub-miniature fuse-links	F 4A L
3405.0172.24	UMF 250	Sub-miniature fuse-links	F 4A L
3405.0173.11	UMF 250	Sub-miniature fuse-links	F 5A L
3405.0173.24	UMF 250	Sub-miniature fuse-links	F 5A L
3405.0174.11	UMF 250	Sub-miniature fuse-links	F 6.3A L
3405.0174.24	UMF 250	Sub-miniature fuse-links	F 6.3A L
3405.0175.11	UMF 250	Sub-miniature fuse-links	F 8A L
3405.0175.24	UMF 250	Sub-miniature fuse-links	F 8A L
3405.0176.11	UMF 250	Miniature fuse-links	10A
3405.0176.24	UMF 250	Miniature fuse-links	10A
3405.0178.11	UMF 250	Sub-miniature fuse-links	15A
3405.0178.24	UMF 250	Sub-miniature fuse-links	15A
3404.2463.11	UMK 250	Fuse-links + Fuseholder	F 500mA L
3404.2463.22	UMK 250	Fuse-links + Fuseholder	F 500mA L
3404.2464.11	UMK 250	Fuse-links + Fuseholder	F 630mA L
3404.2464.22	UMK 250	Fuse-links + Fuseholder	F 630mA L
3404.2465.11	UMK 250	Fuse-links + Fuseholder	F 800mA L
3404.2465.22	UMK 250	Fuse-links + Fuseholder	F 800mA L
3404.2466.11	UMK 250	Fuse-links + Fuseholder	F 1A L
3404.2466.22	UMK 250	Fuse-links + Fuseholder	F 1A L
3404.2467.11	UMK 250	Fuse-links + Fuseholder	F 1.25A L
3404.2467.22	UMK 250	Fuse-links + Fuseholder	F 1.25A L
3404.2468.11	UMK 250	Fuse-links + Fuseholder	F 1.6A L
3404.2468.22	UMK 250	Fuse-links + Fuseholder	F 1.6A L
3404.2469.11	UMK 250	Fuse-links + Fuseholder	F 2A L
3404.2469.22	UMK 250	Fuse-links + Fuseholder	F 2A L
3404.2470.11	UMK 250	Fuse-links + Fuseholder	F 2.5A L
3404.2470.22	UMK 250	Fuse-links + Fuseholder	F 2.5A L
3404.2471.11	UMK 250	Fuse-links+Fuseholder	F 3.15A L
3404.2471.22	UMK 250	Fuse-links + Fuseholder	F 3.15A L
3404.2472.11	UMK 250	Fuse-links + Fuseholder	F 4A L
3404.2472.22	UMK 250	Fuse-links + Fuseholder	F 4A L
3-101-576	UMT 250	Sub-miniature fuse-links	T 6.3A L AC250V / DC125V
3403.0173.11	UMT 250	Sub-miniature fuse-links	T 5A L AC250V / DC125V
3403.0173.24	UMT 250	Sub-miniature fuse-links	T 5A L AC250V / DC125V
3403.0174.11	UMT 250	Sub-miniature fuse-links	T 6.3A L AC250V / DC125V
3403.0174.24	UMT 250	Sub-miniature fuse-links	T 6.3A L AC250V / DC125V
3403.0174.24	UMT 250	Sub-miniature fuse-links	T 6.3A L AC250V / DC125V
3403.0174.24	UMT 250	Sub-miniature fuse-links	T 6.3A L AC250V / DC125V
3403.0175.11	UMT 250	Sub-miniature fuse-links	T 8A AC250V / DC125V
3403.0175.24	UMT 250	Sub-miniature fuse-links	T 8A AC250V / DC125V
3403.0176.11	UMT 250	Sub-miniature fuse-links	T 10A AC250V / DC125V
3403.0176.24	UMT 250	Sub-miniature fuse-links	T 10A AC250V / DC125V
3403.0155.11	UMT 250	Sub-miniature fuse-links	T 80mA L AC250V / DC125V
3403.0155.24	UMT 250	Sub-miniature fuse-links	T 80mA L AC250V / DC125V
3-101-577	UMT 250	Sub-miniature fuse-links	T 1.25A L AC250V / DC125V
3403.0161.11	UMT 250	Sub-miniature fuse-links	T 315mA L AC250V / DC125V
3403.0161.24	UMT 250	Sub-miniature fuse-links	T 315mA L AC250V / DC125V
3403.0162.11	UMT 250	Sub-miniature fuse-links	T 400mA L AC250V / DC125V
3403.0162.24	UMT 250	Sub-miniature fuse-links	T 400mA L AC250V / DC125V
3403.0163.11	UMT 250	Sub-miniature fuse-links	T 500mA L AC250V / DC125V
3403.0163.24	UMT 250	Sub-miniature fuse-links	T 500mA L AC250V / DC125V
3403.0163.24	UMT 250	Sub-miniature fuse-links	T 500mA L AC250V / DC125V
3403.0164.11	UMT 250	Sub-miniature fuse-links	T 630mA L AC250V / DC125V
3403.0164.24	UMT 250	Sub-miniature fuse-links	T 630mA L AC250V / DC125V

3403.0165.11	UMT 250	Sub-miniature fuse-links	T 800mA L AC250V / DC125V
3403.0165.24	UMT 250	Sub-miniature fuse-links	T 800mA L AC250V / DC125V
3403.0166.11	UMT 250	Sub-miniature fuse-links	T 1A L AC250V / DC125V
3403.0166.24	UMT 250	Sub-miniature fuse-links	T 1A L AC250V / DC125V
3403.0167.11	UMT 250	Sub-miniature fuse-links	T 1.25A L AC250V / DC125V
3403.0167.24	UMT 250	Sub-miniature fuse-links	T 1.25A L AC250V / DC125V
3403.0168.11	UMT 250	Sub-miniature fuse-links	T 1.6A L AC250V / DC125V
3403.0168.24	UMT 250	Sub-miniature fuse-links	T 1.6A L AC250V / DC125V
3403.0169.11	UMT 250	Sub-miniature fuse-links	T 2A L AC250V / DC125V
3403.0169.24	UMT 250	Sub-miniature fuse-links	T 2A L AC250V / DC125V
3403.0170.11	UMT 250	Sub-miniature fuse-links	T 2.5A L AC250V / DC125V
3403.0170.24	UMT 250	Sub-miniature fuse-links	T 2.5A L AC250V / DC125V
3403.0171.11	UMT 250	Sub-miniature fuse-links	T 3.15A L AC250V / DC125V
3403.0171.24	UMT 250	Sub-miniature fuse-links	T 3.15A L AC250V / DC125V
3403.0172.11	UMT 250	Sub-miniature fuse-links	T 4 AL AC250V / DC125V
3403.0172.24	UMT 250	Sub-miniature fuse-links	T 4 A L AC250V / DC125V
3403.0173.11.RM	UMT 250	Sub-miniature fuse-links	T 5 A AC250V / DC125V
3403.0173.24.RM	UMT 250	Sub-miniature fuse-links	T 5 A AC250V / DC125V
3403.0176.11.RM	UMT 250	Sub-miniature fuse-links	T 10A AC250V / DC125V
3403.0176.24.RM	UMT 250	Sub-miniature fuse-links	T 10A AC250V / DC125V
3-120-959	UMT 250	Sub-miniature fuse-links	T 250mA L AC250V / DC125V
3-120-960	UMT 250	Sub-miniature fuse-links	T 250mA L AC250V / DC125V
3403.0156.11	UMT 250	Sub-miniature fuse-links	T 100mA L AC250V / DC125V
3403.0156.24	UMT 250	Sub-miniature fuse-links	T 100mA L AC250V / DC125V
3403.0157.11	UMT 250	Sub-miniature fuse-links	T 125mA L AC250V / DC125V
3403.0157.24	UMT 250	Sub-miniature fuse-links	T 125mA L AC250V / DC125V
3403.0158.11	UMT 250	Sub-miniature fuse-links	T 160mA L AC250V / DC125V
3403.0158.24	UMT 250	Sub-miniature fuse-links	T 160mA L AC250V / DC125V
3403.0159.11	UMT 250	Sub-miniature fuse-links	T 200mA L AC250V / DC125V
3403.0159.24	UMT 250	Sub-miniature fuse-links	T 200mA L AC250V / DC125V
3403.0160.11	UMT 250	Sub-miniature fuse-links	T 250mA L AC250V / DC125V
3403.0160.24	UMT 250	Sub-miniature fuse-links	T 250mA L AC250V / DC125V
3403.0263.11	UMT-H	Surface mount fuses (SMD)	80mA
3403.0264.11	UMT-H	Surface mount fuses (SMD)	100mA
3403.0265.11	UMT-H	Surface mount fuses (SMD)	125mA
3403.0266.11	UMT-H	Surface mount fuses (SMD)	160mA
3403.0263.23	UMT-H	Surface mount fuses (SMD)	80mA
3403.0264.23	UMT-H	Surface mount fuses (SMD)	100mA
3403.0265.23	UMT-H	Surface mount fuses (SMD)	125mA
3403.0266.23	UMT-H	Surface mount fuses (SMD)	160mA
3403.0276.11	UMT-H	Surface mount fuses (SMD)	1.6A
3403.0276.23	UMT-H	Surface mount fuses (SMD)	1.6A
3403.0277.11	UMT-H	Surface mount fuses (SMD)	2A
3403.0277.23	UMT-H	Surface mount fuses (SMD)	2A
3403.0277.23.K	UMT-H	Surface mount fuses (SMD)	2A
3403.0277.23.K2	UMT-H	Surface mount fuses (SMD)	2A
3403.0282.11	UMT-H	Surface mount fuses (SMD)	6.3A
3403.0282.23	UMT-H	Surface mount fuses (SMD)	6.3A
3403.0266	UMT-H	Surface mount fuses (SMD)	160mA
3403.0276	UMT-H	Surface mount fuses (SMD)	1.6A
3403.0282	UMT-H	Surface mount fuses (SMD)	6.3A
3403.0267	UMT-H	Surface mount fuses (SMD)	200mA
3403.0267.11	UMT-H	Surface mount fuses (SMD)	200mA
3403.0267.23	UMT-H	Surface mount fuses (SMD)	200mA
3403.0268	UMT-H	Surface mount fuses (SMD)	250mA

3403.0268.23	UMT-H	Surface mount fuses (SMD)	250mA
3403.0269.23	UMT-H	Surface mount fuses (SMD)	315mA
3403.0287	UMT-H	Surface mount fuses (SMD)	20A
3403.0287.11	UMT-H	Surface mount fuses (SMD)	20A
3403.0287.23	UMT-H	Surface mount fuses (SMD)	20A
3403.0288	UMT-H	Surface mount fuses (SMD)	25A
3403.0288.11	UMT-H	Surface mount fuses (SMD)	25A
3403.0288.23	UMT-H	Surface mount fuses (SMD)	25A
3403.0289	UMT-H	Surface mount fuses (SMD)	30A
3403.0289.11	UMT-H	Surface mount fuses (SMD)	30A
3403.0289.23	UMT-H	Surface mount fuses (SMD)	30A
3403.0264	UMT-H	Surface mount fuses (SMD)	100mA
3403.0265	UMT-H	Surface mount fuses (SMD)	125mA
3403.0268.11	UMT-H	Surface mount fuses (SMD)	250mA
3403.0269	UMT-H	Surface mount fuses (SMD)	315mA
3403.0269.11	UMT-H	Surface mount fuses (SMD)	315mA
3403.0270	UMT-H	Surface mount fuses (SMD)	400mA
3403.0270.11	UMT-H	Surface mount fuses (SMD)	400mA
3403.0270.23	UMT-H	Surface mount fuses (SMD)	400mA
3403.0271	UMT-H	Surface mount fuses (SMD)	500mA
3403.0271.11	UMT-H	Surface mount fuses (SMD)	500mA
3403.0271.23	UMT-H	Surface mount fuses (SMD)	500mA
3403.0272	UMT-H	Surface mount fuses (SMD)	630mA
3403.0272.11	UMT-H	Surface mount fuses (SMD)	630mA
3403.0272.23	UMT-H	Surface mount fuses (SMD)	630mA
3403.0273	UMT-H	Surface mount fuses (SMD)	800mA
3403.0273.11	UMT-H	Surface mount fuses (SMD)	800mA
3403.0273.23	UMT-H	Surface mount fuses (SMD)	800mA
3403.0274	UMT-H	Surface mount fuses (SMD)	1A
3403.0274.11	UMT-H	Surface mount fuses (SMD)	1A
3403.0274.23	UMT-H	Surface mount fuses (SMD)	1A
3403.0275	UMT-H	Surface mount fuses (SMD)	1.25A
3403.0275.11	UMT-H	Surface mount fuses (SMD)	1.25A
3403.0275.23	UMT-H	Surface mount fuses (SMD)	1.25A
3403.0278	UMT-H	Surface mount fuses (SMD)	2.5A
3403.0278.11	UMT-H	Surface mount fuses (SMD)	2.5A
3403.0278.23	UMT-H	Surface mount fuses (SMD)	2.5A
3403.0279	UMT-H	Surface mount fuses (SMD)	3.15A
3403.0279.11	UMT-H	Surface mount fuses (SMD)	3.15A
3403.0279.23	UMT-H	Surface mount fuses (SMD)	3.15A
3403.0280	UMT-H	Surface mount fuses (SMD)	4A
3403.0280.11	UMT-H	Surface mount fuses (SMD)	4A
3403.0280.23	UMT-H	Surface mount fuses (SMD)	4A
3403.0281	UMT-H	Surface mount fuses (SMD)	5A
3403.0281.11	UMT-H	Surface mount fuses (SMD)	5A
3403.0281.23	UMT-H	Surface mount fuses (SMD)	5A
3403.0283	UMT-H	Surface mount fuses (SMD)	8A
3403.0283.11	UMT-H	Surface mount fuses (SMD)	8A
3403.0283.23	UMT-H	Surface mount fuses (SMD)	8A
3403.0284	UMT-H	Surface mount fuses (SMD)	10A
3403.0284.11	UMT-H	Surface mount fuses (SMD)	10A
3403.0284.23	UMT-H	Surface mount fuses (SMD)	10A
3403.0285.11	UMT-H	Surface mount fuses (SMD)	12.5A
3403.0285.23	UMT-H	Surface mount fuses (SMD)	12.5A
3403.0286.11	UMT-H	Surface mount fuses (SMD)	16A

3403.0286.23	UMT-H	Surface mount fuses (SMD)	16A
3-103-079	UMT-M	Surface mount fuses (SMD)	16A
3-109-343	UMT-M	Surface mount fuses (SMD)	16A
3404.2411.11	UMZ 250	Fuse-links + Fuseholder	T 315mA L AC250V
3404.2411.22	UMZ 250	Fuse-links + Fuseholder	T 315mA L AC250V
3404.2412.11	UMZ 250	Fuse-links + Fuseholder	T 400mA L AC250V
3404.2412.22	UMZ 250	Fuse-links + Fuseholder	T 400mA L AC250V
3404.2413.11	UMZ 250	Fuse-links + Fuseholder	T 500mA L AC250V
3404.2413.22	UMZ 250	Fuse-links + Fuseholder	T 500mA L AC250V
3404.2414.11	UMZ 250	Fuse-links + Fuseholder	T 630mA L AC250V
3404.2414.22	UMZ 250	Fuse-links + Fuseholder	T 630mA L AC250V
3404.2415.11	UMZ 250	Fuse-links + Fuseholder	T 800mA L AC250V
3404.2415.22	UMZ 250	Fuse-links + Fuseholder	T 800mA L AC250V
3404.2416.11	UMZ 250	Fuse-links + Fuseholder	T 1A L AC250V
3404.2416.22	UMZ 250	Fuse-links + Fuseholder	T 1A L AC250V
3404.2417.11	UMZ 250	Fuse-links + Fuseholder	T 1.25A L AC250V
3404.2417.22	UMZ 250	Fuse-links + Fuseholder	T 1.25A L AC250V
3404.2418.11	UMZ 250	Fuse-links + Fuseholder	T 1.6A L AC250V
3404.2418.22	UMZ 250	Fuse-links + Fuseholder	T 1.6A L AC250V
3404.2419.11	UMZ 250	Fuse-links + Fuseholder	T 2A L AC250V
3404.2419.22	UMZ 250	Fuse-links + Fuseholder	T 2A L AC250V
3404.2420.22	UMZ 250	Fuse-links + Fuseholder	T 2.5A L AC250V
3404.2421.11	UMZ 250	Fuse-links + Fuseholder	T 3.15A L AC250V
3404.2421.22	UMZ 250	Fuse-links + Fuseholder	T 3.15A L AC250V
3404.2422.22	UMZ 250	Fuse-links + Fuseholder	T 4A L AC250V
3404.2420.11	UMZ 250	Fuse-links + Fuseholder	T 2.5A L AC250V
3404.2422.11	UMZ 250	Fuse-links + Fuseholder	T 4A L AC250V
3404.2405.11	UMZ 250	Fuse-links + Fuseholder	T 80mA L AC250V
3404.2405.22	UMZ 250	Fuse-links + Fuseholder	T 80mA L AC250V
3404.2406.11	UMZ 250	Fuse-links + Fuseholder	T 100mA L AC250V
3404.2406.22	UMZ 250	Fuse-links + Fuseholder	T 100mA L AC250V
3404.2407.11	UMZ 250	Fuse-links + Fuseholder	T 125mA L AC250V
3404.2407.22	UMZ 250	Fuse-links + Fuseholder	T 125mA L AC250V
3404.2408.11	UMZ 250	Fuse-links + Fuseholder	T 160mA L AC250V
3404.2408.22	UMZ 250	Fuse-links + Fuseholder	T 160mA L AC250V
3404.2409.11	UMZ 250	Fuse-links + Fuseholder	T 200mA L AC250V
3404.2409.22	UMZ 250	Fuse-links + Fuseholder	T 200mA L AC250V
3404.2410.11	UMZ 250	Fuseholder with fuse-links	T 250mA L AC250V
3404.2410.22	UMZ 250	Fuse-links + Fuseholder	T 250mA L AC250V
3412.0114.24	USF 0603	Surface mount fuse	FF 750mA 32VAC / 63VDC
3412.0114.26	USF 0603	Surface mount fuse	FF 750mA 32VAC / 63VDC
3412.0113.24	USF 0603	Surface mount fuse	FF 500mA 32VAC / 63VDC
3412.0113.26	USF 0603	Surface mount fuse	FF 500mA 32VAC / 63VDC
3412.0115.24	USF 0603	Surface mount fuse	FF 1A 32VAC / 63VDC
3412.0115.26	USF 0603	Surface mount fuse	FF 1A 32VAC / 63VDC
3412.0117.24	USF 0603	Surface mount fuse	FF 1.5A 32VAC / 63VDC
3412.0117.26	USF 0603	Surface mount fuse	FF 1.5A 32VAC / 63VDC
3412.0119.26	USF 0603	Surface mount fuse	FF 2A 32VAC / 32VDC
3412.0120.24	USF 0603	Surface mount fuse	FF 2.5A 32VAC / 32VDC
3412.0120.26	USF 0603	Surface mount fuse	FF 2.5A 32VAC / 32VDC
3412.0121.26	USF 0603	Surface mount fuse	FF 3A 32VAC / 32VDC
3412.0122.24	USF 0603	Surface mount fuse	FF 3.5A 32VAC / 32VDC
3412.0122.26	USF 0603	Surface mount fuse	FF 3.5A 32VAC / 32VDC
3412.0123.26	USF 0603	Surface mount fuse	FF 4A 32VAC / 32VDC
3412.0124.24	USF 0603	Surface mount fuse	FF 5A 32VAC / 32VDC

3412.0124.26	USF 0603	Surface mount fuse	FF 5A 32VAC / 32VDC
3412.0113.11	USF 0603	Surface mount fuse	FF 500mA 32VAC / 63VDC
3412.0114.11	USF 0603	Surface mount fuse	FF 750mA 32VAC / 63VDC
3412.0115.11	USF 0603	Surface mount fuse	FF 1A 32VAC / 63VDC
3412.0117.11	USF 0603	Surface mount fuse	FF 1.5A 32VAC / 63VDC
3412.0119.11	USF 0603	Surface mount fuse	FF 2A 32VAC / 32VDC
3412.0120.11	USF 0603	Surface mount fuse	FF 2.5A 32VAC / 32VDC
3412.0121.11	USF 0603	Surface mount fuse	FF 3A 32VAC / 32VDC
3412.0122.11	USF 0603	Surface mount fuse	FF 3.5A 32VAC / 32VDC
3412.0123.11	USF 0603	Surface mount fuse	FF 4A 32VAC / 32VDC
3412.0124.11	USF 0603	Surface mount fuse	FF 5A 32VAC / 32VDC
3412.0119.24	USF 0603	Surface mount fuse	FF 2A 32VAC / 32VDC
3412.0113.22	USF 0603	Surface mount fuse	FF 500mA 32VAC / 63VDC
3412.0114.22	USF 0603	Surface mount fuse	FF 750mA 32VAC / 63VDC
3412.0115.22	USF 0603	Surface mount fuse	FF 1A 32VAC / 63VDC
3412.0117.22	USF 0603	Surface mount fuse	FF 1.5A 32VAC / 63VDC
3412.0119.22	USF 0603	Surface mount fuse	FF 2A 32VAC / 32VDC
3412.0120.22	USF 0603	Surface mount fuse	FF 2.5A 32VAC / 32VDC
3412.0121.22	USF 0603	Surface mount fuse	FF 3A 32VAC / 32VDC
3412.0122.22	USF 0603	Surface mount fuse	FF 3.5A 32VAC / 32VDC
3412.0123.22	USF 0603	Surface mount fuse	FF 4A 32VAC / 32VDC
3412.0124.22	USF 0603	Surface mount fuse	FF 5A 32VAC / 32VDC
3412.0121.24	USF 0603	Surface mount fuse	FF 3A 32VAC / 32VDC
3412.0123.24	USF 0603	Surface mount fuse	FF 4A 32VAC / 32VDC
3413.0112.22	USF 1206	Surface mount fuse	FF 375mA 125VAC / DC
3413.0112.24	USF 1206	Surface mount fuse	FF 375mA 125VAC / DC
3413.0112.26	USF 1206	Surface mount fuse	FF 375mA 125VAC / DC
3413.0112.11	USF 1206	Surface mount fuse	FF 375mA 125VAC / DC
3413.0113.11	USF 1206	Surface mount fuse	FF 500mA 125VAC / DC
3413.0114.11	USF 1206	Surface mount fuse	FF 750mA 32VAC / 63V DC
3413.0115.11	USF 1206	Surface mount fuse	FF 1A 32VAC / 63V DC
3413.0116.11	USF 1206	Surface mount fuse	FF 1.25A 32VAC / 63V DC
3413.0117.11	USF 1206	Surface mount fuse	FF 1.5A 32VAC / 63V DC
3413.0119.11	USF 1206	Surface mount fuse	FF 2A 32VAC / 63V DC
3413.0120.11	USF 1206	Surface mount fuse	FF 2.5A 32VAC / 63V DC
3413.0121.11	USF 1206	Surface mount fuse	FF 3A 32VAC / 63V DC
3413.0123.11	USF 1206	Surface mount fuse	FF 4A 32VAC / 63V DC
3413.0113.22	USF 1206	Surface mount fuse	FF 500mA 125VAC / DC
3413.0113.24	USF 1206	Surface mount fuse	FF 500mA 125VAC / DC
3413.0113.26	USF 1206	Surface mount fuse	FF 500mA 125VAC / DC
3413.0114.22	USF 1206	Surface mount fuse	FF 750mA 32VAC / 63V DC
3413.0114.24	USF 1206	Surface mount fuse	FF 750mA 32VAC / 63V DC
3413.0114.26	USF 1206	Surface mount fuse	FF 750mA 32VAC / 63V DC
3413.0115.22	USF 1206	Surface mount fuse	FF 1A 32VAC / 63V DC
3413.0115.24	USF 1206	Surface mount fuse	FF 1A 32VAC / 63V DC
3413.0115.26	USF 1206	Surface mount fuse	FF 1A 32VAC / 63V DC
3413.0116.22	USF 1206	Surface mount fuse	FF 1.25A 32VAC / 63V DC
3413.0116.24	USF 1206	Surface mount fuse	FF 1.25A 32VAC / 63V DC
3413.0116.26	USF 1206	Surface mount fuse	FF 1.25A 32VAC / 63V DC
3413.0117.22	USF 1206	Surface mount fuse	FF 1.5A 32VAC / 63V DC
3413.0117.24	USF 1206	Surface mount fuse	FF 1.5A 32VAC / 63V DC
3413.0117.26	USF 1206	Surface mount fuse	FF 1.5A 32VAC / 63V DC
3413.0119.22	USF 1206	Surface mount fuse	FF 2A 32VAC / 63V DC
3413.0119.24	USF 1206	Surface mount fuse	FF 2A 32VAC / 63V DC
3413.0119.26	USF 1206	Surface mount fuse	FF 2A 32VAC / 63V DC

3413.0120.22	USF 1206	Surface mount fuse	FF 2.5A 32VAC / 63V DC
3413.0120.24	USF 1206	Surface mount fuse	FF 2.5A 32VAC / 63V DC
3413.0120.26	USF 1206	Surface mount fuse	FF 2.5A 32VAC / 63V DC
3413.0121.22	USF 1206	Surface mount fuse	FF 3A 32VAC / 63V DC
3413.0121.24	USF 1206	Surface mount fuse	FF 3A 32VAC / 63V DC
3413.0121.26	USF 1206	Surface mount fuse	FF 3A 32VAC / 63V DC
3413.0123.22	USF 1206	Surface mount fuse	FF 4A 32VAC / 63V DC
3413.0123.24	USF 1206	Surface mount fuse	FF 4A 32VAC / 63V DC
3413.0123.26	USF 1206	Surface mount fuse	FF 4A 32VAC / 63V DC
3413.0002.11	USFF 1206	Surface mount fuse	FF 50mA 125VAC / 63VDC
3413.0002.22	USFF 1206	Surface mount fuse	FF 50mA 125VAC / 63VDC
3413.0002.24	USFF 1206	Surface mount fuse	FF 50mA 125VAC / 63VDC
3413.0006.11	USFF 1206	Surface mount fuse	FF 125mA 125VAC / 63VDC
3413.0006.22	USFF 1206	Surface mount fuse	FF 125mA 125VAC / 63VDC
3413.0006.24	USFF 1206	Surface mount fuse	FF 125mA 125VAC / 63VDC
3413.0008.11	USFF 1206	Surface mount fuse	FF 160mA 125VAC / 63VDC
3413.0008.22	USFF 1206	Surface mount fuse	FF 160mA 125VAC / 63VDC
3413.0008.24	USFF 1206	Surface mount fuse	FF 160mA 125VAC / 63VDC
3413.0009.11	USFF 1206	Surface mount fuse	FF 200mA 125VAC / 63VDC
3413.0009.22	USFF 1206	Surface mount fuse	FF 200mA 125VAC / 63VDC
3413.0009.24	USFF 1206	Surface mount fuse	FF 200mA 125VAC / 63VDC
3413.0010.11	USFF 1206	Surface mount fuse	FF 250mA 125VAC / 63VDC
3413.0010.22	USFF 1206	Surface mount fuse	FF 250mA 125VAC / 63VDC
3413.0010.24	USFF 1206	Surface mount fuse	FF 250mA 125VAC / 63VDC
3413.0002.26	USFF 1206	Surface mount fuse	FF 50mA 125VAC / 63VDC
3413.0006.26	USFF 1206	Surface mount fuse	FF 125mA 125VAC / 63VDC
3413.0008.26	USFF 1206	Surface mount fuse	FF 160mA 125VAC / 63VDC
3413.0009.26	USFF 1206	Surface mount fuse	FF 200mA 125VAC / 63VDC
3413.0010.26	USFF 1206	Surface mount fuse	FF 250mA 125VAC / 63VDC
3413.0213.22	USI 1206	Surface mount fuse	F 500mA L 32VAC / 63V DC
3413.0219.22	USI 1206	Surface mount fuse	F 2A L 32VAC / 63V DC
3413.0223.22	USI 1206	Surface mount fuse	F 5A L 32VAC / 63V DC
3413.0213.11	USI 1206	Surface mount fuse	F 500mA L 32VAC / 63V DC
3413.0214.11	USI 1206	Surface mount fuse	F 630mA L 32VAC / 63V DC
3413.0215.11	USI 1206	Surface mount fuse	F 800mA L 32VAC / 63V DC
3413.0216.11	USI 1206	Surface mount fuse	F 1A L 32VAC / 63V DC
3413.0217.11	USI 1206	Surface mount fuse	F 1.25A L 32VAC / 63V DC
3413.0218.11	USI 1206	Surface mount fuse	F 1.6A L 32VAC / 63V DC
3413.0219.11	USI 1206	Surface mount fuse	F 2A L 32VAC / 63V DC
3413.0220.11	USI 1206	Surface mount fuse	F 2.5A L 32VAC / 63V DC
3413.0221.11	USI 1206	Surface mount fuse	F 3.15A L AC32V / DC63V
3413.0222.11	USI 1206	Surface mount fuse	F 4A L 32VAC / 63V DC
3413.0223.11	USI 1206	Surface mount fuse	F 5A L 32VAC / 63V DC
3413.0224.11	USI 1206	Surface mount fuse	F 6.3A L 32VAC / 63V DC
3413.0214.22	USI 1206	Surface mount fuse	F 630mA L 32VAC / 63V DC
3413.0216.22	USI 1206	Surface mount fuse	HCSF
3413.0222.22	USI 1206	Surface mount fuse	F 4A L 32VAC / 63V DC
3413.0224.22	USI 1206	Surface mount fuse	F 6.3A L 32VAC / 63V DC
3413.0213.24	USI 1206	Surface mount fuse	F 500mA L 32VAC / 63V DC
3413.0213.26	USI 1206	Surface mount fuse	F 500mA L 32VAC / 63V DC
3413.0214.24	USI 1206	Surface mount fuse	F 630mA L 32VAC / 63V DC
3413.0214.26	USI 1206	Surface mount fuse	F 630mA L 32VAC / 63V DC
3413.0215.22	USI 1206	Surface mount fuse	F 800mA L 32VAC / 63V DC
3413.0215.24	USI 1206	Surface mount fuse	F 800mA L 32VAC / 63V DC
3413.0215.26	USI 1206	Surface mount fuse	F 800mA L 32VAC / 63V DC

3413.0216.24	USI 1206	Surface mount fuse	F 1A L 32VAC / 63V DC
3413.0216.26	USI 1206	Surface mount fuse	F 1A L 32VAC / 63V DC
3413.0217.22	USI 1206	Surface mount fuse	F 1.25A L 32VAC / 63V DC
3413.0217.24	USI 1206	Surface mount fuse	F 1.25A L 32VAC / 63V DC
3413.0217.26	USI 1206	Surface mount fuse	F 1.25A L 32VAC / 63V DC
3413.0218.22	USI 1206	Surface mount fuse	F 1.6A L 32VAC / 63V DC
3413.0218.24	USI 1206	Surface mount fuse	F 1.6A L 32VAC / 63V DC
3413.0218.26	USI 1206	Surface mount fuse	F 1.6A L 32VAC / 63V DC
3413.0219.24	USI 1206	Surface mount fuse	F 2A L 32VAC / 63V DC
3413.0219.26	USI 1206	Surface mount fuse	F 2A L 32VAC / 63V DC
3413.0220.22	USI 1206	Surface mount fuse	F 2.5A L 32VAC / 63V DC
3413.0220.24	USI 1206	Surface mount fuse	F 2.5A L 32VAC / 63V DC
3413.0220.26	USI 1206	Surface mount fuse	F 2.5A L 32VAC / 63V DC
3413.0221.00	USI 1206	Surface mount fuse	F 3.15A L 32VAC / 63V DC
3413.0221.22	USI 1206	Surface mount fuse	F 3.15A L 32VAC / 63V DC
3413.0221.24	USI 1206	Surface mount fuse	F 3.15A L 32VAC / 63V DC
3413.0221.26	USI 1206	Surface mount fuse	F 3.15A L 32VAC / 63V DC
3413.0222.24	USI 1206	Surface mount fuse	F 4A L 32VAC / 63V DC
3413.0222.26	USI 1206	Surface mount fuse	F 4A L 32VAC / 63V DC
3413.0223.24	USI 1206	Surface mount fuse	F 5A L 32VAC / 63V DC
3413.0223.26	USI 1206	Surface mount fuse	F 5A L 32VAC / 63V DC
3413.0224.24	USI 1206	Surface mount fuse	F 6.3A L 32VAC / 63V DC
3413.0224.26	USI 1206	Surface mount fuse	F 6.3A L 32VAC / 63V DC
3413.0512.11	USN 1206		12A
3413.0550.25	USN 1206		12A
3413.0331.22	UST 1206	Surface mount fuse	F 20A 32VAC / 63V DC
3413.0331.24	UST 1206	Surface mount fuse	F 20A 32VAC / 63V DC
3413.0331.26	UST 1206	Surface mount fuse	F 20A 32VAC / 63V DC
3413.0332.22	UST 1206	Surface mount fuse	F 25A 32VAC / 63V DC
3413.0332.24	UST 1206	Surface mount fuse	F 25A 32VAC / 63V DC
3413.0332.26	UST 1206	Surface mount fuse	F 25A 32VAC / 63V DC
3413.0326.11	UST 1206	Surface mount fuse	F 7A 32VAC / 63V DC
3413.0327.11	UST 1206	Surface mount fuse	F 8A 32VAC / 63V DC
3413.0328.11	UST 1206	Surface mount fuse	F 10A 32VAC / 63V DC
3413.0329.11	UST 1206	Surface mount fuse	F 12A 32VAC / 63V DC
3413.0330.11	UST 1206	Surface mount fuse	F 15A 32VAC / 63V DC
3413.0331.11	UST 1206	Surface mount fuse	F 20A 32VAC / 63V DC
3413.0332.11	UST 1206	Surface mount fuse	F 25A 32VAC / 63V DC
3413.0326.22	UST 1206	Surface mount fuse	F 7A 32VAC / 63V DC
3413.0326.24	UST 1206	Surface mount fuse	F 7A 32VAC / 63V DC
3413.0326.26	UST 1206	Surface mount fuse	F 7A 32VAC / 63V DC
3413.0327.22	UST 1206	Surface mount fuse	F 8A 32VAC / 63V DC
3413.0327.24	UST 1206	Surface mount fuse	F 8A 32VAC / 63V DC
3413.0327.26	UST 1206	Surface mount fuse	F 8A 32VAC / 63V DC
3413.0328.22	UST 1206	Surface mount fuse	F 10A 32VAC / 63V DC
3413.0328.24	UST 1206	Surface mount fuse	F 10A 32VAC / 63V DC
3413.0328.24.CI	UST 1206	Surface mount fuse	F 10A 32VAC / 63V DC
3413.0328.26	UST 1206	Surface mount fuse	F 10A 32VAC / 63V DC
3413.0329.22	UST 1206	Surface mount fuse	F 12A 32VAC / 63V DC
3413.0329.24	UST 1206	Surface mount fuse	F 12A 32VAC / 63V DC
3413.0329.26	UST 1206	Surface mount fuse	F 12A 32VAC / 63V DC
3413.0330.22	UST 1206	Surface mount fuse	F 15A 32VAC / 63V DC
3413.0330.24	UST 1206	Surface mount fuse	F 15A 32VAC / 63V DC
3413.0330.26	UST 1206	Surface mount fuse	F 15A 32VAC / 63V DC
3413.0327.11	UST 1206	Surface mount fuse	F 8A 32VAC / 63V DC

3413.0327.24	UST 1206	Surface mount fuse	F 8A 32VAC / 63V DC
3413.0327.26	UST 1206	Surface mount fuse	F 8A 32VAC / 63V DC
3413.0328.11	UST 1206	Surface mount fuse	F 10A 32VAC / 63V DC
3413.0328.24	UST 1206	Surface mount fuse	F 10A 32VAC / 63V DC
3413.0328.26	UST 1206	Surface mount fuse	F 10A 32VAC / 63V DC
3413.0330.11	UST 1206	Surface mount fuse	F 15A 32VAC / 63V DC
3413.0330.24	UST 1206	Surface mount fuse	F 15A 32VAC / 63V DC
3413.0330.26	UST 1206	Surface mount fuse	F 15A 32VAC / 63V DC
3-101-050	HCF	Sub-miniature fuse	7.5 A 125VAC / DC
3-101-051	HCF	Sub-miniature fuse	10 A 125VAC / DC
3-101-056	HCF	Sub-miniature fuse	5 A 125VAC / DC
3-101-062	HCF	Sub-miniature fuse	15A 125VAC / DC
3-122-712	UMT-W	Surface mount fuse (SMD)	5A
3-122-713	UMT-W	Surface mount fuse (SMD)	5A
3-122-714	UMT-W	Surface mount fuse (SMD)	7.5A
3-122-715	UMT-W	Surface mount fuse (SMD)	7.5A
3-122-716	UMT-W	Surface mount fuse (SMD)	10A
3-122-717	UMT-W	Surface mount fuse (SMD)	10A
3-122-718	UMT-W	Surface mount fuse (SMD)	15A
3-122-719	UMT-W	Surface mount fuse (SMD)	15A
3-122-720	UMT-W	Surface mount fuse (SMD)	20A
3-122-721	UMT-W	Surface mount fuse (SMD)	20A

New Label Information

Type	Short Text	Configuration Code
HCSF	HCSF Fuse FF 4A	HCSF-3220-4A000-SMD-SF-PB-00
HCSF	HCSF Fuse FF 4A	HCSF-3220-4A000-SMD-SF-PB-00
HCSF	HCSF Fuse FF 4A	HCSF-3220-4A000-SMD-SF-PB-00
HCSF	HCSF Fuse FF 5A	HCSF-3220-5A000-SMD-SF-PB-00
HCSF	HCSF Fuse FF 6.3A	HCSF-3220-6A300-SMD-SF-PB-00
HCSF	HCSF Fuse FF 6.3A	HCSF-3220-6A300-SMD-SF-PB-00
HCSF	HCSF Fuse FF 6.3A	HCSF-3220-6A300-SMD-SF-PB-00
HCSF	HCSF Fuse FF 7.5A	HCSF-3220-7A500-SMD-SF-PB-00
HCSF	HCSF Fuse FF 10A	HCSF-3220-10A00-SMD-SF-PB-00
HCSF	HCSF Fuse FF 15A	HCSF-3220-15A00-SMD-SF-PB-00
MGA	MGA Fuse FF 200mA	MGA-1206-0A200-SMD-SF-SN-00
MGA	MGA Fuse FF 200mA	MGA-1206-0A200-SMD-SF-SN-00
MGA	MGA Fuse FF 200mA	MGA-1206-0A200-SMD-SF-SN-00
MGA	MGA Fuse FF 200mA	MGA-1206-0A200-SMD-SF-SN-00
MGA	MGA Fuse FF 250mA	MGA-1206-0A250-SMD-SF-SN-00
MGA	MGA Fuse FF 250mA	MGA-1206-0A250-SMD-SF-SN-00
MGA	MGA Fuse FF 250mA	MGA-1206-0A250-SMD-SF-SN-00
MGA	MGA Fuse FF 250mA	MGA-1206-0A250-SMD-SF-SN-00
MGA	MGA Fuse FF 375mA	MGA-1206-0A375-SMD-SF-SN-00
MGA	MGA Fuse FF 375mA	MGA-1206-0A375-SMD-SF-SN-00
MGA	MGA Fuse FF 375mA	MGA-1206-0A375-SMD-SF-SN-00
MGA	MGA Fuse FF 375mA	MGA-1206-0A375-SMD-SF-SN-00
MGA	MGA Fuse FF 500mA	MGA-1206-0A500-SMD-SF-SN-00
MGA	MGA Fuse FF 500mA	MGA-1206-0A500-SMD-SF-SN-00
MGA	MGA Fuse FF 500mA	MGA-1206-0A500-SMD-SF-SN-00
MGA	MGA Fuse FF 500mA	MGA-1206-0A500-SMD-SF-SN-00
MGA	MGA Fuse FF 750mA	MGA-1206-0A750-SMD-SF-SN-00
MGA	MGA Fuse FF 750mA	MGA-1206-0A750-SMD-SF-SN-00
MGA	MGA Fuse FF 750mA	MGA-1206-0A750-SMD-SF-SN-00
MGA	MGA Fuse FF 750mA	MGA-1206-0A750-SMD-SF-SN-00
MGA	MGA Fuse FF 1A	MGA-1206-1A000-SMD-SF-SN-00
MGA	MGA Fuse FF 1A	MGA-1206-1A000-SMD-SF-SN-00
MGA	MGA Fuse FF 1A	MGA-1206-1A000-SMD-SF-SN-00
MGA	MGA Fuse FF 1A	MGA-1206-1A000-SMD-SF-SN-00
MGA	MGA Fuse FF 1.5A	MGA-1206-1A500-SMD-SF-SN-00
MGA	MGA Fuse FF 1.5A	MGA-1206-1A500-SMD-SF-SN-00
MGA	MGA Fuse FF 1.5A	MGA-1206-1A500-SMD-SF-SN-00
MGA	MGA Fuse FF 1.5A	MGA-1206-1A500-SMD-SF-SN-00
MGA	MGA Fuse FF 2A	MGA-1206-2A000-SMD-SF-SN-00
MGA	MGA Fuse FF 2A	MGA-1206-2A000-SMD-SF-SN-00
MGA	MGA Fuse FF 2A	MGA-1206-2A000-SMD-SF-SN-00
MGA	MGA Fuse FF 2A	MGA-1206-2A000-SMD-SF-SN-00
MGA	MGA Fuse FF 2.5A	MGA-1206-2A500-SMD-SF-SN-00
MGA	MGA Fuse FF 2.5A	MGA-1206-2A500-SMD-SF-SN-00
MGA	MGA Fuse FF 2.5A	MGA-1206-2A500-SMD-SF-SN-00
MGA	MGA Fuse FF 2.5A	MGA-1206-2A500-SMD-SF-SN-00
MGA	MGA Fuse FF 3A	MGA-1206-3A000-SMD-SF-SN-00
MGA	MGA Fuse FF 3A	MGA-1206-3A000-SMD-SF-SN-00
MGA	MGA Fuse FF 3A	MGA-1206-3A000-SMD-SF-SN-00

[illegible]

MGA-A	MGA-A Fuse FF 5A	MGAA-1206-5A000-SMD-SF-AU-00
MGA-A	MGA-A Fuse FF 5A	MGAA-1206-5A000-SMD-SF-AU-00
MGA-S	MGA-S Fuse FF 140mA	MGAS-1206-0A140-SMD-SF-PB-00
MGA-S	MGA-S Fuse FF 2.1A	MGAS-1206-2A100-SMD-SF-PB-00
MGA-S	MGA-S Fuse FF 3.5A	MGAS-1206-3A500-SMD-SF-PB-00
MGA-S	MGA-S Fuse FF 3.5A	MGAS-1206-3A500-SMD-SF-PB-00
MGA-S	MGA-S Fuse FF 175mA	MGAS-1206-0A175-SMD-SF-PB-00
MGA-S	MGA-S Fuse FF 1.4A	MGAS-1206-1A400-SMD-SF-PB-00
MGA-S	MGA-S Fuse FF 2.8A	MGAS-1206-2A800-SMD-SF-PB-00
MGA-S	MGA-S Fuse FF 262mA	MGAS-1206-0A262-SMD-SF-PB-00
MGA-S	MGA-S Fuse FF 2.8A	MGAS-1206-2A800-SMD-SF-PB-00
MGA-S	MGA-S Fuse FF 700mA	MGAS-1206-0A700-SMD-SF-PB-00
MGA-S	MGA-S Fuse FF 1.05A	MGAS-1206-1A050-SMD-SF-PB-00
MGA-S	MGA-S Fuse FF 350mA	MGAS-1206-0A350-SMD-SF-PB-00
MGA-S	MGA-S Fuse FF 525mA	MGAS-1206-0A525-SMD-SF-PB-00
MGA-S	MGA-S Fuse FF 1.75A	MGAS-1206-1A750-SMD-SF-PB-00
MGA-S	MGA-S Fuse FF 2.1A	MGAS-1206-2A100-SMD-SF-PB-00
MGA-S	MGA-S Fuse FF 3.5A	MGAS-1206-3A500-SMD-SF-PB-00
MSF 125	MSF 125 Fuse F 1A	MSF125-6488-1A000-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 1A	MSF125-6488-1A000-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 100mA	MSF125-6488-0A100-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 125mA	MSF125-6488-0A125-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 160mA	MSF125-6488-0A160-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 200mA	MSF125-6488-0A200-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 250mA	MSF125-6488-0A250-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 315mA	MSF125-6488-0A315-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 400mA	MSF125-6488-0A400-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 500mA	MSF125-6488-0A500-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 630mA	MSF125-6488-0A630-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 710mA	MSF125-6488-0A710-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 750mA	MSF125-6488-0A750-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 800mA	MSF125-6488-0A800-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 1A	MSF125-6488-1A000-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 1.25A	MSF125-6488-1A250-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 1.6A	MSF125-6488-1A600-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 2A	MSF125-6488-2A000-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 2.5A	MSF125-6488-2A500-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 3.15A	MSF125-6488-3A150-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 4A	MSF125-6488-4A000-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 5A	MSF125-6488-5A000-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 100mA	MSF125-6488-0A100-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 125mA	MSF125-6488-0A125-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 160mA	MSF125-6488-0A160-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 200mA	MSF125-6488-0A200-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 250mA	MSF125-6488-0A250-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 315mA	MSF125-6488-0A315-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 400mA	MSF125-6488-0A400-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 500mA	MSF125-6488-0A500-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 630mA	MSF125-6488-0A630-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 710mA	MSF125-6488-0A710-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 750mA	MSF125-6488-0A750-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 800mA	MSF125-6488-0A800-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 1A	MSF125-6488-1A000-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 1.25A	MSF125-6488-1A250-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 1.6A	MSF125-6488-1A600-THT-0F-SN-00

MSF 125	MSF 125 Fuse F 2A	MSF125-6488-2A000-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 2.5A	MSF125-6488-2A500-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 3.15A	MSF125-6488-3A150-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 4A	MSF125-6488-4A000-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 5A	MSF125-6488-5A000-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 100mA	MSF125-6488-0A100-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 125mA	MSF125-6488-0A125-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 160mA	MSF125-6488-0A160-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 200mA	MSF125-6488-0A200-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 250mA	MSF125-6488-0A250-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 315mA	MSF125-6488-0A315-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 400mA	MSF125-6488-0A400-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 500mA	MSF125-6488-0A500-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 630mA	MSF125-6488-0A630-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 710mA	MSF125-6488-0A710-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 750mA	MSF125-6488-0A750-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 800mA	MSF125-6488-0A800-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 1A	MSF125-6488-1A000-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 1.25A	MSF125-6488-1A250-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 1.6A	MSF125-6488-1A600-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 2A	MSF125-6488-2A000-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 2.5A	MSF125-6488-2A500-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 3.15A	MSF125-6488-3A150-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 4A	MSF125-6488-4A000-THT-0F-SN-00
MSF 125	MSF 125 Fuse F 5A	MSF125-6488-5A000-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 40mA	MSF250-8585-0A040-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 50mA	MSF250-8585-0A050-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 63mA	MSF250-8585-0A063-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 80mA	MSF250-8585-0A080-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 100mA	MSF250-8585-0A100-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 125mA	MSF250-8585-0A125-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 160mA	MSF250-8585-0A160-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 200mA	MSF250-8585-0A200-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 250mA	MSF250-8585-0A250-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 315mA	MSF250-8585-0A315-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 400mA	MSF250-8585-0A400-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 500mA	MSF250-8585-0A500-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 630mA	MSF250-8585-0A630-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 800mA	MSF250-8585-0A800-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 1A	MSF250-8585-1A000-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 1.25A	MSF250-8585-1A250-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 1.6A	MSF250-8585-1A600-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 2A	MSF250-8585-2A000-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 2.5A	MSF250-8585-2A500-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 3.15A	MSF250-8585-3A150-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 4A	MSF250-8585-4A000-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 5A	MSF250-8585-5A000-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 40mA	MSF250-8585-0A040-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 50mA	MSF250-8585-0A050-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 63mA	MSF250-8585-0A063-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 80mA	MSF250-8585-0A080-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 100mA	MSF250-8585-0A100-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 125mA	MSF250-8585-0A125-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 160mA	MSF250-8585-0A160-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 200mA	MSF250-8585-0A200-THT-0F-SN-00

MSF 250	MSF 250 Fuse F 250mA	MSF250-8585-0A250-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 315mA	MSF250-8585-0A315-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 400mA	MSF250-8585-0A400-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 500mA	MSF250-8585-0A500-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 630mA	MSF250-8585-0A630-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 800mA	MSF250-8585-0A800-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 1A	MSF250-8585-1A000-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 1.25A	MSF250-8585-1A250-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 1.6A	MSF250-8585-1A600-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 2A	MSF250-8585-2A000-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 2.5A	MSF250-8585-2A500-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 3.15A	MSF250-8585-3A150-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 4A	MSF250-8585-4A000-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 5A	MSF250-8585-5A000-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 40mA	MSF250-8585-0A040-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 50mA	MSF250-8585-0A050-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 63mA	MSF250-8585-0A063-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 80mA	MSF250-8585-0A080-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 100mA	MSF250-8585-0A100-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 125mA	MSF250-8585-0A125-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 160mA	MSF250-8585-0A160-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 200mA	MSF250-8585-0A200-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 250mA	MSF250-8585-0A250-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 315mA	MSF250-8585-0A315-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 400mA	MSF250-8585-0A400-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 500mA	MSF250-8585-0A500-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 630mA	MSF250-8585-0A630-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 800mA	MSF250-8585-0A800-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 1A	MSF250-8585-1A000-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 1.25A	MSF250-8585-1A250-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 1.6A	MSF250-8585-1A600-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 2A	MSF250-8585-2A000-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 2.5A	MSF250-8585-2A500-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 3.15A	MSF250-8585-3A150-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 3.15A	MSF250-8585-3A150-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 4A	MSF250-8585-4A000-THT-0F-SN-00
MSF 250	MSF 250 Fuse F 5A	MSF250-8585-5A000-THT-0F-SN-00
MST 250	MST 250 Fuse T 2A	MST250-8585-2A000-THT-0T-SN-00
MST 250	MST 250 Fuse T 2A	MST250-8585-2A000-THT-0T-SN-00
MST 250	MST 250 Fuse T 1.6A	MST250-8585-1A600-THT-0T-SN-00
MST 250	MST 250 Fuse T 2A	MST250-8585-2A000-THT-0T-SN-00
MST 250	MST 250 Fuse T 1A	MST250-8585-1A000-THT-0T-SN-00
MST 250	MST 250 Fuse T 1.25A	MST250-8585-1A250-THT-0T-SN-00
MST 250	MST 250 Fuse T 250mA	MST250-8585-0A250-THT-0T-SN-00
MST 250	MST 250 Fuse T 63mA	MST250-8585-0A063-THT-0T-SN-00
MST 250	MST 250 Fuse T 2A	MST250-8585-2A000-THT-0T-SN-00
MST 250	MST 250 Fuse T 50mA	MST250-8585-0A050-THT-0T-SN-00
MST 250	MST 250 Fuse T 63mA	MST250-8585-0A063-THT-0T-SN-00
MST 250	MST 250 Fuse T 80mA	MST250-8585-0A080-THT-0T-SN-00
MST 250	MST 250 Fuse T 100mA	MST250-8585-0A100-THT-0T-SN-00
MST 250	MST 250 Fuse T 125mA	MST250-8585-0A125-THT-0T-SN-00
MST 250	MST 250 Fuse T 160mA	MST250-8585-0A160-THT-0T-SN-00
MST 250	MST 250 Fuse T 200mA	MST250-8585-0A200-THT-0T-SN-00
MST 250	MST 250 Fuse T 250mA	MST250-8585-0A250-THT-0T-SN-00
MST 250	MST 250 Fuse T 315mA	MST250-8585-0A315-THT-0T-SN-00

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

OMK 63	OMK 63 F. in Holder F 3A	OMK63-1252-3A000-FHD-0F-SN-00
OMK 63	OMK 63 F. in Holder F 3.5A	OMK63-1252-3A500-FHD-0F-SN-00
OMK 63	OMK 63 F. in Holder F 3.5A	OMK63-1252-3A500-FHD-0F-SN-00
OMK 63	OMK 63 F. in Holder F 4A	OMK63-1252-4A000-FHD-0F-SN-00
OMK 63	OMK 63 F. in Holder F 4A	OMK63-1252-4A000-FHD-0F-SN-00
OMK 63	OMK 63 F. in Holder F 5A	OMK63-1252-5A000-FHD-0F-SN-00
OMK 63	OMK 63 F. in Holder F 5A	OMK63-1252-5A000-FHD-0F-SN-00
OMK 63	OMK 63 F. in Holder F 50mA	OMK63-1252-0A050-FHD-0F-SN-00
OMK 63	OMK 63 F. in Holder F 350mA	OMK63-1252-0A350-FHD-0F-SN-00
OMK 63	OMK 63 F. in Holder F 375mA	OMK63-1252-0A375-FHD-0F-SN-00
OMK 63	OMK 63 F. in Holder F 375mA	OMK63-1252-0A375-FHD-0F-SN-00
OMK 63	OMK 63 F. in Holder F 500mA	OMK63-1252-0A500-FHD-0F-SN-00
OMK 63	OMK 63 F. in Holder F 500mA	OMK63-1252-0A500-FHD-0F-SN-00
OMK 63	OMK 63 F. in Holder F 750mA	OMK63-1252-0A750-FHD-0F-SN-00
OMK 63	OMK 63 F. in Holder F 750mA	OMK63-1252-0A750-FHD-0F-SN-00
OMK 63	OMK 63 F. in Holder F 1.5A	OMK63-1252-1A500-FHD-0F-SN-00
OMK 63	OMK 63 F. in Holder F 1.5A	OMK63-1252-1A500-FHD-0F-SN-00
OMK 63	OMK 63 F. in Holder F 3.15A	OMK63-1252-3A150-FHD-0F-SN-00
OMK 63	OMK 63 F. in Holder F 3.15A	OMK63-1252-3A150-FHD-0F-SN-00
OMT	OMT Fuse T 1A	OMT-1146-1A000-SMD-0T-SN-00
OMT	OMT Fuse T 1A	OMT-1146-1A000-SMD-0T-SN-00
OMT	OMT Fuse T 1.25A	OMT-1146-1A250-SMD-0T-SN-00
OMT	OMT Fuse T 1.25A	OMT-1146-1A250-SMD-0T-SN-00
OMT	OMT Fuse T 2A	OMT-1146-2A000-SMD-0T-SN-00
OMT	OMT Fuse T 2A	OMT-1146-2A000-SMD-0T-SN-00
OMT	OMT Fuse T 2.5A	OMT-1146-2A500-SMD-0T-SN-00
OMT	OMT Fuse T 2.5A	OMT-1146-2A500-SMD-0T-SN-00
OMT	OMT Fuse T 4A	OMT-1146-4A000-SMD-0T-SN-00
OMT	OMT Fuse T 4A	OMT-1146-4A000-SMD-0T-SN-00
OMT	OMT Fuse T 750mA	OMT-1146-0A750-SMD-0T-SN-00
OMT	OMT Fuse T 750mA	OMT-1146-0A750-SMD-0T-SN-00
OMT	OMT Fuse T 1.5A	OMT-1146-1A500-SMD-0T-SN-00
OMT	OMT Fuse T 1.5A	OMT-1146-1A500-SMD-0T-SN-00
OMT	OMT Fuse T 3A	OMT-1146-3A000-SMD-0T-SN-00
OMT	OMT Fuse T 3A	OMT-1146-3A000-SMD-0T-SN-00
OMT	OMT Fuse T 3.5A	OMT-1146-3A500-SMD-0T-SN-00
OMT	OMT Fuse T 3.5A	OMT-1146-3A500-SMD-0T-SN-00
OMT	OMT Fuse T 5A	OMT-1146-5A000-SMD-0T-SN-00
OMT	OMT Fuse T 5A	OMT-1146-5A000-SMD-0T-SN-00
OMT 125	OMT 125 Fuse T 500mA	OMT125-7431-0A500-SMD-0T-SN-00
OMT 125	OMT 125 Fuse T 1.6A	OMT125-7431-1A600-SMD-0T-SN-00
OMT 125	OMT 125 Fuse T 1.5A	OMT125-7431-1A500-SMD-0T-SN-00
OMT 125	OMT 125 Fuse T 1.6A	OMT125-7431-1A600-SMD-0T-SN-00
OMT 125	OMT 125 Fuse T 1.6A	OMT125-7431-1A600-SMD-0T-SN-00
OMT 125	OMT 125 Fuse T 250mA	OMT125-7431-0A250-SMD-0T-SN-00
OMT 125	OMT 125 Fuse T 250mA	OMT125-7431-0A250-SMD-0T-SN-00
OMT 125	OMT 125 Fuse T 250mA	OMT125-7431-0A250-SMD-0T-SN-00
OMT 125	OMT 125 Fuse T 375mA	OMT125-7431-0A375-SMD-0T-SN-00
OMT 125	OMT 125 Fuse T 375mA	OMT125-7431-0A375-SMD-0T-SN-00
OMT 125	OMT 125 Fuse T 375mA	OMT125-7431-0A375-SMD-0T-SN-00
OMT 125	OMT 125 Fuse T 500mA	OMT125-7431-0A500-SMD-0T-SN-00
OMT 125	OMT 125 Fuse T 750mA	OMT125-7431-0A750-SMD-0T-SN-00
OMT 125	OMT 125 Fuse T 750mA	OMT125-7431-0A750-SMD-0T-SN-00
OMT 125	OMT 125 Fuse T 750mA	OMT125-7431-0A750-SMD-0T-SN-00
OMT 125	OMT 125 Fuse T 1A	OMT125-7431-1A000-SMD-0T-SN-00

[illegible]

OMZ 125	OMZ 125 F. in Holder T 3A	OMZ125-1252-3A000-FHD-0T-SN-00
OMZ 125	OMZ 125 F. in Holder T 4A	OMZ125-1252-4A000-FHD-0T-SN-00
OMZ 125	OMZ 125 F. in Holder T 4A	OMZ125-1252-4A000-FHD-0T-SN-00
OMZ 125	OMZ 125 F. in Holder T 4A	OMZ125-1252-4A000-FHD-0T-SN-00
OMZ 125	OMZ 125 F. in Holder T 500mA	OMZ125-1252-0A500-FHD-0T-SN-00
OMZ 125	OMZ 125 F. in Holder T 500mA	OMZ125-1252-0A500-FHD-0T-SN-00
OMZ 125	OMZ 125 F. in Holder T 500mA	OMZ125-1252-0A500-FHD-0T-SN-00
OMZ 125	OMZ 125 F. in Holder T 5A	OMZ125-1252-5A000-FHD-0T-SN-00
OMZ 125	OMZ 125 F. in Holder T 5A	OMZ125-1252-5A000-FHD-0T-SN-00
OMZ 125	OMZ 125 F. in Holder T 5A	OMZ125-1252-5A000-FHD-0T-SN-00
OMZ 125	OMZ 125 F. in Holder T 750mA	OMZ125-1252-0A750-FHD-0T-SN-00
OMZ 125	OMZ 125 F. in Holder T 750mA	OMZ125-1252-0A750-FHD-0T-SN-00
OMZ 125	OMZ 125 F. in Holder T 750mA	OMZ125-1252-0A750-FHD-0T-SN-00
RTS	RTS Thermal Fuse >210°C	RTS-AC100
RTS	RTS Thermal Fuse >210°C	RTS-AC100
RTS	RTS Thermal Fuse >210°C	RTS-AC100
RTS	RTS Thermal Fuse >210°C with shunt	RTS-AS500
RTS	RTS Thermal Fuse >210°C with shunt	RTS-AS500
RTS	RTS Thermal Fuse >210°C with shunt	RTS-AS500
UAI 1206	UAI 1206 Fuse F 5.3A	UAI1206-1206-5A300-SMD-0F-AU-00
UAI 1206	UAI 1206 Fuse F 7.5A	UAI1206-1206-7A500-SMD-0F-AU-00
UAI 1206	UAI 1206 Fuse F 7.5A	UAI1206-1206-7A500-SMD-0F-AU-00
UAI 1206	UAI 1206 Fuse F 7.5A	UAI1206-1206-7A500-SMD-0F-AU-00
UAI 1206	UAI 1206 Fuse F 7.5A	UAI1206-1206-7A500-SMD-0F-AU-00
UAI 1206	UAI 1206 Fuse F 7.5A	UAI1206-1206-7A500-SMD-0F-AU-00
UAI 1206	UAI 1206 Fuse F 5.3A	UAI1206-1206-5A300-SMD-0F-AU-00
UAI 1206	UAI 1206 Fuse F 5.3A	UAI1206-1206-5A300-SMD-0F-AU-00
UAI 1206	UAI 1206 Fuse F 5.3A	UAI1206-1206-5A300-SMD-0F-AU-00
UAI 1206	UAI 1206 Fuse F 5.3A	UAI1206-1206-5A300-SMD-0F-AU-00
UAI 1206	UAI 1206 Fuse F 5.3A	UAI1206-1206-5A300-SMD-0F-AU-00
UAI 1206	UAI 1206 Fuse F 5.3A	UAI1206-1206-5A300-SMD-0F-AU-00
UAI 1206	UAI 1206 Fuse F 5.3A	UAI1206-1206-5A300-SMD-0F-AU-00
UAI 1206	UAI 1206 Fuse F 5.3A	UAI1206-1206-5A300-SMD-0F-AU-00
UAI 1206	UAI 1206 Fuse F 5.3A	UAI1206-1206-5A300-SMD-0F-AU-00
UAI 1206	UAI 1206 Fuse F 5.3A	UAI1206-1206-5A300-SMD-0F-AU-00
UMF 250	UMF 250 Fuse F 15A	UMF250-0310-15A00-SMD-0F-SN-00
UMF 250	UMF 250 Fuse F 500mA L 250V AC	UMF250-0310-0A500-SMD-0F-SN-00
UMF 250	UMF 250 Fuse F 500mA L 250V AC	UMF250-0310-0A500-SMD-0F-SN-00
UMF 250	UMF 250 Fuse F 630mA L 250V AC	UMF250-0310-0A630-SMD-0F-SN-00
UMF 250	UMF 250 Fuse F 630mA L 250V AC	UMF250-0310-0A630-SMD-0F-SN-00
UMF 250	UMF 250 Fuse F 800mA L 250V AC	UMF250-0310-0A800-SMD-0F-SN-00
UMF 250	UMF 250 Fuse F 800mA L 250V AC	UMF250-0310-0A800-SMD-0F-SN-00
UMF 250	UMF 250 Fuse F 1A L 250V AC	UMF250-0310-1A000-SMD-0F-SN-00
UMF 250	UMF 250 Fuse F 1A L 250V AC	UMF250-0310-1A000-SMD-0F-SN-00
UMF 250	UMF 250 Fuse F 1.25A L 250V AC	UMF250-0310-1A250-SMD-0F-SN-00
UMF 250	UMF 250 Fuse F 1.25A L 250V AC	UMF250-0310-1A250-SMD-0F-SN-00
UMF 250	UMF 250 Fuse F 1.6A L 250V AC	UMF250-0310-1A600-SMD-0F-SN-00
UMF 250	UMF 250 Fuse F 1.6A L 250V AC	UMF250-0310-1A600-SMD-0F-SN-00
UMF 250	UMF 250 Fuse F 2A L 250V AC	UMF250-0310-2A000-SMD-0F-SN-00
UMF 250	UMF 250 Fuse F 2A L 250V AC	UMF250-0310-2A000-SMD-0F-SN-00
UMF 250	UMF 250 Fuse F 2.5A L 250V AC	UMF250-0310-2A500-SMD-0F-SN-00
UMF 250	UMF 250 Fuse F 2.5A L 250V AC	UMF250-0310-2A500-SMD-0F-SN-00
UMF 250	UMF 250 Fuse F 3.15A L 250V AC	UMF250-0310-3A150-SMD-0F-SN-00
UMF 250	UMF 250 Fuse F 3.15A L 250V AC	UMF250-0310-3A150-SMD-0F-SN-00

UMF 250	UMF 250 Fuse F 4A L 250V AC	UMF250-0310-4A000-SMD-0F-SN-00
UMF 250	UMF 250 Fuse F 4A L 250V AC	UMF250-0310-4A000-SMD-0F-SN-00
UMF 250	UMF 250 Fuse F 5A L 250V AC	UMF250-0310-5A000-SMD-0F-SN-00
UMF 250	UMF 250 Fuse F 5A L 250V AC	UMF250-0310-5A000-SMD-0F-SN-00
UMF 250	UMF 250 Fuse F 6.3A L 250V AC	UMF250-0310-6A300-SMD-0F-SN-00
UMF 250	UMF 250 Fuse F 6.3A L 250V AC	UMF250-0310-6A300-SMD-0F-SN-00
UMF 250	UMF 250 Fuse F 8A L 250V AC	UMF250-0310-8A000-SMD-0F-SN-00
UMF 250	UMF 250 Fuse F 8A L 250V AC	UMF250-0310-8A000-SMD-0F-SN-00
UMF 250	UMF 250 Fuse F 10A	UMF250-0310-10A00-SMD-0F-SN-00
UMF 250	UMF 250 Fuse F 10A	UMF250-0310-10A00-SMD-0F-SN-00
UMF 250	UMF 250 Fuse F 15A	UMF250-0310-15A00-SMD-0F-SN-00
UMF 250	UMF 250 Fuse F 15A	UMF250-0310-15A00-SMD-0F-SN-00
UMK 250	UMK 250 F. in Holder F 500mA L 250V AC	UMK250-4211-0A500-FHD-0F-AG-00
UMK 250	UMK 250 F. in Holder F 500mA L 250V AC	UMK250-4211-0A500-FHD-0F-AG-00
UMK 250	UMK 250 F. in Holder F 630mA L 250V AC	UMK250-4211-0A630-FHD-0F-AG-00
UMK 250	UMK 250 F. in Holder F 630mA L 250V AC	UMK250-4211-0A630-FHD-0F-AG-00
UMK 250	UMK 250 F. in Holder 800mA F	UMK250-4211-0A800-FHD-0F-AG-00
UMK 250	UMK 250 F. in Holder F 800mA L 250V AC	UMK250-4211-0A800-FHD-0F-AG-00
UMK 250	UMK 250 F. in Holder F 1A L 250V AC	UMK250-4211-1A000-FHD-0F-AG-00
UMK 250	UMK 250 F. in Holder F 1A L 250V AC	UMK250-4211-1A000-FHD-0F-AG-00
UMK 250	UMK 250 F. in Holder F 1.25A L 250V AC	UMK250-4211-1A250-FHD-0F-AG-00
UMK 250	UMK 250 F. in Holder F 1.25A L 250V AC	UMK250-4211-1A250-FHD-0F-AG-00
UMK 250	UMK 250 F. in Holder 1.6A F	UMK250-4211-1A600-FHD-0F-AG-00
UMK 250	UMK 250 F. in Holder F 1.6A L 250V AC	UMK250-4211-1A600-FHD-0F-AG-00
UMK 250	UMK 250 F. in Holder F 2A L 250V AC	UMK250-4211-2A000-FHD-0F-AG-00
UMK 250	UMK 250 F. in Holder 2 A F	UMK250-4211-2A000-FHD-0F-AG-00
UMK 250	UMK 250 F. in Holder F 2.5A L 250V AC	UMK250-4211-2A500-FHD-0F-AG-00
UMK 250	UMK 250 F. in Holder F 2.5A L 250V AC	UMK250-4211-2A500-FHD-0F-AG-00
UMK 250	UMK 250 F. in Holder 3.15A F	UMK250-4211-3A150-FHD-0F-AG-00
UMK 250	UMK 250 F. in Holder F 3.15A L 250V AC	UMK250-4211-3A150-FHD-0F-AG-00
UMK 250	UMK 250 F. in Holder F 4A L 250V AC	UMK250-4211-4A000-FHD-0F-AG-00
UMK 250	UMK 250 F. in Holder 4A F	UMK250-4211-4A000-FHD-0F-AG-00
UMT 250	UMT 250 Fuse T 6.3A	UMT250-0310-6A300-SMD-0T-SN-00
UMT 250	UMT 250 Fuse T 5A L 250V AC	UMT250-0310-5A000-SMD-0T-SN-00
UMT 250	UMT 250 Fuse T 5A L 250V AC	UMT250-0310-5A000-SMD-0T-SN-00
UMT 250	UMT 250 Fuse T 6.3A L 250V AC	UMT250-0310-6A300-SMD-0T-SN-00
UMT 250	UMT 250 Fuse T 6.3A L 250V AC	UMT250-0310-6A300-SMD-0T-SN-00
UMT 250	UMT 250 Fuse T 6.3A L 250V AC	UMT250-0310-6A300-SMD-0T-SN-00
UMT 250	UMT 250 Fuse T 6.3A L 250V AC	UMT250-0310-6A300-SMD-0T-SN-00
UMT 250	UMT 250 Fuse T 6.3A L 250V AC	UMT250-0310-6A300-SMD-0T-SN-00
UMT 250	UMT 250 Fuse T 8A	UMT250-0310-8A000-SMD-0T-SN-00
UMT 250	UMT 250 Fuse T 8A	UMT250-0310-8A000-SMD-0T-SN-00
UMT 250	UMT 250 Fuse T 10A	UMT250-0310-10A00-SMD-0T-SN-00
UMT 250	UMT 250 Fuse T 10A	UMT250-0310-10A00-SMD-0T-SN-00
UMT 250	UMT 250 Fuse T 80mA L 250V AC	UMT250-0310-0A080-SMD-0T-SN-00
UMT 250	UMT 250 Fuse T 80mA L 250V AC	UMT250-0310-0A080-SMD-0T-SN-00
UMT 250	UMT 250 Fuse T 1.25A	UMT250-0310-1A250-SMD-0T-SN-00
UMT 250	UMT 250 Fuse T 315mA L 250V AC	UMT250-0310-0A315-SMD-0T-SN-00
UMT 250	UMT 250 Fuse T 315mA L 250V AC	UMT250-0310-0A315-SMD-0T-SN-00
UMT 250	UMT 250 Fuse T 400mA L 250V AC	UMT250-0310-0A400-SMD-0T-SN-00
UMT 250	UMT 250 Fuse T 400mA L 250V AC	UMT250-0310-0A400-SMD-0T-SN-00
UMT 250	UMT 250 Fuse T 500mA L 250V AC	UMT250-0310-0A500-SMD-0T-SN-00
UMT 250	UMT 250 Fuse T 500mA L 250V AC	UMT250-0310-0A500-SMD-0T-SN-00
UMT 250	UMT 250 Fuse T 500mA L 250V AC	UMT250-0310-0A500-SMD-0T-SN-00
UMT 250	UMT 250 Fuse T 630mA L 250V AC	UMT250-0310-0A630-SMD-0T-SN-00
UMT 250	UMT 250 Fuse T 630mA L 250V AC	UMT250-0310-0A630-SMD-0T-SN-00

[illegible]

[illegible]

UMT-H	UMT-M Fuse 16A	UMTH-5316-16A00-SMD-OT-SN-00
UMT-H	UMT-H Fuse 16A	UMTM-5316-16A00-SMD-OT-SN-00
UMT-H	UMT-M Fuse 16A	UMTM-5316-16A00-SMD-OT-SN-00
UMZ 250	UMZ 250 F. in Holder T 315mA	UMZ250-4211-0A315-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 315mA	UMZ250-4211-0A315-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 400mA	UMZ250-4211-0A400-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 400mA	UMZ250-4211-0A400-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 500mA	UMZ250-4211-0A500-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 500mA	UMZ250-4211-0A500-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 630mA	UMZ250-4211-0A630-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 630mA	UMZ250-4211-0A630-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 800mA	UMZ250-4211-0A800-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 800mA	UMZ250-4211-0A800-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 1A	UMZ250-4211-1A000-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 1A	UMZ250-4211-1A000-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 1.25A	UMZ250-4211-1A250-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 1.25A	UMZ250-4211-1A250-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 1.6A	UMZ250-4211-1A600-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 1.6A	UMZ250-4211-1A600-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 2A	UMZ250-4211-2A000-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 2A	UMZ250-4211-2A000-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 2.5A	UMZ250-4211-2A500-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 3.15A	UMZ250-4211-3A150-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 3.15A	UMZ250-4211-3A150-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 4A	UMZ250-4211-4A000-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 2.5A	UMZ250-4211-2A500-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 4A	UMZ250-4211-4A000-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 80mA	UMZ250-4211-0A080-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 80mA	UMZ250-4211-0A080-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 100mA	UMZ250-4211-0A100-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 100mA	UMZ250-4211-0A100-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 125mA	UMZ250-4211-0A125-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 125mA	UMZ250-4211-0A125-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 160mA	UMZ250-4211-0A160-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 160mA	UMZ250-4211-0A160-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 200mA	UMZ250-4211-0A200-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 200mA	UMZ250-4211-0A200-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 250mA	UMZ250-4211-0A250-FHD-OT-AG-00
UMZ 250	UMZ 250 F. in Holder T 250mA	UMZ250-4211-0A250-FHD-OT-AG-00
USF 0603	USF 0603 Fuse FF 750mA	USF0603-0603-0A750-SMD-SF-AU-00
USF 0603	USF 0603 Fuse FF 750mA	USF0603-0603-0A750-SMD-SF-AU-00
USF 0603	USF 0603 Fuse FF 500mA	USF0603-0603-0A500-SMD-SF-AU-00
USF 0603	USF 0603 Fuse FF 500mA	USF0603-0603-0A500-SMD-SF-AU-00
USF 0603	USF 0603 Fuse FF 1A	USF0603-0603-1A000-SMD-SF-AU-00
USF 0603	USF 0603 Fuse FF 1A	USF0603-0603-1A000-SMD-SF-AU-00
USF 0603	USF 0603 Fuse FF 1.5A	USF0603-0603-1A500-SMD-SF-AU-00
USF 0603	USF 0603 Fuse FF 1.5A	USF0603-0603-1A500-SMD-SF-AU-00
USF 0603	USF 0603 Fuse FF 2A	USF0603-0603-2A000-SMD-SF-AU-00
USF 0603	USF 0603 Fuse FF 2.5A	USF0603-0603-2A500-SMD-SF-AU-00
USF 0603	USF 0603 Fuse FF 2.5A	USF0603-0603-2A500-SMD-SF-AU-00
USF 0603	USF 0603 Fuse FF 3A	USF0603-0603-3A000-SMD-SF-AU-00
USF 0603	USF 0603 Fuse FF 3.5A	USF0603-0603-3A500-SMD-SF-AU-00
USF 0603	USF 0603 Fuse FF 3.5A	USF0603-0603-3A500-SMD-SF-AU-00
USF 0603	USF 0603 Fuse FF 4A	USF0603-0603-4A000-SMD-SF-AU-00
USF 0603	USF 0603 Fuse FF 5A	USF0603-0603-5A000-SMD-SF-AU-00

[illegible]

[illegible]

UST 1206	UST 1206 Fuse T 8A	UST-1206-8A000-SMD-0T-AU-00
UST 1206	UST 1206 Fuse T 8A	UST-1206-8A000-SMD-0T-AU-00
UST 1206	UST 1206 Fuse T 10A	UST-1206-10A00-SMD-0T-AU-00
UST 1206	UST 1206 Fuse T 10A	UST-1206-10A00-SMD-0T-AU-00
UST 1206	UST 1206 Fuse T 10A	UST-1206-10A00-SMD-0T-AU-00
UST 1206	UST 1206 Fuse T 15A	UST-1206-15A00-SMD-0T-AU-00
UST 1206	UST 1206 Fuse T 15A	UST-1206-15A00-SMD-0T-AU-00
UST 1206	UST 1206 Fuse T 15A	UST-1206-15A00-SMD-0T-AU-00
HCF	HCF Fuse 7.5A	HCF-3220-7A500-SMD-SF-SN-00
HCF	HCF Fuse 10A	HCF-3220-10A00-SMD-SF-SN-00
HCF	HCF Fuse 5A	HCF-3220-5A000-SMD-SF-SN-00
HCF	HCF Fuse 15A	HCF-3220-15A00-SMD-SF-SN-00
UMT-W	UMT-W Fuse TT 5A	UMTW-5316-5A000-SMD-ST-SN-00
UMT-W	UMT-W Fuse TT 5A	UMTW-5316-5A000-SMD-ST-SN-00
UMT-W	UMT-W Fuse TT 7.5A	UMTW-5316-7A500-SMD-ST-SN-00
UMT-W	UMT-W Fuse TT 7.5A	UMTW-5316-7A500-SMD-ST-SN-00
UMT-W	UMT-W Fuse TT 10A	UMTW-5316-10A00-SMD-ST-SN-00
UMT-W	UMT-W Fuse TT 10A	UMTW-5316-10A00-SMD-ST-SN-00
UMT-W	UMT-W Fuse TT 15A	UMTW-5316-15A00-SMD-ST-SN-00
UMT-W	UMT-W Fuse TT 15A	UMTW-5316-15A00-SMD-ST-SN-00
UMT-W	UMT-W Fuse TT 20A	UMTW-5316-20A00-SMD-ST-SN-00
UMT-W	UMT-W Fuse TT 20A	UMTW-5316-20A00-SMD-ST-SN-00